

Operating Instructions

Memograph M, RSG45

Advanced Data Manager




Table of contents

1	Document information	6		
1.1	Document function	6		
1.2	Symbols used	6		
1.2.1	Safety symbols	6		
1.2.2	Electrical symbols	6		
1.2.3	Symbols for certain types of information	7		
1.2.4	Symbols in graphics	7		
1.3	Terminology	7		
1.4	Registered trademarks	7		
2	Basic safety instructions	8		
2.1	Requirements concerning the staff	8		
2.2	Designated use	8		
2.3	Workplace safety	9		
2.4	Operational safety	9		
2.5	Product safety	9		
2.6	Safety information for table version (option)	9		
2.7	IT security	10		
3	Product description	10		
3.1	Product design	10		
4	Incoming acceptance and product identification	10		
4.1	Incoming acceptance	10		
4.2	Scope of delivery	10		
4.3	Product identification	11		
4.3.1	Nameplate	11		
4.4	Storage and transport	11		
5	Installation	11		
5.1	Installation conditions	11		
5.1.1	Installation dimensions	12		
5.2	Mounting the measuring device	12		
5.3	Post-installation check	14		
6	Electrical connection	14		
6.1	Connection conditions	14		
6.2	Connection instructions	15		
6.2.1	Cable specification	15		
6.3	Connecting the measuring device	16		
6.3.1	Terminals on back of device	16		
6.3.2	Electrical connection, terminal assignment	16		
6.3.3	Connection example: Auxiliary voltage output as transmitter power supply for 2-wire sensors	21		
6.3.4	Connection example: Auxiliary voltage output as transmitter power supply for 4-wire sensors	22		
6.3.5	Connection example: HART® input in a point-to-point connection	23		
6.3.6	Connection example: HART® input in multidrop	23		
6.3.7	RS232/RS485 interface (CPU card, rear of device, slot 0)	24		
6.3.8	Ethernet connection (CPU card, rear of device, slot 0)	25		
6.3.9	Option: Anybus® interface (CPU card, rear of device, slot 0)	26		
6.3.10	USB connection, type A (host) (CPU card, rear of device, slot 0)	26		
6.3.11	Connections on front of device (only for version with navigator and front interfaces)	27		
6.3.12	General information on USB devices	27		
6.4	Post-connection check	29		
7	Operation options	30		
7.1	Overview of operation options	30		
7.2	Structure and function of the operating menu	30		
7.2.1	Operating menu for operators and maintenance personnel	30		
7.2.2	Operating menu for experts	31		
7.2.3	Submenus and users	31		
7.3	Measured value display and operating elements	33		
7.4	Display representation of symbols used in operation	34		
7.4.1	Symbols in operating menus	35		
7.4.2	Symbols in the event logbook	35		
7.5	Entering text and numbers (virtual keyboard)	35		
7.6	Channel color assignment	36		
7.7	Access to the operating menu via the local display	36		
7.8	Device access via operating tools	36		
7.8.1	Field Data Manager (FDM) analysis software (SQL database support)	36		
7.8.2	Web server	37		
7.8.3	OPC server (optional)	37		
7.8.4	FieldCare/DeviceCare configuration software (included in the delivery)	37		
8	System integration	38		
8.1	Integrating the measuring device in the system	38		
8.1.1	General notes	38		
8.1.2	Ethernet	38		
8.1.3	Modbus RTU/TCP slave	38		
9	Commissioning	40		
9.1	Function check	40		

9.2	Switching on the measuring device	40	11.10.3	Notes on e-mail encryption	60
9.3	Setting the operating language	40	11.10.4	Notes on WebDAV encryption	60
9.4	Configuring the measuring device (Setup menu)	41	11.10.5	SSL certificates	61
9.4.1	Step-by-step: to the first measured value	41	11.11	Showing measured values history	62
9.4.2	Step-by-step: set or delete the limit values	41	11.11.1	Historical data: changing a group	62
9.4.3	Step-by-step: read HART® values (option)	42	11.11.2	Historical data: Scroll speed	62
9.4.4	Step-by-step: HART® communication between an FDT Frame application (FieldCare) and a HART® device/sensor (option)	42	11.11.3	Historical data: Time scaling	62
9.4.5	Setup directly at the device	43	11.11.4	Historical data: Time range displayed	62
9.4.6	Setup via SD card or USB stick	43	11.11.5	Historical data: Screenshot	62
9.4.7	Setup via Web server	43	11.11.6	Historical data: Change the display mode	63
9.4.8	Setup via FieldCare/DeviceCare configuration software (included in the delivery)	44	11.11.7	Historical data: Store text	63
9.5	Advanced settings (Expert menu)	45	11.12	Signal analysis	63
9.6	Configuration management	45	11.13	Search in trace	63
9.7	Simulation	46	11.14	Changing the display mode	63
9.8	Protecting settings from unauthorized access	46	11.15	Store text	64
10	Fulfilling requirements in accordance with "FDA 21 CFR Part 11"	47	11.16	Printout	64
10.1	General notes	47	11.17	Adjusting the brightness of the display	64
10.2	Important device settings	49	11.18	Limit values	64
10.3	Important settings in the Field Data Manager (FDM) PC software	50	11.19	WebDAV Client	65
11	Operation	51	11.19.1	Access to the WebDAV server via HTTP (HTML)	65
11.1	Displaying and modifying current Ethernet settings	51	12	Diagnostics and troubleshooting ...	66
11.2	Reading the device locking status	51	12.1	General troubleshooting	66
11.3	Reading measured values	52	12.2	Troubleshooting	66
11.4	Reading measured values via the web server ..	53	12.2.1	Device error/alarm relay	66
11.4.1	Access to the web server via HTTP (HTML)	53	12.3	Diagnostic information on the local display ...	67
11.4.2	Access to the web server via XML	53	12.4	Pending, current diagnostic messages	71
11.4.3	Remote control via the web server ...	54	12.5	Diagnosis list	72
11.5	Data analysis and visualization with the Field Data Manager software (FDM) provided	54	12.6	Event logbook	72
11.5.1	Structure/layout of a CSV file	55	12.7	Device information	72
11.5.2	Importing UTF-8-encoded CSV files into spreadsheets	56	12.8	Diagnostics of measured values	72
11.6	Change group	56	12.9	Diagnostics of outputs	72
11.7	Block keyboard/navigator	56	12.10	Simulation	72
11.8	Log on / log out	56	12.10.1	Test bar code reader	72
11.9	Change password	56	12.10.2	E-mail test	73
11.10	SD card / USB stick	57	12.10.3	Test WebDAV Client	73
11.10.1	Function of SD card or USB stick	57	12.10.4	Test telealarm	73
11.10.2	Functions relating to the SD card or USB stick	57	12.10.5	Test time synchronization / SNTP ...	73
			12.10.6	Test universal output	73
			12.10.7	Relay test	73
			12.11	HART® diagnostics	73
			12.12	PROFINET diagnostics (option)	74
			12.13	Initialize modem	74
			12.14	GSM terminal	74
			12.15	Status telealarm	74
			12.16	Resetting the measuring device	74
			12.17	Firmware history	75
			13	Maintenance	75
			13.1	Updating the device software ("firmware")	75
			13.2	Instructions for enabling a software option ...	75
			13.3	Cleaning	75

14	Repairs	76
14.1	General notes	76
14.2	Spare parts	76
14.3	Return	77
14.4	Disposal	78
15	Accessories	79
15.1	Device-specific accessories	79
16	Technical data	81
16.1	Function and system design	81
16.2	Input	84
16.3	Output	88
16.4	Power supply	91
16.5	Performance characteristics	99
16.6	Installation	100
16.7	Environment	102
16.8	Mechanical construction	102
16.9	Display and operating elements	103
16.10	Certificates and approvals	106
16.11	Ordering information	107
17	Appendix	109
17.1	Operating items in the "Expert" menu	109
17.1.1	"System" submenu	109
17.1.2	"Inputs" submenu	130
17.1.3	"Outputs" submenu	161
17.1.4	"Communication" submenu	167
17.1.5	"Application" submenu	191
17.1.6	"Diagnostics" submenu	247
	Index	251

1 Document information

1.1 Document function

These Operating Instructions contain all the information that is required in various phases of the life cycle of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.

Integrated Operating Instructions

At the push of a button, the device displays operating instructions directly on the screen. This manual complements the operating instructions in the device and explains what is not directly described in the operating instructions.

1.2 Symbols used

1.2.1 Safety symbols

Symbol	Meaning
	DANGER! This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.
	WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.
	CAUTION! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.
	NOTE! This symbol contains information on procedures and other facts which do not result in personal injury.

1.2.2 Electrical symbols

Symbol	Meaning	Symbol	Meaning
	Direct current		Alternating current
	Direct current and alternating current		Ground connection A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.
	Protective ground connection A terminal which must be connected to ground prior to establishing any other connections.		Equipotential connection A connection that has to be connected to the plant grounding system: This may be a potential equalization line or a star grounding system depending on national or company codes of practice.

1.2.3 Symbols for certain types of information

Symbol	Meaning
	Permitted Procedures, processes or actions that are permitted.
	Preferred Procedures, processes or actions that are preferred.
	Forbidden Procedures, processes or actions that are forbidden.
	Tip Indicates additional information.
	Reference to documentation
	Reference to page
	Reference to graphic
	Series of steps
	Result of a step
	Help in the event of a problem
	Visual inspection

1.2.4 Symbols in graphics

Symbol	Meaning
1, 2, 3,...	Item numbers
	Series of steps
A, B, C, ...	Views
A-A, B-B, C-C, ...	Sections
 A0013441	Flow direction
 A0011187	Hazardous area Indicates a hazardous area.
 A0011188	Safe area (non-hazardous area) Indicates a non-hazardous area.

1.3 Terminology

To improve clarity, abbreviations or synonyms are used in these instructions for the following terms:

- Endress+Hauser:
Term used in these instructions: "Manufacturer" or "Supplier"
- Memograph M RSG45:
Term used in these instructions: "Device" or "Measuring device"

1.4 Registered trademarks

HART®

Registered trademark of the HART FieldComm Group, Austin, USA

PROFIBUS®

Registered trademark of the PROFIBUS User Organization, Karlsruhe, Germany

PROFINET®

Registered trademark of the PROFIBUS & PROFINET International User Organization e.V., Karlsruhe, Germany

Modbus®

Registered trademark of SCHNEIDER AUTOMATION, INC.

EtherNet/IP™

Registered trademark of ODVA, INC.

Internet Explorer®, Excel™

Registered trademarks of the Microsoft Corporation

Mozilla Firefox®

Registered trademark of the Mozilla Foundation

Opera®

Registered trademark of Opera Software ASA.

Google Chrome™

Registered trademark of Google INC.

2 Basic safety instructions

Reliable and safe operation of the device is guaranteed only if the user reads these Operating Instructions and complies with the safety instructions they contain.



Requirements concerning operating staff to ensure compliance with FDA 21 CFR Part 11:

In order to fully comply with the requirements of 21 CFR Part 11, the operators/users must be properly trained.

2.1 Requirements concerning the staff

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- ▶ Trained, qualified specialists: must have a relevant qualification for this specific function and task
- ▶ Are authorized by the plant owner/operator
- ▶ Are familiar with federal/national regulations
- ▶ Before beginning work, the specialist staff must have read and understood the instructions in the Operating Instructions and supplementary documentation as well as in the certificates (depending on the application)
- ▶ Following instructions and basic conditions

The operating personnel must fulfill the following requirements:

- ▶ Being instructed and authorized according to the requirements of the task by the facility's owner-operator
- ▶ Following the instructions in these Operating Instructions

2.2 Designated use

This device is designed for the electronic capture, display, recording, analysis, remote transmission and archiving of analog and digital input signals.

- The manufacturer accepts no liability for damages resulting from incorrect use or use other than that designated. It is not permitted to convert or modify the device in any way.
- The device is designed for installation in a panel and must only be operated in an installed state.

2.3 Workplace safety

For work on and with the device:

- ▶ Wear the required personal protective equipment according to federal/national regulations.

2.4 Operational safety

Risk of injury.

- ▶ Operate the device in proper technical condition and fail-safe condition only.
- ▶ The operator is responsible for interference-free operation of the device.

Conversions to the device

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers.

- ▶ If, despite this, modifications are required, consult with the manufacturer.

Repair

To ensure continued operational safety and reliability,

- ▶ Carry out repairs on the device only if they are expressly permitted.
- ▶ Observe federal/national regulations pertaining to repair of an electrical device.
- ▶ Use original spare parts and accessories from the manufacturer only.

Hazardous area

To eliminate a danger for persons or for the facility when the device is used in the hazardous area (e.g. explosion protection, pressure vessel safety):

- ▶ Based on the nameplate, check whether the ordered device is permitted for the intended use in the hazardous area.
- ▶ Observe the specifications in the separate supplementary documentation that is an integral part of these Instructions.

2.5 Product safety

This measuring device is designed in accordance with good engineering practice to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate.

It meets general safety standards and legal requirements. It also complies with the EC directives listed in the device-specific EC Declaration of Conformity. The manufacturer confirms this by affixing the CE mark to the device.

2.6 Safety information for table version (option)

- The mains plug should only be inserted into a socket with a ground contact.
- The protective effect may not be suspended by an extension cable without a protective ground.
- Relay outputs: $U(\max) = 30 V_{\text{eff}}(\text{AC}) / 60 V(\text{DC})$

2.7 IT security

The manufacturer only provides a warranty if the device is installed and used as described in the Operating Instructions. The device is equipped with security mechanisms to protect it against any inadvertent changes to the device settings.

IT security measures in line with operators' security standards and designed to provide additional protection for the device and device data transfer must be implemented by the operators themselves.

3 Product description

3.1 Product design

This device is best suited for the electronic acquisition, display, recording, analysis, remote transmission and archiving of analog and digital input signals.

The device is intended for installation in a panel or cabinet. There is also the option of operating it in a table-mounted or field-mounted housing.

4 Incoming acceptance and product identification

4.1 Incoming acceptance

On receipt of the goods, check the following points:

- Is the packaging or the content damaged?
- Is the delivery complete? Compare the scope of delivery against the information on your order form.

4.2 Scope of delivery


The scope of delivery of the device comprises:

- Device (with terminals, as per order)
- 2 fastening clips
- Version with navigator and front interfaces: USB cable
- Sealing rubber towards control panel wall
- "Industrial Grade" SD card, industry standard:
 - Version with navigator and front interfaces: card is located in the SD slot behind the flap on the front of the housing (optional).
 - Version with stainless steel front and touchscreen: card is in the device and cannot be replaced or retrofitted.
- "Field Data Manager (FDM)" analysis software on DVD (Essential, Demo or Professional version, depending on order)
- "FieldCare Device Setup / DeviceCare" configuration software on DVD
- Delivery note
- Multilanguage Brief Operating Instructions, hard copy
- Ex Safety Instructions, hard copy (optional)

4.3 Product identification

4.3.1 Nameplate

Compare the nameplate with the following diagram:



1 Device nameplate (example)

- 1 Device designation, manufacturer details
- 2 Order code, serial number, extended order code
- 3 Power supply, mains frequency and maximum power consumption
- 4 Ambient temperature range
- 5 Firmware version; MAC address (Ethernet)
- 6 Fieldbus interface with MAC address (optional)
- 7 Device approvals
- 8 Degree of protection of the device
- 9 Approval in hazardous area (optional) with number of the relevant Ex documentation (XA...)
- 10 TAG name (optional); 2D-matrix code

4.4 Storage and transport

Compliance with the permitted environmental and storage conditions is mandatory. For precise specifications, see the "Technical data" section of the Operating Instructions.

Please note the following:

- Pack the device so that is protected against impact for storage and transport. The original packaging provides optimum protection.
- The permitted storage temperature is -20 to +60 °C (-4 to +140 °F).

5 Installation

5.1 Installation conditions

NOTICE

Overheating due to buildup of heat in the device

- To avoid heat buildup, always ensure that the device is sufficiently cooled.

The device is designed for use in a panel.

- i** The device must be installed in a pressurized enclosure system for operation in the hazardous area. To ensure safe installation, it is essential to follow the installation instructions for the cabinet and the installation instructions in the Ex-related Safety Instructions (XA).


- Operating temperature range: -10 to +50 °C (14 to 122 °F)
- Climate class as per IEC 60654-1: Class B2
- Degree of protection: IP65, NEMA 4 at front / IP20 rear of housing

5.1.1 Installation dimensions

- Installation depth (excluding terminal cover): approx. 159 mm (6.26 in) for device incl. terminals and fastening clips.
- Installation depth including terminal cover (option): approx. 198 mm (7.8 in)
- Panel cutout: 138 to 139 mm (5.43 to 5.47 in) x 138 to 139 mm (5.43 to 5.47 in)
- Panel thickness: 2 to 40 mm (0.08 to 1.58 in)
- viewing angle range: 50° in all directions from the display central axis
- A minimum distance of 12 mm (0.47 in) between the devices must be observed if aligning the devices vertically above one another or horizontally beside one another.
- The grid dimension of the panel cutouts for multiple devices must be at least 208 mm (8.19 in) horizontally and at least 162 mm (6.38 in) vertically (tolerance not considered).
- Securing to DIN 43 834


5.2 Mounting the measuring device

 Mounting tool: For installation in the panel, all you need is a screwdriver.



A0024610

2 Panel cutout and dimensions in mm (in).
A Version with navigator and front interfaces
B Version with stainless steel front and touchscreen
C Grid dimensions of panel cutouts for multiple devices



A0026672

3 Panel mounting

1. From the rear of the device, push the sealing rubber (B) (supplied) as far as the front frame of the device (A).
2. Slide the device (A) through the panel cutout from the front (C). To avoid the buildup of heat, maintain a distance of >12 mm (>0.47 in) from walls and other devices.
3. Hold the device (A) level and hang the fastening clips (D) in the openings (1 x left, 1 x right).
4. Evenly tighten the screws on the fastening clips (D) using a screwdriver to guarantee a secure seal to the control panel (torque 100 Ncm).

5.3 Post-installation check

- Is the sealing ring undamaged?
- Does the seal run all around the housing collar?
- Are the fastening clips tightened?
- Is the device fixed firmly in the center of the control panel cutout?

6 Electrical connection

6.1 Connection conditions

WARNING

Danger! Electric voltage!

- ▶ The entire connection of the device must take place while the device is de-energized.
- ▶ The mixed connection of safety extra-low voltage and dangerous contact voltage to the relay is **not** permitted.
- ▶ Apart from the relays and the supply voltage, only energy-limited circuits according to IEC/EN 61010-1 may be connected.

Danger if protective ground is disconnected

- ▶ The ground connection must be made before all other connections.

NOTICE

Cable heat load

- ▶ Use suitable cables for temperatures of 5 °C (9 °F) above ambient temperature.

Incorrect supply voltage can damage the device or cause malfunctions

- ▶ Before commissioning the device, make sure that the supply voltage matches the voltage specifications on the nameplate.

Check emergency shutdown for device

- ▶ Provide suitable switch or circuit breaker in building installation. This switch must be provided close to the device (within easy reach) and marked as a circuit breaker.

Protect the device from overload

- ▶ Provide overload protection (nominal current = 10 A) for power cable.

Incorrect wiring may result in the device being destroyed

- ▶ Note terminal designation on the rear of the device.

Energy-rich transients in the case of long signal lines

- Install suitable overvoltage protection (e.g. E+H HAW562) upstream.

 Special requirements according to FDA 21 CFR Part 11:

- The user must have the appropriate skills and qualifications to connect the device. Connection errors can only be prevented in this way.
- The user is responsible for selecting the right input ranges and for connecting suitable sensors.
- Users must ensure that the connected sensors cannot be tampered with by making sure they are suitably mounted and wired.
- An optional terminal cover is available to prevent tampering at the device terminals and terminal temperature measurement. It is the responsibility of the user to verify that the device is correctly installed and sealed following validation.
- The user is responsible for compliance with the EMC limit values at the installation location (see technical data).

6.2 Connection instructions

6.2.1 Cable specification

Cable specification, spring terminals

All connections on the rear of the device are designed as pluggable screw or spring terminal blocks with reverse polarity protection. This makes the connection very quick and easy. The spring terminals are unlocked with a slotted screwdriver (size 0).

Please note the following when connecting:

- Wire cross-section, auxiliary voltage output, digital I/O and analog I/O: max. 1.5 mm² (14 AWG) (spring terminals)
- Wire cross-section, mains: max. 2.5 mm² (13 AWG) (screw terminals)
- Wire cross-section, relays: max. 2.5 mm² (13 AWG) (spring terminals)
- Stripping length: 10 mm (0.39 in)

 No ferrules must be used when connecting flexible wires to spring terminals.

Shielding and grounding

Optimum electromagnetic compatibility (EMC) can only be guaranteed if the system components and, in particular, the lines - both sensor lines and communication lines - are shielded and the shield forms as complete a cover as possible. A shielded line must be used for sensor lines that are longer than 30 m. A shield coverage of 90% is ideal. In addition, make sure not to cross sensor lines and communication lines when routing them. Connect the shield as often as possible to the reference ground to ensure optimum EMC protection for the different communication protocols and the connected sensors.

To comply with requirements, three different types of shielding are possible:

- Shielding at both ends
- Shielding at one end on the supply side with capacitance termination at the device
- Shielding at one end on the supply side

Experience shows that the best results with regard to EMC are achieved in most cases in installations with one-sided shielding on the supply side (without capacitance termination at the device). Appropriate internal device wiring measures must be taken to allow unrestricted operation when EMC interference is present. These measures have been taken into account for this device. Operation in the event of disturbance variables as per NAMUR NE21 is thus guaranteed.


Where applicable, national installation regulations and guidelines must be observed during the installation! Where there are large differences in potential between the

individual grounding points, only one point of the shielding is connected directly with the reference ground.

i If the shielding of the cable is grounded at more than one point in systems without potential matching, mains frequency equalizing currents can occur. These can damage the signal cable or significantly impact signal transmission. In such cases the shielding of the signal cable is to be grounded on one side only, i.e. it may not be connected to the ground terminal of the housing. The shield that is not connected should be insulated!

6.3 Connecting the measuring device

6.3.1 Terminals on back of device




A0024605

4 Terminals on back of device

- 6 Slot 6: Power supply with relays
- 5 Slot 5: Multifunction card or HART® card (channels 17-20) or digital card
- 4 Slot 4: Multifunction card or HART® card (channels 13-16)
- 3 Slot 3: Multifunction card or HART® card (channels 9-12)
- 2 Slot 2: Multifunction card or HART® card (channels 5-8)
- 1 Slot 1: Multifunction card or HART® card (channels 1-4)
- 0 Slot 0: CPU card with interfaces

6.3.2 Electrical connection, terminal assignment


Circuit diagram




5 For connection examples of the HART® inputs (optional), see the Operating Instructions → 23

A0026669-EN

Supply voltage (power unit, slot 6)

Power unit type	Terminal		
			
100-230 VAC	L+	N-	PE
	Phase L	Zero conductor N	Ground
24 V AC/DC	L+	N-	PE
	Phase L or +	Zero conductor N or -	Ground

Relay (power unit, slot 6)


Type	Terminal (max. 250 V, 3 A)				
					
Alarm relay 1	R11	R12	R13		
	Changeover contact	Normally closed contact (NC) ¹⁾	Normally open contact (NO) ²⁾		
Relay 2 to 6				Rx1	Rx2
				Switching contact	Normally open contact (NO ²⁾)


- 1) NC = normally closed (breaker)
- 2) NO = normally open (maker)



The open or close function (= activation or deactivation of the relay coil) in a limit event can be configured in the setup: "Setup -> Advanced setup -> Outputs -> Relay -> Relay x". However, in the event of a power failure, the relay adopts its quiescent switch state regardless of the setting programmed.

Digital inputs; auxiliary voltage output (power unit, slot 6)


Type	Terminal			
				
Digital input 1 to 6	D11 to D61	GND1		
	Digital input 1 to 6 (+)	Ground (-) for digital inputs 1 to 6		

Type	Terminal			
				
Auxiliary voltage output, not stabilized, max. 250 mA			24V Out -	24V Out +
			- Ground	+ 24V (±15%)

 If the auxiliary voltage is to be used for the digital inputs, the **24 V out -** terminal of the auxiliary voltage output must be connected with the **GND1** terminal.

Analog inputs (slot 1-5)


The first digit (x) of the two-digit terminal number corresponds to the associated channel:

Type	Terminal					
						
	x1	x2	x3	x4	x5	x6
Current/pulse/frequency input ¹⁾					(+)	(-)
Voltage > 1V		(+)				(-)
Voltage ≤ 1V				(+)		(-)
Resistance thermometer RTD (2-wire)	(A)					(B)
Resistance thermometer RTD (3-wire)	(A)			b (sense)		(B)
Resistance thermometer RTD (4-wire)	(A)		a (sense)	b (sense)		(B)
Thermocouples TC				(+)		(-)

1) If a universal input is used as a frequency or pulse input, a series resistor must be used in series connection with the voltage source. Example: 1.2 kΩ series resistor at 24 V


HART® inputs (slot 1-5)

The first digit (x) of the two-digit terminal number corresponds to the associated channel:

Type	Terminal					
						
	x1	x2	x3	x4	x5	x6
HART® (4 to 20 mA)	SHD	H_1	H_2	R _{com}	I+	I-

- A 250 Ω communication resistor (load) is installed on the device side between terminals x4 and x5.
- A 10 Ω resistor (shunt) is installed on the device side at the current input between terminals x5 and x6.
- Terminals x2 and x3 (H_1 and H_2) are jumpered internally.
- The internal HART® modem is located between terminals x2/x3 and x6.


Relay extension (digital card, slot 5)

Type	Terminal (max. 250 V, 3 A)			
				
Relay 7, 8	RA	RB	RC	RD
Relay 9, 10	RE	RF	RG	RH
Relay 11, 12	RI	RJ	RK	RL
	Switching contact	Normally open contact (1)	Switching contact	Normally open contact (2)

- 1) NO)
2) NO)

The open or close function (= activation or deactivation of the relay coil) in a limit event can be configured in the setup: "Setup -> Advanced setup -> Outputs -> Relay -> Relay x". However, in the event of a power failure, the relay adopts its quiescent switch state regardless of the setting programmed.

Analog outputs (digital card, slot 5)


Type	Terminal			
				
Analog output 1-2	O15	O16	O25	O26
	Analog output 1 (+)	Ground, analog output 1 (-)	Analog output 2 (+)	Ground, analog output 2 (-)

Extension of digital inputs (digital card, slot 5)

Type	Terminal 		
Digital input 7 to 14	D71 to DE1	GND2	GND2
	Digital input 7 to 14 (+)	Ground (-) for digital inputs 7 to 14	Ground (-) for digital inputs 7 to 14

 If the auxiliary voltage is to be used for the digital inputs, the **24 V out** - terminal of the auxiliary voltage output (power unit, slot 6) must be connected with the **GND2** terminal.


6.3.3 Connection example: Auxiliary voltage output as transmitter power supply for 2-wire sensors



 6 Connecting the auxiliary voltage output when using as a transmitter power supply for 2-wire sensors in the current measuring range

- 1 Sensor 1 (e.g. Cerabar from Endress+Hauser)
- 2 Sensor 2
- 3 External indicator (optional) (e.g. RIA16 from Endress+Hauser)

6.3.4 Connection example: Auxiliary voltage output as transmitter power supply for 4-wire sensors




A0024730

7 Connecting the auxiliary voltage output when using as a transmitter power supply for 4-wire sensors in the current measuring range

- 1 Sensor 1 (e.g. temperature switch TTR31 from Endress+Hauser)
- 2 Sensor 2
- 3 External indicator (optional) (e.g. RIA16 from Endress+Hauser)

6.3.5 Connection example: HART® input in a point-to-point connection



A0024864

8 Connection example: HART® inputs in a point-to-point connection

- 1 Active 4-wire sensor (slave)
- 2 Power supply for 4-wire sensor
- 3 Power supply (electricity source) for actuator
- 4 Actuator (e.g. adjuster or valve)
- 5 Passive 2-wire sensor (slave)
- 6 Power supply (voltage source) for sensor.




The internal auxiliary voltage (24 V OUT) can also be used as the transmitter power supply.

6.3.6 Connection example: HART® input in multidrop



Notes on HART® multidrop topology:

- The analog signal is not available for the process variable. Only the digital signal is used.
- Multidrop topology is **not** recommended for time-critical applications due to the slower update rate.
- The device supports a maximum of 5 sensors per current loop. The address should be in the 1 to 15 range (compatibility with HART®5).



A0024860

9 Connection example: HART® inputs in multidrop

- 1 Sensor (slave 1)
- 2 Sensor (slave 2)
- 3 Sensor (slave 3 to 5)




The internal auxiliary voltage (24 V OUT) can also be used as the transmitter power supply.

6.3.7 RS232/RS485 interface (CPU card, rear of device, slot 0)

 Use shielded signal lines for serial interfaces!

A combined RS232/RS485 connection is available on a shielded SUB D9 socket at the rear of the device. This can be used for data transfer and to connect a modem. For communication via modem, we recommend an industrial modem with a watchdog function.



Type	Pin of the SUB-D9 socket								
	1	2	3	4	5	6	7	8	9
RS232 assignment		TxD (data output)	RxD (data input)		GND				
RS485 assignment					GND			RxD/TxD -	RxD/TxD +

Unoccupied connections should be left empty.
Maximum cable length:
RS232: 2 m (6.6 ft)
RS485: 1000 m (3280 ft)

 Only one interface can be used at any one time (RS232 or RS485).

Option: Modbus RTU master

As a Modbus master, the device can interrogate other Modbus slaves via RS485. The Modbus RTU master can be operated in parallel with the Profibus DP slave, EtherNet/IP adapter, PROFINET I/O device or Modbus TCP slave.

Up to 40 analog inputs can be transmitted via Modbus and stored in the device.

Option: Modbus RTU slave

The device can be interrogated as a Modbus slave by another Modbus master via RS485.

Up to 40 analog inputs and 20 (14 real + 6 virtual) digital inputs can be transmitted via Modbus and stored in the device.



A Modbus RTU master and RTU slave cannot be operated in parallel.

Remote interrogation with analog or GSM/GPRS wireless modem:**Analog modem:**

An analog modem for industrial use (e.g. Devolo or WESTERMO), which is connected to the RS232 interface with a special modem cable (see Accessories → 79), is recommended.

GSM/GPRS wireless modem:

A GSM/GPRS wireless modem (e.g. Cinterion, INSYS or WESTERMO), incl. antenna and power unit), which is connected to the RS232 interface with a special modem cable (see Accessories → 79), is recommended for industry.

Important: the wireless modem needs a SIM card and data transfer subscription. In addition, it must be possible to deactivate the PIN prompt.

6.3.8 Ethernet connection (CPU card, rear of device, slot 0)

The Ethernet interface can be used to integrate the device via a hub or switch into a PC network (TCP/ IP Ethernet). A standard patch cable (e.g. CAT5E) can be used for the connection. Using DHCP, the device can be fully integrated into an existing network without the need for additional configuration. The device can be accessed from every PC in the network.

- Standard: 10/100 Base T/TX (IEEE 802.3)
- Socket: RJ-45
- Max. line length: 100 m
- Galvanic isolation; testing voltage: 500 V

The following functions are implemented:

- Data communication with PC software (analysis software, configuration software, OPC server)
- Web server

Meaning of the LEDs

Beneath the Ethernet connection (see rear of device) there are two light emitting diodes which indicate the status of the Ethernet interface.

- Yellow LED: link signal; is lit when the device is connected to a network. If this LED is not illuminated then communication is impossible.
- Green LED: Tx/Rx; flashes irregularly if the device is transmitting or receiving data.

Option: Ethernet Modbus TCP master

As a Modbus master, the device can interrogate other Modbus slaves via Ethernet. The Modbus TCP master can be operated in parallel with the Profibus DP slave, Modbus RTU, Modbus TCP slave, EtherNet/IP adapter or PROFINET I/O device.

Up to 40 analog inputs can be transmitted via Modbus and stored in the device.

Option: Ethernet Modbus TCP slave

The Modbus TCP interface is used to connect to higher-ranking SCADA systems (Modbus master) to transmit all measured values and process values.

Up to 40 analog inputs and 20 (14 real + 6 virtual) digital inputs can be transmitted via Modbus and stored in the device.

6.3.9 Option: Anybus® interface (CPU card, rear of device, slot 0)**PROFIBUS-DP slave:**

The device can be integrated into a fieldbus system as per the PROFIBUS-DP standard by means of the PROFIBUS-DP interface. Up to 40 analog inputs and 20 (14 real + 6 virtual) digital inputs can be transmitted via PROFIBUS-DP and stored in the device. For bidirectional communication in cyclic data transfer. Connection via Sub-D socket.

Baudrate: maximum 12 Mbit/s

EtherNet/IP adapter (slave):

Up to 40 analog inputs and 20 (14 real + 6 virtual) digital inputs can be transmitted via EtherNet/IP and stored in the device. The built-in module corresponds to I/O server category (Level 2). It has an integrated 2-port switch, thereby supporting EtherNet/IP communication with line or ring topology. Connection via 2 RJ45 standard sockets.


PROFINET I/O device:

Up to 40 analog inputs and 20 (14 real + 6 virtual) digital inputs can be transmitted via PROFINET IO and stored in the device. The 2-port module for Profinet IO meets compliance class B. The integrated switch enables communication in line or ring topologies without an additional external switch. Connection via 2 RJ45 standard sockets.

6.3.10 USB connection, type A (host) (CPU card, rear of device, slot 0)

Two USB 2.0 ports are available on shielded USB A sockets at the rear of the device. A USB stick as a memory medium, for example, can be connected to these ports. An external keyboard/mouse for device operation, a USB hub, a barcode reader or a printer (PCL5c or higher) may also be connected.

6.3.11 Connections on front of device (only for version with navigator and front interfaces)



A0024737

 10 Version with navigator and front interfaces with open flap

- 1 Navigator
- 2 Slot for SD card
- 3 USB B socket "Function" e.g. to connect to PC or laptop
- 4 USB A socket "Host" e.g. for USB memory stick, external keyboard/mouse, USB hub, barcode reader or printer
- 5 LED at SD slot. Yellow LED lit or flashing when the device writes to the SD card or reads it.

USB connection type A (host)

A USB 2.0 port is available on a shielded USB A socket at the front of the device. A USB stick as a memory medium, for example, can be connected to this port. An external keyboard/mouse for device operation, a USB hub, a barcode reader or a printer (PCL5c or higher) may also be connected.

USB connection type B (function)

A USB 2.0 port is available on a shielded USB B socket at the front of the device. This can be used to connect the device for communication with a laptop, for example.

 USB-2.0 is compatible with USB-1.1 or USB-3.0, i.e. communication is possible.

Requirements for the SD card

Industrial grade SD-HC cards with max. 32 GB are supported.

 Use only the industrial-grade SD cards described in the "Accessories" section of the Operating Instructions. These have been tested by the manufacturer and guaranteed to function faultlessly in the device. →  79

 The SD card must be formatted to FAT or FAT32. NTFS format is not readable.

6.3.12 General information on USB devices

The USB devices are detected by the "plug-and-play" function. If several devices of the same type are connected, only the USB device that was connected first is available. Settings for the USB devices are made in the setup. A maximum of 8 external USB devices (incl. USB hub) can be connected if they do not exceed the maximum load of 500 mA. If overloaded, the corresponding USB devices are automatically disabled. An active USB hub can be used for higher power ratings.

Requirements with regard to the USB stick

There is no guarantee that all manufacturers' USB sticks will function faultlessly. That is why an industrial grade SD card is recommended to ensure the reliable recording of data.
→ 79

-  The USB stick must be formatted to FAT or FAT32. NTFS format is not readable. The system supports only USB sticks with max. 32 GB.
-  The USB stick must not be connected to the device via a USB hub. Interference from other USB devices may result in data loss.

Requirements with regard to an external USB keyboard

The system only supports keyboards which can be addressed using generic drivers (HID keyboard - Human Interface Device). Special keys are not supported (e.g. Windows keys). Users can only enter characters that are available in the entry character set of the device. All unsupported characters are rejected. It is not possible to connect a wireless keyboard. The following keyboard layouts are supported: DE, CH, FR, USA, USA International, UK, IT. See setting under "Setup -> Advanced setup -> System -> Keyboard layout".

Requirements with regard to an external USB barcode reader

The connected barcode reader has to act like a HID keyboard (human interface device) (universal keyboard driver). The barcode reader must complete every barcode with a carriage return (0x0D) + line feed (0x0A).

Checking the barcode reader at a PC

Before connecting the barcode reader to the device, it should be checked at a Windows® PC.

1. Connect the barcode reader to the PC and wait until Microsoft Windows® recognizes the device as a HID keyboard and installs it (check with the Windows Device Manager).
2. Configure the barcode reader as specified in the Operating Instructions of the barcode reader.
3. Start the Notepad (editor).
4. Using the barcode reader, read in a barcode (as it is used later) and check it.
5. Do not connect the barcode reader to the device until the barcode reader has been correctly configured and tested on the PC.
6. Select the character set at the device under "Setup -> Advanced setup -> System -> Barcode reader -> Character set". The following character sets are supported: DE, CH, FR, USA, USA International, UK, IT. Note: This setting has to be identical to the configuration of the barcode reader! The system only reads characters that are available in the entry character set of the device. All other characters are rejected.
7. The barcode reader should also be tested at the device via "Main menu -> Diagnostics -> Simulation -> Test barcode reader".

If problems arise, please contact the manufacturer of the barcode reader.

Reference list: Datalogic Gryphon D230, Metrologic MS5100 Eclipse Series, Symbol LS2208, Datalogic Quickscan 1, Godex GS220, Honeywell Voyager 9590

Requirements with regard to an external USB printer

The printer must support PCL5c (or higher). Laser jet and ink jet printers are supported. The printouts are always color printouts (if supported by the printer). The printout has different shades of gray if you use a black/white printer.

Reference list: HP Color LaserJet CP1515n, HP Color LaserJet Pro CP1525n, Kyocera FS-C5015N

Note! GDI printers are not supported!

6.4 Post-connection check

Device condition and specifications	Notes
Are cables or the device damaged?	Visual inspection
Electrical connection	Notes
Does the supply voltage match the specifications on the nameplate?	-
Are all terminals firmly engaged in their correct slot?	-
Are the mounted cables strain-relieved?	-
Are the power supply and signal cables correctly connected?	See connection diagram and rear of device.


7 Operation options

7.1 Overview of operation options

The device can be operated directly onsite with the Navigator and USB keyboard/mouse or via interfaces (serial, USB, Ethernet) and operating tools (Web server, FieldCare/ DeviceCare configuration software).


7.2 Structure and function of the operating menu

7.2.1 Operating menu for operators and maintenance personnel



A0024770-EN

7.2.2 Operating menu for experts



A0019596-EN


7.2.3 Submenus and users

Certain parts of the menu are assigned to certain user roles. Each user role corresponds to typical tasks within the lifecycle of the device.

User role	Typical tasks	Menu	Content/meaning
Operator	Tasks during operation: ■ Configuration of the display. ■ Reading measured values.	"Operation"	Contains all the parameters that are required in ongoing operation: configuration of the measured value display (displayed values, display format, etc.).
Maintenance	Commissioning: ■ Configuration of the measurement. ■ Configuration of data processing.	"Setup"	Contains all parameters for commissioning: ■ Change date/time ■ "Advanced setup" submenu Contains additional submenus and parameters: – System: Basic settings required for operating the device. – Inputs: Settings for analog and digital inputs. – Outputs: Setup required only if outputs (e.g. relays) are to be used. – Communication: Setup required if you are using the USB, RS232, RS485 or Ethernet interface or the HART® inputs of the unit (PC operation, serial data read-out, modem operation, etc). – Application: Define different application-specific settings (e.g. group settings, limit values, etc.). Once values have been set for these parameters, the measurement should generally be completely configured.

User role	Typical tasks	Menu	Content/meaning
	Fault elimination: ▪ Diagnosing and eliminating process errors. ▪ Interpretation of device error messages and correcting associated errors.	"Diagnostics"	Contains all parameters for detecting and analyzing errors: ▪ Diagnosis list All diagnosis messages are listed in chronological order. ▪ Event logbook Events such as limit value violations and power failures are listed in chronological order. ▪ Device information Displays important device information (e.g. serial number, firmware version, device options for hardware and software, memory information, etc.). ▪ Measured values Display of current measured values of device. ▪ Outputs Displays the current status of the outputs e.g. switch status of relay outputs. ▪ Simulation Various functions/signals can be simulated for test purposes here. Note: In Simulation mode, normal recording of the measured values is interrupted and the intervention is logged in the event log. ▪ HART® Displays the exact device information of a selected HART® device and the HART® communication signal quality. ▪ Initialize modem Initializes the modem connected to the serial interface (for automatic call answering).
Expert	Tasks that require detailed knowledge of the function of the device: ▪ Commissioning measurements under difficult conditions. ▪ Optimal adaptation of the measurement to difficult conditions. ▪ Detailed configuration of the communication interface. ▪ Error diagnostics in difficult cases.	"Expert"	Contains all parameters of the device (including those that are already in one of the other menus). The expert menu is protected by a code. Factory setting: 0000. This menu is structured according to the function blocks of the device: ▪ "System" submenu Contains all higher-order device parameters that do not concern the measurement or measured value communication. ▪ "Inputs" submenu Contains all parameters for configuring the analog and digital inputs. ▪ "Output" submenu Contains all parameters for configuring the outputs (e.g. relays). ▪ "Communication" submenu Contains all parameters for configuring the communication interfaces. ▪ "Application" submenu Contains all parameters for configuring application-specific settings (e.g. group settings, limit values etc.). ▪ "Diagnostics" submenu Contains all parameters needed to detect and analyze operational errors.

7.3 Measured value display and operating elements



11 Device front (left: version with navigator and front interfaces; right: version with stainless steel front and touchscreen)

Item No.	Operating function (display mode = display of measured values) (Setup mode = operating in the Setup menu)
a	Slot for SD card
b	USB B socket "Function" e.g. to connect to PC or laptop
c	USB A socket "Host" e.g. for USB memory stick, external keyboard, barcode reader or printer
d	LED at SD slot. Yellow LED lit or flashing when the device writes to the SD card or reads it. Do not remove the SD card if the LED is lit or flashing! Risk of data loss!
1	"Navigator": jog/shuttle dial for operating with additional press/hold function. In display mode: turn the dial to switch between the various signal groups. Press the dial to display the main menu. In setup mode or in a selection menu: turn the dial anticlockwise to move the bar or the cursor upwards or counterclockwise, changes the parameter. Turning clockwise moves the bar or cursor down or clockwise, changes parameter. Press = select highlighted function, start parameter change (ENTER key).
2	Functions of LED indicators (according to NAMUR NE44-): - Green LED (top) lit: power supply OK - Red LED (bottom) flashing: maintenance required, caused by external factor (e.g. cable open circuit etc.), or a message/notification requiring acknowledgment is pending, calibration is running.
3	Variable "soft keys", keys 1 to 4 (from left to right)
4	Function indicator of the "soft keys"
5	In display mode: current group name, type of analysis; In setup mode: name of the current operating item (dialog title)
6	In display mode: displays current date/time In setup mode: --
7	In display mode: user ID (if function is active) In setup mode: --

Item No.	Operating function (display mode = display of measured values) (Setup mode = operating in the Setup menu)
8	In display mode: alternating display indicating the percentage space on the SD card or USB stick that has already been used. Status symbols are also displayed in alternation with the memory information (e.g. simulation mode, data storage active, operation locked, batch active) In setup mode: the current "direct access" operating code is displayed
9	In display mode: window for measured value display (e.g. curve display). Display of current measured values and the status in the event of an error/alarm condition. In the case of counters, the type of counter is displayed as a symbol.  If a measuring point has limit value status, the corresponding channel identifier is highlighted in red (quick detection of limit value violations). During a limit value violation and device operation, the acquisition of measured values continues uninterrupted.
9	In setup mode: display of operating menu
10	In display mode: alternating status display (e.g. set zoom range) of the analog or digital inputs in the appropriate color of the channel. In setup mode: different information is displayed here depending on the display type.

7.4 Display representation of symbols used in operation

Item No.	Function	Description
9	Symbols for counters:	
	$\Sigma 1, \Sigma 2, \Sigma 3, \Sigma 4$	Intermediate analysis 1 to 4 / external analysis 1 to 4
	ΣD	Daily analysis
	ΣW	Weekly analysis
	ΣM	Monthly analysis
	ΣY	Annual analysis
	Σ	Totalizer
9	Channel-related symbols:	
		Violation of lower limit value
		Violation of upper limit value or limit value on counter
		Violation of upper and lower limit values at the same time
	S	"Out of specification" e.g. input signal too high/low
	F	Error message "Failure detected" An operating error has occurred. The measured value is no longer valid (e.g. a channel not displayed in the current group is defective).
	M	"Maintenance required" Maintenance is required. The measured value is still valid.
8	-----	Error, measured value not displayed. Possible causes: Sensor / input error, line break, invalid value, input signal too high/low
	Symbol for status signals:	
		"Device locked" Setup is locked via a control input. Disable setup lock via a control input.
	S	"Out of specification" The device is being operated outside its technical specifications (e.g. during startup or cleaning).
	C	"Function check" The device is in Service mode.

Item No.	Function	Description
	M	"Maintenance required" Maintenance is required. The measured value is still valid.
	F	Error message "Failure detected" An operating error has occurred. The measured value is no longer valid (e.g. a channel not displayed in the current group is defective).
		"External communication" The device is communicating externally (e.g. via Modbus).
	SIM	"Simulation" Simulation is active.
4		"Historical data" Historical data are currently shown on screen.

7.4.1 Symbols in operating menus

	Symbol for setup
	Symbol for diagnostics
	Symbol for expert setup
	Symbol for user administration according to "FDA 21 CFR Part 11"
	Back Use the "Back" function, which can be found at the bottom of each menu/submenu, to move up a level in the menu structure.
	To quit the menu immediately, press and hold "Back" (>3 sec.) in the Navigator. The device switches to display mode.

7.4.2 Symbols in the event logbook

	Setup changes
	Power on
	Power off
	Limit value on
	Limit value off
1	Digital on (on/off message)
0	Digital off (on/off message)
	Service
	User administration
	Texts saved / comments added
OK	Acknowledging message
	Back
	Continue searching

7.5 Entering text and numbers (virtual keyboard)

A virtual keyboard is available for entering text and numbers. This is opened automatically if needed. Here, turn and press the navigator, or use the touchscreen or mouse, to select the appropriate character.

The following characters are available for entering free text:

0-9 a-z A-Z = + - * / \ ² ³ ¼ ½ ¾ () [] < > { } I ? ! ` " ' ^ % ° . , : _ μ & # \$ € @ \$ £ ¥ ~

←	Jump one position to the left. If this symbol is selected, the cursor jumps one position to the left.
→	Jump one position to the right. If this symbol is selected, the cursor jumps one position to the right.
←x	Delete backwards. If this symbol is selected, the character to the left of the cursor position is deleted.
x→	Delete forwards. If this symbol is selected, the character to the right of the cursor position is deleted.
	Delete all. If this symbol is selected, the entire entry is deleted.
	Reject entry. If this symbol is selected, the entry is rejected and you quit editing mode. The previously set text remains.
	Accept entry. If this symbol is selected, the entry is applied at the position specified by the user, and you quit editing mode.

7.6 Channel color assignment

Channel color assignment is performed in the main menu under "**Setup -> Advanced setup -> Application -> Signal groups -> Group x**". 8 predefined colors are available per group and can be assigned to the desired channels.

7.7 Access to the operating menu via the local display

Using the "Navigator" (jog/shuttle dial with additional press function), the soft keys or the touchscreen (option), all settings can be made directly onsite at the device.

7.8 Device access via operating tools

7.8.1 Field Data Manager (FDM) analysis software (SQL database support)

The PC analysis software offers external, centralized data management with visualization for recorded data. The analysis software enables the complete archiving of all measuring point data e.g. measured values, diagnostic events and protocols. The analysis software stores data in an SQL database. The database can be operated locally or in a network (client / server). Access is via RS232/RS485, USB or Ethernet interface (network).

Function scope:

- Export of saved data (measured values, analyses, event log)
- Visualization and processing of saved data (measured values, analyses, event log)
- Safe archiving of exported data in a SQL database

The following versions of the software are available:

- Essential version (free, with limited functionalities)
- Professional version (see accessories →  79)
- Demo version (time-limited Professional version)



An "Essential" version of the analysis software is supplied with the device.



For details, see the Operating Instructions on the analysis software DVD provided.

7.8.2 Web server

A web server is integrated into the device. This makes the current measured values of the device available in real time. Access is via an Ethernet interface from a PC in the network via the standard browser. The installation of additional software is not required.

The Web server offers the following range of functions:

- Display of current and historical data and measured value curves via a standard Web browser →  51
- Easy configuration without additional installed software →  41
- Remote access to device and diagnostic information

7.8.3 OPC server (optional)

The OPC server makes it possible to access data on the device. These data are made available to OPC clients in real time. The OPC server meets the requirements of the OPC specifications regarding the supply of data to an OPC client. Access is via RS232/RS485, USB or Ethernet interface (network). Communication takes place using automatic device detection; the operator does not need to make any additional settings. The OPC server enables the flexible and powerful exchange of data and is easy and convenient to use.

The following momentary values can be provided:

- Analog channels
- Digital channels
- Mathematics
- Totalizer



For details, see Operating Instructions BA00223R/09/xx

7.8.4 FieldCare/DeviceCare configuration software (included in the delivery)

Function scope

The configuration software is an FDT/DTM-based system asset management tool. It can configure all smart field devices in a system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition. Access is via USB or Ethernet interface (network).

Typical functions:

- Device configuration
- Loading and saving device data (upload/download)
- Documentation of the measuring point



For details, see the Operating Instructions on the configuration software DVD provided

Overview of device description files (DTM)

Information and files are available free of charge at:



See online at: www.de.endress.com/fieldcare

8 System integration

8.1 Integrating the measuring device in the system

8.1.1 General notes

The device has (optional) fieldbus interfaces for exporting process values. Measured values and statuses can also be transmitted to the device via fieldbus. Note: Counters cannot be transferred.

Alarms or errors in the context of data transmission are displayed depending on the bus system (e.g. status byte).

The process values are transferred in the same devices that are used for display at the device.

 Information on compliance with FDA 21 CFR Part 11 requirements when using fieldbus systems:

If no measured values are received by fieldbus, the device activates a floating switching contact (e.g. relay) after a configurable timeout period. The evaluation of the switching contact is the responsibility of the user.

8.1.2 Ethernet

Setup → Advanced setup → Communication → Ethernet

The IP address can be entered manually (fixed IP address) or assigned automatically using DHCP.

The port for data communication is preset to 8000. The port can be changed in the **Expert → Communication → Ethernet** menu.

The following functions are implemented:

- Data communication with PC software (analysis software, configuration software, OPC server)
- Web server

The following connections are possible at the same time:

- 1x Port 8000 (configuration software, OPC server or analysis software)
- 1x Port 8002 (OPC server only)
- 1x Port 5094 (HART® IP)
- 4x Modbus slave TCP
- 5x Web server

 Ports can be changed!

As soon as the maximum number of connections has been reached, new connection attempts are blocked until an existing connection has been terminated.

8.1.3 Modbus RTU/TCP slave

The device can be connected to a Modbus system via RS485 or Ethernet interface. The general settings for the Ethernet connection are made in the **Setup → Advanced setup → Communication → Ethernet** menu. Configuration for Modbus communication is done in

the **Setup** → **Advanced setup** → **Communication** → **Modbus slave** menu. Up to 12 analog inputs and 6 digital inputs can be transmitted via Modbus and stored in the device.

Menu position	RTU (RS485)	Ethernet
Device address:	1 to 247	IP address manual or automatic
Baud rate:	9600/ 19200 /38400/57600/115200	-
Parity:	Even/Odd/ None	-
Stop bits:	1/2	-
Port:	-	502

Transfer of values

The actual Modbus TCP protocol is located between layer 5 to 6 in the ISO/OSI model.

To transfer a value, 3 registers of 2 bytes each (2-byte status + 4-byte float) or 5 registers of 2 bytes each (2-byte status + 8-byte double) are used.



More detailed information about Modbus is provided in the supplementary documentation.

9 Commissioning

9.1 Function check

Make sure that all post-connection checks have been carried out before putting your device into operation:

- "Post-installation check" checklist →  14.
- "Post-connection check" checklist →  29.

9.2 Switching on the measuring device

Once the operating voltage is applied, the display lights up and the device is ready for operation.

When commissioning the device for the first time, program the setup as described in the following sections of the Operating Instructions.

When commissioning a device that is already configured or preset, the device starts measuring immediately as defined in the settings. The values of the channels currently activated are shown on the display.

 Remove the protective film from the display as this would otherwise affect the readability of the display.

9.3 Setting the operating language

Factory setting: English or ordered local language

Version with stainless steel front and touchscreen, or when operating with the external USB mouse:

Calling the main menu, configuring the operating language:

1. Press or click the "Menu" soft key at the bottom edge of the screen
2. The main menu appears on the display with the "Sprache/Language" option
3. To change the default language setting: press or click "Sprache/Language" and select the desired language from the drop-down menu.
4. Press "Back" or "ESC" to exit the main menu

The operating language has been changed.

Version with navigator and front interfaces:

Calling the main menu, configuring the operating language:

1. Press the navigator
2. The main menu appears on the display with the "Sprache/Language" option
3. Change the default language setting: press the navigator, turn it to select the preferred language and press the navigator again to accept the setting.
4. Press "Back" or "ESC" to exit the main menu

The operating language has been changed.

 Use the  "Back" function, which can be found at the bottom of each menu/submenu, to move up a level in the menu structure.

To quit the menu immediately and return to the measured value display, press and hold "Back" (>3 sec.). The changes made are accepted and saved.

9.4 Configuring the measuring device (Setup menu)

Access to the setup is enabled when the device leaves the factory and can be locked in various ways e.g. by entering a 4-digit access code or by user administration.

When locked, basic settings can be checked but not changed. You can also use a PC to commission or configure the device.

Device configuration options

- Setup directly at the device
- Setup via SD card or USB stick by accepting the parameters stored on the stick or card
- Setup via Web server using Ethernet
- Setup via FieldCare/DeviceCare configuration software using USB interface or Ethernet

9.4.1 Step-by-step: to the first measured value

Procedure and necessary settings:

1. Check the date/time in the main menu under **"Setup"** and set it if necessary
2. Make settings for the interfaces and communication in the main menu under **"Setup -> Advanced setup -> Communication"**
3. Create universal or digital inputs in the main menu under **"Setup -> Advanced setup -> Inputs -> Universal inputs / digital inputs"**: Add input: select **"Universal input x"** or **"Digital input x"** with which the input signal should be recorded. Then select the newly created input and configure it.
4. Activate relays or analog outputs (optional) in the main menu under **"Setup -> Advanced setup -> Outputs"**
5. Assign activated inputs to a group in the main menu under **"Setup -> Advanced setup -> Application -> Signal groups -> Group x"**
6. Press "Back" or "ESC" to exit the menu. The changes made are accepted and saved.

The device is in the measured value display mode and displays the measured values.

9.4.2 Step-by-step: set or delete the limit values

Procedure for setting limit values:

1. Open the limit values in the main menu under **"Setup -> Advanced setup -> Application -> Limits"**
2. Add a limit value: select **"Yes"**
3. Select and configure **"Limit value x"**
4. Press "Back" or "ESC" to exit the menu. The changes made are accepted and saved.

The device is in the measured value display mode and displays the measured values.

Procedure for deleting limit values:

1. Open the limit values in the main menu under **"Setup -> Advanced setup -> Application -> Limits"**
2. Delete a limit value: select **"Yes"**
3. Select the limit value to be deleted from the list
4. Press "Back" or "ESC" to exit the menu. The changes made are accepted and saved.

The device is in the measured value display mode and displays the measured values.

9.4.3 Step-by-step: read HART® values (option)

Procedure for reading measured values from a HART® device/sensor:

1. Make settings for HART® communication (HART® master, connection attempts) under **"Setup -> Advanced setup -> Communication -> HART"**
2. Add new value to be read by selecting **"Add value -> Yes"**
3. Open the configuration for **"Value x"**
4. Select the physical interface to which the HART® device is connected **"Connection -> Channel x"**
5. Set the address of the connected device, the HART® value to be read and the channel name
6. Activate the universal input in the main menu under **"Setup -> Advanced setup -> Inputs -> Universal inputs"**
7. Select the **"HART"** signal type and assign the previously defined HART® values. Make the selection using the channel name of the HART® value.
8. Other settings of the universal input are the same as for standard analog inputs.
9. Assign activated inputs to a group in the main menu under **"Setup -> Advanced setup -> Application -> Signal groups -> Group x"**
10. Press "Back" or "ESC" to exit the menu. The changes made are accepted and saved.

The device is in the measured value display mode and displays the measured values.

9.4.4 Step-by-step: HART® communication between an FDT Frame application (FieldCare) and a HART® device/sensor (option)

The RSG45 HART® CommDTM enables HART® communication between a PC with an FDT Frame application and a HART® device. At this point, the RSG45 acts as a gateway/modem between the PC and the HART® devices that are connected to the HART® input cards of the RSG45. Communication between the PC and the RSG45 is via the TCP/IP protocol only.

Procedure for establishing a connection:

1. Start RSG45 HART® CommDTM in the FDT Frame application
2. Set the communication parameters, IP address of Memograph M RSG45, port for the HART® communication and scan range (scan range 0 for a point-to-point connection)
3. Open the **"Create network"** menu to call up the **"Select communication channel"** dialog field to select the channel
4. Tick the check box beside the slot/channel to which one or more HART® devices are connected. Press **"OK"** to confirm and to start the scanning process.
5. All the HART® devices found are displayed in the FDT Frame application and can now be called up.



Detailed help is provided with the RSG45 HART® CommDTM.

9.4.5 Setup directly at the device

In the **"Setup"** menu and in the **"Advanced setup"** submenu, you will find the **most important** settings for the device:

Parameter		Possible settings	Description
Change date/time		UTC time zone dd.mm.yyyy hh:mm:ss	You can change the date and time here.
Advanced setup			Advanced settings for the device, such as system settings, inputs, outputs, communication, application, etc.
	System		Basic settings required for operating the device (e.g. date/time, security, memory management, notifications, etc.)
	Inputs		Settings for analog and digital inputs.
	Outputs		Setup only required if outputs (e.g. relays or analog outputs) are to be used.
	Communication		Setup required if the USB, RS232 / RS485 or Ethernet interface of the device is to be used (PC operation, serial data read-out, modem operation etc.).  The different interfaces (USB, RS232/RS485, Ethernet) can be operated in parallel. However, simultaneous use of the RS232 and RS485 interface is not possible.
	Application		Make the various application-specific settings (e.g. group settings, limit values, etc.).



A detailed overview of all the operating parameters is provided in the appendix at the end of the Operating Instructions. →  109

9.4.6 Setup via SD card or USB stick

An existing device configuration ("Setup data" *.DEH) from another Memograph M RSG45 or from FieldCare/DeviceCare can be uploaded directly to the device.

Importing new setup directly to the device: The function to load the setup data can be found in the main menu under **"Operation -> SD card (or USB stick) -> Load setup -> Select directory -> Next"**.

9.4.7 Setup via Web server

To configure the device via the Web server, connect the device via Ethernet to your PC.

Please observe the information and communication settings for Ethernet and the Web server under →  38



To configure the device via a Web server, you must have Administrator or Service access. ID and password administration is performed in the main menu under **"Setup -> Advanced setup -> Communication -> Ethernet -> Configuration Web server -> Authentication"**.

Default value for ID: admin; Password: admin

Note: The password should be changed during commissioning!

If security settings are according to "FDA 21 CFR Part 11", you must have Administrator rights to configure the device via a Web server.

Establishing a connection and setup

Procedure for setting up a connection:

1. Connect the device to the PC via Ethernet
2. Start the browser at the PC; open the Web server for the device by entering the IP address: `http://<ip-address>` Note: Leading zeros in IP addresses must not be entered (e.g. enter 192.168.1.11 instead of 192.168.001.011).
3. Enter ID and password, and confirm each by clicking "OK"
4. The Web server shows the momentary value display of the device. Click **"Menu -> Setup -> Advanced setup"** in the Web server function bar.
5. Starting configuration

Continue with device configuration in accordance with the Operating Instructions for the device. The complete Setup menu i.e. all of the parameters listed in the Operating Instructions, can also be found on the Web server. After configuration, accept the setup with **"Save settings"**.

 Procedure to establish a direct connection via Ethernet (point-to-point connection):
→  51

NOTICE

Undefined switching of outputs and relays

- During configuration using a Web server, the device may assume undefined statuses! This may result in the undefined switching of outputs and relays.

 An existing device configuration ("Setup data"*.DEH) from another Memograph M RSG45 or from FieldCare/DeviceCare can be uploaded directly to the device via the Web server.

Procedure for uploading a new setup via the Web server:

1. Make the connection to the device with the Web server →  44
2. Click **"Data management -> Import device settings"** in the Web server function bar
3. Select the setup file and press **"OK"** to confirm
4. The file is transferred, checked and accepted
5. Once the device settings have been accepted, information to this effect is displayed in the Web server.

9.4.8 Setup via FieldCare/DeviceCare configuration software (included in the delivery)

To configure the device using the configuration software, connect the device to your PC via USB or Ethernet.

Establishing a connection and setup

 For details, see the Operating Instructions on the configuration software DVD provided

Continue with device configuration in accordance with the Operating Instructions for the device. The complete Setup menu, i.e. all the parameters listed in the Operating Instructions, can also be found in the configuration software.

NOTICE

Undefined switching of outputs and relays

- During configuration using the configuration software, the device may assume undefined statuses! This may result in the undefined switching of outputs and relays.

9.5 Advanced settings (Expert menu)

 The Expert menu is protected by the code "0000". If an access code is set up under "Setup -> Advanced setup -> System -> Security -> Protected by -> Access code", this must be entered here.

If security settings are according to "FDA 21 CFR Part 11", you must be logged in as a user with Administrator rights to access the Expert menu.

You will find **all** settings for the device in the "**Expert**" menu:

Parameter	Possible settings	Description
Direct access	000000-000	Direct access to parameters (fast access)
System		Basic settings required for operating the device (e.g. date/time, security, memory management, notifications, etc.)
Inputs		Settings for analog and digital inputs.
Outputs		Setup only required if outputs (e.g. relays or analog outputs) are to be used.
Communication		Setup required if the USB, RS232 / RS485 or Ethernet interface of the device is to be used (PC operation, serial data read-out, modem operation etc.).  The different interfaces (USB, RS232/RS485, Ethernet) can be operated in parallel. However, simultaneous use of the RS232 and RS485 interface is not possible.
Application		Make the various application-specific settings (e.g. group settings, limit values, etc.).
Diagnosis		Device information and service functions for a swift device check.

 A detailed overview of all the operating parameters is provided in the appendix at the end of the Operating Instructions. →  109

9.6 Configuration management

 You can save the setup data ("Configuration") to an SD card or a USB stick, to a PC drive via the Web server, or store them in a database using the configuration software. This allows additional devices to be configured very easily using the same settings.

Saving the setup: The function to save the setup data can be found in the main menu under "Operation -> SD card (or USB stick) -> Save setup".

CAUTION

If the SD card or USB stick is removed directly,
there is a risk of losing data on the SD card or USB stick

- To remove the SD card or USB stick, always select "**Operation -> SD card (or USB stick) -> Safe removal**" in the main menu!

Procedure for saving a setup via the Web server:

1. Make the connection to the device with the Web server →  44
2. Click "**Data management -> Save device settings**" in the Web server function bar
3. Select the setup file
4. Transfer the file

5. Verify and accept
6. Once the device settings have been accepted, information to this effect is displayed in the Web server.

 The function for saving the setup data must be enabled at the device for the Web server under **"Setup -> Advanced setup -> Communication-> Ethernet -> Web server settings; Setup -> Yes"**.

9.7 Simulation

Various functions/signals can be simulated for test purposes here.

NOTICE

Selecting simulation: Simulation of the relays and the WebDAV client can be found in the main menu under "Diagnostics -> Simulation". The simulation of the measured values can be found in the main menu under "Expert -> Diagnostics -> Simulation". Only the simulated values are recorded during simulation. The simulation is recorded in the event logbook.

- Do not start simulation if measured value recording must not be interrupted!

9.8 Protecting settings from unauthorized access

After configuration, the setup should be protected against unauthorized access. The following options are available:

- Protection per control input
- Protection via release code
- Protection via user roles
- Protection via user administration according to "FDA 21 CFR Part 11"

In order to change any parameter, the correct code must first be entered or the device must be unlocked using the control input.

Setup lock via control input: The settings for the control input can be found in the main menu under **"Setup -> Advanced setup -> Inputs -> Digital inputs -> Digital input X -> Function: Control input; Action: Lock setup"**.

 It is preferable to lock the setup using a control input.

Setting up an access code: The settings for the access code can be found in the main menu under **"Setup -> Advanced setup -> System -> Security -> Protected by -> Access code"**. Factory setting: "open access", i.e. modifications can always be made.

 Make a note of the code and store in a safe place.

Setting up user roles: The settings for the user roles (operator, admin and service) are provided in the main menu under **"Setup -> Advanced setup -> System -> Security -> Protected by -> User roles"**. Factory setting: "open access", i.e. modifications can always be made.

 The passwords should be changed during commissioning.

Make a note of the code and store in a safe place.

Setting up user administration according to "FDA 21 CFR Part 11": The settings for user administration can be found in the main menu under **"Setup -> Advanced setup -> System -> Security -> Protected by -> FDA 21 CFR Part 11"**. Factory setting: "open access", i.e. modifications can always be made.

10 Fulfilling requirements in accordance with "FDA 21 CFR Part 11"

10.1 General notes

Before applying electronic signatures the

Office of Regional Operations (HFC-100)

5600 Fishers Lane

Rockville, MD 20857

USA

is to be informed, by means of an informal letter with handwritten signature, that the company intends to use electronic documents/signatures in future. Administrators and users must be instructed / trained in accordance with 21 CFR 11 or must already possess the relevant knowledge or qualifications. Commercial software used in electronic recording systems in accordance with 21 CFR 11 must be validated. The suitability of the device and the associated PC software (incl. operating system) for the application in question must be specified, validated, and documented (e.g. with regard to data confidentiality, printout of the device parameters, security backup of the set parameters, assignment of access authorizations in the PC software, suitability of the software used for commercial purposes – such as operating system, etc.).

The identity of the relevant person must be verified before assigning / determining the electronic signature (or elements of this electronic signature, e.g. unique ID / initialization password). The administrator must ensure and document the uniqueness of the ID and its correct assignment to the relevant person. Electronic signatures may only be used by authorized users. They must not be passed on to third parties. Administrators and users must undertake not to misuse their user IDs and passwords (including initialization passwords).

Written procedural instructions, which make individuals responsible for all actions carried out using their electronic signature, must be drawn up and observed so as to provide a deterrent mechanism for the falsification of documents and signatures.

Suitable checks of system documentation must be made (distribution, access, and use of documentation for system operation and maintenance). Revision and change control procedures must be implemented for the system documentation in which the chronological order of the development and change to system documentation is documented. The system is not intended for use in Internet applications/open systems.

NOTICE

The user is responsible for observing the following instructions for ensuring compliance with FDA 21 CFR Part 11:

- ▶ The scope of application for this FDA 21 CFR Part 11 evaluation refers to the Memograph M RSG45 and the associated Field Data Manager (FDM) PC software, which have been produced and tested by the manufacturer. The overall system must be subjected to a final evaluation by the end user.
- ▶ Recordings from the device and the associated PC software in accordance with "FDA Guidance for Industry: Computerized Systems Used in Clinical Investigations: 2007" cannot be used for clinical studies.
- ▶ In order to satisfy the requirements of FDA 21 CFR Part 11 with regard to the electronic signature, the device may only be read out with the associated Field Data Manager (FDM) PC software.
- ▶ The device and the associated PC software do **not** take into account the requirements of FDA 21 CFR Part 11, §11.30 for "Open systems". Operation within the context of an open system must be excluded.
- ▶ The operator must take suitable management precautions to prevent the loss of password access data/authentication data.
- ▶ The printer must be connected correctly and its long-term function guaranteed, even in the event of local changes (e.g. network printer).
- ▶ Due to the aging of components, the device must be calibrated at regular intervals.
- ▶ Regular maintenance must also be carried out.
- ▶ Measures must be taken to prevent the device from being moved (e.g. physical protection).
- ▶ No data will be recorded in the event of a power failure.
- ▶ The battery buffer for the backup clock is checked and, where necessary, a warning issued.
- ▶ Wireless transmission may not be used between the device and the PC software. In the case of wired transmission, operation is only permitted within the closed company network. This must be checked during the validation of the complete system.

NOTICE

The user is responsible for observing the following instructions for ensuring compliance with FDA 21 CFR Part 11:

Requirements for connected hardware components:

- ▶ Associated hardware components (e.g. a PC connected to the device) are part of the system but must be provided by the user. Backup measures designed to prevent hard disk defects or a memory overrun are the responsibility of the user.
- ▶ Wired peripherals, such as a USB keyboard for the device or a keyboard for the PC, can be scanned in using "Keylogger". It is the user's responsibility to prevent the use of so-called "sniffers".

10.2 Important device settings

NOTICE

In order to satisfy the requirements from 21 CFR 11, certain device functions are required. In particular, some user administration settings must be made:

- ▶ Activate user administration and password protection according to FDA 21 CFR Part 11: In the main menu go to **"Setup -> Advanced setup > System -> Security -> Protected by -> FDA 21 CFR Part 11"**
- ▶ Create a user: In the main menu go to **"User administration -> Create user account"** to create a new user.
- ▶ Make general user administration settings and define password rules: In the main menu go to **"User administration -> General"**. Recommendation: Password valid for 60 days in order to prevent it from becoming too familiar to the user.
- ▶ Assign the permitted rights to users in the main menu under **"User administration -> General -> User rights"**
- ▶ All changes to the device are automatically recorded in the event logbook. The event logbook can be opened from the main menu under **"Diagnostics -> Event logbook"**

NOTICE

The user is responsible for observing the following instructions for ensuring compliance with FDA 21 CFR Part 11:

Requirements for the device:

- ▶ The device must be regarded as a closed system.
- ▶ Administrator rights are required to change the configuration. The device must be locked via hardware protection (terminal cover) and a digital input assigned. Changes are documented in the event logbook / audit trail. The event logbook can be opened from the main menu under **"Diagnostics -> Event logbook"**.
- ▶ User administration with ID and password must be active.
- ▶ All changes must always be documented with the user's name in the event logbook. It is essential that user administration is active for this. All users must be created accordingly under User administration.
- ▶ All settings relating to password complexity and validity period are the responsibility of the administrator.
- ▶ During commissioning, the special requirements for the admin role must be taken into account (stricter password rules). User administration can only be disabled by the administrator. Under certain circumstances the administrator may lock users out of the system or sabotage user administration.
- ▶ The initial password set by the administrator must be changed on the first login (configurable).
- ▶ If the wrong password is entered repeatedly (max. number of attempts is adjustable), access is blocked and an alarm can be sent by e-mail.
- ▶ After setting up/using the device, the user must log out. Automatic logout after a configurable time must be activated.
- ▶ Communication interfaces can be blocked by the administrator. The interface for using the modem must be switched off.
- ▶ Hardware locking must be performed for the device update. This ensures that only the administrator can perform a firmware update.
- ▶ Any manipulation of the time synchronization is the responsibility of the user.
- ▶ In order to prevent a loss of data, the data must be read out regularly from the memory.
- ▶ Administrator rights are required in order to delete the internal memory. A hardware lock can also be used to prevent the memory from being deleted.
- ▶ The device produces a diagnosis list in which faults are documented. The diagnosis list must be checked regularly; this can be done in the main menu under **"Diagnostics -> Diagnosis list "**.
- ▶ Proof testing of the error log is recommended; this is done from the main menu under **"Diagnostics -> Device information -> Error log"**.

NOTICE

The user is responsible for observing the following instructions for ensuring compliance with FDA 21 CFR Part 11:

Requirements for the external memory:

- ▶ The external storage medium (SD card/USB stick) must only be removed using the function **"Operation -> SD card/USB stick -> Remove safely"**.
- ▶ In contrast to the protected data format, which features CRC16 protective measures, the stored data can be manipulated when using the open format (*.csv).
- ▶ In order to prevent unauthorized access (e.g. through theft), the external memory can also be disabled or removed.

10.3 Important settings in the Field Data Manager (FDM) PC software

NOTICE

In order to satisfy the requirements according to FDA 21 CFR Part 11, certain functions are required in the associated PC software. In particular, some user administration settings must be made.

- ▶ Use only operating systems with user administration (e.g. MS Windows® 2000/XP/Vista/7/8).
- ▶ Create an administrator: Create an administrator under **"Extras -> User administration"**.
- ▶ Activate user administration and password protection according to FDA 21 CFR Part 11: Under **"Extras -> Settings -> User administration"** select **"Activate user management"** and **"Password protection in compliance with FDA 21 CFR Part 11"**. The software applies the settings following a restart.
- ▶ Additional users can now be created under **"Extras -> User administration"** with the corresponding access roles.
- ▶ All changes made to the software are recorded in the "Audit trail". This can be opened via **"Extras -> Audit trail"**.
- ▶ Where appropriate, use the high-performance automatic functions of the PC software (e.g. automatic read out, automatic backup function, automatic e-mail alert).
- ▶ **Note:**Detailed instructions can be found on the DVD provided with the PC software.

NOTICE

The user is responsible for observing the following instructions for ensuring compliance with FDA 21 CFR Part 11:

- ▶ Modem operation cannot be implemented as a closed system.
- ▶ User administration must be active in order to record the user names in the audit trail.
- ▶ The password must be changed on the first login.
- ▶ If the administrator forgets the password, a master password, which is only valid for a limited period, may be used. Access is granted to the user on request and following authorization.
- ▶ If a user does not log out, an automatic lockout (screensaver) is activated via the Windows® system setting.
- ▶ It is possible to use the Field Data Manager PC software without identification or password protection, but this is not compliant with FDA 21 CFR Part 11.
- ▶ The ending of the automatic system service must be controlled via Windows® user rights.
- ▶ Since the PC date/time is used for the audit trail, it is theoretically possible to manipulate the time stamp. This must be prevented by the user by means of Windows® user rights.
- ▶ Regular backups and preventive maintenance (e.g. by means of software updates) must be carried out.
- ▶ It is important to ensure that no data can be intercepted or manipulated during communication between the device and the database.

11 Operation

The "Operation" menu is geared towards the tasks and activities of the operator. It contains all the parameters that are needed in ongoing operation. Historical values and analyses, for example, can be displayed in the "Operation" menu and display settings can be made. Any settings made for the onsite display have no effect on the measurement section or the configured device parameters.

The unit's simple control system and the integrated help function enables you to perform operation for many applications without the need for hardcopy operating instructions.

11.1 Displaying and modifying current Ethernet settings

To establish communication with the device via Ethernet, the following settings must be known or modified where necessary:

Display IP/MAC address (only if DHCP is enabled): The device's IP or MAC address can be found in the main menu under "**Diagnostics -> Device information -> Ethernet**".

Display/change Ethernet settings: The device's Ethernet settings can be found in the main menu under "**Setup -> Advanced setup -> Communication -> Ethernet**".

Procedure to establish a direct connection via Ethernet (point-to-point connection):

1. Configure the PC (depends on operating system): e.g. IP address: 192.168.1.1; subnet mask: 255.255.255.0; gateway: 192.168.1.1
2. Disable DHCP on the device
3. Make communication settings on the device: e.g. IP address: 192.168.1.2; subnet mask: 255.255.255.0; gateway: 192.168.1.1



A crossover cable is not required.


11.2 Reading the device locking status

If setup is locked via a control input, a padlock symbol  appears on the top right of the screen. The setup must first be unlocked via the control input before device parameters can be edited.

Setup lock via control input: The settings for the control input can be found in the main menu under "**Setup -> Advanced setup -> Inputs -> Digital inputs -> Digital input X -> Function: Control input; Action: Lock setup**".

If setup is locked via the access code, all the operating parameters can be displayed, and can also be edited as soon as the access code is entered.

11.3 Reading measured values



A0024709

12 Device front (left: Version with navigator and front interfaces; right: Version with stainless steel front and touchscreen)

- a Slot for SD card
- b USB B socket "Function" e.g. to connect to PC or laptop
- c USB A socket "Host" e.g. for USB memory stick, external keyboard, bar code reader or printer
- d Yellow LED for read/write access to the SD card
- 1 Navigator: press briefly to open the main menu and confirm messages (=Enter); press for longer to open the online help
- 2 Green LED (top) lit: Power supply present. Red LED (bottom) flashing: Maintenance required
- 3 Variable "Softkey" keys 1...4 (from left to right)
- 4 Function indicator of "Softkey" keys
- 5 Header: group name, analysis type
- 6 Header: current date / time
- 7 User ID (when function is active)
- 8 Header: alternating display indicating the percentage space on the SD card or USB stick that has already been used. Status symbols are also displayed in alternation with the memory information.
- 9 Area for measured value display (e.g. curve display). Display of current measured values and the status in the event of an error/alarm condition. In the case of counters, the type of counter is displayed as a symbol.
- 10 Status bar

i An overview of all the symbols and icons is provided in the operating options section.
→ 34

i If a measuring point has limit value status, the corresponding channel identifier is highlighted in red (quick detection of limit value violations). During a limit value violation and device operation, the acquisition of measured values continues uninterrupted.

i Information on how to rectify a problem in the event of an error is provided in the "Troubleshooting" section. → 66

11.4 Reading measured values via the web server

A web server is integrated into the device. If the device is connected via Ethernet, it is possible to display the measured values via the internet using a web server.

Activation of web server in the menu **Setup** → **Advanced setup** → **Communication** → **Ethernet** → **Web server** → **Yes** or the menu **Expert** → **Communication** → **Ethernet** → **Web server** → **Yes**

The web server port is preset to 80. The port can be changed in the **Expert** → **Communication** → **Ethernet** menu.

 If the network is protected by a firewall, the port may need to be activated.

The following web browsers are supported:

- MS Internet Explorer 11 and higher
- Mozilla Firefox 15 and higher
- Opera 12.x and higher
- Google Chrome 23.x and higher

 In order to use the full functionality of the web server, it is recommended that the latest version of the browser is used.

 To configure the device via a web server, you must have Administrator or Service access. Prior to accessing the web server, create an ID and password in the main menu under "**Setup** → **Advanced setup** → **Communication** → **Ethernet** → **Configuration Web server** → **Authentication**".

Default value for ID: admin; Password: admin

Note: The password should be changed during commissioning!

Data can be exported via the web server in HTML or XML format.

11.4.1 Access to the web server via HTTP (HTML)

When using an Internet browser, you just need to enter the address **http://<ip-address>** to have the HTML view displayed in the browser.

 Note: Leading zeros in IP addresses must not be entered (e.g. enter 192.168.1.11 instead of 192.168.001.011).

As on the display, you can alternate between the display groups in the web server. The measured values are automatically updated. In addition to the measured values, status and limit value flags are displayed.

11.4.2 Access to the web server via XML

XML format is available in addition to HTML format and contains all measured values of a group. This can be integrated into additional systems as the user wishes.

The XML file is available in ISO-8859-1 (Latin-1) coding at **http://<ip-address>/values.xml** (alternative: **http://<ip-address>/xml**). However, some special characters, such as the Euro symbol, cannot be displayed in this file. Texts such as digital statuses are not transmitted.

 Note: Leading zeros in IP addresses must not be entered (e.g. enter 192.168.1.11 instead of 192.168.001.011).

 The decimal separator is always displayed as a point in the XML file. Also, all times are given in UTC. The time difference in minutes is noted in the following entry.

The structure of the channel values for the XML file is explained as follows:

```
<device      id="AI01IV" tag="Channel 1" type="INTRN">
    <v1>50.0</v1>
    <u1>%</u1>
    <vtime>20130506-140903</vtime>
    <vstslvl1>0</vstslvl1>
    <hlsts1>L</hlsts1>
    <param><min>0.0</min><max>100.0</max><hh></hh><hi></hi><lo></lo><ll></ll></
    param>
    <tag>Channel 1</tag>
    <man>Manufacturer</man>
</device>
```

Day	Description
device id	Unique ID of measuring point
tag	Channel ident.
type	Data type (INTRN, MODBUS)
v1	Measured value of channel as a decimal value
u1	Unit of measured value
vtime	Date and time
vstslvl1	Error level 0 = OK, 1 = warning, 2 = error
hlsts1	Limit value status H = upper limit value, L = lower limit value, LH = upper and lower limit value violation
param min max hh hi lo ll	Parameter (optional) Lower zoom Upper zoom Upper alarm limit Upper warning limit Lower warning limit Lower alarm limit
MAN	Manufacturer

11.4.3 Remote control via the web server

Remote control of the device is possible via web server. In the web server, remote control can be found under **"Measured values -> Remote control"**. Here the display shown corresponds directly to the device display. The device is operated using buttons below this display. The interval for refreshing the display can be set in the **"Refresh"** menu.

Enabling remote control on the device:

1. In the menu **Setup -> Advanced setup -> Communication -> Ethernet -> Configuration Web server -> Remote control**, select **"Yes"** or under
2. **Expert -> Communication -> Ethernet -> Configuration Web server -> Remote control**, select **"Yes"**.

11.5 Data analysis and visualization with the Field Data Manager software (FDM) provided

The analysis software offers centralized data management with visualization for recorded data.

This enables all measuring point data to be completely archived, e.g.:

- Measured values
- Diagnostic events
- Protocols

The analysis software stores data in an SQL database. The database can be operated locally or in a network (client / server). You can install and use the free PostgreTMSQL database provided on the DVD.



For details, see the Operating Instructions on the analysis software DVD provided.

11.5.1 Structure/layout of a CSV file

The CSV files are comprised as follows:

File name (=serial number + file number + configuration number + date and start time + data type)	Description	Coding
H4000504428 0000000279 0000000185 2013-11-07 11-18-00 GROUP01.csv	Contains all the measured values of the group from the starting time indicated in the file name. An individual CSV file is created for each group.	ANSI
H4000504428 0000000279 0000000185 2013-11-07 11-30-00 ANALYSIS01.csv	Contains the signal analyses of the active channels from the starting time indicated in the file name. An individual CSV file is created for every analysis (01 - 04).	ANSI
H4000504428 0000000279 2013-11-07 11-18-34 EVENTS.csv	Contains the event log from the starting time indicated in the file name.	Unicode UTF-8 (see the notes in the following section)

Meaning of the values under "Status" and "Limit" when analyzing a group:

Status of the channel:

- 0: OK
- 1: Open circuit
- 2: Input signal too high
- 3: Input signal too low
- 4: Invalid measured value
- 6: Error value, i.e. not the calculated value (for mathematics if an input variable is invalid)
- 7: Sensor/input error
- Bit 8: Not assigned
- Bit 9: Alarm storage
- Bit 10..13: Not assigned
- Bit 14: Use error value
- Bit 15: Not assigned

General status:

- 1: Highspeed storage is active
- 2: Additional hour for summer/normal time changeover

Note: A combination of 1 and 2 is also possible.

Status of the limit value ("Limit"):

0: OK, no limit value has been violated

Bit 0: Lower limit value

Bit 1: Upper limit value

Bit 2: Increasing gradient

Bit 4: Decreasing gradient

Note: A combination is also possible.

11.5.2 Importing UTF-8-encoded CSV files into spreadsheets

You might encounter problems displaying information if importing UTF-8-encoded CSV files directly into more recent versions of MS Excel™ (2007 and higher).

Importing CSV data from the event logbook ("Events") into MS Excel™ (version 2007 and higher):

1. Select the menu **"Data -> Get external data - From text"**
2. Select the CSV file
3. Follow the instructions in the wizard
4. Select file origin **"Unicode UTF-8"**

11.6 Change group

The group to be displayed can be changed in the main menu under **"Operation -> Change group"**. Alternatively, the group can also be changed by turning the navigator.

Version with stainless steel front and touchscreen:

The active groups can be changed with a horizontal "swiping" movement.

 Only the **active** groups are displayed here. The settings for this can be made in the main menu under **"Setup -> Advanced setup -> Application -> Signal groups -> Group x"**.

11.7 Block keyboard/navigator

Local operation can be blocked in the main menu under **"Operation -> Lock operation"** to prevent unintended or incorrect operation (e.g. when cleaning the device).

 The device is unlocked by pressing the navigator or the OK operating key for 3 s. When using an external keyboard, the device is unlocked with the key combination "Ctrl-Alt-Del".

11.8 Log on / log out

Log onto the device, or log out the user currently logged on.

 Only when user administration is active (FDA 21 CFR Part 11) or in the case of role-based access protection.

11.9 Change password

Change your user password.

 Only when user administration is active (FDA 21 CFR Part 11).

11.10 SD card / USB stick

11.10.1 Function of SD card or USB stick

Without affecting the internal memory, data packets are copied block by block (min. 1 x daily, midnight) to the SD card. Tests are also made to determine whether the data have been written without any errors. Once a new SD card is inserted, the device starts saving the data automatically after 5 minutes. The use of a USB stick is only recommended if certain data ranges should be copied. The USB stick is **not** used for storing the measured values continuously, i.e. this is **not** automatically updated.

Data is saved in two different folders on the storage media depending on the storage method:

- All data is copied cyclically to the **rec_data_<Device name>** folder if a data packet is complete or the function **"Update"** is activated under **"Operation -> SD card/USB stick -> Update"**.
- The data for the time range selected under **"Operation -> SD card/USB stick -> Save measured value"** is copied to the **rng_data_<Device name>** folder. The copying of this data has no effect on the saving of data in the **rec_data_<Device name>** folder.

-  Only use new, formatted SD cards recommended by the manufacturer (see "Accessories" → 79).
- During normal operation, the used memory space on the SD card or USB stick is displayed on the top right of the display ("SD: xx%" or "USB: xx%"). Dashes "-" on this display mean that no SD card is inserted.
- The SD card must not be write-protected.
- Prior to removing the external data carrier, select **"Operation -> SD card / USB stick -> Update"**. The current data block is closed and saved to the external data carrier. This ensures that all current data (until the last save) is included on it.
- Depending on the configuration of the unit (see **"Setup -> Advanced Setup -> System -> Ext. memory -> Warning at"**), an acknowledgeable message on the display informs you that the external data carrier has to be changed before the data carrier is 100 % full.
- The device keeps track of which data have already been copied onto the SD card or USB stick. Should you ever forget to change the data carrier in time (or if no SD card has been inserted), the new external data carrier is filled with the missing data from the internal memory - as long as the data are still available there. As measured value acquisition / recording is assigned the highest priority, it may take several minutes in this case for the data to be copied from the internal memory to the SD card or USB stick.

11.10.2 Functions relating to the SD card or USB stick

You can find functions to save measured data and device settings on a removable medium in the main menu under **"Operation -> SD card / USB stick"** (only if an SD card or USB stick is provided).

Remove safely:

All internal access is terminated to ensure safe removal of the storage medium from the device. You are notified when it is safe to remove the data storage medium. If the SD card is not removed, the device automatically starts to save data to the storage medium again after 5 minutes.

-  Only remove the data storage medium using this function; otherwise data may be lost!

Update:

Measurement data not yet saved on the storage medium are now saved. Please be patient! Measured value acquisition is running in parallel and has top priority.

-  Data from several devices can be saved onto one storage medium.

■ **Save measured values:**

A user-definable time range can be saved on the data storage medium.

■ **Load setup:**

Loads device settings (setup) from the storage medium onto the device.

■ **Save setup:**

All device settings (setup) are saved onto the storage medium. They can be archived or used for other devices.

■ **Save setup as RTF:**

Saves the setup on the storage medium in a readable format as an RTF file (rich text format).

The RTF file can be opened and formatted using suitable word processing software (e.g. MS Word), allowing printouts to be easily made.

■ **Screenshot:**

Save the current measured value display as a bitmap on the SD card or USB stick.

■ **Update firmware:**

Loads new firmware onto the device. Only visible if a firmware file is provided on the SD card or USB stick.



Caution: The device will restart. Save the setup and measured values beforehand on the SD card or USB stick.

■ **Process-related graphic:**

Load, export or delete process screen.

Load: Loads a process screen from the external storage medium to the device memory.

Export: Saves the current process screen in the device to the external storage medium so that it can be transferred to another device.

Delete: Deletes the selected process screen from the device memory.

Procedure for creating and editing process pictures: → 58

■ **Load user administration:**

Loads all settings and user accounts from the storage medium to the device. The file has the extension ".ids2".



Attention: All existing settings/accounts will be overwritten.

■ **Save user administration:**

Saves all settings and user accounts to the storage medium. The file has the extension ".ids2".

■ **User administration as RTF:**

Saves the user administration on the storage medium in a readable format as an RTF file (rich text format).

■ **Import SSL certificate:**

Uploads an SSL certificate (X.509) to the device. Certificates are needed so that an SSL connection can be established in order to send encrypted e-mails, for instance. The following are supported: DER, CER and CRT (binary or Base64-encoded).

Visible only if there is an SSL certificate on the SD card or USB stick.

Creating a process-related graphic with the process picture generator



The DVD provided with the Field Data Manager (FDM) software includes a process picture generator.

Alternatively, it can be downloaded from:

www.readwin2000.com/tools_files/ProcessPictureGenerator.zip

This program is used to generate a process screen quickly and easily.

Start the process picture generator and create the first project:

1. Copy the entire "ProcessPictureGenerator" directory from the DVD to a local directory on the PC
2. Alternatively, unzip the downloaded ZIP file in a local directory on the PC.
3. Double-click on the "FieldDiagrammer.exe" application it contains

4. The process picture generator is started and a new project is created
5. Select all fields required for the project such as project name, device type, etc. as well as the background picture
6. Edit the process screen accordingly
7. Use the function **"File -> Save"** to save the current project
8. Use the function **"File -> Export"** to save the process screen ("PP_GROUP_<xx>.bmp") with the required INI file ("PP_GROUP_<xx>.ini") to a USB stick or an SD card. Note: The "xx" in the file name stands for the respective group (01...10).
9. Remove the USB stick or SD card from the PC.

Further help can be called directly from the help menu of the process picture generator.

Load the process screen into the device:

1. Insert the USB stick or SD card with the generated process-related graphic into the device.
2. In the main menu go to **"Operation -> SD card/USB stick -> Process-related graphic -> Group"** and select the group to which the process screen should be assigned
3. In the main menu go to **"Operation -> SD card/USB stick -> Process-related graphic -> Load"**, select the desired process screen, and load it into the device
4. In the main menu go to **"Operation -> Change display mode"** and change the display mode to **"Process-related graphic"**.

Editing process screens on the device

Process screens can be edited on the device.

The following functions are possible:

- Add or remove channels to/from the process screen
- Change the position, font size, and alignment
- Delete the process screen

Call up the Context menu: In the measured value display, press the Navigator or "Menu" for longer than 3s.

In the context menu that is now open the "Process-related graphic" submenu can be selected:

Parameter	Parameter/description
"Edit" submenu	Here you can edit the currently displayed process screen (position, font size, etc.).
"Channel 1...8" submenu	Here you can edit the selected channel of the process screen (activate, change position/ font size, etc.).
	Display in the process screen Switch the channel in the process screen on or off. Note: Does not affect the saving of measured values/configuration. Options: No, Yes; Factory setting: No
	Channel ident. Specify whether the channel designation should be displayed in addition to the measured value. The channel designation is displayed above the measured value. Options: No, Yes; Factory setting: No
	Alignment Specify how the measured value should be aligned.  If "Align left" is selected, the x position is the top, left corner of the measured value. If "Align right" is selected, the x position is the top, right corner of the measured value. Options: Left-aligned, right-aligned Factory setting: Right-aligned

Parameter	Parameter/description
	x-position Select the x-position at which the measured value should be displayed. Input: 0...799 pixels; factory setting: 10  The point of origin (x-/y-zero point) is the top left. When the x-value is increased the text moves to the right.
	y-position Select the y-position at which the measured value should be displayed.  The point of origin (x-/y-zero point) is the top left. When the y-value is increased the text moves down. Input: 0...450 pixels; factory setting: 50 (channel 1) ... 260 (channel 8)
	Font size Select the font size in which the measured value should be displayed. Options: Small, Medium, Large, Very large; factory setting: Large
Accept changes	Saves the changes to the process screen in the device memory.
Delete	Deletes the selected process screen from the device memory. The device then changes to the curve display.

11.10.3 Notes on e-mail encryption

In addition to sending unencrypted e-mails, it is also possible to send encrypted e-mails via SSL (TLS). To do so, you can choose either of two ways:

- By **SMTPS**: fully encrypted via port 465.

The complete connection runs over TLS. The port is 465 by default but this value can be changed in the Setup.

- Via port 25 or 587 using **STARTTLS**.

With this method the device first establishes a plain SMTP connection via port 25 and continues this connection following agreement and switchover to encryption.

The required process can be selected as follows: **"Setup -> Advanced setup -> Application -> E-mail -> Server requires SSL"** or under **"Expert -> Application -> E-mail -> Server requires SSL"**.

Only TLS V1.0 (= SSL 3.1) or TLS V1.1 is supported. Older standards are not supported. The cryptographic technique is automatically agreed with the counterparty.

A certificate must be installed in order to be able to send encrypted e-mails. These certificates can be obtained from your e-mail service provider. The following file formats are supported:

- *.CER: DER- or Base64-encoded certificate
- *.CRT: DER- or Base64-encoded certificate
- *.DER: DER-encoded certificate

 The file name of the certificate may only contain the following characters: a..z, A..Z, 0..9, +, -, _, #, (,), !

To establish an SSL connection, the device automatically selects the certificate that best suits the counterparty from all the installed certificates. An error message is displayed if the device does not have any of the required certificates.

 When e-mail encryption is enabled, no e-mails can be sent if a valid certificate is not available or if the certificate has expired.

11.10.4 Notes on WebDAV encryption

In addition to sending unencrypted data to the WebDAV server, it is also possible to send encrypted data via SSL (TLS). All data is sent in encrypted format via the SSL port of the external WebDAV server.

The complete connection runs over TLS. The port is 80 by default but this value can be changed in the Setup. The procedure to be used can be selected as follows: **"Setup ->**

Advanced setup -> Application -> WebDAV Client -> Enable -> Yes (SSL)" or under "Expert -> Application -> WebDAV Client -> Enable -> Yes (SSL)".

Only TLS V1.0 (= SSL 3.1) or TLS V1.1 is supported. Older standards are not supported. The cryptographic technique is automatically agreed with the counterparty.

A certificate must be installed in order to be able to send encrypted data. These certificates can be obtained from your WebDAV server service provider. The following file formats are supported:

- *.CER: DER- or Base64-encoded certificate
- *.CRT: DER- or Base64-encoded certificate
- *.DER: DER-encoded certificate

 The file name of the certificate may only contain the following characters: a..z, A..Z, 0..9, +, -, _, #, (,), !

To establish an SSL connection, the device automatically selects the certificate that best suits the counterparty from all the installed certificates. An error message is displayed if the device does not have any of the required certificates.

 When WebDAV Client encryption is enabled, no data can be sent if a valid certificate is not available or if the certificate has expired.

11.10.5 SSL certificates

Importing an SSL certificate

Installing a certificate via SD card or USB stick:

1. Copy a certificate on a PC to an SD card or USB stick
2. Insert the SD card or USB stick into the device.
3. In the main menu, select **"Operation -> SD card (or USB stick) -> Import SSL certificate"**.
4. Select the required certificate from the list and follow the dialog on the display.

 Up to 3 certificates can be installed simultaneously.

Verifying the installed SSL certificates

The installed certificates can be verified in the main menu under **"Diagnostics -> Device information -> SSL certificates"**. The most important certificate information, e.g. subject key ID, organisation and validity period, are displayed in the parameter list.

 Not all fields are completed on all the certificates. This is because the parties issuing the certificates do not make all the information available.

Deleting an SSL certificate

In the main menu select the certificate to be deleted under **"Diagnostics -> Device information -> SSL certificate -> Certificate"** and select **"Yes"** under **"Delete certificate"**.

Period of validity of certificates

Certificates are valid for a defined period (valid from ... to ...). The device checks the certificate validity once a day or each time the device is rebooted. 14 days before the certificate expires the device notifies the user daily (by e-mail, screen display, entry in event log) that the certificate will expire shortly.

If the certificate has expired the alarm relay switches (if activated) and a message is displayed on the screen. An entry is also made in the event log. If a certificate is deleted all errors related to this certificate are reset.

11.11 Showing measured values history

You can scroll through the saved measured values in the main menu under **"Operation -> History"**. Turn the navigator clockwise or counterclockwise to scroll back and forth between the measured value curves. Press the navigator to make other settings for the historical data display (e.g. scroll speed, time scaling or change display mode) or to quit the historical data function.

Version with stainless steel front and touchscreen:

The measured value curves can be scrolled back and forth with a horizontal "swiping" movement.

 The gray header in the display and the  symbol in the status bar indicate that historical values are being displayed. In the instantaneous value display the color of the header is blue.

11.11.1 Historical data: changing a group

It is possible to change the group to be displayed in the historical data under **"Operation -> Change group"** in the data history.

11.11.2 Historical data: Scroll speed

It is possible to change the scroll speed in the historical data under **"Operation -> Scroll speed"** in the data history.

The scroll speed can also be set via the soft key with the arrow symbol < or >. The speed can be changed from < (slow) to <<<< (fast) by pressing the softkey repeatedly.

11.11.3 Historical data: Time scaling

It is possible to scale the displayed time range in the historical data under **"Operation -> Time scaling"** in the data history.

-  Notes:
- "1:1" option: Every measured value is displayed.
 - "1:n" option: Only every nth measured value is displayed (increases the displayed time range).
 - No interpolation is performed, nor is the mean value determined.
 - If the value for "n" is large, this can result in extended loading times.
 - Time scaling does not affect the process for storing the measured value.
 - The time range displayed per screen for the currently set time scaling is also displayed in the menu.

11.11.4 Historical data: Time range displayed

The displayed time range is shown in the historical data under **"Operation -> Time range displayed"** in the data history. This tells the user which time range is displayed per screen in the standard memory cycle.

 If the alarm cycle differs from the standard memory cycle, this is not taken into consideration.

11.11.5 Historical data: Screenshot

The current measured value display can be saved as a bitmap to an SD card or USB stick in the historical data under **"Operation -> Screenshot"**.

11.11.6 Historical data: Change the display mode

It is possible to change the display mode of the active group in the historical data under **"Operation -> Change display mode"** in the data history.

The following display modes are possible: Curve, Curve in ranges, Waterfall, Waterfall in ranges, and Circular chart.



The various display modes have no influence on the signal recording.

11.11.7 Historical data: Store text

You can store a text predefined in the list or a text of your own. This text is assigned to a definable point in time.

A predefined text can be selected or a user-defined text can be saved in the historical data under **"Operation -> Store text"**.

11.12 Signal analysis

The analyses saved in the device are displayed in the main menu under **"Operation -> Signal analysis"**.

- **Actual intermediate analysis:**

Here, you can have the current (i.e. not yet completed) intermediate analysis displayed.

- **External analysis 1...4:**

Here, you can have current (i.e. not yet completed) external analyses displayed.

- **Actual day:**

Here, you can have the current (i.e. not yet completed) daily analysis displayed.

- **Actual week:**

Here, you can have the current (i.e. not yet completed) weekly analysis displayed.

- **Actual month:**

Here, you can have the current (i.e. not yet completed) monthly analysis displayed.

- **Actual year:**

Here, you can have the current (i.e. not yet completed) annual analysis displayed.

- **Search:**

Search and display of analyses. Select which analyses should be searched for/displayed: Intermediate analysis, Daily analysis, Monthly analysis, Annual analysis.

11.13 Search in trace

In the main menu, the internal memory can be searched for events or times under **"Operation -> Search in trace"**.

Search for events: The event logbook forms the basis for searches for events. To search more easily for certain events (e.g. setup changes), the search filter can be used to select and search for the desired events. In the standard all events are shown. In the event list displayed, it is possible to select an event and go directly to this point in the history (if still in the memory).

Search for time: When searching for a time in the past, the user can enter a date and a time to specify when the system should start displaying historical data. Once the date/time have been entered and confirmed, the display goes to the selected time in the active group.

11.14 Changing the display mode

The display mode of the active group can be changed in the main menu under **"Operation -> Change display mode"**.

The following display modes are possible: Curve, Curve in ranges, Waterfall, Waterfall in ranges, Bargraph, Digital display, Instrument display, Circular chart, and Process screen.

 The various display modes have no influence on the signal recording.

11.15 Store text

You can store a text predefined in the list or a text of your own. This text is assigned to a definable point in time.

A predefined text can be selected, or a user-defined text can be saved, in the main menu under **"Operation -> Store text"**.

11.16 Printout

The device settings, user administration data, event log, current measured values or a screenshot of the measured value display can be printed out in the main menu under **"Operation -> Printout"**.

NOTICE

Due to technical restrictions, the printout from the device is always in English when using the following operating languages: Polish, Russian, Swedish, Czech, Japanese, and Chinese.

Printout via PC:

- ▶ The device settings or user administration can be saved in the set language in the form of an RTF file and printed out from the PC.

NOTICE

Due to technical restrictions, the event log cannot be printed out from the device when using the following operating languages: Polish, Russian, Swedish, Czech, Japanese, and Chinese.

Printout via PC:

- ▶ The event log can be printed out via the Field Data Manager (FDM) software.
Alternatively the event log can be saved as a CSV file and printed out from the PC.

11.17 Adjusting the brightness of the display

You can adjust the brightness of the display in the main menu under **"Operation -> Adjust brightness"**:

Parameter	Possible settings	Description
Adjust brightness	0-100 Default: 80	Sets the brightness of the display

11.18 Limit values

It is possible to change the limit values during operation in the main menu under **"Operation -> Limits"**.

 This function must be enabled beforehand in the main menu under **"Expert -> Application -> Limits-> Change set points: Outside of setup also"**.

Detailed description of the limit values: →  222

11.19 WebDAV Client

The function of the WebDAV client is to transmit recorded data automatically to a connected WebDAV server (e.g. NAS drive). The generated files correspond as far as possible to the files that are automatically saved to the SD card.

The client is configured via **"Setup -> Advanced setup -> Application -> WebDAV Client"**. The settings under **"Setup -> Advanced setup -> System -> External memory"** are also used for this, with the exception of the SD card settings (memory build-up, warning, and relay). The memory is regarded as a stack memory.

Detailed description of the parameters: →  246

 Note: With the WebDAV client, the data are transmitted to the WebDAV server in accordance with the selection made in the .CSV or "protected format".

11.19.1 Access to the WebDAV server via HTTP (HTML)

Address entry in browser: **http://<ipadresse>/webdav**

 Note: Leading zeros in IP addresses must not be entered (e.g. enter 192.168.1.11 instead of 192.168.001.011).

 Administrator or service authentication is required. ID and password administration is performed in the main menu under **"Setup -> Advanced setup -> Communication -> Ethernet -> Configuration Web server -> Authentication"**.

Default value for ID: admin; Password: admin

Note: The password should be changed during commissioning!

If security is activated in accordance with "FDA 21 CFR Part 11", authentication as a user with administrator rights is required in order to establish a connection.

Note: For devices with a stainless steel front and touchscreen, the data are always made available in "protected format" via the WebDAV server.

12 Diagnostics and troubleshooting

To help you troubleshoot, the following section is designed to provide an overview of possible causes of errors and initial remedial measures.

12.1 General troubleshooting

WARNING

Danger! Electric voltage!

- Do not operate the device in an open condition for error diagnosis!

Display	Cause	Solution
No measured value display; no LED lit	No supply voltage connected	Check the supply voltage of the device.
	Supply voltage is applied; device or power unit is defective	The power unit or the device must be replaced.
Diagnostic message is displayed	The list of diagnostic messages is provided in the following section.	

 **Dead pixels:** Dead pixels refer to pixels on LCD and TFT displays that are defect due to the technology or manufacturing techniques used. The TFT display used can have up to 10 dead pixels (Class III as per ISO 13406-2). These dead pixels do not entitle the user to a warranty claim.

12.2 Troubleshooting

The Diagnostics menu is used for the analysis of the device functions and offers comprehensive assistance during troubleshooting. Always proceed as follows to locate the cause of the device errors or alarms.

General troubleshooting procedure

1. Open diagnosis list: lists the 30 most recent diagnostic messages. This can be used to determine which errors are currently present and whether an error has repeatedly occurred.
2. Diagnosis of current measured values: Verify the input signals by displaying the current measured values or the scaled measuring ranges. To verify calculations, call up calculated auxiliary variables if necessary.
3. Most errors can be rectified by performing steps 1 and 2. If the error persists follow the troubleshooting instructions in the following sections.
4. If this does not rectify the problem, contact the Service Department. Any time you contact the Service Department please always have the error number and the information in the main menu under **"Diagnostics -> Device information"** (program name, serial number etc.) ready.

The contact details of your Endress+Hauser representative can be found on the internet at www.endress.com/worldwide.

12.2.1 Device error/alarm relay

One relay can be used as an alarm relay. If the device detects a system error (e.g. hardware defect) or a malfunction (e.g. cable open circuit), the selected output/relay switches. The alarm relay is assigned in the main menu under **"Setup -> Advanced setup -> System -> Fault switching -> Relay x"**. **Factory setting: Relay 1.**

This "alarm relay" switches if "F"-type or "S"-type errors occur, i.e. "M"-type or "C"-type errors do not switch the alarm relay.

12.3 Diagnostic information on the local display

The diagnostic message consists of a diagnostic code and a message text.

The diagnostic code consists of the error category as per Namur NE 107 and the message number.

Error category (letter in front of the message number)

■ **F = Failure.** A malfunction has been detected.

The measured value of the affected channel is no longer reliable. The cause of the malfunction is to be found in the measuring point. Any control system connected should be set to manual mode. An alarm relay can be assigned to this error category in the Advanced setup.

■ **M = Maintenance required.** Action must be taken as soon as possible.

The device still measures correctly. Immediate measures are not necessary. However, proper maintenance efforts would prevent a possible malfunction in the future.

■ **S = Out of specification.** The measuring point is being operated outside specifications. Operation is still possible. However, you run the risk of increased wear, shorter operating life or lower measurement accuracy. The cause of the problem is to be found outside the measuring point.

■ **C = Function check.** The device is in Service mode.

Diagnostic code	Message text	Description	Remedy
F100	Sensor/input error	Sensor/input error	Check connections and parameters
F101	Open circuit	Open circuit	Check connections
F105	Invalid value!	Measured value is invalid (when calculating --> NAN)	Check connections and process variables
F201	Device fault	Device error	Contact the Service Department
F261	Error: RAM	No access to RAM	Contact the Service Department
F261	Error: Flash	No access to flash	Contact the Service Department
F261	Error: SRAM	No access to SRAM	Contact the Service Department
F261	Analog card x out of order!	Hardware defect detected	Contact the Service Department, replace card
F261	HART card out of order!	Hardware defect detected	Contact the Service Department, replace card
F261	Power supply out of order!	Hardware defect detected	Contact the Service Department, replace power unit
F261	Digital card out of order!	Hardware defect detected	Contact the Service Department, replace card
F261	Fieldbus card out of order!	Hardware defect detected	Check contacts of Anybus card, contact the Service Department
M284	Firmware update	Firmware has been updated.	No action required. Message can be acknowledged.
F301	Error: Cannot load setup	Setup defective	Switch the device off/on, reconfigure, contact the Service Department where necessary
M302	Setup restored from backup	Setup has been loaded from backup.	Check setup
F303	Error: Device data	Device data defective	Contact the Service Department
M304	Backup: Device data	Device data defective. However it was possible to continue working with the backup data.	Check settings (e.g. serial number)
F307	Error: Customer preset value defective	Customer preset value defective	
F309	Error: Date/time is not set	Invalid date/time (e.g. internal battery is empty)	Device was switched off too long. The date/time must be set again. Battery might need to be replaced (contact the Service Department).
F310	Error: Cannot save setup	The setup could not be saved.	Contact the Service Department
F311	Error: Device data	The device data could not be saved.	Contact the Service Department
F312	Error: Calibration data defective	The calibration data could not be saved.	Contact the Service Department

Diagnostic code	Message text	Description	Remedy
F312	Analog card x is not calibrated!	Analog card x is not calibrated! The device works with default values, i.e. the measured values could possibly be inaccurate under certain circumstances.	Contact the Service Department
M313	SRAM has been defragmented	SRAM was defragmented after firmware update	No action required. Message can be acknowledged.
F314	Error: Option code	Activation code is no longer correct (incorrect serial number/program name). Option has been switched off and setup preset has been performed.	Enter new code
M315	No IP address could be obtained from the DHCP server!	No IP address could be obtained from the DHCP server!	Check the network cable
M316	Invalid MAC address!	No or incorrect MAC address	Contact the Service Department
M317	Battery voltage < 2 V. Please replace battery!		Battery needs to be replaced (contact the Service Department)
F348	Firmware cannot be updated: ■ Checksum incorrect ■ Firmware incompatible!	Firmware update has been aborted because the firmware file is damaged or is not compatible with this device	Contact the Service Department
M350	Measured value acquisition interrupted for calibration/ service work. Measured value acquisition restarted.	Measured value acquisition was interrupted/ reactivated for service/maintenance purposes. Causes include: ■ Calibration of inputs/outputs ■ Firmware update	No action required. Message can be acknowledged.
M351	The device will restart.	The device is rebooting. Causes include: ■ Following a firmware update ■ Change of device options	No action required. Message can be acknowledged.
F431	Error:Calibration	Calibration data missing	Contact the Service Department
M502	Device is locked!	Device is locked! The message appears when an attempt is made to update the firmware, for example.	Check lock per digital channel
F510	Setup was corrected.	The device detected that the configuration was no longer correct. All the parameters affected have been reset to the factory default settings. Possible causes: ■ Input cards have been removed or replaced by another type ■ An input card is no longer working correctly A firmware update has caused compatibility problems. Note: This error message appears each time the device is restarted until at least one change has been made to the configuration.	Please check the configuration of the device. If hardware has been replaced, no other action is needed (recommendation: change the operating language so that the error message no longer appears after the next restart).
F510	User administration was corrected	The device detected that the user administration settings were no longer correct. All the parameters affected have been reset to the factory default settings.	
M520	SMTP: Name could not be resolved (DNS)! SNTP: Name could not be resolved (DNS)!	Problem with name resolution (DNS). SMTP: e-mail SNTP: time synchronization	Check the corresponding settings

Diagnostic code	Message text	Description	Remedy
F526	- Support points not OK - Support points: x-value exists more than once - Upper and lower support points are identical	The support points for the specified linearization table are not plausible.	Check support points
M528	Setup is not compatible with this firmware!	An attempt was made to load a setup which is not compatible with this firmware (e.g. another device type)	Check whether the correct file has been selected.
M530	Cannot copy setup.	An error occurred when a setup was loaded from an SD card or USB stick An error occurred when a setup was saved to an SD card or USB stick	Replace the SD card or USB stick Setup file defective?
S901	Input signal too low	Input signal too low	Check Connections and parameters. Check connected sensor/transmitter.
S902	Input signal too high	Input signal too high	Check Connections and parameters. Check connected sensor/transmitter.
M905	Set point x	Set point x has been violated	Note: Error number only occurs if e-mails are sent
M906	End limit value x	Set point x no longer violated	Note: Error number only occurs if e-mails are sent
F907	Error DP flow	Error during DP flow calculation	
F910	This software is not enabled for this device.	The current firmware is not enabled for this hardware	Contact the Service Department
M913	DP flow: Outside of ISO 5167	Error during DP flow calculation	
M914	DP flow: Density calculation	Error during DP flow calculation	
M920	Too many messages that need to be acknowledged!	There are too many messages that need to be acknowledged. Another message could not be added.	Acknowledge messages
M921	SD card x% full.	External memory is full	Replace SD card
M922	No cyclic measurement transfer	The instantaneous values were not read out for a set time	
M922	No cyclic transfer	The device was not read out via fieldbus for a configurable time	Check the communication of the fieldbus. Check PLC.
M923	Error in printing	Various problems while printing, e.g.: - Printer spooler is full - Printer out of paper - Printer not ready - Please replace the toner/ink	Check the printer status on the printer.
M924	Error accessing SD card! Error accessing USB stick! SD card is not or wrong formatted! USB stick is not or wrong formatted!	Impossible to access the removable data medium. Causes include: Memory is larger than 32 GB Invalid format (only FAT or FAT32 are permitted)	Check/replace removable data medium
M925	SD card is write-protected!	SD card is write-protected!	Remove write protection
M927	Insufficient space free on data storage medium!	An attempt was made to save to the SD card or USB stick (setup, screenshot, etc.), but not enough free memory space is available.	Use other SD card / USB stick. Delete files that are no longer needed from the SD card / USB stick
M927	Insufficient space free on data storage medium!	An attempt was made to save the data onto the WebDAV server, but there was not sufficient memory available.	Use other WebDAV server. Delete files no longer required from the WebDAV server.

Diagnostic code	Message text	Description	Remedy
F929	File is damaged!	The file that should be loaded is damaged/invalid (e.g. wrong checksum). This message can occur in connection with the following actions, for instance: Loading setup from SD card / USB stick Firmware update Loading process-related graphics	Create file again, use other storage medium.
M940	E-mail could not be sent! (x)	E-mail could not be sent! Optional: Error code (x) from server: e.g.: 451: Requested action aborted: local processing error 554: Transaction failed. Possible reason: e-mail was not sent as suspected of being SPAM 1: No free buffer 2: No receiver specified	Check settings / network connection 451: Try again 554: Use other e-mail provider
M941	No connection to the e-mail server!	A connection to the e-mail server could not be established because: - The entered connection data is incorrect - The connection has been disconnected	Check settings / network connection
M942	SMTP: fault occurred (x).	An error occurred when sending an e-mail. x= error code: 0: SMTP was switched off when the mail was being sent 3: TCP/IP connection was denied 4: TCP/IP connection error 5: SMTP server denied 6: Error during authentication 7: Connection unexpectedly lost 8: Server responded with error code 9: Timeout 10: Internal protocol error	Check settings / network connection
M944	SMTP: authentication failed!		Check settings / network connection
M945	SNTP: Time was not synchronized!	Time could not be synchronized via SNTP. Possible reasons: - SNTP server temporarily unavailable - Settings not correct	- Check settings - Check whether the error occurs often. If it does, choose another time server.
M945	SNTP server 1 not responding. Try server 2.	Time could not be synchronized via SNTP. Possible reasons: - SNTP server temporarily unavailable - Settings not correct	- Check settings - Check whether the error occurs often. If it does, choose another time server.
M946	Screenshot could not be saved (x)!	Screenshot could not be created. Possible causes (x): 0: Error when writing 1: Insufficient free space 2: Bitmap could not be created 3: SD card/USB stick not available or ready	Check/replace the SD card or USB stick
M947	Modem could not be initialized! Please check the cable and modem.	The connected modem could not be initialized by the device.	Please check the cable and modem.
M950	Unable to load SSL certificate.	Unable to load SSL certificate. Cause: - Invalid file format - File is damaged	- Use a certificate with a valid file format - Import certificate to device again
F951	SSL certificate '...' has expired!	Certificates have an expiry date, i.e. they must be renewed from time to time.	Install a new certificate
M952	SSL certificate '...' expires on ...!	The device warns the user shortly before the certificate expires.	Install a new certificate

Diagnostic code	Message text	Description	Remedy
M953	x certificates have already been installed. First of all, please delete certificates that are no longer required.	The device can manage max. 3 X.509 certificates.	Delete a certificate that is already installed and no longer required
M954	SSL certificate not found: key ID = ...	Unable to establish SSL connection as a suitable certificate is not installed.	Install a suitable certificate
M955	SSL connection denied!		
M956	Incorrect password. Your user account has been deactivated.	Incorrect password. User account has been deactivated.	Please contact your administrator to reactivate your account.
M956	Incorrect password. Your user account has been deactivated for 10 minutes.	An incorrect password was entered and the account has been temporarily blocked.	Wait until the temporary block has been disabled or contact your administrator.
M957	Wet steam alarm	Warning for wet steam alarm	Check the application (pressure, temperature inputs)
M965	SMS could not be sent.	SMS could not be sent because: ■ The entered connection data is incorrect ■ There is no connection to the service provider	Check connections and communication settings
M971	No channels assigned to batch x.	The batch functionality has been activated but no channels have been assigned to the batch.	Check group settings
M980	No connection to the WebDAV server	A connection to the WebDAV server could not be established because the entered connection data is incorrect or the connection has been disconnected.	Check settings / network connection
M981	WebDAV: Authentication failed.		Check settings
M982	WebDAV: Directory or file could not be created.	Set directory path does not exist.	Create a directory manually in the WebDAV server
M983	WebDAV: Fault	An unassigned error has occurred. The error is displayed in English.	

HART® error messages

Diagnostic code	Message text	Description	Remedy
M490	Channel x: Max. 5 devices may be connected per channel in multidrop mode.	Max. 5 HART® devices may be connected to the input.	Use other channels
M960	Value uncertain/ communication faulty	In the case of fieldbuses: The status of the value is uncertain In the case of HART®: The current value is used instead of the digital value	
M970	Multi-master collision		■ Check additional master in the HART® network (e.g. handheld). ■ Check master settings (secondary/primary)

12.4 Pending, current diagnostic messages

The diagnostic message that is currently pending, the last diagnostic message and the last device restart are displayed in the main menu under **"Diagnostics -> Actual diagnostics"**, **"Diagnostics -> Last diagnostics"** or under **"Diagnostics -> Last restart"**.

12.5 Diagnosis list

The last 30 diagnostic messages are displayed in the main menu under **"Diagnostics -> Diagnosis list"** (messages with Fxxx, Sxxx or Mxxx-type error numbers).

The diagnosis list is designed as a ring memory, i.e. when the memory is full the oldest messages are automatically overwritten (no message).

The following information is saved:

- Error number
- Error text
- Date/time

12.6 Event logbook

Events such as limit value violations and power failures are displayed in chronological order in the event logbook. It can be found in the main menu under **"Diagnostics -> Event logbook"**. Individual events can be selected and details displayed.

12.7 Device information

Important device information, e.g. serial number, firmware version, device name, device options, memory information, SSL certificates etc. are displayed in the main menu under **"Diagnostics -> Device information"**.



For further information open the online help on the device.

12.8 Diagnostics of measured values

Displays the current measured values in the main menu under **"Diagnostics -> Measured values"**. The input signals can be verified here by displaying the scaled and calculated values. To verify calculations, call up calculated auxiliary variables if necessary.

12.9 Diagnostics of outputs

Displays the current states of the outputs (analog outputs, relays) in the main menu under **"Diagnostics -> Outputs"**.

12.10 Simulation

Various functions/signals can be simulated for test purposes here.

NOTICE

Selecting simulation: Simulation of the relays can be found in the main menu under "Diagnostics -> Simulation". The simulation of the measured values can be found in the main menu under "Expert -> Diagnostics -> Simulation".

Only the simulated values are recorded during simulation. The simulation is recorded in the event logbook.

- Do not start simulation if measured value recording must not be interrupted!

12.10.1 Test bar code reader

The function (e.g. character set) of the bar code reader can be tested in the main menu under **"Diagnostics -> Simulation -> Test bar code reader"**.



Only visible when a bar code reader is connected.

12.10.2 E-mail test

A test mail can be sent to the selected recipient in the main menu under **"Diagnostics -> Simulation -> E-mail"**.

 At least one e-mail address must be set beforehand. A message is provided on the device to confirm if the email was sent or not.

12.10.3 Test WebDAV Client

A test file can be sent to the selected WebDAV server in the main menu under **"Diagnostics -> Simulation -> WebDAV Client"**.

 The settings for the WebDAV server to be addressed must be set beforehand under **"Setup -> Advanced setup -> Application -> WebDAV Client"**.

12.10.4 Test telealarm

The telealarm functionality can be tested in the main menu under **"Diagnostics -> Simulation -> Test telealarm"**. During this test, alarms are simulated and triggered.

 Only possible with the "Tele-Alarm" device option.
Detailed descriptions of this device option can be found in the associated documentation.

12.10.5 Test time synchronization / SNTP

Time synchronization (SNTP setting) can be tested in the main menu under **"Diagnostics -> Simulation -> SNTP"**.

 SNTP must be enabled beforehand in the main menu under **"Setup -> Advanced setup -> System -> Date/time set-up -> SNTP"**.

Note: The test can take some time. A message is provided on the device once the test has finished.

12.10.6 Test universal output

The active analog and pulse outputs can be tested in the main menu under **"Diagnostics -> Simulation -> Universal output"**.

12.10.7 Relay test

The relay selected under **"Diagnostics -> Simulation -> Relay x"** can be switched manually in the main menu.

12.11 HART® diagnostics

Display of device information and status of the connected HART® devices/sensors in the main menu under **"Diagnostics -> HART"**.

 Note: It can take several seconds until all information is available from the device/sensor.

Attention: Measured value acquisition will be slower because additional information needs to be read.

 For further information open the online help on the device.

12.12 PROFINET diagnostics (option)

Display of diagnostic PROFINET information in the main menu under "**Diagnostics -> PROFINET**".

12.13 Initialize modem

Initializes the modem connected (to automatically answer calls). The modem must support the complete AT command syntax.

-  ▪ Set the baudrate in the main menu under "**Setup -> Advanced setup -> Communication -> Serial interface**" and select "**RS232**" as the interface type.
- Connect the modem to the RS232 interface of the device. For this purpose only use the modem cable, which is available as an accessory.
-  A GSM modem can only be initialized if a SIM card is inserted and the PIN is entered or the prompt to enter the PIN has been disabled.

12.14 GSM terminal

Information on the reception quality.

-  Only possible with the "Tele-Alarm" device option.
Detailed descriptions of this device option can be found in the associated documentation.

12.15 Status telealarm

Information on the status of individual alarms.

-  Only possible with the "Tele-Alarm" device option.
Detailed descriptions of this device option can be found in the associated documentation.

12.16 Resetting the measuring device

The device can be reset to the as-delivered state with a PRESET. This function should only be performed by a service technician.

The function can be found in the main menu under "**Expert -> System -> PRESET**".

-  PRESET is only visible under "Expert" once the service code has been entered.

Procedure for resetting the measuring device

The PRESET returns all parameters to the factory default setup! The internal memory content is deleted!

- Save the setup and measured values on the USB stick or SD card. Then perform a PRESET.
 - ↳ The device is reset to the factory default settings.

12.17 Firmware history

Overview of unit software history:

Unit software version / date	Software modification	FDM analysis software version	Version of OPC server	Operating Instructions
V02.00.00 / 08.2015	Original software	V01.03.00.00 and higher	V5.00.03.00 and higher	BA01338R/09/01.15
V2.01.00 / 04.2016	Extended functionality/bug fixes	V01.03.01.00 and higher	V5.00.03.00 and higher	BA01338O/09/02.16

13 Maintenance

No special maintenance work is required for the device.

13.1 Updating the device software ("firmware")

Updating the device software ("firmware") via USB stick, SD card or web server.



It is recommended that the setup and measured values are saved beforehand on the SD card or USB stick.

The device software ("firmware") should only be updated by a service technician.

The device will restart following the firmware update.

13.2 Instructions for enabling a software option

Various device options can be enabled via an activation code. Available device options can be ordered as an accessory → 79. Once you place your order, you receive instructions on how to activate the option and a code which you must enter under **"Main menu -> Expert -> System -> Device options -> Activation code"**.

13.3 Cleaning

The front of the housing can be cleaned with a clean dry or damp cloth.


14 Repairs

14.1 General notes

-  Repairs that are not described in these Operating Instructions must only be carried out directly by the manufacturer or by the service department.
-  If ordering spare parts, please specify the serial number of the unit! Installation instructions are included with the spare part.

14.2 Spare parts

-  Accessories and spare parts currently available for your product can be found online at: www.endress.com/spareparts_consumables → **access to specific device information** → enter serial number.



13 Spare parts diagram

Spare parts list:

Item No.	Description	Order No.
1	Power supply 24 V AC/DC for Slot 6	XPR0011-NB
1	Power supply 100-230 V AC (+/-10%) for slot 6	XPR0011-NA
2	Seal housing	XPR0011-A1
3	Digital board extension (8x digital inputs + 6x relays + 2x analog outputs) for slot 5 (rear panel must also be ordered with the extension)	XPR0011-A7
4	Rear panel analog inputs	XPR0011-A2
4	Rear panel analog + digital inputs	XPR0011-A3
5	Terminal cover lead sealable	XPR0011-A5
6	Analog board (4 channels) for slots 1-5	XPR0011-A6
6	HART® card (4 channels) for slots 1-5	XPR0011-A4
7	Jack screw short (1 piece)	71035184
	RS232/RS485 adapter set, DIN rail, 230 V AC, galvanic isolation + interface cable for PC/modem	RSG40A-S6

Item No.	Description	Order No.
	RS232/RS485 adapter set, DIN rail, 150 V AC, galvanic isolation + interface cable for PC/modem	RSG40A-S7
	SD card "Industrial Grade" industry standard, 1 GB	71213190
3	Terminals:	
	Terminal plug 3 pole for mains connection "N L PE" RM5.08 – orange color at slot 6	71123475
	Terminal plug 3 pole for power supply at slot 6	50078843
	Terminal plug-in 3 pole FKC2,5/3-ST-5,08 for relay 1 (changeover) at slot 6	71037408
	Terminal plug-in 4 pole FMC1,5/4-ST-3,5 for digital board extension, slot 5 (analog outputs)	71037350
	Terminal plug-in 10 pole FMC1,5/10-ST-3,5 for digital board extension, slot 5 (digital inputs)	71037351
	Terminal plug-in 4-pole FKC2,5/4-ST-5,08 for relay 2+3 on slot 6 or relay 7+8 / 9+10 / 11+12 on slot 5	71037410
	Terminal plug-in 6 pole FKC2,5/6-ST-5,08 for relays 4+5+6 at slot 6	71037411
	Terminal plug-in 9 pole FMC1,5/9-ST-3,5 for digital inputs at slot 6	71037363
	Terminal plug-in 6 pole FMC1,5/6-ST-3,5 for analog input at slots 1-5	51009211

Product structure for option retrofit

Item No.	Description	Order code
	Option retrofit (please enter the serial number)	XPR0012- _ _ _ _
	Software: Without software application Mathematics Tele-Alarm + mathematics Batch + mathematics Wastewater + stormwater overflow tank + Tele-Alarm + mathematics Energy software, water + steam + mathematics Tele-Alarm + energy software + water + steam + mathematics	XPR0012-0 _ _ _ XPR0012-B _ _ _ XPR0012-C _ _ _ XPR0012-D _ _ _ XPR0012-E _ _ _ XPR0012-F _ _ _ XPR0012-G _ _ _
	Communication Master functionality: None Standard + Modbus RTU/TCP master, max. 40 x analog	XPR0012- _ A _ _ XPR0012- _ B _ _
	Communication Slave functionality: None Standard + Modbus RTU/TCP slave, max. 40 x analog	XPR0012- _ _ A _ XPR0012- _ _ B _
	Option: Standard	XPR0012- _ _ _ A



The software option can be enabled directly on the device. After ordering you will receive instructions and a code that you must enter.

14.3 Return

The measuring device must be returned if it is need of repair or a factory calibration, or if the wrong measuring device has been delivered or ordered. Legal specifications require Endress+Hauser, as an ISO-certified company, to follow certain procedures when handling products that are in contact with the medium.

To ensure safe, swift and professional device returns, please refer to the procedure and conditions for returning devices provided on the Endress+Hauser website at <http://www.endress.com/support/return-material>

14.4 Disposal

The device contains electronic components and must therefore be disposed of as electronic waste. Please pay particular attention to the national disposal regulations in your country.


15 Accessories

i Always quote the serial number of the device when ordering accessories! Installation instructions are provided with the accessory!

Various accessories, which can be ordered with the device or subsequently from Endress+Hauser, are available for the device. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.

15.1 Device-specific accessories

Description	Order No.
"Industrial Grade" SD card, industry standard, 1GB	71213190
Field Data Manager analysis software with SQL database support (1 x workstation license, Professional version)	MS20-A1
OPC server software (full version on CD)	RXO20-11

Description	Order No.
Accessories for RXU10 data manager	RXU10- _ _
Designation: Cable set RS232 for connection to PC or modem USB - RS232 converter Cable USB-A - USB-B, 1.8 m (5.9 ft) Configuration software "FieldCare Device Setup" + USB cable	RXU10-B _ RXU10-E _ RXU10-F _ RXU10-G _
Field housing IP65  320 (12.6) 320 (12.6) 254 (10) A0024766	RXU10-H _

 14 Dimensions in mm (in)

Description	Order No.
Desktop housing, cable with Schuko plug Desktop housing, cable with US plug Desktop housing, cable with Swiss plug A0024767 15 <i>Dimensions in mm (in)</i>	RXU10-I _ RXU10-J _ RXU10-K _
Version: Standard Neutral	RXU10- _ 1 RXU10- _ 2

Description	Order No.
Terminal cover lead sealable An optional terminal cover is available to prevent tampering at the device terminals and terminal temperature measurement. A0029023	XPR0011-A5

16 Technical data

16.1 Function and system design

Measuring principle	Electronic acquisition, display, recording, analysis, remote transmission and archiving of analog and digital input signals as well as calculated values. The device is intended for installation in a panel or cabinet door. There is also the option of operating it in a desktop housing or field housing.
Measuring system	Multichannel data recording system with multicolor TFT display (178 mm / 7" screen size), internal memory, external memory (SD card and USB stick), galvanically isolated universal inputs (U, I, TC, RTD, pulse, frequency), HART® inputs, digital inputs, transmitter power supply, limit relays, digital and analog outputs, communication interfaces (USB, Ethernet, RS232/485), optionally available with Modbus, Profibus DP or PROFINET I/O or EtherNet/IP. An Essential Version of the Field Data Manager (FDM) software is included for SQL-supported data analysis at the PC.  The number of inputs available in the basic device can be individually increased using a maximum of 5 plug-in cards. The device supplies power directly to connected two-wire transmitters. The device is configured and operated via the navigator (jog/shuttle dial) or by touchscreen (optional), using the integrated Web server and a PC, or via an external USB keyboard or mouse or with the FieldCare / DeviceCare configuration software. Online help supports the user during local operation.  Ex version: ■ The hazardous area version (Ex version) is only available in conjunction with the stainless steel front and touch control. ■ In this version, the SD card is integrated in the device and cannot be removed. The card can be read out using the Field Data Manager (FDM) software supplied via USB or Ethernet, or by WebDAV.
Application packages / software options	In the standard version, the Advanced Data Manager has a variety of functions, including an end-to-end safety concept to meet the requirements of FDA 21 CFR Part 11. The following application packages are available to help users meet the requirements of their applications and save time: ■ Mathematics ■ Telealarm ■ Batch management ■ Wastewater + RSB (rain spillway basin) ■ Energy calculation The application packages contain the standard functions and the specific package functions. The individual packages can be largely combined as the user requires. The application packages can also be activated retroactively by entering the activation code. Standard functions ■ Signal analysis: external, 1 min to 12 h, day, week, month, year ■ Web server ■ User administration compliant with FDA 21 CFR Part 11 ■ Event log/audit trail ■ Process screen ■ Operation time counter ■ Text entry/comments ■ Change language

- Time synchronization
- Linearization
- Access protection through release code
- E-mail notification in event of alarms and limit violation
- Encrypted e-mail transmission via SSL (TLS)
- Operation via external USB keyboard and mouse
- External USB or network printer

Mathematics

With the mathematics package, measured values of the inputs or the results of other math channels can be linked mathematically. A formula with up to 200 characters can be created using a formula editor. Once entered, the user can then check the plausibility of the formula.

Functions:

- 12 math channels
- Mathematics functions via formula editor
- Basic arithmetic operations, relational operators, logic operations and functions

Telealarm software

The Telealarm software facilitates user mobility, allowing users to respond to events while they are on the road. E-mails or SMS messages triggered by process alarms or other important process events can be sent to several recipients simultaneously or automatically forwarded to a recipient/destination. Messages can be confirmed, relays controlled remotely and current values queried by cellular phone. The Advanced Data Manager with GSM (GPRS) or Ethernet is ideal both for environmental applications to monitor unstaffed outstations, and for tank monitoring applications.



The Telealarm software contains the mathematics package.

Functions:

- Advanced SMS/e-mail notification in the event of an alarm
- Instantaneous values queried by cellular phone
- Remote relay switching
- Alarm confirmation by SMS

Batch software

Batch management allows users to reliably record and visualize discontinuous processes. User-definable or externally controlled analysis intervals are possible for up to four batches simultaneously. Batches are assigned batch-specific values and the measured data, the start, end and duration of every batch, along with the current batch status, are displayed on the device and in the Field Data Manager software. At the end of the batch, a batch print-out is automatically started directly at the device (USB or network printer) or is printed out at a PC with the Field Data Manager software.



The batch software contains the mathematics package.

Functions:

- Batch report for 4 batches simultaneously
- USB barcode reader
- Automatic batch printout
- Preset counter

Wastewater + RSB (rain spillway basin)

The water/wastewater software supports operations monitoring of the water/wastewater sewage network to obtain information about the quality and efficiency of the plant. The daily, weekly, monthly and yearly maximum and minimum value is determined per

quantity channel. Infiltration water recording and the monitoring of rain spillway basins for reservoir and overflow events are also functions of this software option.



The water/wastewater software contains the mathematics package and the telealarm software.

Functions:

- Rain spillway basin (reservoir/overflow)
- Highest and lowest values for quantities
- Highest and lowest values from ¼-hourly averages
- Determination of infiltration water

Energy package (water + steam)

The energy package allows users to calculate the mass and energy flow in water and steam applications on the basis of the flow, pressure and temperature (or temperature difference) input variables. Furthermore, energy calculations are also possible using glycol-based refrigerant media.

By balancing the results against one another or by linking the results to other input variables (e.g. gas flow, electr. energy), users can calculate overall balances, efficiency levels etc. These values are important indicators for the quality of the process and form the basis for process optimization and maintenance.

The internationally recognized standard IAPWS-IF 97 is used to calculate the thermodynamic state variables of water and steam.

In the energy software, it is also possible to compensate differential pressure flow measurement ("DP-Flow"). The calculation of flow based on the differential pressure method is a special form of flow measurement. Volumes or mass flow rates that are determined using the DP method require specific correction. By solving the calculation equations listed in the standard in an iterative manner, highly accurate results for DP flow measurements can be achieved. The measurement (orifice plate, nozzle, Venturi pipe) is performed in accordance with ISO5167. Flow measurement based on the dynamic pressure method uses the interrelation between differential pressure and flow.



The energy package contains the mathematics package.

Additional functions:

- 12 math channels
(Channels 1-8: energy-specific formulas and formula editor, channels 9-12: formula editor)
- Heat quantity + mass calculation for water and steam applications
- Efficiency calculation

Dependability

Reliability

Depending on the device version, the mean time between failures (MTBF) is between 52 years and 16 years (calculated based on SN29500 standard at 40°C)

Maintainability

Battery-backed time and data memory. It is advisable to have the backup battery replaced by a service technician after 10 years.

Real time clock (RTC)

- Automatic or manual summer time changeover
- Battery buffer. It is advisable to have the backup battery replaced by a service technician after 10 years.
- Drift: <10 min/year.
- Time synchronization possible via SNTP or via digital input.

Standard diagnostic functions as per Namur NE 107

The diagnostic code is made up of the error category as per Namur NE 107 and the message number.

- Cable open circuit, short-circuit
- Incorrect wiring
- Internal device errors
- Overrange/underrange detection
- Ambient temperature out-of-range detection

Device error/alarm relay

One relay can be used as an alarm relay. The selected relay switches if the device detects a system error (e.g. hardware defect) or a malfunction (e.g. cable open circuit).

This "alarm relay" switches if the device status is "F" (Failure). If the device status is "M" (Maintenance required), the alarm relay does not switch.

Safety

Recorded data are saved in a tamper-proof format and can be exported and archived with manipulation protection using the Field Data Manager software.

16.2 Input

Measured variables

Analog universal inputs

Standard version without universal inputs. Optional multifunction cards (slot 1-5) with 4 universal inputs (4/8/12/16/20) each.

You are free to choose between the following measured variables for each universal input: U, I, RTD, TC, pulse input or frequency input.

Integration of input variable for totalization e.g. flow (m³/h) in quantity (m³).

HART® inputs

Standard version without HART® inputs. Optional HART® input cards (slot 1-5) with 4 inputs (4/8/12/16/20) each.

Both the digital HART® values and the 4 to 20 mA signal can be evaluated at every input.

The 4 HART® values (PV, SV, TV, QV) of a sensor can be evaluated and the analog HART® value (PV) can be measured via the digital HART® signal. Up to 40 digital HART® values can be recorded in total. It is possible to access the HART® sensor in the field from a PC tool (e.g. FieldCare). In this way, the sensor can be configured from the control room and the status information of the sensor can be analyzed/displayed. The Memograph M acts as a HART® Gateway.



Access to the connected sensors is only possible if the device is connected by Ethernet.

Port 5094 must be open in the firewall.

Digital inputs

Standard version: 6 digital inputs

Optional digital card (slot 5): 8 additional digital inputs, 6 additional relays and 2 analog outputs

Math channels

12 math channels (optional). Mathematics functions can be freely edited via a formula editor.

Integration of calculated values e.g. for totalization.

Limit values

60 limit values (individual channel assignment)

Calculated values

The values of the universal and HART® inputs can be used to perform calculations in the math channels.

The results of the math channels can also be used for calculations in other math channels.

Measuring range According to IEC 60873-1: An additional display error of ± 1 digit is permitted for every measured value.

User-definable measuring ranges per universal input of the multifunction card:

Measured variable	Measuring range	Maximum measured error of measuring range (oMR), temperature drift	Input resistance
Current (I)	0 to 20 mA; 0 to 20 mA quadratic 0 to 5 mA 4 to 20 mA; 4 to 20 mA quadratic ± 20 mA Overrange: up to 22 mA or -22 mA	$\pm 0.1\%$ oMR Temperature drift: $\pm 0.01\%/K$ oMR	Load: 50 Ω $\pm 1 \Omega$
Voltage (U) >1 V	0 to 10 V; 0 to 10 V quadratic 0 to 5 V 1 to 5 V; 1 to 5 V quadratic ± 10 V ± 30 V	$\pm 0.1\%$ oMR Temperature drift: $\pm 0.01\%/K$ oMR	$\geq 1 M\Omega$
Voltage (U) ≤ 1 V	0 to 1 V; 0 to 1 V quadratic ± 1 V ± 150 mV	$\pm 0.1\%$ oMR Temperature drift: $\pm 0.01\%/K$ oMR	$\geq 2.5 M\Omega$
Resistance thermometer (RTD)	Pt100: -200 to 850 °C (-328 to 1562 °F) (IEC 60751:2008, $\alpha=0.00385$) Pt100: -200 to 510 °C (-328 to 950 °F) (JIS C 1604:1984, $\alpha=0.003916$) Pt100: -200 to 850 °C (-328 to 1562 °F) (GOST 6651-94, $\alpha=0.00391$) Pt500: -200 to 850 °C (-328 to 1562 °F) (IEC 60751:2008, $\alpha=0.00385$) Pt500: -200 to 510 °C (-328 to 950 °F) (JIS C 1604:1984, $\alpha=0.003916$) Pt1000: -200 to 600 °C (-328 to 1112 °F) (IEC 60751:2008, $\alpha=0.00385$) Pt1000: -200 to 510 °C (-328 to 950 °F) (JIS C 1604:1984, $\alpha=0.003916$)	4-wire: $\pm 0.1\%$ oMR 3-wire: $\pm (0.1\% \text{ oMR} + 0.8 \text{ K})$ 2-wire: $\pm (0.1\% \text{ oMR} + 1.5 \text{ K})$ Temperature drift: $\pm 0.01\%/K$ oMR	
	Cu50: -50 to 200 °C (-58 to 392 °F) (GOST 6651-94, $\alpha=4260$) Cu50: -200 to 200 °C (-328 to 392 °F) (GOST 6651-94, $\alpha=4280$) Pt50: -200 to 1100 °C (-328 to 2012 °F) (GOST 6651-94, $\alpha=0.00391$) Cu100: -200 to 200 °C (-328 to 392 °F) (GOST 6651-94, $\alpha=4280$)	4-wire: $\pm 0.2\%$ oMR 3-wire: $\pm (0.2\% \text{ oMR} + 0.8 \text{ K})$ 2-wire: $\pm (0.2\% \text{ oMR} + 1.5 \text{ K})$ Temperature drift: $\pm 0.02\%/K$ oMR	
	Pt46: -200 to 1100 °C (-328 to 2012 °F) (GOST 6651-94, $\alpha=0.00391$) Cu53: -200 to 200 °C (-328 to 392 °F) (GOST 6651-94, $\alpha=4280$)	4-wire: $\pm 0.3\%$ oMR 3-wire: $\pm (0.3\% \text{ oMR} + 0.8 \text{ K})$ 2-wire: $\pm (0.3\% \text{ oMR} + 1.5 \text{ K})$ Temperature drift: $\pm 0.02\%/K$ oMR	
Thermocouples (TC)	Type J (Fe-CuNi): -210 to 1200 °C (-346 to 2192 °F) (IEC 60584:2013) Type K (NiCr-Ni): -270 to 1300 °C (-454 to 2372 °F) (IEC 60584:2013) Type L (NiCr-CuNi): -200 to 800 °C (-328 to 1472 °F) (GOST R8.585:2001) Type L (Fe-CuNi): -200 to 900 °C (-328 to 1652 °F) (DIN 43710-1985) Type N (NiCrSi-NiSi): -270 to 1300 °C (-454 to 2372 °F) (IEC 60584:2013) Type T (Cu-CuNi): -270 to 400 °C (-454 to 752 °F) (IEC 60584:2013)	$\pm 0.1\%$ oMR from -100 °C (-148 °F) $\pm 0.1\%$ oMR from -130 °C (-202 °F) $\pm 0.1\%$ oMR from -100 °C (-148 °F) $\pm 0.1\%$ oMR from -100 °C (-148 °F) $\pm 0.1\%$ oMR from -100 °C (-148 °F) $\pm 0.1\%$ oMR from -200 °C (-328 °F) Temperature drift: $\pm 0.01\%/K$ oMR	$\geq 1 M\Omega$

Measured variable	Measuring range	Maximum measured error of measuring range (oMR), temperature drift	Input resistance
	Type A (W5Re-W20Re): 0 to 2500 °C (32 to 4532 °F) (ASTME 988-96) Type B (Pt30Rh-Pt6Rh): 42 to 1820 °C (107.6 to 3308 °F) (IEC 60584:2013) Type C (W5Re-W26Re): 0 to 2315 °C (32 to 4199 °F) (ASTME 988-96) Type D (W3Re-W25Re): 0 to 2315 °C (32 to 4199 °F) (ASTME 988-96) Type R (Pt13Rh-Pt): -50 to 1768 °C (-58 to 3214 °F) (IEC 60584:2013) Type S (Pt10Rh-Pt): -50 to 1768 °C (-58 to 3214 °F) (IEC 60584:2013)	±0.15% oMR from 500 °C (932 °F) ±0.15% oMR from 600 °C (1112 °F) ±0.15% oMR from 500 °C (932 °F) ±0.15% oMR from 500 °C (932 °F) ±0.15% oMR from 100 °C (212 °F) ±0.15% oMR from 100 °C (212 °F) Temperature drift: ±0.01%/K oMR	≥1 MΩ
Pulse input (I) ¹⁾	Min. Pulse length 40 µs, max. 12.5 kHz; 0 to 7 mA = LOW; 13 to 20 mA = HIGH		Load: 50 Ω ±1 Ω
Frequency input (I) ¹⁾	0 to 10 kHz, overrange: up to 12.5 kHz; 0 to 7 mA = LOW; 13 to 20 mA = HIGH	±0.02% @ f <100 Hz of reading ±0.01% @ f ≥100 Hz of reading Temperature drift: 0.01% of measured value over the entire temperature range	

- 1) If a universal input is used as a frequency or pulse input, a series resistor must be used in series connection with the voltage source. Example: 1.2 kΩ series resistor at 24 V

Current measuring range of the HART® card:

Measured variable	Measuring range	Maximum measured error of measuring range (oMR), temperature drift	Input impedance
Current (I)	4 to 20 mA Overrange: up to 22 mA	±0.1% oMR Temperature drift: ±0.01%/K oMR	Load: 10 Ω ±1 Ω

Maximum load and additional input parameters of the multifunction cards

Limit values for input voltage and current as well as cable open circuit detection/line influence/temperature compensation:

Measured variable	Limit values (steady-state, without destroying input)	Cable open circuit detection/line influence/temperature compensation
Current (I)	Maximum permitted input voltage: 2.5 V Maximum permitted input current: 50 mA	4 to 20 mA range with disengageable cable open circuit monitoring to NAMUR NE43. The following error ranges apply when NAMUR NE43 monitoring is switched on: ≤3.8 mA: underrange ≥20.5 mA: overrange ≤ 3.6 mA or ≥ 21.0 mA: open circuit (display shows: - - -)
Pulse, frequency (I)	Maximum permitted input voltage: 2.5 V Maximum permitted input current: 50 mA	No cable open circuit monitoring
Voltage (U) >1 V	Maximum permitted input voltage: 35 V	1 to 5 V range with disengageable cable open circuit monitoring: <0.8 V or >5.2 V: cable open circuit (display shows: - - -)
Voltage (U) ≤1 V	Maximum permitted input voltage: 24 V	
Resistance thermometer (RTD)	Measuring current: ≤1 mA	Maximum barrier resistance (or line resistance): 4-wire: max. 200 Ω; 3-wire: max. 40 Ω Maximum influence of barrier resistance (or line resistance) for Pt100, Pt500 and Pt1000: 4-wire: 2 ppm/Ω, 3-wire: 20 ppm/Ω Maximum influence of barrier resistance (or line resistance) for Pt46, Pt50, Cu50, Cu53, Cu100 and Cu500: 4-wire: 6 ppm/Ω, 3-wire: 60 ppm/Ω Cable open circuit monitoring if any connection is interrupted.
Thermocouples (TC)	Maximum permitted input voltage: 24 V	Influence of line resistance: <0.001%/Ω Error, internal temperature compensation: ≤ 2 K

Maximum load and additional input parameters of the HART® cards

Limit values for input voltage and current as well as cable open circuit detection:

Measured variable	Limit values (steady-state, without destroying input)	Cable open circuit detection
Current (I)	Maximum permitted input voltage: 0.5 V Maximum permitted input current: 50 mA	4 to 20 mA range with disengageable cable open circuit monitoring to NAMUR NE43. The following error ranges apply when NAMUR NE43 monitoring is switched on: ≤ 3.8 mA: underrange ≥ 20.5 mA: overrange ≤ 3.6 mA or ≥ 21.0 mA: open circuit (display shows: - - -)

Scan rate

Current/voltage/pulse/frequency input: 100 ms per channel

Thermocouples and resistance temperature detector: 1 s per channel

Data storage / memory cycle

Choose from the following for the memory cycle: off / 100 ms / 1s / 2s / 3s / 4s / 5s / 10s / 15s / 20s / 30s / 1min / 2min / 3min / 4min / 5min / 10min / 15min / 30min / 1h



Highspeed storage (100 ms) can be selected for up to 8 channels in Group 1 only.

Highspeed storage is not available in the energy package (option).

Typical recording length

Prerequisites for following tables:

- No limit value violation / integration
- Digital input not used
- Signal analysis 1: off, 2: day, 3: month, 4: year
- No active math channels



Frequent entries in the event log reduce the memory availability!

256 MB internal memory:

Analog inputs	Channels in groups	Storage cycle (weeks, days, hours)				
		5 min	1 min	30 s	10 s	1 s
1	1/0/0/0/0/0/0/0/0/0	1796, 6, 13	362, 5, 17	181, 4, 9	60, 4, 3	6, 0, 10
4	4/0/0/0/0/0/0/0/0/0	1319, 2, 23	267, 5, 17	134, 1, 2	44, 5, 10	4, 3, 8
8	4/4/0/0/0/0/0/0/0/0	661, 4, 3	133, 6, 21	67, 0, 16	22, 2, 17	2, 1, 16
12	4/4/4/0/0/0/0/0/0/0	441, 3, 8	89, 2, 9	44, 5, 3	14, 6, 11	1, 3, 10
20	4/4/4/4/0/0/0/0/0/0	265, 0, 15	53, 4, 7	26, 5, 21	8, 6, 16	0, 6, 6
40	4/4/4/4/4/4/4/4/4/4	132, 4, 8	26, 5, 16	13, 2, 23	4, 3, 8	0, 3, 3

External memory, 1 GB SD card:

Analog inputs	Channels in groups	Storage cycle (weeks, days, hours)				
		5 min	1 min	30 s	10 s	1 s
1	1/0/0/0/0/0/0/0/0/0	12825, 5, 20	2580, 4, 18	1291, 2, 5	430, 4, 14	43, 0, 12
4	4/0/0/0/0/0/0/0/0/0	8672, 5, 12	1749, 6, 13	875, 6, 13	292, 1, 8	29, 1, 14
8	4/4/0/0/0/0/0/0/0/0	4343, 1, 1	875, 1, 17	438, 0, 6	146, 0, 17	14, 4, 7
12	4/4/4/0/0/0/0/0/0/0	2896, 6, 13	583, 3, 21	292, 0, 6	97, 2, 20	9, 5, 4

Analog inputs	Channels in groups	Storage cycle (weeks, days, hours)				
		5 min	1 min	30 s	10 s	1 s
20	4/4/4/4/4/0/0/0/0	1738, 6, 4	350, 1, 3	175, 1, 14	58, 3, 2	5, 5, 22
40	4/4/4/4/4/4/4/4/4/4	869, 5, 0	175, 0, 15	87, 4, 7	29, 1, 13	2, 6, 11

 The available storage capacity of the internal and external memory can be displayed in the main menu under **"Diagnostics → Device information → Memory information"**. The storage capacity depends on the specific device set-up.

Converter resolution

24 bit

Totalization

The interim value, daily value, weekly value, monthly value, annual value and overall value can be determined (13-digit, 64 bit).

Analysis

Recording of quantity/operating time (standard function), also a min/max/median analysis within the set time frame.

Digital inputs	Input level	Logical "0" (corresponds to -3 to +5 V), activation with logical "1" (corresponds to +12 to +30 V)
	Input frequency	max. 25 Hz
	Pulse length	Min. 20 ms (pulse counter)
	Pulse length	Min. 100 ms (control input, messages, operating time)
	Input current	max. 2 mA
	Input voltage	Max. 30 V

Selectable functions

- Functions of the digital input: control input, ON/OFF message, pulse counter (13-digit, 64-bit), operating time, message+operating time, quantity from time, Profibus DP, EtherNet/IP, PROFINET.
- Functions of the control input: start recording, screensaver on, lock setup, time synchronization, change group, limit value monitoring on/off, individual LV on/off, block keyboard/navigator, start/stop analysis.
Additionally for the batch software option: reset batch number, batch limit values on/off.

16.3 Output

Auxiliary voltage output	The auxiliary voltage output can be used for loop power supply or to control the digital inputs. The auxiliary voltage is short-circuit proof and galvanically isolated.
Output voltage	24 V _{DC} ±15%
Output current	Max. 250 mA

Analog and pulse outputs

Number

Optional digital card (slot 5): 2 analog outputs which can be operated as current or pulse outputs.

Analog output (current output)

Output current: 0/4 to 20 mA with 10% overrange

Max. output voltage: approx. 16 V

Accuracy: $\leq 0.1\%$ of end of range value

Temperature drift: $\leq 0.015\%/K$ of end of range value

Resolution: 13 Bit

Load: 0 to 500 Ω

Error signal as per NAMUR NE43: 3.6 mA or 21 mA can be configured

Digital output (pulse output)

Output voltage:

≤ 5 V corresponds to LOW

≥ 12 V corresponds to HIGH

Short-circuit proof (maximum 25 mA)

Speed: max. 1000 pulses/s

Pulse width: 0.5 to 1000 ms



The pulse pause is at least as long as the pulse width.

Load: ≥ 1 k Ω

Relay outputs

A mix of low voltage (230 V) and safety extra low voltage (SELV circuits) is not permitted at the connections of the relay contacts.

Alarm relay

1 alarm relay with changeover contact.

Standard relay

5 relays with NO contact, e.g. for limit value messages (can be configured as NC contact).

Optional relays

Optional digital card (slot 5): 6 additional relays with NO contact e.g. for limit value alarms (can be configured as an NC contact).

Relay switching capacity

- Max. relay switching capacity: 3 A @ 30 V DC
- Max. relay switching capacity: 3 A @ 250 V AC
- Min. switching load: 300 mW

Switching cycles

$> 10^5$

Galvanic isolation

All inputs and outputs are galvanically isolated from each other and designed for the following test voltages:

	Relay	Digital in	Analog in/HART®	Analog out	Ethernet	RS232/RS485	USB	Auxiliary voltage output
Relay	500 V _{DC}	2 kV _{DC}	2 kV _{DC}	2 kV _{DC}	2 kV _{DC}	2 kV _{DC}	2 kV _{DC}	2 kV _{DC}
Digital in	2 kV _{DC}	500 V _{DC} but: ¹⁾	500 V _{DC}	500 V _{DC}	500 V _{DC}	500 V _{DC}	500 V _{DC}	500 V _{DC}
Analog in/HART®	2 kV _{DC}	500 V _{DC}	500 V _{DC}	500 V _{DC}	500 V _{DC}	500 V _{DC}	500 V _{DC}	500 V _{DC}
Analog out	2 kV _{DC}	500 V _{DC}	500 V _{DC}	500 V _{DC}	500 V _{DC}	500 V _{DC}	500 V _{DC}	500 V _{DC}
Ethernet	2 kV _{DC}	500 V _{DC}	500 V _{DC}	500 V _{DC}	-	500 V _{DC}	500 V _{DC}	500 V _{DC}
RS232/RS485	2 kV _{DC}	500 V _{DC}	500 V _{DC}	500 V _{DC}	500 V _{DC}	-	500 V _{DC}	500 V _{DC}
USB	2 kV _{DC}	500 V _{DC}	500 V _{DC}	500 V _{DC}	500 V _{DC}	500 V _{DC}	Galvanically connected	500 V _{DC}
Auxiliary voltage output	2 kV _{DC}	500 V _{DC}	500 V _{DC}	500 V _{DC}	500 V _{DC}	500 V _{DC}	500 V _{DC}	-

- 1) Test voltage applies between inputs on power unit (terminals D11 to D61) to inputs on optional digital card (terminals D71 to DE1). The inputs are galvanically connected on the same plug-in connector.

Cable specification

Cable specification, spring terminals

All connections on the rear of the device are designed as pluggable screw or spring terminal blocks with reverse polarity protection. This makes the connection very quick and easy. The spring terminals are unlocked with a slotted screwdriver (size 0).

Please note the following when connecting:

- Wire cross-section, auxiliary voltage output, digital I/O and analog I/O: max. 1.5 mm² (14 AWG) (spring terminals)
- Wire cross-section, mains: max. 2.5 mm² (13 AWG) (screw terminals)
- Wire cross-section, relays: max. 2.5 mm² (13 AWG) (spring terminals)
- Stripping length: 10 mm (0.39 in)



No ferrules must be used when connecting flexible wires to spring terminals.

Shielding and grounding

Optimum electromagnetic compatibility (EMC) can only be guaranteed if the system components and, in particular, the lines - both sensor lines and communication lines - are shielded and the shield forms as complete a cover as possible. A shielded line must be used for sensor lines that are longer than 30 m. A shield coverage of 90% is ideal. In addition, make sure not to cross sensor lines and communication lines when routing them. Connect the shield as often as possible to the reference ground to ensure optimum EMC protection for the different communication protocols and the connected sensors.

To comply with requirements, three different types of shielding are possible:

- Shielding at both ends
- Shielding at one end on the supply side with capacitance termination at the device
- Shielding at one end on the supply side

Experience shows that the best results with regard to EMC are achieved in most cases in installations with one-sided shielding on the supply side (without capacitance termination


at the device). Appropriate internal device wiring measures must be taken to allow unrestricted operation when EMC interference is present. These measures have been taken into account for this device. Operation in the event of disturbance variables as per NAMUR NE21 is thus guaranteed.

Where applicable, national installation regulations and guidelines must be observed during the installation! Where there are large differences in potential between the individual grounding points, only one point of the shielding is connected directly with the reference ground.

i If the shielding of the cable is grounded at more than one point in systems without potential matching, mains frequency equalizing currents can occur. These can damage the signal cable or significantly impact signal transmission. In such cases the shielding of the signal cable is to be grounded on one side only, i.e. it may not be connected to the ground terminal of the housing. The shield that is not connected should be insulated!


16.4 Power supply

Terminals on back of device



The power actually consumed depends on the individual operating state and the device version (LPS, USB, brightness of screen, number of channels, etc). The active power here is approx. 3 W to 25 W.


Power supply failure	Battery-backed time and data memory. The device starts automatically following a power failure.
Electrical connection	Details about the electrical connection: →  16
Electrical connection, terminal assignment	Circuit diagram




A0026669-EN

 17 For connection examples of the HART® inputs (optional), see the Operating Instructions →  23

Supply voltage (power unit, slot 6)

Power unit type	Terminal		
			
100-230 VAC	L+	N-	PE
	Phase L	Zero conductor N	Ground
24 V AC/DC	L+	N-	PE
	Phase L or +	Zero conductor N or -	Ground

Relay (power unit, slot 6)


Type	Terminal (max. 250 V, 3 A)				
					
Alarm relay 1	R11	R12	R13		
	Changeover contact	Normally closed contact (NC) ¹⁾	Normally open contact (NO) ²⁾		
Relay 2 to 6				Rx1	Rx2
				Switching contact	Normally open contact (NO ²⁾)


- 1) NC = normally closed (breaker)
- 2) NO = normally open (maker)



The open or close function (= activation or deactivation of the relay coil) in a limit event can be configured in the setup: "Setup -> Advanced setup -> Outputs -> Relay -> Relay x". However, in the event of a power failure, the relay adopts its quiescent switch state regardless of the setting programmed.

Digital inputs; auxiliary voltage output (power unit, slot 6)


Type	Terminal			
				
Digital input 1 to 6	D11 to D61	GND1		
	Digital input 1 to 6 (+)	Ground (-) for digital inputs 1 to 6		

Type	Terminal			
				
Auxiliary voltage output, not stabilized, max. 250 mA			24V Out -	24V Out +
			- Ground	+ 24V (±15%)

 If the auxiliary voltage is to be used for the digital inputs, the **24 V out -** terminal of the auxiliary voltage output must be connected with the **GND1** terminal.

Analog inputs (slot 1-5)


The first digit (x) of the two-digit terminal number corresponds to the associated channel:

Type	Terminal					
						
	x1	x2	x3	x4	x5	x6
Current/pulse/frequency input ¹⁾					(+)	(-)
Voltage > 1V		(+)				(-)
Voltage ≤ 1V				(+)		(-)
Resistance thermometer RTD (2-wire)	(A)					(B)
Resistance thermometer RTD (3-wire)	(A)			b (sense)		(B)
Resistance thermometer RTD (4-wire)	(A)		a (sense)	b (sense)		(B)
Thermocouples TC				(+)		(-)

1) If a universal input is used as a frequency or pulse input, a series resistor must be used in series connection with the voltage source. Example: 1.2 kΩ series resistor at 24 V


HART® inputs (slot 1-5)

The first digit (x) of the two-digit terminal number corresponds to the associated channel:

Type	Terminal					
						
	x1	x2	x3	x4	x5	x6
HART® (4 to 20 mA)	SHD	H_1	H_2	R _{com}	I+	I-

- A 250 Ω communication resistor (load) is installed on the device side between terminals x4 and x5.
- A 10 Ω resistor (shunt) is installed on the device side at the current input between terminals x5 and x6.
- Terminals x2 and x3 (H_1 and H_2) are jumpered internally.
- The internal HART® modem is located between terminals x2/x3 and x6.


Relay extension (digital card, slot 5)

Type	Terminal (max. 250 V, 3 A)			
				
Relay 7, 8	RA	RB	RC	RD
Relay 9, 10	RE	RF	RG	RH
Relay 11, 12	RI	RJ	RK	RL
	Switching contact	Normally open contact (1)	Switching contact	Normally open contact (2)


- 1) NO)
2) NO)

The open or close function (= activation or deactivation of the relay coil) in a limit event can be configured in the setup: "Setup -> Advanced setup -> Outputs -> Relay -> Relay x". However, in the event of a power failure, the relay adopts its quiescent switch state regardless of the setting programmed.

Analog outputs (digital card, slot 5)

Type	Terminal			
				
Analog output 1-2	O15	O16	O25	O26
	Analog output 1 (+)	Ground, analog output 1 (-)	Analog output 2 (+)	Ground, analog output 2 (-)

Extension of digital inputs (digital card, slot 5)

Type	Terminal		
			
Digital input 7 to 14	D71 to DE1	GND2	GND2
	Digital input 7 to 14 (+)	Ground (-) for digital inputs 7 to 14	Ground (-) for digital inputs 7 to 14



If the auxiliary voltage is to be used for the digital inputs, the **24 V out -** terminal of the auxiliary voltage output (power unit, slot 6) must be connected with the **GND2** terminal.

Connector	■ Panel-mounted device: connected to mains via plug-in screw terminals with reverse polarity protection ■ Desktop version (option): connected to mains via IEC connector
Overvoltage protection	To avoid high-energy transients on long signal cables, connect a suitable surge arrester upstream (e.g. E+H HAW562) in series upstream.
Connection data interface, communication	USB interfaces: <i>1 x USB port type A (host) on the front of device (only for version with navigator and front interfaces)</i> A USB 2.0 port is available on a shielded USB A socket at the front of the device. A USB stick as a memory medium, for example, can be connected to this port, as can an external keyboard/mouse for device operation, a USB hub, a barcode reader or a printer (PCL5c or higher). <i>1 x USB port type B (function) on the front of device (only for version with navigator and front interfaces)</i> A USB 2.0 port is available on a shielded USB B socket at the front of the device. This can be used to connect the device for communication with a laptop, for example. <i>2 x USB port type A (host) on the rear of the device (standard)</i> Two USB 2.0 ports are available on shielded USB A sockets on the rear of the device. A USB stick as a memory medium, for example, can be connected to these ports, as can an external keyboard/mouse for device operation, a USB hub, a barcode reader or a printer (PCL5c or higher). ■ USB-2.0 is compatible with USB-1.1 or USB-3.0, i.e. communication is possible. ■ The assignment of the USB interfaces complies with the standard such that shielded standard cables with a maximum length of 3 meters (9.8 ft) can be used here. ■ The USB devices are detected by the "plug-and-play" function. If several devices of the same type are connected, only the USB device that was connected first is available. ■ A maximum of 8 external USB devices (incl. USB hub) can be connected if they do not exceed the maximum load of 500 mA. If overloaded, the corresponding USB devices are automatically disabled. An active USB hub can be used for higher power ratings.

Reference list for USB printers:

HP Color LaserJet CP1515n, HP Color LaserJet Pro CP1525n, ECOSYS P6021cdn



The printer must support PCL5c (or higher). GDI printers are not supported!

Reference list for USB barcode readers:

Datalogic Gryphon D230; Metrologic MS5100 Eclipse Series; Symbol LS2208, Datalogic Quickscan 1, Godex GS220, Honeywell Voyager 9590

Ethernet interface (standard):

Ethernet interface on back, 10/100 Base-T, plug type RJ45. The Ethernet interface can be used to integrate the device via a hub or switch into a PC network (TCP/ IP Ethernet). A standard patch cable (e.g. CAT5E) can be used for the connection. Using DHCP, the device can be fully integrated into an existing network without the need for additional configuration. The device can be accessed from every PC in the network. Normally only the automatic assignment of the IP address must be configured at the client. When the device is started, it can automatically retrieve the IP address, subnet mask and gateway from a DHCP server. If a DHCP is not used (depending on the specific network) these settings must be made directly in the device. Two Ethernet function LEDs are located on the rear of the device.

The following functions are implemented:

- Data communication with PC software (analysis software, configuration software, OPC server)
- Web server
- WebDAV (Web-based Distributed Authoring and Versioning) is an open standard for the provisioning of files via the HTTP protocol. The data saved on the device's SD card can be read out using a PC. A web browser or dedicated WebDAV client can be selected as network drive on the PC for this purpose.

Ethernet Modbus TCP master (option):

As a Modbus master, the device can interrogate other Modbus slaves via Ethernet. The Modbus TCP master can be operated in parallel with the Profibus DP slave, Modbus RTU / TCP slave or PROFINET I/O Device.

Up to 40 analog inputs can be transmitted via Modbus and stored in the device.

Ethernet Modbus TCP slave (option):

Connection to SCADA systems (Modbus master).

Up to 40 analog inputs and 20 (14 real + 6 virtual) digital inputs can be transmitted via Modbus and stored in the device.

Serial RS232/RS485 interface:

A combined RS232/RS485 connection is available on a shielded SUB D9 socket at the rear of the device. This can be used for data transfer and to connect a modem. For communication via modem, we recommend an industrial modem with a watchdog function.

- The following baud rates are supported: 9600, 19200, 38400, 57600, 115200
- Max. cable length with a shielded cable: 2 m (6.6 ft) (RS232), or 1000 m (3281 ft) (RS485)



Only one interface can be used at any one time (RS232 or RS485).

Modbus RTU master (option):

As a Modbus master, the device can interrogate other Modbus slaves via RS485. The Modbus RTU master can be operated in parallel with the Profibus-DP slave, PROFINET I/O Device or Modbus TCP slave.

Up to 40 analog inputs can be transmitted via Modbus and stored in the device.

Modbus RTU slave (option):

The device can be interrogated as a Modbus slave by another Modbus master via RS485.

Up to 40 analog inputs and 20 (14 real + 6 virtual) digital inputs can be transmitted via Modbus and stored in the device.



A Modbus RTU master and RTU slave cannot be operated in parallel.

Remote interrogation with analog or GSM/GPRS wireless modem:

Analog modem:

An analog modem for industrial use (e.g. Devolo or WESTERMO), which is connected to the RS232 interface with a special modem cable (see Accessories → 79), is recommended.

GSM/GPRS wireless modem:

A GSM/GPRS wireless modem (e.g. Cinterion, INSYS or WESTERMO), incl. antenna and power unit), which is connected to the RS232 interface with a special modem cable (see Accessories → 79), is recommended for industry.

Important: The wireless modem needs a SIM card and data transfer subscription. In addition, it must be possible to deactivate the PIN prompt.

AnyBus® interface (CPU card, slot 0, optional)

PROFIBUS-DP slave:

The device can be integrated into a fieldbus system as per the PROFIBUS-DP standard by means of the PROFIBUS-DP interface. Up to 40 analog inputs and 20 (14 real + 6 virtual) digital inputs can be transmitted via PROFIBUS-DP and stored in the device. Bidirectional communication with cyclic data transfer is possible. Connection via Sub-D socket.

Baudrate: maximum 12 Mbit/s

EtherNet/IP adapter (slave):

Up to 40 analog inputs and 20 (14 real + 6 virtual) digital inputs can be transmitted via Ethernet/IP and stored in the device. The built-in module corresponds to I/O server category (Level 2). It has an integrated 2-port switch, thereby supporting Ethernet/IP communication in line or ring topologies. Connection via 2 RJ45 standard sockets.

PROFINET I/O device:

Up to 40 analog inputs and 20 (14 real + 6 virtual) digital inputs can be transmitted via PROFINET IO and stored in the device. The 2-port module for PROFINET IO meets compliance class B. The integrated switch enables communication in line or ring topologies without an additional external switch. Connection via 2 RJ45 standard sockets.

16.5 Performance characteristics

Response time

Input	Output	Time [ms]
Current, voltage, pulse	Relays, OC, analog output	≤ 550
RTD	Relays, OC, analog output	≤ 1150
TC ¹⁾	Relays, OC, analog output	≤ 1550
Cable open circuit detection, current input	Relays, OC, analog output	≤ 1150
Sensor error RTD, TC	Relays, OC, analog output	≤ 5000

Input	Output	Time [ms]
Digital input	Relays, OC, analog output	≤ 350
HART® input	Relays, OC, analog output	Non-deterministic

1) If internal measuring point temperature compensation is used, otherwise values as for voltage

Reference operating conditions	Reference temperature	25 °C (77 °F) ±5 K
	Warm-up period	120 min.
	Humidity	20 to 60 % rel. humidity

Hysteresis Can be configured for limit values in the setup


Long-term drift As per IEC 61298-2: max. ±0.1%/year (of measuring range)

16.6 Installation

Panel mounting: mounting location and installation dimensions

The device is designed for use in a panel.

 The device must be installed in a pressurized enclosure system for operation in the hazardous area. To ensure safe installation, it is essential to follow the installation instructions for the cabinet and the installation instructions in the Ex-related Safety Instructions (XA).



18 Panel mounting and dimensions in mm (in).

- A Version with navigator and front interfaces
 B Version with stainless steel front and touchscreen
 C Grid dimensions of panel cutouts for multiple devices

Installation dimensions

- Installation depth (excluding terminal cover): approx. 159 mm (6.26 in) for device incl. terminals and fastening clips.
- Installation depth including terminal cover (option): approx. 198 mm (7.8 in)
- Panel cutout: 138 to 139 mm (5.43 to 5.47 in) x 138 to 139 mm (5.43 to 5.47 in)
- Panel thickness: 2 to 40 mm (0.08 to 1.58 in)
- viewing angle range: 50° in all directions from the display central axis
- A minimum distance of 12 mm (0.47 in) between the devices must be observed if aligning the devices vertically above one another or horizontally beside one another.
- The grid dimension of the panel cutouts for multiple devices must be at least 208 mm (8.19 in) horizontally and at least 162 mm (6.38 in) vertically (tolerance not considered).
- Securing to DIN 43 834

Field housing assembly and design (optional)

As an option, the device can be ordered ready-mounted in a field housing with IP65.

Dimensions (B x H x D) approx.: 320 mm (12.6 in) x 320 mm (12.6 in) x 254 mm (10 in)

Desktop housing assembly and design (optional)	As an option, the device can be ordered ready-mounted in a desktop housing. Dimensions (B x H x D) approx.: 293 mm (11.5 in) x 188 mm (7.4 in) x 213 mm (8.39 in) (dimensions with bracket, feet and installed device)
--	---

16.7 Environment

Ambient temperature range	-10 to +50 °C (14 to 122 °F)				
Storage temperature	-20 to +60 °C (-4 to +140 °F)				
Humidity	5 to 85 %, not condensating				
Climate class	To IEC 60654-1: Class B2				
Electrical safety	Class I equipment, overvoltage category II Pollution level 2				
Altitude	< 2 000 m (6 561 ft) above MSL				
Degree of protection	<table><tr><td>Front</td><td>IP65 / NEMA 4 (not assessed by UL)</td></tr><tr><td>Rear</td><td>IP20</td></tr></table>	Front	IP65 / NEMA 4 (not assessed by UL)	Rear	IP20
Front	IP65 / NEMA 4 (not assessed by UL)				
Rear	IP20				

Electromagnetic compatibility	EMC to all relevant requirements of the IEC/EN 61326- series and NAMUR NE21. For details see declaration of conformity. ■ Interference immunity: as per IEC/EN 61326 series (industrial environment) / NAMUR NE21 Maximum measured error <1% of measuring range ■ Interference emissions: as per IEC 61326-1 Class A
-------------------------------	---

16.8 Mechanical construction

Design, dimensions	Information about design and dimensions →  100						
Weight	■ Panel-mounted device with navigator and front interfaces (with maximum configuration): approx. 2.7 kg (5.9 lbs) ■ Panel-mounted device with stainless steel front and touchscreen (with maximum configuration): approx. 3.2 kg (7 lbs) ■ Desktop housing (excluding device): approx. 2.3 kg (5 lbs) ■ Field housing (excluding device): approx. 4 kg (8.8 lbs)						
Materials	<table><tr><th>Version with navigator and front interfaces</th><th></th></tr><tr><td>Front frame</td><td>Zinc die cast GD-Z410, powder-coated</td></tr><tr><td>Display glass</td><td>Transparent Makrolon® plastic (FR clear 099) UL94-V2</td></tr></table>	Version with navigator and front interfaces		Front frame	Zinc die cast GD-Z410, powder-coated	Display glass	Transparent Makrolon® plastic (FR clear 099) UL94-V2
Version with navigator and front interfaces							
Front frame	Zinc die cast GD-Z410, powder-coated						
Display glass	Transparent Makrolon® plastic (FR clear 099) UL94-V2						

Version with navigator and front interfaces	
Flap; jog/shuttle dial ("Navigator")	Plastic ABS UL94-V2
Membrane keypad	Polyester membrane PC-ABS UL94-V2
Intermediate frame (front towards control panel)	Plastic PA6-GF20 UL94-V2
Seal towards panel wall; seal in flap; seal towards navigator	Rubber EPDM 70 Shore A
Casing; rear panel	Galvanized sheet steel St 12 ZE

Version with stainless steel front and touchscreen	
Front frame	AISI 316L
Display glass	6 mm single-pane safety glass (soda-lime glass)
Intermediate frame (front towards control panel)	Plastic PA6-GF20 UL94-V2
Seal towards control panel wall	Rubber EPDM 70 Shore A
Window seal between front frame and glass	Rubber EPDM 60 Shore A
Casing; rear panel	Galvanized sheet steel St 12 ZE

Designation	Short form	Properties
AISI 316L (corresponds to 1.4404 or 1.4435)	X2CrNiMo17-13-2, X2CrNiMo18-14-3	Austenitic, stainless steel High corrosion resistance in general



All materials are silicone-free.

Materials of desktop housing

- Housing half-panels: sheet steel, electrolytically plated (powder-coated)
- Side sections: aluminum extruded section (powder-coated)
- Section ends: colored polyamide
- Feet: colored polyamide, fiber-glass reinforced

Field housing materials

- Housing (front frame, door, base frame, side parts): thermoplastic polycarbonate PC
- Front panel and wall mounting: chrome-nickel stainless steel 1.4301 V2A

16.9 Display and operating elements

Operating concept

The device can be operated directly onsite, or via remote configuration with the PC via interfaces and operating tools (Web server, configuration software).

Web server

A Web server is integrated into the device. The Web server offers the following range of functions:

- Easy configuration without additional installed software
- Instantaneous value display and diagnostics information
- Display of current measured value curves via Web browser (remote control)
- Loading/saving of device configuration
- Device firmware update
- Printout of device configuration

Integrated operating instructions

The device's simple control system enables you to perform commissioning for many applications without the need for hardcopy operating instructions. The device has an integrated help function and displays operating instructions directly on screen.

Local operation

Display elements*Type*

Wide-screen TFT color graphic display (optionally with touch control)

Size (diagonal screen measurement)

178 mm (7")

Resolution

Wide VGA 384,000 pixels (800 x 480 pixels)

Backlight

50,000 h half value time (= half brightness)

Number of colors

262,000 viewable colors, 256 colors used


Viewing angle

Max. viewing angle range: 50° in all directions from the display central axis

Screen display

- Users can choose between black or white for the background color
- Active channels can be assigned to up to 10 groups. To clearly identify these groups, they can be assigned a name, such as "temp. boiler 1" or "daily averages".
- Scales linear or logarithmic
- Measured value history: quick retrieval of historic data with zoom function
- Preformatted display formats, such as horizontal or vertical curves, instrument display, circular chart, process screen, bargraph or digital display.

Measured value display and operating elements



A0024709

19 Device front (left: version with navigator and front interfaces; right: version with stainless steel front and touchscreen)

Item No.	Operating function (display mode = display of measured values) (Setup mode = operating in the Setup menu)
a	Slot for SD card
b	USB B socket "Function" e.g. to connect to PC or laptop
c	USB A socket "Host" e.g. for USB memory stick, external keyboard, barcode reader or printer
d	LED at SD slot. Yellow LED lit or flashing when the device writes to the SD card or reads it. Do not remove the SD card if the LED is lit or flashing! Risk of data loss!
1	"Navigator": jog/shuttle dial for operating with additional press/hold function. In display mode: turn the dial to switch between the various signal groups. Press the dial to display the main menu. In setup mode or in a selection menu: turn the dial anticlockwise to move the bar or the cursor upwards or counterclockwise, changes the parameter. Turning clockwise moves the bar or cursor down or clockwise, changes parameter. Press = select highlighted function, start parameter change (ENTER key).
2	Functions of LED indicators (according to NAMUR NE44:) - Green LED (top) lit: power supply OK - Red LED (bottom) flashing: maintenance required, caused by external factor (e.g. cable open circuit etc.), or a message/notification requiring acknowledgment is pending, calibration is running.
3	Variable "soft keys", keys 1 to 4 (from left to right)
4	Function indicator of the "soft keys"
5	In display mode: current group name, type of analysis; In setup mode: name of the current operating item (dialog title)
6	In display mode: displays current date/time In setup mode: --
7	In display mode: user ID (if function is active) In setup mode: --

Item No.	Operating function (display mode = display of measured values) (Setup mode = operating in the Setup menu)
8	In display mode: alternating display indicating the percentage space on the SD card or USB stick that has already been used. Status symbols are also displayed in alternation with the memory information (e.g. simulation mode, data storage active, operation locked, batch active) In setup mode: the current "direct access" operating code is displayed
9	In display mode: window for measured value display (e.g. curve display). Display of current measured values and the status in the event of an error/alarm condition. In the case of counters, the type of counter is displayed as a symbol.  If a measuring point has limit value status, the corresponding channel identifier is highlighted in red (quick detection of limit value violations). During a limit value violation and device operation, the acquisition of measured values continues uninterrupted.
9	In setup mode: display of operating menu
10	In display mode: alternating status display (e.g. set zoom range) of the analog or digital inputs in the appropriate color of the channel. In setup mode: different information is displayed here depending on the display type.

Languages

The following languages can be selected in the operating menu: German, English, Spanish, French, Italian, Dutch, Swedish, Polish, Portuguese, Czech, Russian, Japanese, Chinese (Traditional), Chinese (Simplified)

Remote operation

Device access via operating tools

Device configuration and measured value retrieval can also be done via interfaces. The following operating tools are available for this purpose:

Operating tool	Functions	Access via
"Field Data Manager (FDM)" analysis software, SQL database support (included in the delivery)	- Export of saved data (measured values, analyses, event log) - Visualization and processing of saved data (measured values, analyses, event log) - Safe archiving of exported data in a SQL database	RS232/RS485, USB, Ethernet
Web server (integrated into the device; access via browser)	- Display of current and historical data and measured value curves via the web browser - Easy configuration without additional installed software - Remote access to device and diagnostic information	Ethernet
OPC server (optional)	The following momentary values can be provided: - Analog channels - Digital channels - Mathematics - Totalizer	RS232/RS485, USB, Ethernet
"FieldCare / DeviceCare" configuration software (included in the delivery)	- Device configuration - Loading and saving of device configurations (upload/download) - Documentation of the measuring point	USB, Ethernet

16.10 Certificates and approvals

CE mark

The measuring system meets the legal requirements of the applicable EC guidelines. These are listed in the corresponding EC Declaration of Conformity together with the standards applied. Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.

Ex approval	Information about currently available Ex versions (ATEX, FM, CSA, etc.) can be supplied by your E+H Sales Center on request. All explosion protection data are given in separate documentation which is available upon request.
UL approval	UL recognized component (see www.ul.com/database , search for Keyword "E225237")
Electronic recording/ electronic signature	FDA 21 CFR Part 11 The device meets the requirements of the "Food and Drug Administration" for electronic recording/electronic signature.
Certifications	■ HART® certification (HCF) ■ PROFINET certification ■ EtherNet/IP certification
Other standards and guidelines	■ IEC 60529: Degree of protection provided by housing (IP code) ■ IEC/EN 61010-1: Safety requirements for electrical equipment for measurement, control and laboratory use ■ IEC/EN 61326 Series: Electromagnetic compatibility (EMC requirements)

16.11 Ordering information



The hazardous area version (Ex version) is only available in conjunction with the stainless steel front and touch control.

Ordering information	Detailed ordering information is available from the following sources: ■ In the Product Configurator on the Endress+Hauser website: www.endress.com -> Click "Corporate" -> Select your country -> Click "Products" -> Select the product using the filters and search field -> Open product page -> The "Configure" button to the right of the product image opens the Product Configurator. ■ From your Endress+Hauser Sales Center: www.addresses.endress.com Product Configurator - the tool for individual product configuration ■ Up-to-the-minute configuration data ■ Depending on the device: Direct input of measuring point-specific information such as measuring range or operating language ■ Automatic verification of exclusion criteria ■ Automatic creation of the order code and its breakdown in PDF or Excel output format ■ Ability to order directly in the Endress+Hauser Online Shop
Scope of delivery	The scope of delivery of the device comprises: ■ Device (with terminals, as per order) ■ 2 fastening clips ■ Version with navigator and front interfaces: USB cable ■ Sealing rubber towards control panel wall ■ "Industrial Grade" SD card, industry standard: Version with navigator and front interfaces: card is located in the SD slot behind the flap on the front of the housing (optional). Version with stainless steel front and touchscreen: card is in the device and cannot be replaced or retrofitted.

- "Field Data Manager (FDM)" analysis software on DVD (Essential, Demo or Professional version, depending on order)
- "FieldCare Device Setup / DeviceCare" configuration software on DVD
- Delivery note
- Multilanguage Brief Operating Instructions, hard copy
- Ex Safety Instructions, hard copy (optional)

17 Appendix

17.1 Operating items in the "Expert" menu

The parameter groups for the Expert setup contain all the parameters of the operating menus: System, Input and Output Setup, Communication, Application, Diagnostics as well as other parameters that are reserved for experts only.

 For most settings, the "Setup" or "Expert" menu must be quit before the settings are adopted. However settings such as the date/time are accepted immediately.

Direct access

Navigation	 Expert → Direct access
Description	Direct access to active operating items (rapid access). Entering the direct access code takes you directly to the desired operating parameter. The direct access code is displayed in the Setup menu on the top right of the display (e.g. 00000-000).
Text entry	(e.g. 00000-000)

17.1.1 "System" submenu

Basic settings that are needed to operate the device (e.g. date, time, etc.)

Language

Navigation	 Expert → System → Language Direct access code: 010000-000
Description	Select unit operating language.
Options	German, English, Spanish, French, Italian, Dutch, Polish, Portuguese, Russian, Swedish, Czech, Japanese, Chinese (Simplified), Chinese (Traditional)
Factory setting	English; or preset to customer's preferred language

Device tag

Navigation	 Expert → System → Device tag Direct access code: 000031-000
Description	Individual device tag
User entry	Text entry (max. 32 characters)
Factory setting	Unit 1

Temp. unit		
Navigation		Expert → System → Temp. unit Direct access code: 100001-000
Description		Selection of temperature unit. All directly connected thermocouples or resistance thermometers (RTD) are displayed in the preset engineering units.
Options		°C, °F, K
Factory setting		°C
Decimal separator		
Navigation		Expert → System → Decimal separator Direct access code: 100003-000
Description		Select in which form the decimal separator character is to be displayed.
Options		Comma, point
Factory setting		Comma
Fault switching		
Navigation		Expert → System → Fault switching Direct access code: 100002-000
Description		If the device detects a system error (e.g. hardware defect) or a fault (e.g. cable open circuit), the selected output switches.
Options		Not used, Relay x All the available relays are displayed.
Factory setting		Relay 1
Keyboard layout		
Navigation		Expert → System → Keyboard layout Direct access code: 100020/000
Description		Please select the keyboard layout. Only relevant if external keyboard is used.

Options	Germany, Switzerland, France, USA, USA International, UK, Italy
----------------	---

Factory setting	Germany
------------------------	---------

Swap mouse buttons

Navigation	 Expert → System → Swap mouse buttons Direct access code: 100050/000
-------------------	--

Description	Swap function of left and right mouse button.
--------------------	---

Options	No, Yes
----------------	---------

Factory setting	No
------------------------	----

Paper size

Navigation	 Expert → System → Paper size Direct access code: 540004/000
-------------------	--

Description	Please select the paper size of your printer.
--------------------	---

Options	DIN A4, US Letter
----------------	-------------------

Factory setting	DIN A4
------------------------	--------

Lock operation

Navigation	 Expert → System → Lock operation Direct access code: 100060/000
-------------------	--

Description	Local operation is locked in cases of inactivity once the set time has elapsed to prevent inadvertent operation (e.g. when cleaning the device). The device is unlocked by pressing the navigator or the OK operating key for 3 s. When using an external keyboard, the device is unlocked with the key combination "Ctrl-Alt-Del".
--------------------	---

Options	Never, After 2 (5, 10, 15) minutes
----------------	------------------------------------

Factory setting	After 5 minutes
------------------------	-----------------

LED mode

Navigation	 Expert → System → LED mode Direct access code: 100005/000
Description	NAMUR NE 44: Green LED -> Power supply OK. Red LED -> Measuring signal failure. Red LED flashing -> Maintenance required. NAMUR NE 44+: As per NAMUR NE 44, with red LED in the event of a limit value violation.
Options	NAMUR NE 44, NAMUR NE 44+
Factory setting	NAMUR NE 44

PRESET

Navigation	 Expert → System → PRESET Direct access code: 000044-000
Description	Caution: Resets all the parameters to the factory settings!  Only visible/editable if the service code has been entered.
Options	No, Factory reset, Customer setting

Clear memory

Navigation	 Expert → System → Clear memory Direct access code: 059000-000
Description	Delete internal memory  Note: In the version with stainless steel front and touchscreen the internal SD card is also cleared.
Options	No, Yes

"Date/time setup" submenu

Navigation	 Expert → System → Date/time setup
Description	Contains settings for date/time.

Date format

Navigation	 Expert → System → Date/time setup → Date format Direct access code: 110000-000
-------------------	---

Description	Select in which format the date is to be set and displayed.
Options	DD.MM.YYYY, MM/DD/YYYY, YYYY-MM-DD
Factory setting	DD.MM.YYYY

Time format

Navigation	 Expert → System → Date/time setup → Time format Direct access code: 110001-000
Description	Select in which format the time is to be set and displayed.
Options	24 hour, 12 hour AM/PM
Factory setting	24 hour

"Date/time" submenu

Navigation	 Expert → System → Date/time setup → Date/time
Description	Contains parameters for setting the date/time.

UTC time zone

Navigation	 Expert → System → Date/time setup → Date/time → UTC time zone Direct access code: 120000-000
Description	Display of the current UTC time zone is on (UTC = universal time coordinated).

Current date/time

Navigation	 Expert → System → Date/time setup → Date/time → Current date/time Direct access code: 120003-000
Description	Displays the current date and the current time.

"Change date/time" submenu

Description	Contains parameters for changing the date/time.
Navigation	 Expert → System → Date/time setup → Change date/time

UTC time zone	
Navigation	 Expert → System → Date/time setup → Date/time → Change date/time → UTC time zone Direct access code: 120010-000
Description	Set your UTC time zone (UTC = universal time coordinated).
Options	-12:00, -11:00: Samoa, -10:00: Hawaii, -09:30: Marquesas, -09:00: Alaska, -08:00: LA, -07:00: Denver, -06:00: Chicago, -05:00: New York, -04:00: Caracas, -03:30: St.John's, -03:00: Brasilia, -02:00: Atlantic, -01:00: Azores, +00:00: London, +01:00: Berlin, +02:00: Cairo, +03:00: Moscow, +03:30: Tehran, +04:00: Abu Dhabi, +04:30: Kabul, +05:00: Islamabad, +05:30: New Delhi, +05:45: Kathmandu, +06:00: Dhaka, +06:30: Pyinmana, +07:00: Bangkok, +08:00: Peking, +08:45, +09:00: Tokyo, +09:30: Adelaide, +10:00: Canberra, +10:30: Lord-Howe, +11:00:Solom.Isl., +11:30: Norfolk, +12:00: Auckland, +12:45: Chatham, +13:00, +14:00
Date/time	
Navigation	 Expert → System → Date/time setup → Date/time → Change date/time → Date/time Direct access code: 120013-000
Description	Set the current date and time for the unit here.
User entry	Date/time in set format
"NT/ST changeover" submenu	
Navigation	 Expert → System → Date/time setup → NT/ST changeover
Description	Contains settings for normal time/summer time changeover.
NT/ST changeover	
Navigation	 Expert → System → Date/time setup → NT/ST changeover → NT/ST changeover Direct access code: 110002-000
Description	Function for summer/normal time changeover. Automatic: Changeover according to applicable directives for the selected region; Manual: Set changeover times in the next items; Off: No time changeover.
Options	Off, Manual, Automatic
Factory setting	Automatic

NT/ST region

Navigation	 Expert → System → Date/time setup → NT/ST changeover → NT/ST region Direct access code: 110003-000
Description	Selects the regional settings for summer/normal time changeover. Only visible if NT/ST changeover = automatic.
Options	Europe, USA
Factory setting	Europe

Begin summer time

Occurrence

Navigation	 Expert → System → Date/time setup → NT/ST changeover → Occurrence Direct access code: 110005-000
Description	Day, when in the spring a change from normal to summer time occurs. Visible for NT/ST changeover = Automatic or Manual. Only editable if NT/ST changeover = Manual.
Options	1st, 2nd, 3rd, 4th, Last
Factory setting	Last

Day

Navigation	 Expert → System → Date/time setup → NT/ST changeover → Day Direct access code: 110006-000
Description	Day, when in the spring a change from normal to summer time occurs. Visible for NT/ST changeover = Automatic or Manual. Only editable if NT/ST changeover = Manual.
Options	Sunday, Monday, Tuesday, Wednesday, Thursday, Friday, Saturday
Factory setting	Sunday

Month

Navigation	 Expert → System → Date/time setup → NT/ST changeover → Month Direct access code: 110007-000
Description	Month, when in the spring a change from normal to summer time occurs. Visible for NT/ST changeover = Automatic or Manual. Only editable if NT/ST changeover = Manual.
Options	January, February, March, April, May, June, July, August, September, October, November, December
Factory setting	March

Date

Navigation	 Expert → System → Date/time setup → NT/ST changeover → Date Direct access code: 110008-000
Description	Date next spring when a change from normal to summer time occurs. Only visible if NT/ST changeover = Automatic or Manual. Cannot be edited.

Time

Navigation	 Expert → System → Date/time setup → NT/ST changeover → Time Direct access code: 110009-000
Description	Point of time when the time is moved forward by 1 hour on the day of the changeover from normal time to summer time (in the set time format). Visible for NT/ST changeover = Automatic or Manual. Only editable if NT/ST changeover = Manual.
User entry	Time in set time format
Factory setting	02:00

End summer time

Occurrence

Navigation	 Expert → System → Date/time setup → NT/ST changeover → Occurrence Direct access code: 110011-000
Description	Day, when in the autumn a change from summer to normal time occurs. Visible for NT/ST changeover = Automatic or Manual. Only editable if NT/ST changeover = Manual.

Options 1st, 2nd, 3rd, 4th, Last

Factory setting Last

Day

Navigation  Expert → System → Date/time setup → NT/ST changeover → Day
Direct access code: 110012-000

Description Day, when in the autumn a change from summer to normal time occurs.
Visible for NT/ST changeover = Automatic or Manual. Only editable if NT/ST changeover = Manual.

Options Sunday, Monday, Tuesday, Wednesday, Thursday, Friday, Saturday

Factory setting Sunday

Month

Navigation  Expert → System → Date/time setup → NT/ST changeover → Month
Direct access code: 110013-000

Description Month, when in the autumn a change from summer to normal time occurs.
Visible for NT/ST changeover = Automatic or Manual. Only editable if NT/ST changeover = Manual.

Options January, February, March, April, May, June, July, August, September, October, November, December

Factory setting October

Date

Navigation  Expert → System → Date/time setup → NT/ST changeover → Date
Direct access code: 110014-000

Description Date next autumn when summer time changes back to normal time.
Only visible if NT/ST changeover = Automatic or Manual. Cannot be edited.

Time

Navigation	 Expert → System → Date/time setup → NT/ST changeover → Time Direct access code: 110015-000
Description	Point of time when the time is moved back by 1 hour on the day of the changeover from summer time to normal time (in the set time format). Visible for NT/ST changeover = Automatic or Manual. Only editable if NT/ST changeover = Manual.
User entry	Time in set time format
Factory setting	02:00

"SNTP" submenu

Navigation	 Expert → System → Date/time setup → SNTP
Description	Contains settings for time synchronization using the Simple Network Time Protocol (SNTP).

SNTP

Navigation	 Expert → System → Date/time setup → SNTP Direct access code: 110020-000
Description	If switched on, time synchronization is carried out via SNTP once a day. Note: Only possible via Ethernet. Port 123 must be open in the firewall. The user/network administrator is responsible for accuracy of the time server.
Options	No, Yes
Factory setting	No

SNTP server 1

Navigation	 Expert → System → Date/time setup → SNTP server → SNTP server 1 Direct access code: 110021-000
Description	Please specify the address of the time server (or the IP address). Note: The DNS server must be configured (see Communication/Ethernet). Your administrator can provide the address where necessary.
User entry	Text field

SNTP server 2

Navigation	 Expert → System → Date/time setup → SNTP Server → SNTP server 2 Direct access code: 110025-000
Description	Shows the IP address of the time server if it was automatically allocated via DHCP. Non-editable display text.  An attempt is always made to synchronize the time via SNTP server 1 first (provided it is configured) DHCP must be switched on (see Communication/Ethernet). DHCP server: Option 42

"Security" submenu

Navigation	 Expert → System → Security
Description	Contains settings that protect the unit against unauthorized operation and configuration.

Protected by

Navigation	 Expert → System → Security → Protected by Direct access code: 100006-000
Description	Configure how the device should be protected.
Options	Open access, access code, FDA 21 CFR Part 11, user roles
Factory setting	Open access

Access code

Navigation	 Expert → System → Security → Access code Direct access code: 100000-000
Description	Using this code setup access can be protected from unauthorized persons. In order to change any parameter the correct code must be entered. Factory setting: "0", i.e. changes can be made at any time. Hint: Make a note of the code and store in a safe place. Only visible if "Protected by" = "Access code"
User entry	4-digit number
Factory setting	0

Set point code

Navigation	 Expert → System → Security → Set point code Direct access code: 100030-000
Description	If the unit is protected by an access code a set point code can also be defined. The user can change the set points once the set point code is entered. All other operating positions remain locked, however. Only visible if an access code has been defined. Factory default: "0" means that alarm set points can only be changed by entering the access code.  Alarm set point code and access code should not be identical!
User entry	4-digit number
Factory setting	0

IP address

Navigation	 Expert → System → Security → IP address Direct access code: 190001-000
Description	Enter the IP address or DNS name of the PC on which user administration is running. Please contact your network administrator if necessary.
User entry	Text
Factory setting	0.0.0.0

Port

Navigation	 Expert → System → Security → Port Direct access code: 190002-000
Description	A connection to the host PC is established through this communication port.  If your network is protected by a firewall, this port may have to be enabled. Please contact your network administrator if this is the case.
User entry	5-digit number
Factory setting	8010

Lock hardware

Navigation	 Expert → System → Security → Lock hardware Direct access code: 100099-000
-------------------	--

Description	Device functions/interfaces that are not used can be switched off for security reasons.  Fieldbuses may also be affected in the case of Ethernet or the serial interface. Please follow the operating instructions.
Options	Ethernet (all ports/services), USB A socket front, USB A socket back, USB B socket front, Serial interface, SD card
Factory setting	No lock

"Authentication" submenu

Navigation  Expert → System → Security → Authentication

Description Define the passwords for the various user roles to allow device access.
Visible only if "Protected by" = "User roles"

Operator
ID: operator
Password

Navigation  Expert → System → Security → Authentication → Password
Direct access code: 470105/000

Description Enter a password for this user account.

Options Text entry max. 12 characters

Factory setting operator

Administrator
ID: admin
Password

Navigation  Expert → System → Security → Authentication → Password
Direct access code: 470102/000

Description Enter a password for this user account.

Options Text entry max. 12 characters

Factory setting admin

Service	
ID: service	
Password	

Navigation	 Expert → System → Security → Authentication → Password Direct access code: 470101/000
-------------------	--

Description	Enter a password for this user account.
--------------------	---

Options	Text entry max. 12 characters
----------------	-------------------------------

Factory setting	service
------------------------	---------

"External memory" submenu

Navigation	 Expert → System → External memory
-------------------	---

Description	Contains settings for the external data carrier, amongst other things which data is to be stored in which format on the external data carrier.
--------------------	--

Save as

Navigation	 Expert → System → External memory → Save as Direct access code: 140000-000
-------------------	---

Description	"Protected format": All data is stored in a manipulation protected encrypted format. They can be interpreted only by the PC analysis software provided. "Open format": data is stored in a CSV format, this can be opened by a number of different programs (e.g. MS Excel) (Attention: no manipulation security).
--------------------	---

Options	Protected format, Open format (*.csv)
----------------	---------------------------------------

	Note: For the device version with stainless steel front and touch operation, only the selection "protected format" is possible!
---	---

Factory setting	Protected format
------------------------	------------------

SD card

Memory build-up

Navigation	 Expert → System → External memory → Memory build-up Direct access code: 140001-000
-------------------	---

Description	"Stack memory": no more data can be stored once the data carrier is full. "Ring memory": once the data carrier is full the oldest data is deleted so that new data can be stored (First in first out (FIFO)).  The "Ring memory" setting refers only to the automatic storage of measured values. Manual save functions ("Operation -> SD card -> Update/Save measured values") are not affected.
Options	Stack memory, Ring memory (FIFO)  "Ring memory" can be selected only if "Save as" is set to "protected format" (and not "CSV").
Factory setting	Stack memory

Warning at

Navigation	 Expert → System → External memory → Warning at Direct access code: 140005-000
Description	Issues a warning before the data carrier is x% full. A warning is indicated on the device and this is also stored in the event buffer. A relay can also be switched.  Only for external SD card (does not apply to USB stick)!
User entry	0 to 99%
Factory setting	90

Switches relay

Navigation	 Expert → System → External memory → Switches relay Direct access code: 140006-000
Description	When the warning "Data carrier full" is displayed a relay can also be switched on.
Options	Not used, Relay x All the available relays are displayed.
Factory setting	Not used

CSV settings

 Also configurable if "Protected format" is set.

Separator for CSV

Navigation	 Expert → System → External memory → Separator for CSV Direct access code: 140002-000
Description	Configure which separator is used by your application (e.g. in Excel = semicolon).
Options	Comma, Semicolon
Factory setting	Semicolon

Date/time

Navigation	 Expert → System → External memory → Date/time Direct access code: 140003-000
Description	Please select if the date and time should be stored in one column or separate columns when data is saved in CSV format files.
Options	One column, Separate columns
Factory setting	Separate columns

Operating time

Navigation	 Expert → System → External memory → Operating time Direct access code: 140004-000
Description	Please select in which format operation times will be stored/displayed.
Options	0 seconds, 0.0000 hours, 0.00000 days, 0000h00:00
Factory setting	0000h00:00

"Messages" submenu

Navigation	 Expert → System → Messages
Description	Contains settings for displaying/acknowledging messages. Examples of messages include: messages triggered by set-points; messages triggered by a digital input; error messages; etc.

Acknowledging messages

Navigation	 Expert → System → Messages → Acknowledging messages Direct access code: 100040-000
Description	The time the message is acknowledged can be saved in the events list.  This setting cannot be altered if the user administration system is activated (FDA 21 CFR Part 11).
Options	Do not save, Save
Factory setting	Do not save

Switches relay

Navigation	 Expert → System → Messages → Switches relay Direct access code: 100042-000
Description	A relay can be switched as soon as a message that has to be confirmed is displayed (e.g. on/off message, device errors etc.). The relay assumes the initial status as soon as all messages have been confirmed.
Options	Not used, Relay x All the available relays are displayed.
Factory setting	Not used

"Screen saver" submenu

Navigation	 Expert → System → Screensaver
Description	To increase the life span of the LCDs the rear illumination can be switched off (= screen saver).

Screen saver

Navigation	 Expert → System → Screen saver → Screen saver Direct access code: 160000-000
Description	"Switched off": LCD is always switched on. "Switch on for x min.": display goes dark after x minutes. All other functions remain in operation. Press an operating key: Illumination is switched back on. "Switch daily": Enter time span.
Options	Switched off, On after 10 min, On after 30 min, On after 60 min, Switched daily, Control input
Factory setting	Switched off This setting has no effect if the screen saver is controlled by a digital input →  156.

ON daily from

Navigation	 Expert → System → Screen saver → ON daily from Direct access code: 160001-000
Description	Set time (hh:mm) as of when the screensaver should be switched on (e.g. shift end time).  The screen saver is switched off as soon as the device is operated via onsite operation. After 1 min of inactivity it switches back on automatically. Only visible if screen saver = switched daily
User entry	Time (hh:mm)
Factory setting	20:00

OFF daily from

Navigation	 Expert → System → Screen saver → OFF daily from Direct access code: 160002-000
Description	Set time (hh:mm) as of when the screensaver should be switched off (e.g. shift start time). Only visible if screen saver = switched daily
User entry	Time (hh:mm)
Factory setting	07:00

Alarm response

Navigation	 Expert → System → Screen saver → Alarm response Direct access code: 160003-000
Description	"Off on alarm": If limit value violations occur or status signal "Maintenance required (Mxxx)" or "Check function (Cxxx)" is active, the screensaver will be automatically deactivated. "Always on": If limit value violations occur or status signal "Maintenance required (Mxxx)" or "Check function (Cxxx)" is active, the screensaver will not be deactivated.  Active messages that require acknowledgment or an active status signal "Failure (Fxxx)" or "Out of specification (Sxxx)" deactivate the screensaver always.
Options	Off on alarm, Always on
Factory setting	Off on alarm

"Barcode reader" submenu

Navigation	 Expert → System → Barcode reader
Description	Settings for bar code reader (only relevant if a USB bar code reader is connected to the device).  Notes on operating a bar code reader: it must behave like a HID keyboard; texts must be terminated with a carriage return.

Character set

Navigation	 Expert → System → Barcode reader → Character set Direct access code: 100021-000
Description	Please select the keyboard layout.
Options	Germany, Switzerland, France, USA, USA International, UK, Italy
Factory setting	Germany

Save as event

Navigation	 Expert → System → Barcode reader → Save as event Direct access code: 100022-000
Description	The device can save texts read in using a bar code reader in the events list. Texts are stored as events if one of the following conditions is NOT met: ■ A command sequence was read in ■ The dialog where batch information is input is active ■ The dialog for testing the bar code reader is active ■ The "Save text" function is executed
Options	No, Yes
Factory setting	No

Timeout sequences

Navigation	 Expert → System → Barcode reader → Timeout sequences Direct access code: 100023-000
Description	Specify the number of seconds after which a command sequence is canceled if the necessary data are not read in.
User entry	Time in seconds (10-180)
Factory setting	30

"Device options" submenu

Navigation	 Expert → System → Device options
Description	Hardware and software options of the device.

Activation code

Navigation	 Expert → System → Device options → Activation code Direct access code: 000057-000
Description	Here, you can enter a code to enable the device options. Options that can be upgraded can be found under "Spare parts" →  77 Note: When an activation code is entered, the device is restarted in order to enable the new option.  ■ The activation code entered is not displayed, i.e. this parameter is always empty following a restart. ■ Pay attention to case-sensitivity.
User entry	Text

Slot 1

Navigation	 Expert → System → Device options → Slot 1 Direct access code: 990000-000
Description	Shows hardware or software options. Cannot be edited.  The assignment can be specified in the PC operating software for offline configuration.
Options	Not assigned, Universal inputs, HART

Slot 2

Navigation	 Expert → System → Device options → Slot 2 Direct access code: 990001-000
Description	Shows hardware or software options. Cannot be edited.  The assignment can be specified in the PC operating software for offline configuration.
Options	Not assigned, Universal inputs, HART

Slot 3

Navigation	 Expert → System → Device options → Slot 3 Direct access code: 990002-000
Description	Shows hardware or software options. Cannot be edited.  The assignment can be specified in the PC operating software for offline configuration.
Options	Not assigned, Universal inputs, HART

Slot 4

Navigation	 Expert → System → Device options → Slot 4 Direct access code: 990003-000
Description	Shows hardware or software options. Cannot be edited.  The assignment can be specified in the PC operating software for offline configuration.
Options	Not assigned, Universal inputs, HART

Slot 5

Navigation	 Expert → System → Device options → Slot 5 Direct access code: 990004-000
Description	Shows hardware or software options. Cannot be edited.  The assignment can be specified in the PC operating software for offline configuration.
Options	Not assigned, Universal inputs, Digital inputs, HART

Communication

Navigation	 Expert → System → Device options → Communication Direct access code: 990006-000
Description	Shows hardware or software options. Cannot be edited.

Options USB + Ethernet, USB + Ethernet + RS232/485

Fieldbus

Navigation  Expert → System → Device options → Fieldbus
Direct access code: 990005-000

Description Shows hardware or software options.
Cannot be edited.

Options Not available, Modbus Slave, Profibus DP, EtherNet/IP, PROFINET

Modbus Master

Navigation  Expert → System → Device options → Modbus Master
Direct access code: 990008-000

Description Shows hardware or software options.
Cannot be edited.

 Detailed descriptions of this device option can be found in the associated documentation.

Options No, Yes

Application

Navigation  Expert → System → Device options → Application
Direct access code: 990007-000

Description Shows hardware or software options.
Cannot be edited.

Options Standard, Mathematics, Tele-Alarm, Tele-Alarm + wastewater, Batch, Tele-Alarm + batch, Energy, Energy + Tele-Alarm

17.1.2 "Inputs" submenu
Settings for analog and digital inputs.

"Universal inputs" submenu

Navigation  Expert → System → Inputs → Universal inputs

Description Settings for the connected measuring points.

Add input

Navigation  Expert → System → Inputs → Universal inputs → Add input
Direct access code: 222000/000

Description Addition of an input that must be switched on and configured according to the input signal.

Options No, universal input x

Factory setting No

Delete input

Navigation  Expert → System → Inputs → Universal inputs → Delete input
Direct access code: 222001/000

Description Delete an input configuration.

Options No, universal input x

Factory setting No

"Universal input x" submenu

Navigation  Expert → System → Inputs → Universal inputs → Universal input x

Description View or change settings for the selected channel.

 x = place holder for selected universal input

Signal

Navigation  Expert → Inputs → Universal inputs → Universal input x → Signal
Direct access code: 220000-0xx
Examples: Universal input 1: 220000-000; Universal input 12: 220000-011

Description Select the type of signal connected (current, voltage, etc.). The channel is switched off if no signal type is selected (factory default).

Options Switched off, Current, Voltage, Resistance thermometer (RTD), Thermocouple, Pulse counter, Frequency input, Profibus DP (option), Modbus Slave (option), Modbus Master (option), HART (option), EtherNet/IP (option), PROFINET (option)

Factory setting Switched off

Range

Navigation  Expert → Inputs → Universal inputs → Universal input x → Range
 Direct access code: 220001-0xx
 Examples: Universal input 1: 220001-000; Universal input 12: 220001-011

Description Select the input range or which resistance thermometer/thermocouple is connected. The respective terminal layout can be found in the operating manual or on the rear of the unit.
 Only visible if signal ≠ switched off

Options Switched off
 Current: 4-20 mA, 0-20 mA, 0-5 mA, 0-20 mA squared, 4-20 mA squared, ±20 mA
 Voltage: 0-1 V, 0-10 V, 0-5 V, 1-5 V, ±150 mV, ±1 V, ±10 V, ±30 V, 0-1 V squared, 0-10 V squared, 1-5 V squared
 Resistance thermometer: Pt100 (IEC), Pt100 (JIS), Pt100 (GOST), Pt500 (IEC), Pt500 (JIS), Pt1000 (IEC), Pt1000 (JIS), Pt46 (GOST), Pt50 (GOST), Cu50 (GOST, α=4260), Cu50 (GOST, α=4280), Cu53 (GOST, α=4280), Cu100 (GOST, α=4280)
 Thermocouple: Type A (W5Re-W20Re), type B (Pt30Rh-Pt6Rh), type C (W5Re-W26Re), type D (W3Re-W25Re), type J (Fe-CuNi), type K (NiCr-Ni), type L (Fe-CuNi), type L (NiCr-CuNi, GOST), type N (NiCrSi-NiSi), type R (Pt13Rh-Pt), type S (Pt10Rh-Pt), type T (Cu-CuNi)
 Pulse counter
 Frequency input
 Profibus DP (option)
 Modbus (option)
 Modbus Master (option)
 HART (option)
 EtherNet/IP (option)
 PROFINET (option)

Factory setting Switched off

Value

Navigation  Expert → Inputs → Universal inputs → Universal input x → Value
 Direct access code: 220023-0xx
 Examples: Universal input 1: 220023-000; Universal input 12: 220023-011

Description Specify the value, which was read out digitally via HART, that should be recorded/processed.
 Only visible if signal = HART

Options Switched off, Value x
 All the available values are displayed.

Factory setting Switched off

Measured value type

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Measured value type Direct access code: 220022-0xx Examples: Universal input 1: 220022-000; Universal input 12: 220022-011
Description	Type of measured value received. Only visible if signal = HART or Modbus Master.
Options	Instantaneous value, Counter
Factory setting	Instantaneous value

Connection

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Connection Direct access code: 220002-0xx Examples: Universal input 1: 220002-000; Universal input 12: 220002-011
Description	Specify whether RTDs are connected as 2-, 3- or 4-wire systems. Only visible if signal = resistance thermometer
Options	2-wire, 3-wire, 4-wire
Factory setting	4-wire

Transmission protocol

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Transmission protocol Direct access code: 220049-0xx Examples: Universal input 1: 220049-000; Universal input 12: 220049-011
Description	Modbus TCP: Addressing Modbus TCP slaves. Modbus TCP with slave address: Addressing gateways which use a table to link the address to the right slave. Modbus RTU via TCP: Transmission of the pure Modbus RTU protocol with CRC sum. Used in signal converters for Ethernet -> RS485. Only visible if signal = Modbus Master
Options	Modbus TCP, Modbus TCP with slave address, Modbus RTU over TCP
Factory setting	Modbus TCP

IP address

Navigation	 Expert → Inputs → Universal inputs → Universal input x → IP address Direct access code: 220041-0xx Examples: Universal input 1: 220041-000; Universal input 12: 220041-011
-------------------	--

Description	Address of the Modbus Slave Only visible if signal = Modbus Master
--------------------	---

User entry	IP address
-------------------	------------

Factory setting	0.0.0.0
------------------------	---------

Port

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Port Direct access code: 220048-0xx Examples: Universal input 1: 220048-000; Universal input 12: 220048-011
-------------------	--

Description	Modbus slave port Only visible if signal = Modbus Master
--------------------	---

User entry	Number (max. 5 digits)
-------------------	------------------------

Factory setting	502
------------------------	-----

Slave address

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Slave address Direct access code: 220040-0xx Examples: Universal input 1: 220040-000; Universal input 12: 220040-011
-------------------	---

Description	Address of the Modbus Slave Only visible if signal = Modbus Master
--------------------	---

User entry	Number (1...255)
-------------------	------------------

Factory setting	1
------------------------	---

Readout function

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Readout function Direct access code: 220042-0xx Examples: Universal input 1: 220042-000; Universal input 12: 220042-011
-------------------	--

Description	Modbus function with which the registers are to be read out. Only visible if signal = Modbus Master
--------------------	--

Options Read Input Register (3xxxxx), Read Holding Register (4xxxxx)

Factory setting Read Input Register (3xxxxx)

Register address

Navigation  Expert → Inputs → Universal inputs → Universal input x → Register address
Direct access code: 220043-0xx
Examples: Universal input 1: 220043-000; Universal input 12: 220043-011

Description Register address 1-65535
Only visible if signal = Modbus Master

User entry Number (1...65535)

Factory setting 1

Data type

Navigation  Expert → Inputs → Universal inputs → Universal input x → Data type
Direct access code: 220044-0xx
Examples: Universal input 1: 220044-000; Universal input 12: 220044-011

Description Describes the data type of the value received and its sequence of bytes.
Only visible if signal = Modbus Master

Options INT16, UINT16, INT32_B, INT32_L, UINT32_B, UINT32_L, FLOAT_B, FLOAT_L, DOUBLE_B, DOUBLE_L

Factory setting FLOAT_B

Channel ident.

Navigation  Expert → Inputs → Universal inputs → Universal input x → Channel ident.
Direct access code: 220003-0xx
Examples: Universal input 1: 220003-000; Universal input 12: 220003-011

Description Name of the measuring point connected to this input.
Only visible if signal ≠ switched off

User entry Text (16 characters)

Factory setting Channel x

Plot type	
Navigation	 Expert → Inputs → Universal inputs → Universal input x → Plot type Direct access code: 220016-0xx Examples: Universal input 1: 220016-000; Universal input 12: 220016-011
Description	The analog inputs are scanned in a 100ms cycle. Depending on the memory cycle, the selected data is determined, saved, and displayed based on the scanned values.
Options	Instantaneous value, Average, Minimum value, Maximum value, Minimum + Maximum, Counter, Current value + Counter
Factory setting	Average
Time base	
Navigation	 Expert → Inputs → Universal inputs → Universal input x → Time base Direct access code: 220025-0xx Examples: Universal input 1: 220025-000; Universal input 12: 220025-011
Description	A current value can be determined from the counter reading with the aid of the time base e.g. input liters, time base = second → current value = liters/second. Only visible if signal = "Pulse counter" and plot type = "Current value + counter"
Options	Second (s), Minute (min), Hour (h), Day (d)
Factory setting	Second (s)
Engineering unit	
Navigation	 Expert → Inputs → Universal inputs → Universal input x → Engineering unit Direct access code: 220004-0xx Examples: Universal input 1: 220004-000; Universal input 12: 220004-011
Description	Specify the technical (physical) unit for the measuring point connected to this input. Only visible if signal ≠ switched off
User entry	Text (6 characters)
Unit/dimension counter	
Navigation	 Expert → Inputs → Universal inputs → Universal input x → Unit/dimension counter Direct access code: 220024-00x Examples: Universal input 1: 220024-000; Universal input 12: 220024-011

Description Technical units of the count input, e.g. gal, cf
Only visible if signal = "Pulse counter" and plot type = "Current value + counter"

User entry Text (max. 6 characters)

Pulse counter

Navigation  Expert → Inputs → Universal inputs → Universal input x → Pulse counter
Direct access code: 220017-0xx
Examples: Universal input 1: 220017-000; Universal input 12: 220017-011

Description Please check if the pulse counter used is a fast or slow (up to a max. 25 Hz) counter. For example if the number of state changes from a relay are to be monitored then you must set up "up to 25Hz".
Only visible if signal = pulse counter

Options Up to 13kHz, Up to 25Hz

Factory setting Up to 13kHz

Pulse value

Navigation  Expert → Inputs → Universal inputs → Universal input x → Pulse value
Direct access code: 220010-0xx
Examples: Universal input 1: 220010-000; Universal input 12: 220010-011

Description Factor, that when multiplied by the input signal results in the required physical value.
Example: 1 pulse equals 5 m³-> enter "5".
Only visible if signal = pulse counter

User entry Number, max. 8 digits

Factory setting 1

Calc. factor

Navigation  Expert → Inputs → Universal inputs → Universal input x → Calc. factor
Direct access code: 220045-0xx
Examples: Universal input 1: 220045-000; Universal input 12: 220045-011

Description Factor for converting the counter (e.g. the transmitter returns m³/100 -> desired unit is m³ --> enter 0.01 as the factor)
Only visible if signal = Modbus Master

User entry Number (max. 15 digits)

Factory setting 1.0

Decimal point

Navigation  Expert → Inputs → Universal inputs → Universal input x → Decimal point
 Direct access code: 220005-0xx
 Examples: Universal input 1: 220005-000; Universal input 12: 220005-011

Description Number of places after decimal point for the display.
 Only visible if signal ≠ switched off

Options None, One (X.Y), Two (X.YY), Three (X.YYY), Four (X.YYYY), Five (X.YYYYY)

Factory setting One (X.Y)

Start value range

Navigation  Expert → Inputs → Universal inputs → Universal input x → Start value range
 Direct access code: 220046-0xx
 Examples: Universal input 1: 220046-000; Universal input 12: 220046-011

Description Scaling of the Modbus value
 Here, enter the lower-range value for the scale which corresponds to the start of the measuring range.
 Only visible if signal = Modbus Master

User entry Number (max. 8 digits)

Factory setting 0

End value range

Navigation  Expert → Inputs → Universal inputs → Universal input x → End value range
 Direct access code: 220047-0xx
 Examples: Universal input 1: 220047-000; Universal input 12: 220047-011

Description Scaling of the Modbus value
 Here, enter the upper-range value for the scale which corresponds to the end of the measuring range.
 Only visible if signal = Modbus Master

User entry Number (max. 8 digits)

Factory setting 100

Lower frequency

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Lower frequency Direct access code: 220018-0xx Examples: Universal input 1: 220018-000; Universal input 12: 220018-011
Description	Configure the lower frequency that corresponds to the start of the measuring range. Only visible if signal = frequency input
User entry	0...12500 (Hz)
Factory setting	5.0 (Hz)

Range start

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Range start Direct access code: 220006-0xx Examples: Universal input 1: 220006-000; Universal input 12: 220006-011
Description	Transmitters convert the physical measured variable to standardized signals. Enter the start of the measuring range here.  ▪ The start and end of the measuring range may not be identical. ▪ The start of the measuring range can also be larger than the end (e.g. for deep wells). ▪ The parameter can be defined independently of the number of decimal places configured for the measured value as these are only taken into consideration for the display.
User entry	Number (max. 8 digits)
Factory setting	0 (Depends on the input signal selected)

Upper frequency

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Upper frequency Direct access code: 220019-0xx Examples: Universal input 1: 220019-000; Universal input 12: 220019-011
Description	Configure the upper frequency that corresponds to the end of the measuring range. Only visible if signal = frequency input
User entry	0...12500 (Hz)
Factory setting	1000.0 (Hz)

Meas. range end	
Navigation	 Expert → Inputs → Universal inputs → Universal input x → Meas. range end Direct access code: 220007-0xx Examples: Universal input 1: 220007-000; Universal input 12: 220007-011
Description	Transmitters convert the physical measured variable to standardized signals. Enter the end of the measuring range here.  ▪ The start and end of the measuring range may not be identical. ▪ The end of the measuring range can also be smaller than the start (e.g. for deep wells). ▪ The parameter can be defined independently of the number of decimal places configured for the measured value as these are only taken into consideration for the display.
User entry	Number (max. 8 digits)
Factory setting	100 (Depends on the input signal selected)
Zoom start	
Navigation	 Expert → Inputs → Universal inputs → Universal input x → Zoom start Direct access code: 220011-0xx Examples: Universal input 1: 220011-000; Universal input 12: 220011-011
Description	If the whole value range is not used, you can configure the lower value of the required section here. Zooming does not affect the save function.  ▪ The zoom can also be set outside the measuring range. The only restriction is that the start and end of the zoom may not be identical. ▪ If the signal or the range is changed, the zoom is corrected if it no longer fits the measuring range. ▪ The zoom start can also be larger than the zoom end. The device will automatically rotate the values on the display.
User entry	Number (max. 8 digits)
Factory setting	0 (Depends on the input signal selected)
Zoom end	
Navigation	 Expert → Inputs → Universal inputs → Universal input x → Zoom end Direct access code: 220012-0xx Examples: Universal input 1: 220012-000; Universal input 12: 220012-011

Description	Like "Zoom start". However, enter the upper value of the required range here.  ▪ The zoom can also be set outside the measuring range. The only restriction is that the start and end of the zoom may not be identical. ▪ If the signal or the range is changed, the zoom is corrected if it no longer fits the measuring range. ▪ The zoom end can also be smaller than the zoom start. The device will automatically rotate the values on the display.
User entry	Number (max. 8 digits)
Factory setting	100 (Depends on the input signal selected)

Damping

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Damping Direct access code: 220008-0xx Examples: Universal input 1: 220008-000; Universal input 12: 220008-011
Description	The more unwanted interference there is on the measurement signal the higher the value that should be entered here. Result: Fast changes will be damped/suppressed. Only visible if signal = current, voltage, resistance thermometer or thermocouple
User entry	0 to 999.9 s
Factory setting	Current, voltage: 0.0 s Resistance thermometer, thermocouple: 0.2 s

Comparison point

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Comparison point Direct access code: 220013-0xx Examples: Universal input 1: 220013-000; Universal input 12: 220013-011
Description	Intern: Compensation of the voltage error by measuring the terminal temperature. Extern: Compensation of the voltage error by using an external controlled comparison measurement point. Only visible if signal = thermocouple
Options	Internal, External
Factory setting	Internal

Comparison temp.

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Comparison temp. Direct access code: 220014-0xx Examples: Universal input 1: 220014-000; Universal input 12: 220014-011
Description	Settings for the external comparison temperature (only when connecting thermocouples). Only visible if comparison point = external
User entry	0...9999999 (Depends on the temperature unit selected)
Factory setting	0 (Depends on the temperature unit selected)

Totalizer

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Totalizer Direct access code: 220015-0xx Examples: Universal input 1: 220015-000; Universal input 12: 220015-011
Description	Initial setting for the totalizer. Useful when continuing measurements recorded to date with an (electro)-mechanical counter. Only visible if signal = pulse counter or counter for Modbus Master
User entry	Number (max. 15 digits)
Factory setting	0

"Linearization" submenu

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Linearization
Description	Contains settings for linearization.  Only current and voltage inputs can be linearized.

Linearization

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Linearization → Linearization Direct access code: 230000-0xx Examples: Universal input 1: 230000-000; Universal input 12: 230000-011
Description	Specify whether this analog input should be linearized.
Options	No, Yes
Factory setting	No

Number of Points

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Linearization → Number of points Direct access code: 230001-0xx Examples: Universal input 1: 230001-000; Universal input 12: 230001-011
Description	Specify how many support points your linearization table has.  Note: The first and last point always has to correspond to the start and end of the measuring range respectively.
User entry	2...32
Factory setting	2

Dim. linearized value

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Linearization → Dim. linearized value Direct access code: 230002-0xx Examples: Universal input 1: 230002-000; Universal input 12: 230002-011
Description	Unit/dimension for the linearized value.
User entry	Text (max. 6 characters)

Zoom start

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Linearization → Zoom start Direct access code: 230003-0xx Examples: Universal input 1: 230003-000; Universal input 12: 230003-011
Description	If the total transmitter range is not used, you can enter the lower value of the required section here (higher resolution). Example: Transmitter 0-14 pH, required section: 5-9 pH. Set "5" here. Zooming does not affect the save function.
User entry	0...9999999
Factory setting	0

Zoom end

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Linearization → Zoom end Direct access code: 230004-0xx Examples: Universal input 1: 230004-000; Universal input 12: 230004-011
Description	Like "Zoom start". However, enter the upper value of the required range here. Example: Transmitter 0-14 pH, required section: 5-9 pH. Input here: "9".
User entry	0...9999999
Factory setting	100

Points

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Linearization → Points
Description	Enter the support points of the linearization table here. Note: The first and last point always has to correspond to the start and end of the measuring range respectively. The support points can only be viewed in the PC software here. To change the support points use the "Edit table" switch.

Sort table

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Linearization → Points → Sort table Direct access code: 230020-0xx Examples: Universal input 1: 230020-000; Universal input 12: 230020-011
Description	You can sort the linearization table here.
Options	No, Yes
Factory setting	No

Check table

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Linearization → Points → Check table Direct access code: 230008-0xx Examples: Universal input 1: 230008-000; Universal input 12: 230008-011
Description	Here you can check whether the linearization table has been entered correctly.
Options	No, Yes
Factory setting	No

x-value (1...32)

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Linearization → Points → x-value (1...32) Direct access code, x-value 1: 230100-0xx Direct access code, x-value 2: 230102-0xx Examples: Universal input 1, x-value 1: 230100-000; Universal input 12, x-value 1: 230100-011
Description	x-value for the linearization (value from the device input). e.g. 10 cm corresponds to 20 liters --> enter 10.
User entry	0...99999999
Factory setting	0

y-value (1...32)

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Linearization → Support points → y-value (1...32) Direct access code, y-value 1: 230101-0xx Direct access code, y-value 2: 230103-0xx Examples: Universal input 1, y-value 1: 230101-000; Universal input 12, y-value 1: 230101-011
Description	Enter the y-value that the measured x-value corresponds to e.g. 10 cm corresponds to 20 liters --> enter 20.
User entry	0...99999999
Factory setting	0

"Meas. val. corrct" submenu

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Meas. val. corrct
Description	Determining the correction values to balance measurement tolerances. Proceed as follows: ■ Measure the current value at the lower measurement range. ■ Measure the current value at the upper measurement range. ■ Enter the lower and upper target and actual value.

Offset

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Meas. val. corrct → Offset Direct access code: 220050-0xx Examples: Universal input 1: 220050-000; Universal input 12: 220050-011
-------------------	--

Description This offset is only effective on the analog input signal (no maths / bus channels).
Only visible if signal = resistance thermometer or thermocouple

User entry Number (max. 8 digits)

Factory setting 0

Correction RPT

Navigation  Expert → Inputs → Universal inputs → Universal input x → Meas. val. correct →
Correction RPT
Direct access code: 220057-0xx
Examples: Universal input 1: 220057-000; Universal input 12: 220057-011

Description Rear panel temperature correction value for this analog input (only required for thermocouples).

 Only visible/editable if the service code has been entered.

User entry Number (max. 8 digits)

Factory setting -0.1

Range start

Target value

Navigation  Expert → Inputs → Universal inputs → Universal input x → Meas. val. correct → Target
value
Direct access code: 220052-0xx
Examples: Universal input 1: 220052-000; Universal input 12: 220052-011

Description Enter the lower setpoint here (e.g. measuring range 0°C to 100°C: 0°C).
Only visible if signal = current or voltage

User entry Number (max. 8 digits)

Factory setting 0

Actual value

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Meas. val. correct → Actual value Direct access code: 220053-0xx Examples: Universal input 1: 220053-000; Universal input 12: 220053-011
Description	Enter the lower value actually measured here (e.g. measuring range 0°C to 100°C: measured value 0.5°C). Only visible if signal = current or voltage
User entry	Number (max. 8 digits)
Factory setting	0

Meas. range end

Target value

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Meas. val. correct → Target value Direct access code: 220055-0xx Examples: Universal input 1: 220055-000; Universal input 12: 220055-011
Description	Enter the upper setpoint here (e.g. measuring range 0°C to 100°C: 100°C). Only visible if signal = current or voltage
User entry	Number (max. 8 digits)
Factory setting	100

Actual value

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Meas. val. correct → Actual value Direct access code: 220056-0xx Examples: Universal input 1: 220056-000; Universal input 12: 220056-011
Description	Enter the upper value actually measured here (e.g. measuring range 0°C to 100°C: measured value 100.5°C). Only visible if signal = current or voltage
User entry	Number (max. 8 digits)
Factory setting	100

"Totalization" submenu

Navigation  Expert → Inputs → Universal inputs → Universal input x → Totalization

Description Set up only required for totalization of flow or power consumption.

Totalization

Navigation  Expert → Inputs → Universal inputs → Universal input x → Totalization → Totalization
 Direct access code: 220030-0xx
 Examples: Universal input 1: 220030-000; Universal input 12: 220030-011

Description By totalizing the analog signal (e.g. flow rate in m³/h) quantities (in m³) can be calculated.

Options No, Yes

Factory setting No

Totalization base

Navigation  Expert → Inputs → Universal inputs → Universal input x → Totalization → Totalization base
 Direct access code: 220031-0xx
 Examples: Universal input 1: 220031-000; Universal input 12: 220031-011

Description Select the required time base. Example: ml/s -> time base seconds (s); m³/h -> time base hours (h).
 Only visible if totalization = yes

Options Second (s), Minute (min), Hour (h), Day (d)

Factory setting Second (s)

Unit

Navigation  Expert → Inputs → Universal inputs → Universal input x → Totalization → Unit
 Direct access code: 220032-0xx
 Examples: Universal input 1: 220032-000; Universal input 12: 220032-011

Description Enter the unit for the calculated quantity (e.g. "m³").
 Only visible if totalization = yes

User entry Text (max. 6 characters)

Low flow cut off

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Totalization → Low flow cut off Direct access code: 220033-0xx Examples: Universal input 1: 220033-000; Universal input 12: 220033-011
Description	If the volume flow recorded is below the set value, these quantities are not added to the counter. If the input is scaled from 0 to y, or if the pulse input is used, all values that are smaller than the set value are not recorded. If the input is scaled from -x to +y, all values around the zero point (e.g. also negative values) are not recorded. Only visible if totalization = yes
User entry	Number (max. 8 digits)
Factory setting	0

Calc. factor

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Totalization → Calc. factor Direct access code: 220034-0xx Examples: Universal input 1: 220034-000; Universal input 12: 220034-011
Description	Factor for calculating the integrated value (e.g. the transmitter delivers l/s → totalization base = second → engineering unit required is m ³ → enter factor 0.001) Only visible if totalization = yes
User entry	Number (max. 8 digits)
Factory setting	1.0

Totalizer

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Totalization → Totalizer Direct access code: 220035-0xx Examples: Universal input 1: 220035-000; Universal input 12: 220035-011
Description	Initial setting for the totalizer. Useful when continuing measurements recorded to date with an (electro)-mechanical counter. Only visible if totalization = yes
User entry	Number (max. 15 digits)
Factory setting	0

"Fault mode" submenu



In the event of an error the alarm relay is switched if so configured → 110

Navigation

Expert → Inputs → Universal inputs → Universal input x → Fault mode

Description

Contains settings that define how this channel is to react under fault conditions (e.g. cable open circuit, over range).

NAMUR NE 43

Navigation

Expert → Inputs → Universal inputs → Universal input x → Fault mode → NAMUR NE 43

Direct access code: 220060-0xx

Examples: Universal input 1: 220060-000; Universal input 12: 220060-011

Description

Activate/deactivate the 4-20mA loop monitoring as per NAMUR recommendation NE 43. The following error ranges apply when NAMUR NE43 is switched on:

≤ 3.8 mA: under range

≥ 20.5 mA: over range

≤ 3.6 mA or ≥ 21.0 mA: sensor error

≤ 2 mA: cable open circuit

Only visible if signal = "Current" and range = "4-20 mA" or "4-20 mA squared".

Options

Off, On

Factory setting

On

Cable open circ.

Navigation

Expert → Inputs → Universal inputs → Universal input x → Fault mode → Cable open circ.

Direct access code: 220060-0xx

Examples: Universal input 1: 220060-000; Universal input 12: 220060-011

Description

Cable open circuit detection

Only visible if signal = "Voltage" and range = "1-5 V" or "1-5 V squared".

Options

Off, On

Factory setting

On

Lower error value

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Fault mode → Lower error value Direct access code: 220065-0xx Examples: Universal input 1: 220065-000; Universal input 12: 220065-011
Description	When NE43 is switched off, defines the value that must be undershot for the device to output an error. Only visible if signal = "Current", range = "4-20 mA", and NAMUR NE 43 = "Off"
User entry	Number (max. 8 digits); 0 to 4 mA
Factory setting	3.9mA

Upper error value

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Fault mode → Upper error value Direct access code: 220066-0xx Examples: Universal input 1: 220066-000; Universal input 12: 220066-011
Description	When NE43 is switched off, defines the value that must be exceeded for the device to output an error. Only visible if signal = "Current", range = "4-20 mA", and NAMUR NE 43 = "Off"
User entry	Number (max. 8 digits); 20 to 22mA
Factory setting	20.8mA

Time delay

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Fault mode → Time delay Direct access code: 220064-0xx Examples: Universal input 1: 220064-000; Universal input 12: 220064-011
Description	The device only reacts (e.g. Relay switch) when this condition, open circuit/under range/over range, has been operational for the preset time. Only visible if NAMUR NE 43 = on
User entry	0...99 s
Factory setting	0s

On error

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Fault mode → On error Direct access code: 220061-0xx Examples: Universal input 1: 220061-000; Universal input 12: 220061-011
Description	Configure what value the device should continue working with (for calculations) if the measured value is not valid (e.g. cable open circuit).  In the event of an error value, all the dependent calculations are flagged accordingly as "error value". Counters are not flagged, however!
Options	Invalid calculation, Error value
Factory setting	Invalid calculation

Error value

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Fault mode → Error value Direct access code: 220062-0xx Examples: Universal input 1: 220062-000; Universal input 12: 220062-011
Description	The device continues calculating with this value in the event of an error. Only visible if On error = Error value
User entry	Number (max. 8 digits)
Factory setting	0

Save event

Navigation	 Expert → Inputs → Universal inputs → Universal input x → Fault mode → Save event Direct access code: 220063-0xx Examples: Universal input 1: 220063-000; Universal input 12: 220063-011
Description	Stores a message in the event log when a fault occurs.
Options	No, Yes
Factory setting	No

Copy settings

Navigation	 Expert → Inputs → Universal inputs → Universal input x → → Copy settings Direct access code: 220200-0xx Examples: Universal input 1: 220200-000; Universal input 12: 220200-011
Description	Copies settings from actual channel to selected channel.

Options Switched off, Universal input x
Users can choose from all the available universal inputs.

Factory setting Switched off

Submenu "Digital inputs -> Digital input x"

Navigation  Expert → Inputs → Digital inputs → Digital input x

Description Setting up only required if the digital inputs (e.g. events) are to be used.

 x = place holder for selected digital input

Add input

Navigation  Expert → System → Digital inputs → Add input
Direct access code: 252000/000

Description Addition of a digital input that must be configured according to the function.

Options No, Digital input x

Factory setting No

Delete input

Navigation  Expert → System → Digital inputs → Delete input
Direct access code: 252001/000

Description Delete an input configuration.

Options No, Digital input x

Factory setting No

Function

Navigation  Expert → Inputs → Digital inputs → Digital input x → Function
Direct access code: 250000-00x
Examples: Digital input 1: 250000-000; Digital input 6: 250000-005

Description Select the required function: Digital inputs are High active; this means the described effect is achieved by a high input.
Low = -3...+5V
High = +12...+30V

Options Switched off, control input, on/off event, pulse counter, operational time, event+operation time, quantity from time, Profibus DP (option), Modbus slave (option), EtherNet/IP (option), PROFINET (option)

Factory setting Switched off

Function

Navigation  Expert → Inputs → Digital inputs → Digital input x → Function
Direct access code: 250014-00x
Examples: Digital input 1: 250014-000; Digital input 6: 250014-005

Description Specifies how the data from the fieldbus is interpreted/processed.
Visible only if function = Profibus DP, Modbus slave, EtherNet/IP, PROFINET

Options Switched off, Control input, On/off event, Pulse counter, Operational time, Event +operation time, Quantity from time

Factory setting Switched off

Channel ident.

Navigation  Expert → Inputs → Digital inputs → Digital input x → Channel ident
Direct access code: 250001-00x
Examples: Digital input 1: 250001-000; Digital input 6: 250001-005

Description Measurement point name (e.g. "Pump") or description of the function of this input (e.g. "Fault message").
Only visible if function ≠ switched off

User entry Text (max. 16 characters)

Factory setting Digital x

Engineering unit

Navigation  Expert → Inputs → Digital inputs → Digital input x → Engineering unit
Direct access code: 250002-00x
Examples: Digital input 1: 250002-000; Digital input 6: 250002-005

Description Technical units of the count input, e.g. gal, cf ...
Only visible if function = pulse counter or quantity from time

User entry Text (max. 6 characters)

Decimal point

Navigation  Expert → Inputs → Digital inputs → Digital input x → Decimal point
Direct access code: 250004-00x
Examples: Digital input 1: 250004-000; Digital input 6: 250004-005

Description Number of places after decimal point for the display.
Only visible if function = pulse counter or quantity from time

Options None, One (X.Y), Two (X.YY), Three (X.YYY), Four (X.YYYY), Five (X.YYYYY)

Factory setting One (X.Y)

Input factor in

Navigation  Expert → Inputs → Digital inputs → Digital input x → Input factor in
Direct access code: 250019-00x
Examples: Digital input 1: 250019-000; Digital input 6: 250019-005

Description Defines if the set up factor is respective to 1 second or 1 hour.
Only visible if function = quantity from time

Options Seconds, hours

Factory setting Seconds

Pulse value

Navigation  Expert → Inputs → Digital inputs → Digital input x → Pulse value
Direct access code: 250005-00x
Examples: Digital input 1: 250005-000; Digital input 6: 250005-005

Description Factor, that when multiplied by the input signal results in the required physical value.
Examples:
1 pulse equals 5 m³ -> enter "5".
Only visible if function = pulse counter

User entry Number (max. 8 digits)

Factory setting 1

1 second= / 1 hour= (depends on the setting in "Input factor in")

Navigation	 Expert → Inputs → Digital inputs → Digital input x → 1 second= / 1 hour= Direct access code: 250005-00x Examples: Digital input 1: 250005-000; Digital input 6: 250005-005
Description	Factor, that when multiplied by the operating time results in the required physical value. Examples: 1 second equals 8 l → enter "8". Only visible if function = quantity from time
User entry	Number (max. 8 digits)
Factory setting	1

Time delay

Navigation	 Expert → Inputs → Digital inputs → Digital input x → Time delay Direct access code: 250017-00x Examples: Digital input 1: 250017-000; Digital input 6: 250017-005
Description	The high signal must be active for at least the preset time before the device changes the channel from low to high. The change from high to low is always immediate. Only visible if function = control input, on/off event, event+operation time
User entry	0 to 99 999 s
Factory setting	0

Action

Navigation	 Expert → Inputs → Digital inputs → Digital input x → Action Direct access code: 250003-00x Examples: Digital input 1: 250003-000; Digital input 6: 250003-005
-------------------	---

Description	Set up the function of the control input. Only visible if function = control input
--------------------	---

Action	Description
Start/stop recording	The device only saves data as long as a high signal is present
Screensaver on	Switches backlight/display off, low = off, high = on
Lock setup	The user can only change the setup if a low signal is present
Time synchronization	If a high signal is applied, the device rounds the system time up or down (only for low→high change) to the nearest minute: 0 to 29 → Round down; 30 to 59 → round up

Action	Description
Change group	When switching low→high the display switches to the next active group.
Set point monitoring on/off	The entire set point monitoring function of the device can be switched on (for "high") or switched off (for "low").
Individual LV on/off	The monitoring of a selected limit value can be switched on (high) or off (low).
Block keyboard/navigator	The device can only be operated if a low signal is present. Otherwise all key activation and navigator actions are discarded.
Start/stop analysis 1...4	Starts/ends one of the max. 4 external analyses (the analysis runs only as long as the signal is high). Measured value acquisition for the graphic display continues. Batches are also started/ended with this function. Note: This function is not available in the case of batch and control input via a maths channel.
Reset batch number x (option)	Resets the automatically generated batch number (1..x) to 0 (in the event of a LowHigh change).
Batch x limit values on/off (option)	Switches the limits of batch x on/off. The limits relating to the batch are determined based on the group settings (via the channels assigned to the batch). If a channel is assigned to several batches, the limits for this channel are not disabled.

Options Switched off, Start/stop recording, Screen saver on, Lock setup, Time synchronization, Change group, Set point monitoring on/off, Individual LV on/off, Block keyboard/navigator, Start/stop analysis x, Reset batch no. x, Batch x limits on/off

Factory setting Switched off

Group

Navigation  Expert → Inputs → Digital inputs → Digital input x → Group
Direct access code: 250015-00x
Examples: Digital input 1: 250015-000; Digital input 6: 250015-005

Description Select which group should be displayed in the event of a Low->High flank change. Alternatively the next active group can be displayed.
Only visible if function = control input and action = change group

Options Change automatically, Group x

Factory setting Change automatically

Set point

Navigation  Expert → Inputs → Digital inputs → Digital input x → Set point
Direct access code: 250016-00x
Examples: Digital input 1: 250016-000; Digital input 6: 250016-005

Description Select the set point which should be switched on or off by means of this control input.
Only visible if function = control input and action = individual LV on/off

Options	Switched off, Universal input xx, Digital input xx, Math xx, Set point xx, Relay xx
Factory setting	Change automatically

Switches relay

Navigation	 Expert → Inputs → Digital inputs → Digital input x → Switches relay Direct access code: 250006-00x Examples: Digital input 1: 250006-000; Digital input 6: 250006-005
Description	Switches the respective relay when the digital input is low or high. Please take note of the connection hints in the operating manual! Only visible if function = control input, on/off event, event+operation time
Options	Not used, Relay x All the available relays are displayed.
Factory setting	Not used

Description 'H'

Navigation	 Expert → Inputs → Digital inputs → Digital input x → Description 'H' Direct access code: 250007-00x Examples: Digital input 1: 250007-000; Digital input 6: 250007-005
Description	Condition description when the digital input is active. This text is both shown in the display and saved to memory. Only visible if function = control input, on/off event, event+operation time
User entry	Text (max. 6 characters)
Factory setting	On

Description 'L'

Navigation	 Expert → Inputs → Digital inputs → Digital input x → Description 'L' Direct access code: 250008-00x Examples: Digital input 1: 250008-000; Digital input 6: 250008-005
Description	Condition description when the digital input is not active. This text is both shown in the display and saved to memory. Only visible if function = control input, on/off event, event+operation time
User entry	Text (max. 6 characters)
Factory setting	Off

Save event

Navigation	 Expert → Inputs → Digital inputs → Digital input x → Save event Direct access code: 250009-00x Examples: Digital input 1: 250009-000; Digital input 6: 250009-005
Description	Determines whether the condition change from low to high or high to low is stored in the event log.  Requires higher memory capacity. Only visible if function = control input, on/off event, event+operation time
Options	No, Yes
Factory setting	Yes

Event message

Navigation	 Expert → Inputs → Digital inputs → Digital input x → Event message Direct access code: 250018-00x Examples: Digital input 1: 250018-000; Digital input 6: 250018-005
Description	"Do not acknowledge": No message is shown if the digital input switches. "Acknowledge": A message window is shown on the screen which has to be acknowledged by operating a push button. Only visible if function = control input, on/off event, event+operation time
Options	Do not acknowledge, Acknowledge
Factory setting	Do not acknowledge

Event text L->H

Navigation	 Expert → Inputs → Digital inputs → Digital input x → Event text L->H Direct access code: 250010-00x Examples: Digital input 1: 250010-000; Digital input 6: 250010-005
Description	Description of condition change from low to high. Event text is stored (e.g. Start filling).  If no event text is set, the device generates an automatic event text (factory setting), e.g. digital 1 L->H. Only visible if function = control input, on/off event, event+operation time
User entry	Text (max. 22 characters)

Event text H->L	
Navigation	 Expert → Inputs → Digital inputs → Digital input x → Event text H->L Direct access code: 250011-00x Examples: Digital input 1: 250011-000; Digital input 6: 250011-005
Description	Description of condition change from high to low. Event text is stored (e.g. Stop filling).  If no event text is set, the device generates an automatic event text (factory setting), e.g. digital 1 H->L. Only visible if function = control input, on/off event, event+operation time
User entry	Text (max. 22 characters)
Record duration	
Navigation	 Expert → Inputs → Digital inputs → Digital input x → Record duration Direct access code: 250012-00x Examples: Digital input 1: 250012-000; Digital input 6: 250012-005
Description	The duration between "On" and "Off" can be recorded. The duration is appended to the "Off" event text (<hhhh>h<mm>:<ss>). Power failure times do not affect the duration. If the digital channel was "on" before the power failure and is still "on" after the power failure, the duration continues. Only visible if function = control input, on/off event, event+operation time
Options	No, Yes
Factory setting	No
Totalizer	
Navigation	 Expert → Inputs → Digital inputs → Digital input x → Totalizer Direct access code: 250013-00x Examples: Digital input 1: 250013-000; Digital input 6: 250013-005
Description	Initial setting for the totalizer. Useful when continuing measurements recorded to date with an (electro)-mechanical counter. Only visible if function = pulse counter, operational time, event+operation time or quantity from time
User entry	Number (max. 15 digits)
Factory setting	0

Copy settings

Navigation	 Expert → Inputs → Digital inputs → Digital input x → Copy settings Direct access code: 250200-00x Examples: Digital input 1: 250200-000; Digital input 6: 250200-005
Description	Copies settings from actual channel to selected channel.
Options	No, Digital input x Users can choose from all the available digital inputs.
Factory setting	No

17.1.3 "Outputs" submenu

Setting up only required if outputs (e.g. relays) are to be used.

"Universal output x" submenu

Navigation	 Expert → Outputs → Universal output x
Description	Settings for the universal output selected (current or pulse output).

Signal

Navigation	 Expert → Outputs → Universal output x → Signal Direct access code: 340000-00x Examples: Universal output 1: 340000-000; Universal output 2: 340000-001
Description	Select the output signal for this channel.
Options	Switched off, 4-20 mA, 0-20 mA, Pulse output
Factory setting	Switched off

Reference channel

Navigation	 Expert → Outputs → Universal output x → Reference channel Direct access code: 340001-00x Examples: Universal output 1: 340001-000; Universal output 2: 340001-001
Description	Select the input to which the analog output refers.
Options	Switched off, Universal input x, Digital input x, Maths x, Set point x, Relay x All active inputs are available for selection.

Factory setting Switched off

Start value

Navigation  Expert → Outputs → Universal output x → Start value
 Direct access code: 340003-00x
 Examples: Universal output 1: 340003-000; Universal output 2: 340003-001

Description Configure what value corresponds to 0/4 mA.
 Visible only if signal = 4-20 mA or 0-20 mA

User entry Number (max. 8 characters)

Factory setting 0

Full scale value

Navigation  Expert → Outputs → Universal output x → Full scale value
 Direct access code: 340004-00x
 Examples: Universal output 1: 340004-000; Universal output 2: 340004-001

Description Configure what value corresponds to 20 mA.
 Visible only if signal = 4-20 mA or 0-20 mA

User entry Number (max. 8 characters)

Factory setting 100

Damping/filter

Navigation  Expert → Outputs → Universal output x → Damping/filter
 Direct access code: 340005-00x
 Examples: Universal output 1: 340005-000; Universal output 2: 340005-001

Description Time constant of the first order low pass for the output signal. This is used to prevent strong fluctuations of the output signal.
 Visible only if signal = 4-20 mA or 0-20 mA

User entry 0...999.9 s

Factory setting 0.0 s

Pulse value

Navigation	 Expert → Outputs → Universal output x → Pulse value Direct access code: 340006-00x Examples: Universal output 1: 340006-000; Universal output 2: 340006-001
Description	The pulse value specifies what quantity an output pulse corresponds to (e.g. 1 pulse = 5 liters). Only visible if signal = pulse output
User entry	Number (min. 0.000001; max. 8 characters)
Factory setting	1

Pulse width

Navigation	 Expert → Outputs → Universal output x → Pulse width Direct access code: 340007-00x Examples: Universal output 1: 340007-000; Universal output 2: 340007-001
Description	The pulse width limits the maximum possible output frequency of the pulse output. Define a fixed or dynamic pulse width. Only visible if signal = pulse output
Options	User-defined, dynamic (max. 1000ms)
Factory setting	User-defined

Pulse width

Navigation	 Expert → Outputs → Universal output x → Pulse width Direct access code: 340008-00x Examples: Universal output 1: 340008-000; Universal output 2: 340008-001
Description	You can set the pulse width in the range of 0.5...1000 ms here. Only visible if signal = pulse output
Value	0.5...1000 ms
Factory setting	100 ms

"Meas. val. corrct" submenu

Navigation	 Expert → Outputs → Universal output x → Measured value correction
-------------------	---

Description	Here, you can correct the output current value (necessary only if the device that carries out the further processing cannot compensate for any measurement section tolerances). Proceed as follows: 1. On the connected device, read out the displayed value in both the upper and lower measuring range. 2. Enter the lower and upper target and actual value. Visible only if signal = 4-20 mA or 0-20 mA
--------------------	--

Lower correction value

Target value

Navigation	 Expert → Outputs → Universal output x → Measured value correction → Lower correction value → Target value Direct access code: 340021-00x Examples: Universal output 1: 340021-000; Universal output 2: 340021-001
-------------------	---

Description	Enter the lower set point here. Visible only if signal = 4-20 mA or 0-20 mA
--------------------	--

User entry	Number (max. 8 characters)
-------------------	----------------------------

Factory setting	0
------------------------	---

Actual value

Navigation	 Expert → Outputs → Universal output x → Measured value correction → Lower correction value → Actual value Direct access code: 340022-00x Examples: Universal output 1: 340022-000; Universal output 2: 340022-001
-------------------	---

Description	Here, enter the lower actual value which is displayed at the connected device. Visible only if signal = 4-20 mA or 0-20 mA
--------------------	---

User entry	Number (max. 8 characters)
-------------------	----------------------------

Factory setting	0
------------------------	---

Upper correction value

Target value

Navigation	 Expert → Outputs → Universal output x → Measured value correction → Upper correction value → Target value Direct access code: 340024-00x Examples: Universal output 1: 340024-000; Universal output 2: 340024-001
-------------------	---

Description	Enter the upper set point here. Visible only if signal = 4-20 mA or 0-20 mA
User entry	Number (max. 8 characters)
Factory setting	100

Actual value

Navigation	 Expert → Outputs → Universal output x → Measured value correction → Upper correction value → Actual value Direct access code: 340025-00x Examples: Universal output 1: 340025-000; Universal output 2: 340025-001
-------------------	---

Description	Here, enter the upper actual value which is displayed at the connected device. Visible only if signal = 4-20 mA or 0-20 mA
--------------------	---

User entry	Number (max. 8 characters)
Factory setting	100

"Fault mode" submenu

Navigation	 Expert → Outputs → Universal output x → Fault mode
-------------------	--

Description	Configure how the analog output should behave in the event of an error (e.g. if the input channel has a cable open circuit). Visible only if signal = 4-20 mA or 0-20 mA
--------------------	---

NAMUR NE 43

Navigation	 Expert → Outputs → Universal output x → Fault mode → NAMUR NE 43 Direct access code: 340015-00x Examples: Universal output 1: 340015-000; Universal output 2: 340015-001
-------------------	--

Description	Activate/deactivate the 4-20 mA loop output as per NAMUR recommendation NE 43. The following error ranges apply when NAMUR NE43 is switched on: ≤3.8 mA: underrange ≥20.5 mA: overrange ≤ 3.6 mA or ≥ 21.0 mA: Cable open circuit Visible only if signal = 4-20 mA or 0-20 mA
--------------------	---

Options	Off, On
----------------	---------

Factory setting	On
------------------------	----

On error

Navigation	 Expert → Outputs → Universal output x → Fault mode → On error Direct access code: 340016-00x Examples: Universal output 1: 340016-000; Universal output 2: 340016-001
Description	What value should the output assume in the event of an error (e.g. cable open circuit or calculated value invalid)? Visible only if signal = 4-20 mA or 0-20 mA
Options	Invalid calculation, Error value
Factory setting	Invalid calculation

Error value

Navigation	 Expert → Outputs → Universal output x → Fault mode → Error value Direct access code: 340017-00x Examples: Universal output 1: 340017-000; Universal output 2: 340017-001
Description	This value is output in the event of an error. Note: Must be between 0 and 22 mA. Visible only if signal = 4-20 mA or 0-20 mA
User entry	0...22 mA
Factory setting	0 mA

"Relay x" submenu

Navigation	 Expert → Outputs → Relay x
Description	Contains setup for the selected relay  x = place holder for selected relay

Operating mode

Navigation	 Expert → Outputs → Relay x → Operating mode Direct access code: 330000-00x Examples: Relay 1: 330000-000; Relay 6: 330000-005
Description	Relay function: NC contact: The relay is closed in its quiescent state (maximum safety). NO contact: The relay is open in its quiescent state.
Options	Closing, Opening
Factory setting	Closing

Identifier	
Navigation	 Expert → Outputs → Relay x → Identifier Direct access code: 330001-00x Examples: Relay 1:330001-000; Relay 6: 330001-005
Description	Presetable relay identifier.
User entry	Text (max. 16 characters)
Factory setting	Relay x
Remote controlled	

Navigation	 Expert → Outputs → Relay x → Remote controlled Direct access code: 330002-00x Examples: Relay 1:330002-000; Relay 6: 330002-005
Description	Configure whether the relay may be controlled remotely (e.g. PC or SMS). Only visible with the option "Tele-Alarm".
Options	No, Yes
Factory setting	No

17.1.4 "Communication" submenu

Set-up required if you are using the USB, RS232, RS485 or Ethernet interface of the unit (PC operation, serial data read-out, modem operation, etc.).

 The various interfaces can be operated in parallel.

Timeout	
Navigation	 Expert → Communication → Timeout Direct access code: 150200-000
Description	Timeout is modifiable between 1 and 99 seconds. 0 seconds means that the functionality is inactivated.
User entry	0 to 99s
Factory setting	0 s

Switches

Navigation	 Expert → Communication → Switches Direct access code: 150201-000
Description	After the given timeout the dedicated relay/OC is active while no readout of actual measured values are in process.
Options	Not used, Relay x All the available relays are displayed.
Factory setting	Not used

Timeout fieldbus

Navigation	 Expert → Communication → Timeout fieldbus Direct access code: 150210-000
Description	Time within which measured values must be received via fieldbus (otherwise an error will be set). Not relevant if only measured values are read out.
User entry	1 to 99s
Factory setting	10 s

"Ethernet" submenu

Navigation	 Expert → Communication → Ethernet
Description	Contains the set-up required if you are using the Ethernet interface of the unit.

MAC-address

Navigation	 Expert → Communication → Ethernet → MAC-address Direct access code: 150000-000
Description	Displays the MAC address

DHCP

Navigation	 Expert → Communication → Ethernet → DHCP Direct access code: 150002-000
-------------------	--

Description	The device can get its Ethernet settings through DHCP. Caution: The settings determined are not displayed until after setup acceptance!  Note: The unit always gets the same IP address if the leasing time is set long enough on the DHCP server. The PC software needs the IP address determined to establish a connection!
--------------------	--

Options No, Yes

Factory setting Yes

IP address

Navigation  Expert → Communication → Ethernet → IP address
Direct access code: 150003-000

Description Please enter the IP address (given from your network administrator). Please talk to your network administrator about this.
Only editable if DHCP = no

User entry IP address

Factory setting 000.000.000.000

Subnetmask

Navigation  Expert → Communication → Ethernet → Subnetmask
Direct access code: 150004-000

Description Please enter the subnetmask (given from your network administrator).
Only editable if DHCP = no

User entry IP address

Factory setting 255.255.255.000

Gateway

Navigation  Expert → Communication → Ethernet → Gateway
Direct access code: 150005-000

Description Please enter the Gateway (given from your network administrator).
Only editable if DHCP = no

User entry IP address

Factory setting	000.000.000.000
-----------------	-----------------

Domain Name System (DNS)

Navigation	 Expert → Communication → Ethernet → Domain Name System (DNS) Direct access code: 150009-000
Description	Please enter the IP-address of the DNS server (you can get this from your network administrator). Is needed if you wish to send e-mails and want to use the e-mail server name instead of the IP address (e.g. smtp.example.org). Only editable if DHCP = no
User entry	IP address
Factory setting	000.000.000.000

Disable port

Navigation	 Expert → Communication → Ethernet → Disable port Direct access code: 150020-000
Description	You can disable unused ports for security reasons. CDI is the protocol that the configuration software or reporting software uses to communicate with the device.  All other ports (e.g. SNTP, SMTP, web server) are automatically disabled if the function is switched off.
Options	CDI, OPC, Modbus Slave, HART IP
Factory setting	---- (no port disabled)

Port

Navigation	 Expert → Communication → Ethernet → Port Direct access code: 150001-000
Description	The system communicates with the PC software through this communication port.  If your network is protected by a firewall, this port may have to be enabled. Please contact your network administrator if this is the case.
User entry	Number (max. 5 digits)
Factory setting	8000

OPC port

Navigation	 Expert → Communication → Ethernet → OPC port Direct access code: 150010-000
Description	Values can be read via OPC server using this communication port.  If your network is protected by a firewall, this port may have to be enabled. Please contact your network administrator if this is the case.
User entry	Number (max. 5 digits)
Factory setting	8002

HART IP port

Navigation	 Expert → Communication → Ethernet → HART IP port Direct access code: 150030-000
Description	Connected HART devices can be accessed via this communication port using the communication device type manager (DTM). Only visible if a HART card is present.  Note: If your network is protected by a firewall, this port will have to be enabled. Please contact your network administrator if this is the case. The "RSG45 HART CommDTM" is required in order to access connected HART devices via the RSG45. This establishes the connection between an FDT Frame application and a HART device. The DTM for the connected device must also be installed in the FDT Frame application. The "RSG45 HART CommDTM" is available from www.endress.com/rsg45. Further information →  37
User entry	Number (max. 5 digits)
Factory setting	5094

Web server

Navigation	 Expert → Communication → Ethernet → Web server Direct access code: 470000-000
Description	Switch the web server functionality on/off. The instantaneous values can only be displayed using an Internet browser when the web browser is activated.  A connection to the web server can only be established via the Ethernet interface.
Options	No (web server is off), Yes (web server is active)
Factory setting	Yes

"Configuration Web server" submenu

Navigation	 Expert → Communication → Ethernet → Configuration Web server
Description	Configure the Web server or specify which functionality should be possible via Web server. Only visible if Web server = yes.  Instantaneous value display is always possible once the Web server is switched on.

Port

Navigation	 Expert → Communication → Ethernet → Configuration Web server → Port Direct access code: 470003-000
Description	The web server communicates through this communication port.  If your network is protected by a firewall, this port may have to be enabled. Please contact your network administrator if this is the case.
User entry	Number (max. 5 digits)
Factory setting	80

Setup

Navigation	 Expert → Communication → Ethernet → Configuration Web server → Setup Direct access code: 470001-000
Description	The device can be configured via Web server. For security reasons it is advisable to switch off configuration via the web server after commissioning. With regard to IT security please contact your network administrator if necessary.
Options	No, Yes
Factory setting	Yes

Firmware update

Navigation	 Expert → Communication → Ethernet → Configuration Web server → Firmware update Direct access code: 470002-000
Description	Firmware can be updated via Web server.

Options No, Yes

Factory setting No

Remote control

Navigation  Expert → Communication → Ethernet → Configuration Web server → Remote control
Direct access code: 470004-000

Description Remote control of the device is possible via web server.

Options No, Yes

Factory setting No

WebDAV server

Navigation  Expert → Communication → Ethernet → Configuration Web server → WebDAV server
Direct access code: 470006-000

Description The SD card can be read via a WebDAV Client.

Options No, Yes

Factory setting No

Batch (option)

Navigation  Expert → Communication → Ethernet → Configuration Web server → Batch
Direct access code: 470007-000

Description Batches can be controlled via the Web server.



Detailed descriptions of this device option can be found in the associated documentation.

Options No, Yes

Factory setting No

Control relays (option)

Navigation	 Expert → Communication → Ethernet → Configuration Web server → Control relays Direct access code: 470008-000
Description	Relays can be remote-controlled via the Web server.  Detailed descriptions of this device option can be found in the associated documentation.
Options	No, Yes
Factory setting	No

"Authentication" submenu

Navigation


Expert → Communication → Ethernet → Configuration Web server → Authentication

Description

Set the passwords for the various users with which the device can be accessed via web server.

Only relevant if the device is not protected by user administration.

	Operator	Admin	Service
Measured value display	Yes	Yes	Yes
Display instrument health status	Yes	Yes	Yes
Configuration	No	Yes	Yes
Configuration incl. Service parameters	No	No	Yes
Update firmware	No	Yes	Yes
WebDAV	Yes	Yes	Yes


Note: The following passwords should be changed during commissioning.

Operator

ID

Navigation	 Expert → Communication → Ethernet → Configuration Web server → Authentication → ID Direct access code: 470104-000
Description	ID required in order to access the device. Pay attention to case-sensitivity. Cannot be edited.
Factory setting	operator

Password

Navigation	 Expert → Communication → Ethernet → Configuration Web server → Authentication → Password Direct access code: 470105-000
Description	Enter a password for this user account. Pay attention to case-sensitivity.
User entry	Text (max. 12 characters)
Factory setting	operator

Administrator

ID

Navigation	 Expert → Communication → Ethernet → Configuration Web server → Authentication → ID Direct access code: 470101-000
Description	ID required in order to access the device. Pay attention to case-sensitivity. Cannot be edited.
Factory setting	admin

Password

Navigation	 Expert → Communication → Ethernet → Configuration Web server → Authentication → Password Direct access code: 470102-000
Description	Enter a password for this user account. Pay attention to case-sensitivity.
User entry	Text (max. 12 characters)
Factory setting	admin

Service

ID

Navigation	 Expert → Communication → Ethernet → Configuration Web server → Authentication → ID Direct access code: 470107-000
-------------------	--

Description	ID required in order to access the device. Pay attention to case-sensitivity. Cannot be edited.
--------------------	--

Factory setting	service
------------------------	---------

Password

Navigation	 Expert → Communication → Ethernet → Configuration Web server → Authentication → Password Direct access code: 470108-000
-------------------	--

Description	Enter a password for this user account. Pay attention to case-sensitivity.
--------------------	---

User entry	Text (max. 12 characters)
-------------------	---------------------------

Factory setting	service
------------------------	---------

"Timeouts" submenu

Navigation	 Expert → Communication → Ethernet → Configuration Web server → Timeouts
-------------------	---

Description	Timeouts for the web server. Settings should only be modified if slow network connections are causing transmission problems.
--------------------	--

	The settings are only adopted if the browser has been restarted or a new tab opened. Caution: Settings should only be changed by experts.
---	--

Connection quality

Navigation	 Expert → Communication → Ethernet → Configuration Web server → Timeouts → Connection quality Direct access code: 470200-000
-------------------	--

Description	Configuration of typical timeout values for the Web server connection.
--------------------	--

	The default values can be changed if necessary.
---	---

Options	Please select, Local network (LAN/WLAN), Wireless/mobile (fast connect.), Wireless/mobile (slow connect)
----------------	--

Factory setting	Please select
------------------------	---------------

Get timeout

Navigation	 Expert → Communication → Ethernet → Configuration Web server → Timeouts → Get timeout Direct access code: 470201-000
Description	Maximum time to load a new page before the browser ends the connection.
User entry	5...999 s
Factory setting	25

Set timeout

Navigation	 Expert → Communication → Ethernet → Configuration Web server → Timeouts → Set timeout Direct access code: 470202-000
Description	Maximum time to write a value or execute an action before the browser ends the connection.
User entry	5...999 s
Factory setting	5

Put timeout

Navigation	 Expert → Communication → Ethernet → Configuration Web server → Timeouts → Put timeout Direct access code: 470203-000
Description	Maximum time to transmit files to or from the device before the browser ends the connection.
User entry	5 to 9999 s
Factory setting	240

Ping interval

Navigation	 Expert → Communication → Ethernet → Configuration Web server → Timeouts → Ping interval Direct access code: 470204-000
-------------------	---

Description	Interval in which the browser checks device reachability.  The check is switched off if 0s is set. This is for diagnostic purposes only and should not be set!
--------------------	--

User entry	0 to 999 s
-------------------	------------

Factory setting	10
------------------------	----

Ping timeout

Navigation	 Expert → Communication → Ethernet → Configuration Web server → Timeouts → Ping timeout Direct access code: 470205-000
-------------------	--

Description	Time in which the device must respond before the browser ends the connection.
--------------------	---

User entry	5...999 s
-------------------	-----------

Factory setting	15
------------------------	----

Ping retry

Navigation	 Expert → Communication → Ethernet → Configuration Web server → Timeouts → Ping retry Direct access code: 470206-000
-------------------	--

Description	Number of retries if the device does not respond.
--------------------	---

User entry	0 to 5
-------------------	--------

Factory setting	0
------------------------	---

Poll timeout

Navigation	 Expert → Communication → Ethernet → Configuration Web server → Timeouts → Poll timeout Direct access code: 470207-000
-------------------	--

Description	Maximum permitted time to refresh the website.
--------------------	--

User entry	5...999 s
-------------------	-----------

Factory setting	5
------------------------	---

"HART" submenu

Navigation	 Expert → Communication → HART
Description	Specify the values that should be read out via HART.

Master type

Navigation	 Expert → Communication → HART → Master type Direct access code: 550010-000
Description	Select the HART master type – usually "Primary". Select "Secondary" if another device (e.g. a PLC) is already operating as the primary master.
Options	Primary, Secondary
Factory setting	Primary

Attempts on error

Navigation	 Expert → Communication → HART → Attempts on error Direct access code: 550011-000
Description	Number of attempts to establish HART communication before a communication error is issued.
User entry	0 to 99
Factory setting	3

Failure mode

Navigation	 Expert → Communication → HART → Fault mode Direct access code: 550013-000
Description	If HART communication is disrupted, the primary process variable (PV) can be calculated if a valid current is present.  This function is not possible in multidrop mode. Start/end of measuring range must be correctly configured.
Options	PV rendered invalid, calculate PV based on current
Factory setting	PV rendered invalid

Add value

Navigation	 Expert → Communication → HART → Add value Direct access code: 550300-000
Description	A value read from a connected HART device is added.
Options	No, Yes
Factory setting	No

Delete value

Navigation	 Expert → Communication → HART → Delete value Direct access code: 550301-000
Description	Deletes a process value from the list.
Options	No, value x
Factory setting	No

"Value x" submenu

Navigation	 Expert → Communication → HART → Value x
Description	Specify the value that should be read out via HART. Note: This value must then be assigned to a channel for universal inputs.

Connection

Navigation	 Expert → Communication → HART → Value x → Connection Direct access code: 550000-0xx
Description	Select the physical channel to which the HART device is connected and from which you wish to query the value.
Options	Switched off, Channel x
Factory setting	Switched off

Unit address

Navigation	 Expert → Communication → HART → Value x → Device address Direct access code: 550001-0xx
Description	Enter the device address of the HART device.  Note: The entered device address must match the address set in the HART device (polling address; HART address).
User entry	0...62
Factory setting	0

Process variable

Navigation	 Expert → Communication → HART → Value x → Process variable Direct access code: 550002-0xx
Description	Select the process variable that should be requested.
Options	Primary process variable (PV), Secondary process variable (SV), Third process variable (TV), Fourth process variable (QV)
Factory setting	Primary process variable (PV)

Channel ident.

Navigation	 Expert → Communication → HART → Value x → Channel ident Direct access code: 550003-0xx
Description	Designation of the measuring point connected to this input.
User entry	Text (max. 16 characters)
Factory setting	Value x

"Serial interface" submenu

Navigation	 Expert → Communication → Serial interface
Description	Contains the set-up required if you are using the RS232 or RS485 unit interface.

Type

Navigation	 Expert → Communication → Serial interface → Type Direct access code: 150100-000
Description	Configure how the serial interface is used. Pay attention to the connections.

Options RS232, RS485, Debug (only for service purposes)

Factory setting RS232

Protocol

Navigation  Expert → Communication → Serial interface → Protocol
Direct access code: 150105-000

Description Define the serial interface protocol.
Note: The device automatically disables incompatible settings.

Options PC software, Printer, Modbus Slave (only if type = RS485), Modbus Master (only if type = RS485)

Factory setting PC software

Baudrate

Navigation  Expert → Communication → Serial interface → Baudrate
Direct access code: 150101-000

Description Transmission speed ("Baudrate") - must be the same as the settings for the PC software.

Options 9600, 19200, 38400, 57600, 115200

Factory setting 19200

Parity

Navigation  Expert → Communication → Serial interface → Parity
Direct access code: 150103-000

Description Parity
Only visible if protocol ≠ PC software

Options None, Even, Odd

Factory setting None

Stop bits

Navigation	 Expert → Communication → Serial interface → Stop bits Direct access code: 150104-000
Description	Stop bits Only visible if protocol ≠ PC software
Options	1, 2
Factory setting	1

Unit address

Navigation	 Expert → Communication → Serial interface → Unit address Direct access code: 150102-000
Description	Every unit operating using RS232/RS485 must have an individual address (00-30). Only visible if type = RS485
User entry	0 to 30
Factory setting	0

"Modbus Slave" submenu (option)

Navigation	 Expert → Communication → Modbus Slave
Description	Configure the Modbus settings for the device.  Detailed descriptions of this device option can be found in the associated documentation.

Modbus

Navigation	 Expert → Communication → Modbus Slave → Modbus Direct access code: 480000-000
Description	Specify the physical interface you wish to use.
Options	Not used, RS485, Ethernet
Factory setting	Not used

Unit address

Navigation	 Expert → Communication → Modbus Slave → Unit address Direct access code: 480001-000
Description	Enter the device address where it should be possible to reach this device in the bus. Only visible if Modbus = RS485
User entry	1 to 247
Factory setting	1

Port

Navigation	 Expert → Communication → Modbus Slave → Port Direct access code: 480004-000
Description	Port via which the Modbus protocol can be activated. Only visible if Modbus = Ethernet
User entry	Number (max. 5 digits)
Factory setting	502

"Serial interface" submenu

Navigation	 Expert → Communication → Modbus Slave → Serial interface
Description	Contains settings for the serial interface. Only visible if Modbus = RS485

Baudrate

Navigation	 Expert → Communication → Modbus Slave → Serial interface → Baudrate Direct access code: 150101-000
Description	Transmission speed ("Baudrate") - must be the same as the settings for the PC software. Only visible if Modbus = RS485
Options	9600, 19200, 38400, 57600, 115200
Factory setting	19200

Parity

Navigation	 Expert → Communication → Modbus Slave → Serial interface → Parity Direct access code: 150103-000
Description	Parity Only visible if Modbus = RS485
Options	None, Even, Odd
Factory setting	None

Stop bits

Navigation	 Expert → Communication → Modbus Slave → Serial interface → Stop bits Direct access code: 150104-000
Description	Parity Only visible if Modbus = RS485 and parity = none
Options	1, 2
Factory setting	1

"Modbus Master" submenu

Navigation	 Expert → Communication → Modbus Master
Description	Configure the Modbus settings for the device.  Detailed descriptions of this device option can be found in the associated documentation.

Modbus

Navigation	 Expert → Communication → Modbus Master → Modbus Direct access code: 480050-000
Description	Specify the physical interface you wish to use.
Options	Not used, RS485, Ethernet
Factory setting	Not used

Scan cycle

Navigation	 Expert → Communication → Modbus Master → Scan cycle Direct access code: 480053-000
Description	Cycle time for scanning the end devices. Only visible if Modbus = RS485
Options	Off, 1 s, 2 s, 5 s, 10 s, 30 s, 1 min, 2 min, 5 min, 10 min
Factory setting	1 s

Response timeout

Navigation	 Expert → Communication → Modbus Master → Response timeout Direct access code: 480054-000
Description	Time within which the system must receive a response from the end device. Only visible if Modbus = RS485
Options	Off, 1 s, 2 s, 5 s, 10 s, 30 s, 1 min, 2 min, 5 min, 10 min
Factory setting	1 s

Register per command

Navigation	 Expert → Communication → Modbus Master → Register per command Direct access code: 480055-000
Description	Maximum number of registers that can be read out per command.
User entry	3 ... 125
Factory setting	20

Connection attempts

Navigation	 Expert → Communication → Modbus Master → Connection attempts Direct access code: 480056-000
Description	Number of repeated connection attempts until a slave signals a timeout. Only visible if Modbus = RS485
User entry	1 ... 10
Factory setting	1

Command distribution

Navigation	 Expert → Communication → Modbus Master → Command distribution Direct access code: 480057-000
Description	Distributed over the scan cycle: The commands are uniformly distributed over the scan cycle. At the start of the scan cycle: The commands are sent at the start of the scan cycle with a pause between commands. A new scan commences when the scan cycle ends. Continuously: The commands are sent continuously with only a pause between commands. The scan cycle is not taken into account. Only visible if Modbus = RS485
Options	Distributed over the scan cycle, At the start of the scan cycle, Continuously
Factory setting	Distributed over the scan cycle

Pause between commands

Navigation	 Expert → Communication → Modbus Master → Pause between commands Direct access code: 480058-000
Description	Time system waits between a response and a new command to be sent. Only visible if Modbus = RS485
User entry	5 ... 600,000 ms
Factory setting	10 ms

"Serial interface" submenu

Navigation	 Expert → Communication → Modbus Master → Serial interface
Description	Contains the settings required if you are using the RS485 interface of the device.

Baudrate

Navigation	 Expert → Communication → Modbus Master → Serial interface → Baudrate Direct access code: 150101-000
Description	Transmission speed ("Baudrate") - must be the same as the settings for the PC software. Only visible if Modbus = RS485
Options	9600, 19200, 38400, 57600, 115200
Factory setting	19200

Parity	
Navigation	 Expert → Communication → Modbus Master → Serial interface → Parity Direct access code: 150103-000
Description	Parity Only visible if Modbus = RS485
Options	None, Even, Odd
Factory setting	None

Stop bits	
Navigation	 Expert → Communication → Modbus Master → Serial interface → Stop bits Direct access code: 150104-000
Description	Parity Only visible if Modbus = RS485 and parity = none
Options	1, 2
Factory setting	1

"Profibus DP" submenu (option)	
Navigation	 Expert → Communication → Profibus DP
Description	Configure the Profibus DP settings for the device.  Detailed descriptions of this device option can be found in the associated documentation.

Slave address	
Navigation	 Expert → Communication → Profibus DP → Slave address Direct access code: 480100-000
Description	Enter the device address where it should be possible to reach this device in the bus.
User entry	1 ... 125
Factory setting	1

Show status

Navigation	 Expert → Communication → Profibus DP → Show status Direct access code: 480101-000
Description	The status is shown on the display in addition to the measured value. Status changes are saved in the event log.
Options	No, Yes
Factory setting	No

"Slot x" submenu

Navigation	 Expert → Communication → Profibus DP → Slot x
Description	Slot assignment of the channels. Settings only required if you wish to connect the device to a PLC via Profibus DP.

Master In/Out

Navigation	 Expert → Communication → Profibus DP → Slot x → Master In/Out Direct access code: 480110-0xx Examples: Slot 1: 480110-000; Slot 16: 480110-015
Description	Selection of the modules that can be selected in the PLC. AI/AO: Transmission of a floating point number + status. DI/DO: Transmission of digital statuses. AI/DI: To the PLC. AO/DO: From the PLC.
Options	Not used, 1 AI-PA: 5 Byte, 2 AI-PA: 10 Byte, 3 AI-PA: 15 Byte, 4 AI-PA: 10 Word, 8 DI: 2 Byte, 1 AO-PA: 5 Byte, 2 AO-PA: 10 Byte, 3 AO-PA: 15 Byte, 4 AO-PA: 10 Word, 8 DO: 2 Byte
Factory setting	Not used

Byte x...y

Navigation	 Expert → Communication → Profibus DP → Slot x → Byte x...y Direct access code, byte 0..4: 480111-0xx Direct access code, byte 5..9: 480113-0xx Direct access code, byte 10..14: 480115-0xx Direct access code, byte 15..19: 480117-0xx Examples: Slot 1, Byte 0..4: 480111-000; Slot 16: 480111-015
-------------------	--

Description	Please select the value that should be used within the module from this address offset.
Options	Switched off, Universal input x, Digital input x, Maths x, Set point x, Relay x Note: All active inputs are available for selection.
Factory setting	Switched off

-->

Navigation	 Expert → Communication → Profibus DP → Slot x → --> Direct access code, byte 0..4 -->: 480112-0xx Direct access code, byte 5..9 -->: 480114-0xx Direct access code, byte 10..14 -->: 480116-0xx Direct access code, byte 15..19 -->: 480118-0xx Examples: Slot 1, Byte 0..4 -->: 480112-000; Slot 16 -->: 480112-015
-------------------	---

Description	Data type of the value to be transmitted. Note: Item only visible if a digital input with the function Operational time, Event +operation time or Quantity from time has been selected under "Byte x..y".
Options	Not used, Instantaneous value, State, Totalizer, Total operational time
Factory setting	Not used

Bit 0.0 ... 0.7

Navigation	 Expert → Communication → Profibus DP → Slot x → Bit 0.0 ... 0.7 Direct access code, bit 0.0: 480111-0xx Direct access code, bit 0.1: 480113-0xx Direct access code, bit 0.2: 480115-0xx Direct access code, bit 0.3: 480117-0xx Direct access code, bit 0.4: 480119-0xx Direct access code, bit 0.5: 480120-0xx Direct access code, bit 0.6: 480121-0xx Direct access code, bit 0.7: 480122-0xx Examples: Slot 1, Bit 0.0: 480111-000; Slot 16: 480111-015
-------------------	---

Description	Please select the value that should be used within the module from this address offset.
Options	Switched off, Universal input x, Digital input x, Maths x, Set point x, Relay x All active inputs are available for selection.
Factory setting	Switched off

17.1.5 "Application" submenu

Configure various application-specific settings (e.g. group settings, limit values, etc.).

Submenu "Maths - Maths x"

Navigation	 Expert → Application → Maths → Maths x
Description	Configuration of the mathematics channels.  x = place holder for selected mathematics channel

Function

Navigation	 Expert → Application → Maths → Maths x → Function Direct access code: 400000-000 Examples: Maths 1: 400000-000; Maths 4: 400000-003
Description	Switch the mathematics channel on or off.
Options	Switched off, Formula editor Included with energy package (option): Energy calculation, mass calculation, density calculation, calculation of heat quantity, DP flow mass calculation
Factory setting	Switched off

Channel ident.

Navigation	 Expert → Application → Maths → Maths x → Channel ident. Direct access code: 400001-000 Examples: Maths 1: 400001-000; Maths 4: 400001-003
Description	Measurement point name (e.g. "Pump") or description of the function of this input (e.g. "Fault message").
User entry	Text (max. 16 characters)
Factory setting	Maths x

Formula

Navigation	 Expert → Application → Maths → Maths x → Formula Direct access code: 400002-000 Examples: Maths 1: 400002-000; Maths 4: 400002-003
-------------------	--

Description Enter the desired calculation formula.
 The formula can be any combination of arithmetic calculations and logical operations.
 Analog, digital or already active mathematics channels can be used.
 Description of formula editor →  202
 Only visible if Function = Formula Editor

User entry Formula

Application

Navigation  Expert → Application → Maths → Maths x → Application
 Direct access code: 400100-0xx
 Examples: Maths 1: 400100-000; Maths 4: 400100-003

Description Please select application.
 Only visible with energy package (option) and selected energy function.

Options Water heat quantity, Water heat difference, Steam heat quantity, Steam heat difference,
 Water/glycol heat difference, Water DP flow, Steam DP flow, Liquids DP flow, Gas DP flow

Factory setting Water heat quantity or Water DP flow (depends on selected function)

Device type

Navigation  Expert → Application → Maths → Maths x → Device type
 Direct access code: 400122-0xx
 Examples: Maths 1: 400122-000; Maths 4: 400122-003

Description Configure the transmitter type used.
 Only visible with energy package (option) and Function = Mass calculation DP flow.

Options Orifice (corner), Orifice (D/D2), Orifice (flange), Nozzle (ISA1932), Nozzle (l. radius),
 Venturi nozzle, Venturi tbe, cast, Venturi tbe, bear., Venturi tbe, steel, V-cone, Pitot tube,
 Gilflo

Factory setting Orifice (corner)

Flow

Navigation  Expert → Application → Maths → Maths x → Flow
 Direct access code: 400101-0xx
 Examples: Maths 1: 400101-000; Maths 4: 400101-003

Description Please select a flow input.
 Visible only with energy package (option) and function = energy or mass calculation.

Options Switched off, Universal input x, Maths x
All active inputs are available for selection.

Factory setting Switched off

Engineering unit

Navigation  Expert → Application → Maths → Maths x → Engineering unit
Direct access code: 400102-0xx
Examples: Maths 1: 400102-000; Maths 4: 400102-003

Description Please select the unit you would like to use for scaling the selected flow input.
Only visible with energy package (option) and selected flow input.

Options m³/h, l/h, ft³/m, ft³/h, gpm, gal/h, kg/h, t/h, ton/h, lb/h

Factory setting m³/h

Flow installation point

Navigation  Expert → Application → Maths → Maths x → Flow installation point
Direct access code: 400103-0xx
Examples: Maths 1: 400103-000; Maths 4: 400103-003

Description Please specify where the flow sensor is installed. This is important so that the correct temperature is used for density calculation.
Only visible with energy package (option) and active flow input.

Options Steam, Water, Warm, Cold (depending on the selected application)

Factory setting Steam or warm (depends on selected application)

Pressure

Navigation  Expert → Application → Maths → Maths x → Pressure
Direct access code: 400104-0xx
Examples: Maths 1: 400104-000; Maths 4: 400104-003

Description Please select a pressure input. If you select "deactivated" the temperature input is used to calculate the saturated steam conditions.
Only visible with energy package (option) and selected steam application.

Options Switched off, Universal input x, Maths x
All active inputs are available for selection.

Factory setting Switched off

Engineering unit	
Navigation	 Expert → Application → Maths → Maths x → Engineering unit Direct access code: 400105-0xx Examples: Maths 1: 400105-000; Maths 4: 400105-003
Description	Please select the unit used for scaling the selected pressure input. Only visible with energy package (option) and selected steam application. Only visible with energy packet (option) and active pressure input.
Options	bar (a), psi (a), MPa (a), inH2O (a), bar (g), psi (g), MPa (g), inH2O (g)
Factory setting	bar (a)
Temperature (water/steam/warm)	
Navigation	 Expert → Application → Maths → Maths x → Temperature (water/steam/warm) Direct access code: 400106-0xx Examples: Maths 1: 400106-000; Maths 4: 400106-003
Description	Please select the temperature input used to measure the warm side (or steam line). In steam applications, if you select "deactivated" the pressure is used to calculate the saturated steam conditions. Only visible with energy package (option) and selected energy function.
Options	Switched off, Universal input x, Maths x All active inputs are available for selection.
Factory setting	Switched off
Temperature (steam/cold)	
Navigation	 Expert → Application → Maths → Maths x → Temperature (steam/cold) Direct access code: 400107-0xx Examples: Maths 1: 400107-000; Maths 4: 400107-003
Description	Please select the temperature input used to measure the cold side (or condensate line). Only visible with energy package (option) and selected heat difference measurement.
Options	Switched off, Universal input x, Maths x All active inputs are available for selection.
Factory setting	Switched off

Engineering unit

Navigation	 Expert → Application → Maths → Maths x → Engineering unit Direct access code: 400108-0xx Examples: Maths 1: 400108-000; Maths 4: 400108-003
Description	Please select the unit used for scaling the selected temperature sensors. Only visible with energy package (option) and selected energy function.
Options	°C, °F, K
Factory setting	°C

Medium

Navigation	 Expert → Application → Maths → Maths x → Medium Direct access code: 400110-0xx Examples: Maths 1: 400110-000; Maths 4: 400110-003
Description	Select a cooling medium. If your medium is not in the list and based on glycol, select ethylene or propylene glycol. Only visible with energy package (option) and application = Water/Glycol heat difference.
Options	Ethylene-glycol, Antifrogen N, Glykosol N, Propylene-glycol
Factory setting	Ethylene-glycol

Water/Glycol concentrat.

Navigation	 Expert → Application → Maths → Maths x → Water/Glycol concentrat. Direct access code: 400109-0xx Examples: Maths 1: 400109-000; Maths 4: 400109-003
Description	Concentration of the water/glycol mixture in vol % (0-60 %) Only visible with energy package (option) and application = Water/Glycol heat difference.
User entry	0 ... 60 %
Factory setting	20 %

The result is

Navigation

 Expert → Application → Maths → Maths x → The result is
 Direct access code: 400003-000
 Examples: Maths 1: 400003-000; Maths 4: 400003-003

Description

Configure which data type the calculation returns. This setting affects how the channel saves and is displayed.
 If you add 2 analog channels, for example, the result is a "current value".
 If you logically link 2 channels, for example, (digital 1 AND digital 2), the result is a "state" (on/off).
 Instantaneous value: If, for example, 2 analog channels are added ($AI(1;1)+AI(1;2)$), the result is an instantaneous value.
 State: The state/status of an individual analog input can be output as the result. A relay can also be actuated as a result.
 Counter: If, for example, 2 counters from digital inputs are added ($DI(3;1)+DI(3;5)$), the result is a counter.
 Operating time from status: The status (logical "1" or "0") of one or more digital inputs that are connected by addition can be analyzed. If the result of the calculation is not equal to 0, the counter for the operating time starts. The time is increased by 0.1 s every 100 ms.
 Operating time from total: If several digital inputs that are configured as "operational time" are added together, the result is the total of all the individual operating times.
 Control input: The function corresponds to a digital input that has been configured as a control input.

Options

Instantaneous value, State, Counter, Operating time from status, Operating time from total, Control input, Efficiency

Factory setting

Instantaneous value

Plot type

Navigation

 Expert → Application → Maths → Maths x → Plot type
 Direct access code: 400015-000
 Examples: Maths 1: 400015-000; Maths 4: 400015-003

Description

The mathematics channels are recalculated every 100 ms.
 Depending on the save cycle, the selected data are determined/saved from the calculated values.

Options

Instantaneous value, Average, Minimum value, Maximum value, Minimum + Maximum, Counter, Current value + Counter

Factory setting

Average

Engineering unit

Navigation

 Expert → Application → Maths → Maths x → Engineering unit
 Direct access code: 400004-000
 Examples: Maths 1: 400004-000; Maths 4: 400004-003

Description	Unit of the calculated value Only visible if the result is = instantaneous value, counter or efficiency
User entry	Text (max. 6 characters)

Engineering unit

Navigation	 Expert → Application → Maths → Maths x → Engineering unit Direct access code: 400111-000 Examples: Maths 1: 400111-000; Maths 4: 400111-003
Description	Unit of the calculated value Only visible with energy package (option) and selected energy function.
Options	kW, MW, GJ/h, kBtu/m, kBtu/h, MBtu/h, ther/m, ther/h, ton, RT, kg/h, t/h, lbs/h, ton/h, kg/m ³ , lb/ft ³ , kJ/kg, Btu/lb
Factory setting	(Depends on the selected function)

Decimal point

Navigation	 Expert → Application → Maths → Maths x → Decimal point Direct access code: 400005-000 Examples: Maths 1: 400005-000; Maths 4: 400005-003
Description	Number of places after decimal point for the display. Only visible if function = formula editor, energy calculation, mass calculation, density calculation, calculation of heat quantity and the result is = instantaneous value, counter or efficiency.
Options	None, One (X.Y), Two (X.YY), Three (X.YYY), Four (X.YYYY), Five (X.YYYYY)
Factory setting	One (X.Y)

Action

Navigation	 Expert → Application → Maths → Maths x → Action Direct access code: 400006-000 Examples: Maths 1: 400006-000; Maths 4: 400006-003
Description	Set up the function of the control input. Only visible if the result is = control input

Action	Description
Start/stop recording	The device only saves data as long as a high signal is present
Screensaver on	Switches backlight/display off, low = off, high = on
Lock setup	The user can only change the setup if a low signal is present
Time synchronization	If a high signal is applied, the device rounds the system time up or down (only for low→high change) to the nearest minute: 0 to 29 → Round down; 30 to 59 → round up
Change group	When switching low→high the display switches to the next active group.
Set point monitoring on/off	The entire set point monitoring function of the device can be switched on (for "high") or switched off (for "low").
Individual LV on/off	The monitoring of a selected limit value can be switched on (high) or off (low).
Block keyboard/navigator	The device can only be operated if a low signal is present. Otherwise all key activation and navigator actions are discarded.
Start/stop analysis 1...4	Starts/ends one of the max. 4 external analyses (the analysis runs only as long as the signal is high). Measured value acquisition for the graphic display continues. Batches are also started/ended with this function. Note: This function is not available in the case of batch and control input via a maths channel.
Reset batch number x (option)	Resets the automatically generated batch number (1..x) to 0 (in the event of a LowHigh change).
Batch x limit values on/off (option)	Switches the limits of batch x on/off. The limits relating to the batch are determined based on the group settings (via the channels assigned to the batch). If a channel is assigned to several batches, the limits for this channel are not disabled.

Options Switched off, Start/stop recording, Screen saver on, Lock setup, Time synchronization, Change group, Set point monitoring on/off, Individual LV on/off, Block keyboard/navigator, Start/stop analysis x, Reset batch no. x, Batch x limits on/off

Factory setting Switched off

Set point

Navigation  Expert → Application → Maths → Maths x → Set point
Direct access code: 400019-000
Examples: Maths 1: 400019-000; Maths 4: 400019-003

Description Select the set point which should be switched on or off by means of this control input.
Only visible if Action = Individual LV on/off

Options Switched off, Set point x

Factory setting Switched off

Switches relay

Navigation	 Expert → Application → Maths → Maths x → Switches relay Direct access code: 400007-000 Examples: Maths 1: 400007-000; Maths 4: 400007-003
Description	Switches the respective relay when the digital input is low or high. Only visible if the result is = control input or state
Options	Not used, Relay x All the available relays are displayed.
Factory setting	Not used

Description 'H'

Navigation	 Expert → Application → Maths → Maths x → Description 'H' Direct access code: 400008-00x Examples: Maths 1: 400008-000; Maths 4: 400008-003
Description	Condition description when the digital input is active. This text is both shown in the display and saved to memory. Only visible if the result is = control input or state
User entry	Text (max. 6 characters)
Factory setting	On

Description 'L'

Navigation	 Expert → Application → Maths → Maths x → Description 'L' Direct access code: 400009-00x Examples: Maths 1: 400009-000; Maths 4: 400009-003
Description	Condition description when the digital input is not active. This text is both shown in the display and saved to memory. Only visible if the result is = control input or state
User entry	Text (max. 6 characters)
Factory setting	Off

Save event

Navigation	 Expert → Application → Maths → Maths x → Save event Direct access code: 400010-00x Examples: Maths 1: 400010-000; Maths 4: 400010-003
-------------------	---

Description	Determines whether the condition change from low to high or high to low is stored in the event log.  Requires higher memory capacity. Only visible if the result is = control input or state
Options	No, Yes
Factory setting	Yes

Event message

Navigation	 Expert → Application → Maths → Maths x → Event message Direct access code: 400018-00x Examples: Maths 1: 400018-000; Maths 4: 400018-003
Description	"Do not acknowledge": No message is shown if the state of the mathematics channel changes. "Acknowledge": A message window is shown on the screen which has to be acknowledged by operating a push button. Only visible if the result is = control input or state
Options	Do not acknowledge, Acknowledge
Factory setting	Do not acknowledge

Event text L->H

Navigation	 Expert → Application → Maths → Maths x → Event text L->H Direct access code: 400011-00x Examples: Maths 1: 400011-000; Maths 4: 400011-003
Description	Description of condition change from low to high. Event text is stored (e.g. Start filling). Only visible if the result is = control input or state
User entry	Text (max. 22 characters)

Event text H->L

Navigation	 Expert → Application → Maths → Maths x → Event text H->L Direct access code: 400012-00x Examples: Maths 1: 400012-000; Maths 4: 400012-003
Description	Description of condition change from high to low. Event text is stored (e.g. Stop filling). Only visible if the result is = control input or state

User entry Text (max. 22 characters)

Record duration

Navigation  Expert → Application → Maths → Maths x → Record duration
Direct access code: 400013-00x
Examples: Maths 1: 400013-000; Maths 4: 400013-003

Description The duration between "On" and "Off" can be recorded. The duration is appended to the "Off" event text (<hhhh>h<mm>:<ss>).
Power failure times do not affect the duration. If the digital channel was "on" before the power failure and is still "on" after the power failure, the duration continues.
Only visible if the result is = control input or state

Options No, Yes

Factory setting No

Zoom start

Navigation  Expert → Application → Maths → Maths x → Zoom start
Direct access code: 400016-00x
Examples: Maths 1: 400016-000; Maths 4: 400016-003

Description If the whole value range is not used, you can configure the lower value of the required section here. Zooming does not affect the save function.
Only visible if the result is = instantaneous value

User entry Number (max. 8 digits)

Factory setting 0

Zoom end

Navigation  Expert → Application → Maths → Maths x → Zoom end
Direct access code: 400017-00x
Examples: Maths 1: 400017-000; Maths 4: 400017-003

Description Like "Zoom start". However, enter the upper value of the required range here.
Only visible if the result is = instantaneous value

User entry Number (max. 8 digits)

Factory setting 100

Totalizer

Navigation	 Expert → Application → Maths → Maths x → Totalizer Direct access code: 400014-00x Examples: Maths 1: 400014-000; Maths 4: 400014-003
Description	Initial setting for the totalizer. Useful when continuing measurements recorded to date with an (electro)-mechanical counter. Only visible if the result is = counter, operating time from status or operating time from total
User entry	Number (max. 15 digits)
Factory setting	0

Formula editor

Enter the desired calculation formula.

The formula can be any combination of arithmetic calculations and logical operations. Analog, digital or already active mathematics channels can be used.

Formula editor

Navigation	 Expert → Application → Maths → Maths x → Formula Direct access code: 400002-000  x = place holder for selected mathematics channel  A text field with the formula currently used appears. If the field is empty a formula has not yet been defined for the mathematics channel.
------------	---

Description

Individual channels can be mathematically linked and calculated with functions. The mathematics channels calculated in this way are treated as "real" channels, regardless of whether they are connected conventionally or via fieldbus. Enter the desired calculation formula.

The formula can be any combination of arithmetic calculations and logical operations. Analog and digital channels can be used, as can mathematics channels that are already active.

A formula with up to 200 characters can be created using this editor. If the formula is finished, click OK to close the editor and accept the formula entered. The common entry and arithmetic operators and inputs are described in detail in the following sections.

Inputs

Inputs are described in the formula using the following syntax:

Input type (signal type;channel number)

Type of input	Description
AI	Analog inputs
DI	Digital inputs
MI	Mathematics inputs

Signal type	Description
1	Instantaneous value (measured value)
2	State
3	Counter/operational time
5	Validity: The validity of an analog or maths channel is returned. The relayed value of the function is 0 in the event of: ▪ Open circuit ▪ Invalid measured value ▪ Sensor error ▪ Input signal too high/low ▪ Error value The relayed value of the function is 1 in the event of: Measured value OK, even if the limit value is breached
6	Delta count
7...10	Analysis 1..4
11	Totalizer
12	Duration



Not all signal types are available for each input type. These depend on the respective device options.

Channel number:

Analog channel 1 = 1, analog channel 2 = 2, digital channel 1 = 1, ...

Examples:

DI(2;4)	State of digital channel 4
AI(1;1)	Instantaneous value of analog channel 1

Status of a limit value:

LMT (type, limit number)

Type	Description
1	"Instantaneous value": Currently set limit value
2	"State": The function returns the status of a limit value The result is 1 if the limit value is violated. The result is 0 if ▪ The limit value is not violated ▪ The limit value is not switched on ▪ Limits monitoring is switched off (e.g. per control input)

Examples:

LMT (1;1)	Instantaneous value of limit value 1
LMT (2;3)	State of limit value 3

Priority of operators / functions

The formula is processed based on universally applicable mathematics rules:

- Parentheses first
- Exponents before multiplication or division
- Multiplication or division before addition or subtraction
- Calculate from left to right

*Operators**Arithmetic operators:*

Operator	Function
+	Addition
-	Subtraction / negative sign
*	Multiplication
/	Division
%	Modulo (remainder of division x/y), see function "mod"
^	x high y

Relational operators:

Operator	Function
>	Greater than
>=	Greater than or equal to
<	Less than
<=	Less than or equal to
=	Equal to
<>	Not equal to

Logical operators:

Function	Syntax	Description	Example
	Value 1 Value 2	Logical "or" (see also function "or")	DI(2;1) DI(2;2)
&&	Value 1 && Value 2	Logical "and" (see also function "and")	DI(2;1) && DI(2;2)

*Functions**Standard functions:*

Function	Syntax	Description	Example
In the	ln(number)	Returns the natural logarithm of a number. Natural logarithms are based on a constant e (2.71828182845904). For values ≤ 0 the result is undefined. The device continues with 0	ln(86) = 4.454347
log	log(number)	Calculates the logarithm of the argument for base 10. For values ≤ 0 the result is undefined. The device continues with 0.	log(10) = 1
exp	exp(number)	Exponentiates the base e with the number specified as the argument. The constant e is the basis for the natural logarithm and has the value 2.71828182845904.	exp(2.00) = 7.389056

Function	Syntax	Description	Example
abs	abs(number)	Returns the absolute value of a number. The absolute value of a number is the number without its sign.	abs(-1.23) = 1.23
pi	pi()	Returns the value of the number PI (3.14159265358979323846264)	
sqrt	sqrt(number)	sqrt calculates the positive square root of the argument "Number". In the case of negative values the result is undefined. The device continues with 0.	sqrt(4) = 2
mod	mod(number; divisor)	Returns the remainder of a division. The result has the same sign as the divisor. If the divisor has the value 0, the result is undefined. The device continues with 0.	mod(5;2) = 1
rnd	rnd(number; number_digits)	Rounds a number to a certain number of decimal places. "Number" is the number to which you wish to round up/down. "Number_digits" indicates to how many decimal places you wish to round the number up/down. i Notes: ■ If "Number_digits" is greater than 0 (zero), the number is rounded to the specified number of decimal places. ■ If "Number_digits" is equal to 0, the number is rounded to the next whole number. ■ If "Number_digits" is less than 0, the part of the number to the left of the decimal separator is rounded.	rnd(2.15;1) = 2.2 rnd(2.149;1) = 2.1 rnd(-1.475;2) = -1.48 rnd(-1.473;2) = -1.47 rnd(21.5;-1) = 20 rnd(5.5;-2) = 10 rnd(5.5;-3) = 0

Trigonometric functions:

Function	Syntax	Description	Example
rad	rad(number)	Conversion of degrees to radian	rad(270) = 4.712389
Degrees	Degrees (number)	Conversion of radian to degrees	Degrees(pi()) = 180

The following functions expect an angle in the radian as the argument. If the angle lies in the degree, it must be converted to the radian by multiplying it with $\pi()/180$. Alternatively the function "rad" can be used:

Function	Syntax	Description	Example
sin	sin(number)	Returns the sine of a number	sin(pi()) -> sine of pi radian sin(30*pi()/180) -> sine of 30 degrees (0.5)
cos	cos(number)	Conversion of radian to degrees	Degrees(pi()) = 180
tan	tan(number)	Returns the tangent of the argument	tan(0.785) = 0.99920

With the following functions the returned angle is specified in radian with a value between $-\pi/2$ and $+\pi/2$. If the result is to be expressed in degrees, the respective result must be multiplied by $180/\pi()$ or the "Degrees" function used:

Function	Syntax	Description	Example
asin	asin(number)	Returns the arc sine or inverse sine of a number (inverse function). The arc sine expects a real argument in the range from -1 to +1. In the case of values outside of this range the device continues with 0.	$\arcsin(-0.5) = -0.5236$ $\arcsin(-0.5) * 180 / \pi() = -30^\circ$
acos	acos(number)	Returns the arc cosine or inverse cosine of a number (inverse function). Arc cosine expects a real argument in the range from -1 to +1. In the case of values outside of this range the device continues with 0.	$\arccos(-0.5) = 2.094395$
atan	atan(number)	Returns the arc tangent or inverse tangent of a number (inverse function).	$\text{atan}(1) = 0.785398$

Logical functions:

Function	Syntax	Description	Example
if	if(check; then_value; otherwise_value)	"Check" is any value or expression; the result can be TRUE or FALSE. This argument can use any comparative calculation operator. "Then_value" is the value returned if "Check" is TRUE. "Otherwise_value" is the value returned if "Check" is FALSE.	if(x>10;1;0) If value x is greater than 10 the function returns 1, otherwise 0
or	or(true1;true2)	Returns TRUE if an argument is TRUE. Returns FALSE if all arguments are FALSE. Note: See also operator " " "	or(2>1;3>2) = true or(2<1;3>2) = true or(2<1;3<2) = false
and	and(true1;true2)	Returns TRUE if both arguments are TRUE. If one of the arguments is FALSE, this function returns the value FALSE Note: See also operator "&&"	and(2>1;3>2) = true and(2<1;3<2) = false
not	not(truth value)	Inverts the value of an argument. NOT can be used if a value does not match a certain other value.	not(false) = true

The XX in the following functions stands for one of the inputs described under → 202. Range functions can only ever be executed with one input type.

Range functions:

Function	Syntax	Description	Example
sumXX	sumXX(Type;From;To)	Totals the values for the specified input signal range. "Type": Signal type (see → 202) "From": Channel number from which the values should be totaled (1 = channel 1) "To": Channel number to which the values should be totaled (1 = channel 1)	sumXX(1;2;5) = Sum of all instantaneous values from channel 2 to 5
avgXX	avgXX(Type;From;To)	Calculates the average for the specified input signal range.	avgXX(1;1;6)
minXX	minXX(Type;From;To)	Returns the lowest value for the specified input signal range.	minXX(1;1;6)
maxXX	maxXX(Type;From;To)	Returns the highest value for the specified input signal range.	maxXX(1;1;6)

Date/time functions:

Function	Syntax	Description	Example
dow	dow()	Returns the current day of the week as a number between 1 and 7.	Sunday = 1 Monday = 2 Tuesday = 3 Wednesday = 4 Thursday = 5 Friday = 6 Saturday = 7
time	time()	Returns the current time in seconds.	00:00 = 0 s 12:00 = 43,200 s 23:59:59 = 86,399 s

Decimal separator

Both the decimal point and the decimal comma can be used in the formula editor. Thousand separators are not supported.

Check whether formula is valid or malfunctions

A formula is invalid if:

- The channels used are not switched on or are in the wrong operating mode (is not verified during formula entry as the channel could be switched on subsequently)
- It contains invalid characters/formulas/functions/operators
- Syntax errors (e.g. wrong number of parameters) occur in the formulas
- There are incorrect parentheses in the formula (number of open parentheses unequal to number of closed parentheses)
- Division is by zero
- A channel refers to itself (infinite recursion)

Invalid formulas are deactivated when the setup is accepted or the device is started.

Undetectable errors: wherever possible, errors in the formula are reported immediately during input. However, given the possible complexity of the formula entered (e.g. nested formulas) it is not possible to detect every error.

"DP flow" submenu (option "Energy package")

Navigation  Expert → Application → Maths → Maths x → DP flow

Description Configuration of a flow measurement following the differential pressure process.
Only visible if function = mass calculation DP flow

Differential pressure

Navigation  Expert → Application → Maths → Maths x → DP flow → Differential pressure
Direct access code: 400115-00x
Examples: Maths 1: 400115-000; Maths 4: 400115-003

Description Please select differential pressure input.

Options Switched off, Universal input x, Digital input x, Maths x
All active inputs are available for selection.

Factory setting	Switched off
------------------------	--------------

DP unit

Navigation	 Expert → Application → Maths → Maths x → DP flow → DP unit Direct access code: 400116-00x Examples: Maths 1: 400116-000; Maths 4: 400116-003
-------------------	--

Description	Unit of the differential pressure.
--------------------	------------------------------------

Options	mbar, inH2O
----------------	-------------

Factory setting	mbar
------------------------	------

Diameter unit

Navigation	 Expert → Application → Maths → Maths x → DP flow → Diameter unit Direct access code: 400118-00x Examples: Maths 1: 400118-000; Maths 4: 400118-003
-------------------	---

Description	Unit of the internal diameter of the pipe.
--------------------	--

Options	mm, Inch
----------------	----------

Factory setting	mm
------------------------	----

D at 20 °C

Navigation	 Expert → Application → Maths → Maths x → DP flow → D at 20 °C Direct access code: 400119-00x Examples: Maths 1: 400119-000; Maths 4: 400119-003
-------------------	---

Description	Internal pipe diameter (D) under design conditions at 20 °C/68 °F.
--------------------	--

User entry	Number (max. 8 characters)
-------------------	----------------------------

Factory setting	100 (mm or inches)
------------------------	--------------------

d at 20 °C

Navigation	 Expert → Application → Maths → Maths x → DP flow → d at 20 °C Direct access code: 400120-00x Examples: Maths 1: 400120-000; Maths 4: 400120-003
Description	Internal pipe diameter of the throttle (d) under design conditions at 20 °C/68 °F.
User entry	Number (max. 8 characters)
Factory setting	70 (mm or inches)

K-factor

Navigation	 Expert → Application → Maths → Maths x → DP flow → K-factor Direct access code: 400121-00x Examples: Maths 1: 400121-000; Maths 4: 400121-003
Description	Set the K-factor (blockage factor) for the pitot tube (see nameplate on the probe). Only visible if Device type= Pitot tube
User entry	Number (max. 8 characters)
Factory setting	0,6

Pipe material

Navigation	 Expert → Application → Maths → Maths x → DP flow → Pipe material Direct access code: 400127-00x Examples: Maths 1: 400127-000; Maths 4: 400127-003
Description	Material of the pipe.
Options	Carbon steel, Stainless steel, 1.5415 / A182F1, 1.7335 / A182F12, 1.7380 / A182F22, 1.4922, 1.4401 / 316, 1.4404 / 316L, 1.4571 / 316Ti
Factory setting	C-steel

Density

Navigation	 Expert → Application → Maths → Maths x → DP flow → Density Direct access code: 400123-00x Examples: Maths 1: 400123-000; Maths 4: 400123-003
Description	Please select density input or mathematics channel, in which the density is calculated. Only visible if application = Liquids DP flow or Gas DP flow

Options Switched off, Universal input x, Digital input x, Maths x
All active inputs are available for selection.

Factory setting Switched off

Density unit

Navigation  Expert → Application → Maths → Maths x → DP flow → Density unit
Direct access code: 400124-00x
Examples: Maths 1: 400124-000; Maths 4: 400124-003

Description Please select the density unit.
Only visible if application = Liquids DP flow or Gas DP flow

Options kg/m³, lb/ft³

Factory setting kg/m³

Design density

Navigation  Expert → Application → Maths → Maths x → DP flow → Design density
Direct access code: 400125-00x
Examples: Maths 1: 400125-000; Maths 4: 400125-003

Description Density under design conditions (at design pressure/temperature).
Only visible if design = V-cone or Gilflo

User entry Number (max. 8 characters)

Factory setting 1000 (kg/m³ or lb/ft³)

Isentropic exponent

Navigation  Expert → Application → Maths → Maths x → DP flow → Isentropic exponent
Direct access code: 400128-00x
Examples: Maths 1: 400128-000; Maths 4: 400128-003

Description Input of the kappa isentropic exponent. (Required in order to calculate the expansion number).
Only visible if application = gas DP flow

User entry Number (max. 8 characters)

Factory setting 1.2

"Viscosity" submenu

Navigation	 Expert → Application → Maths → Maths x → DP flow → Viscosity
Description	Input of the viscosity at two support points. (Needed to calculate the Reynolds number and flow coefficient). Only visible if application = Liquids DP flow or Gas DP flow

Support point 1

Temperature

Navigation	 Expert → Application → Maths → Maths x → DP flow → Viscosity → Temperature Direct access code: 400130-00x Examples: Maths 1: 400130-000; Maths 4: 400130-003
Description	Temperature
User entry	Number (max. 8 characters)
Factory setting	0

Viscosity

Navigation	 Expert → Application → Maths → Maths x → DP flow → Viscosity → Viscosity Direct access code: 400131-00x Examples: Maths 1: 400131-000; Maths 4: 400131-003
Description	Viscosity at the specified temperature.
User entry	Number (max. 8 characters)
Factory setting	1 cp

Support point 2

Temperature

Navigation	 Expert → Application → Maths → Maths x → DP flow → Viscosity → Temperature Direct access code: 400135-00x Examples: Maths 1: 400135-000; Maths 4: 400135-003
Description	Temperature
User entry	Number (max. 8 characters)
Factory setting	100

Viscosity

Navigation	 Expert → Application → Maths → Maths x → DP flow → Viscosity → Viscosity Direct access code: 400136-00x Examples: Maths 1: 400136-000; Maths 4: 400136-003
Description	Viscosity at the specified temperature.
User entry	Number (max. 8 characters)
Factory setting	0.3 cp

"Totalization" submenu

Navigation	 Expert → Application → Maths → Maths x → Totalization
Description	Settings only needed if the calculated value - e.g. for quantity calculation - should be integrated. Analysis time frames, see "Signal analysis".

Totalization

Navigation	 Expert → Application → Maths → Maths x → Totalization → Totalization Direct access code: 400050-00x Examples: Maths 1: 400050-000; Maths 4: 400050-003
Description	By totalizing the analog signal (e.g. flow rate in m ³ /h) quantities (in m ³) can be calculated.
Options	No, Yes
Factory setting	No

Totalization base

Navigation	 Expert → Application → Maths → Maths x → Totalization → Totalization base Direct access code: 400051-00x Examples: Maths 1: 400051-000; Maths 4: 400051-003
Description	Select the required time base. Example: ml/s -> time base seconds (s); m ³ /h -> time base hours (h). Only visible if totalization = yes
Options	Second (s), Minute (min), Hour (h), Day (d)
Factory setting	Second (s)

Unit

Navigation	 Expert → Application → Maths → Maths x → Totalization → Unit Direct access code: 400052-00x Examples: Maths 1: 400052-000; Maths 4: 400052-003
Description	Enter the unit for the calculated quantity (e.g. "m ³ "). Only visible if totalization = yes
User entry	Text (max. 6 characters)

Total. eng. unit (option "Energy package")

Navigation	 Expert → Application → Maths → Maths x → Totalization → Total. eng. unit. Direct access code: 400112-00x Examples: Maths 1: 400112-000; Maths 4: 400112-003
Description	Select the unit of the quantity determined by means of totalization here. Only visible if function = energy or mass calculation and totalization = yes
Options	kWh, MWh, MJ, GJ, kBtu, MBtu, tonh, therm, kg, t, lbs, ton

Low flow cut off

Navigation	 Expert → Application → Maths → Maths x → Totalization → Low flow cut off Direct access code: 400053-00x Examples: Maths 1: 400053-000; Maths 4: 400053-003
-------------------	--

Description If the volume flow recorded is below the set value, these quantities are not added to the counter.
 If the input is scaled from 0 to y, or if the pulse input is used, all values that are smaller than the set value are not recorded.
 If the input is scaled from -x to +y, all values around the zero point (e.g. also negative values) are not recorded.
 Only visible if totalization = yes

User entry Number (max. 8 digits)

Factory setting 0

Calc. factor

Navigation  Expert → Application → Maths → Maths x → Totalization → Calc. factor
 Direct access code: 400054-00x
 Examples: Maths 1: 400054-000; Maths 4: 400054-003

Description Factor for calculating the integrated value (e.g. the transmitter delivers l/s → totalization base = second → engineering unit required is m³ → enter factor 0.001)
 Only visible if totalization = yes

User entry Number (max. 8 digits)

Factory setting 1.0

Totalizer

Navigation  Expert → Application → Maths → Maths x → Totalization → Totalizer
 Direct access code: 400055-00x
 Examples: Maths 1: 400055-000; Maths 4: 400055-003

Description Initial setting for the totalizer. Useful when continuing measurements recorded to date with an (electro)-mechanical counter.
 Only visible if totalization = yes

User entry Number (max. 15 digits)

Factory setting 0

"Linearization" submenu

Navigation  Expert → Application → Maths → Maths x → Linearization

Description Linearization settings.
 Only visible if Function = Formula Editor

Linearization

Navigation	 Expert → Application → Maths → Maths x → Linearization → Linearization Direct access code: 400301-00x Examples: Maths 1: 400301-000; Maths 4: 400301-003
Description	Specify whether this input should be linearized.
Options	No, Yes
Factory setting	No

Number of Points

Navigation	 Expert → Application → Maths → Maths x → Linearization → Number of Points Direct access code: 400302-00x Examples: Maths 1: 400302-000; Maths 4: 400302-003
Description	Specify how many support points your linearization table has. Note: The first and last point always has to correspond to the start and end of the measuring range respectively.
User entry	2 ... 32
Factory setting	2

Dim. linearized value

Navigation	 Expert → Application → Maths → Maths x → Linearization → Dim. linearized value Direct access code: 400303-00x Examples: Maths 1: 400303-000; Maths 4: 400303-003
Description	Unit/dimension for the linearized value. Note: The first and last point always has to correspond to the start and end of the measuring range respectively.
User entry	Text (max. 6 characters)

Zoom start

Navigation	 Expert → Application → Maths → Maths x → Linearization → Zoom start Direct access code: 400304-00x Examples: Maths 1: 400304-000; Maths 4: 400304-003
-------------------	---

Description If the total transmitter range is not used, you can enter the lower value of the required section here (higher resolution).
Example: Transmitter 0-14 pH, required section: 5-9 pH. Set "5" here. Zooming does not affect the save function.

User entry Number (max. 8 characters)

Factory setting 0

Zoom end

Navigation  Expert → Application → Maths → Maths x → Linearization → Zoom end
Direct access code: 400305-00x
Examples: Maths 1: 400305-000; Maths 4: 400305-003

Description Like "Zoom start". However, enter the upper value of the required range here.
Example: Transmitter 0-14 pH, required section: 5-9 pH. Input here: "9".

User entry Number (max. 8 characters)

Factory setting 100

"Points" submenu

Navigation  Expert → Application → Maths → Maths x → Linearization → Points

Description Enter the support points of the linearization table here.
Note: The first and last point always has to correspond to the start and end of the measuring range respectively. The support points can only be viewed in the PC software here. To change the support points use the "Edit table" switch.

Check table

Navigation  Expert → Application → Maths → Maths x → Linearization → Points → Check table
Direct access code: 400306-00x
Examples: Maths 1: 400306-000; Maths 4: 400306-003

Description Here you can check whether the linearization table has been entered correctly.

Options No, Yes

Factory setting No

Sort table

Navigation	 Expert → Application → Maths → Maths x → Linearization → Points → Sort table Direct access code: 400307-00x Examples: Maths 1: 400307-000; Maths 4: 400307-003
Description	You can sort the linearization table here.
Options	No, Yes
Factory setting	No

x-value (1...32)

Navigation	 Expert → Application → Maths → Maths x → Linearization → Points → x-value (1...32) Direct access code, x-value 1: 400310-00x Direct access code, x-value 2: 400312-00x Examples: Maths 1, x-value 1: 400310-000; Maths 4: 400310-003
Description	x-value for the linearization (value from the device input). e.g. 10 cm corresponds to 20 liters --> enter 10.
User entry	Number (max. 8 characters)
Factory setting	0

y-value (1...32)

Navigation	 Expert → Application → Maths → Maths x → Linearization → Points → y-value (1...32) Direct access code, y-value 1: 400311-00x Direct access code, y-value 2: 400313-00x Examples: Maths 1, y-value 1: 400311-000; Maths 4: 400311-003
Description	Enter the y-value that the measured x-value corresponds to e.g. 10 cm corresponds to 20 liters --> enter 20.
User entry	Number (max. 8 characters)
Factory setting	0

"Fault mode" submenu

Navigation	 Expert → Application → Maths → Maths x → Fault mode
Description	Contains settings that specify how this channel is to behave in the event of an error (e.g. if an input channel has a cable open circuit or there is division by 0).

Wet steam alarm

Navigation	 Expert → Application → Maths → Maths x → Fault mode → Wet steam alarm Direct access code: 400113-00x Examples: Maths 1: 400113-000; Maths 4: 400113-003
Description	Condensation of steam! Process temperature = saturated steam temperature = condensate temperature. Only visible if application = steam heat quantity or steam heat difference
Options	Counter stop, Saturated steam calculation
Factory setting	Counter stop

On error

Navigation	 Expert → Application → Maths → Maths x → Fault mode → On error Direct access code: 400060-00x Examples: Maths 1: 400060-000; Maths 4: 400060-003
Description	Configure what value the device should continue working with (for calculations) if the measured value is not valid (e.g. cable open circuit).
Options	Invalid calculation, Error value
Factory setting	Invalid calculation

Error value

Navigation	 Expert → Application → Maths → Maths x → Fault mode → Error value Direct access code: 400061-00x Examples: Maths 1: 400061-000; Maths 4: 400061-003
Description	The device continues calculating with this value in the event of an error. Only visible if On error = Error value
User entry	Number (max. 8 digits)
Factory setting	0

Copy settings

Navigation	 Expert → Application → Maths → Maths x → Copy settings Direct access code: 400200-00x Examples: Maths 1: 400200-000; Maths 4: 400200-003
Description	Copies settings from actual channel to selected channel.
Options	No, In maths. channel x Users can choose from all the available maths channels.
Factory setting	No

"Signal analysis" submenu

Navigation	 Expert → Application → Signal analysis
Description	Contains settings for signal analysis (saving).

Analysis x

Navigation	 Expert → Application → Signal analysis → Analysis x Direct access code: 44000x-000 Examples: Analysis 1: 440000-000; Analysis 4: 440003-000
Description	For the set timeframe, determines the minimum, maximum and average value or quantities and operating times.  If the "Externally controlled" option is to be used, a digital input or a maths channel must be set to "Function = Control input" and "Action = Start/stop analysis x".
Options	Switched off, Externally controlled, 1min, 2min, 3min, 4min, 5min, 10min, 15min, 30min, 1h, 2h, 3h, 4h, 6h, 8h, 12h Daily analysis, Weekly analysis, Monthly analysis, Annual analysis
Factory setting	Switched off

Synchron. time

Navigation	 Expert → Application → Signal analysis → Synchron. time Direct access code: 440004-000
Description	Time for completing the signal analysis. If, for example, 07:00 is set up then the daily analysis will run from 07:00 of the actual day until 07:00 of the following day.
User entry	Time
Factory setting	00:00

Week starting on

Navigation	 Expert → Application → Signal analysis → Week starting on Direct access code: 440005-000
Description	Configure what day the weekly analysis should start. Only visible if at least one analysis = weekly analysis
Options	Sunday, Monday, Tuesday, Wednesday, Thursday, Friday, Saturday
Factory setting	Monday

Alarm statistics (option "Tele-Alarm")

Navigation	 Expert → Application → Signal analysis → Alarm statistics Direct access code: 440006-000
Description	The following data can be determined via the signal analysis cycles (e.g. daily analysis): ■ How often was the set point violated ■ How long was the set point violated
Options	No, Yes
Factory setting	No

Group days (option "Tele-Alarm")

Navigation	 Expert → Application → Signal analysis → Group days Direct access code: 440008-000
Description	Set-up how often the weekly- monthly- or yearly analysis are to be calculated. "No": each individual alarm is counted. "Yes": The number of days within the analysis cycle in which at least one limit value violation took place (e.g. required for the number of overflows in a storm overflow tank).
Options	No, Yes
Factory setting	No

Reset to zero

Navigation	 Expert → Application → Signal analysis → Reset to zero Direct access code: 440007-000
-------------------	--

Description Reset analysis.
Note: should only be executed after the device has taken over the setup.

Options Please select, Analysis x, Totalizer, All

Factory setting Please select

Reset channel

Navigation  Expert → Application → Signal analysis → Reset channel
Direct access code: 440010-000

Description Reset analysis of a single channel.
Note: should only be executed after the device has taken over the setup.

Options Please select, Universal input x, Digital input x, Maths x, Set point x, Relay x
All active inputs are available for selection.

Factory setting Please select

"Autom. printout" submenu

Navigation  Expert → Application → Signal analysis → Autom. printout

Description Specify whether an automatic print-out should follow at the end of an evaluation.
 The printout is only made if a USB printer is connected to the device or a network printer is available.
For supported printers please refer to the Operating Instructions.
If the Batch option is selected, the printout is configured in the Batch mode/Print menu.

Analysis x

Navigation  Expert → Application → Signal analysis → Autom. printout → Analysis x
Direct access code, analysis 1: 440020-000
Direct access code, analysis 2: 440021-000
Direct access code, analysis 3: 440022-000
Direct access code, analysis 4: 440023-000

Description Specify whether an automatic print-out should follow at the end of an evaluation.
 The print-out is only made if a USB printer is connected to the device!
For supported printers please refer to the Operating Instructions.
If the Batch option is selected, the printout is configured in the Batch mode/Print menu.

Options No, Yes

Factory setting	No
------------------------	----

"Limits" submenu

Navigation	 Expert → Application → Limits
-------------------	---

Description	Limit values can monitor the measured values. A relay, for example, can be switched if a limit value is violated.
--------------------	---

Add limit value

Navigation	 Expert → Application → Limits → Add limit value Direct access code: 450300-000
-------------------	---

Description	Adding a new limit value.
--------------------	---------------------------

Options	No, Yes
----------------	---------

Factory setting	No
------------------------	----

Delete limit value

Navigation	 Expert → Application → Limits → Delete limit value Direct access code: 450301-000
-------------------	--

Description	Deleting a limit value from the list.
--------------------	---------------------------------------

Options	No, limit value x
----------------	-------------------

Factory setting	No
------------------------	----

Change set points

Navigation	 Expert → Application → Limits → Change set points Direct access code: 450100-000
-------------------	---

Description	Specify where the limit values can be changed. If you select "Outside of setup also", you can change limit values in the "Operation" menu as well as in "Setup". This allows you to adjust your limit values to the process even if setup is locked. Note: This function can/should be protected by the limit value code.
--------------------	--

Options	Only in setup, Outside of setup also
----------------	--------------------------------------

Factory setting	Only in setup
------------------------	---------------

"Set point x" submenu

Navigation	 Expert → Application → Limits → Limit x
Description	View or change the setup for the selected alarm set point.  x = place holder for selected limit value



Channel/value

Navigation	 Expert → Application → Limits → Limit x → Channel/value Direct access code: 450000-0xx Examples: Set point 1: 450000-000; Set point 30: 450000-029
Description	Select which input/calculated value the limit value refers to.
Options	Switched off, Universal input x, Digital input x, Maths x, Set point x
Factory setting	Switched off



Type

Navigation	 Expert → Application → Limits → Limit x → Type Direct access code: 450001-0xx Examples: Set point 1: 450001-000; Set point 30: 450001-029
Description	Type of limit value (depends on the input variable).
Options	Switched off, Upper set point, Lower set point, Analysis x, Gradient dy/dt, Analysis x frequency, Analysis x duration, Inband, Outband

Description of the individual set point types

Set point type/function	Description
Hysteresis	For every set point, the switch point can be controlled via a hysteresis. The hysteresis is set as an absolute value (positive values only) in the unit of the respective channel (e.g. upper set point = 100 m, hysteresis = 1 m: Set point on = 100 m, set point off = 99 m)
Upper set point	The limit value is active if the value exceeds the configured value. The limit is deactivated when the value drops below the limit value incl. hysteresis.  A0010187-EN
Lower set point	The limit is active if the value drops below the configured value. The limit is deactivated when the value exceeds the limit value incl. hysteresis.  A0010186-EN

Set point type/function	Description
Gradient dy/dt	The "Gradient" operating mode is used to monitor the temporal change of the input signal. The alarm is triggered if the measured value reaches or exceeds the preset value. If a positive value has been set, the limit value is monitored on increasing gradients. In the case of negative values the decreasing gradient is monitored. The alarm is canceled when the gradient drops below the preset value. A hysteresis is not possible in the Gradient operating mode. The alarm can be suppressed for the set time delay (unit: seconds s) in order to decrease the sensitivity. Measured value M_0 $\cong$ Set point M_{0-m} T_m = Time for gradient evaluation (Time base in seconds) T_m T_0 Setpoint "on" Setpoint "off" A0010188-EN
Inband	The limit value is violated as soon as the measured value to be checked exceeds or drops below a preset maximum or minimum respectively. The hysteresis must be monitored on the inside of the band. For the limit value to no longer be violated, the value must lie within the hysteresis range. Measured value Setpoint Setpoint Hysteresis Hysteresis Setpoint active Setpoint not active A0010192-EN

Set point type/function	Description
Outband	The limit value is violated as soon as the measured value to be checked lies within a preset band between minimum and maximum. The hysteresis must be monitored on the outside of the band. For the limit value to no longer be violated, the value must lie outside of the hysteresis range.  The graph shows a measured value curve over time. A horizontal band between two 'Setpoint' levels is shaded gray, representing the hysteresis range. The curve enters this band from below, then rises above it, and finally falls back into it. The time when the curve enters the band is marked as 'Setpoint active', and the time when it leaves the band is marked as 'Setpoint not active'. The hysteresis range is labeled 'Hysteresis' on both sides. A0010189-EN
Special case: Hysteresis and delay for one limit value	In the special case that hysteresis and limit value delay are activated, one limit value is switched according to the following principle. If hysteresis and limit value delay are activated, the delay becomes active when a limit value is exceeded and measures the time from which the value is exceeded. If the measured value falls below the limit value, the delay is reset. This also occurs if the measured value falls below the limit value, but continues to be higher than the set hysteresis value. When the limit value is exceeded again, the time delay once more becomes active and starts measuring from 0.  The graph shows a measured value curve over time. A horizontal line represents the 'Setpoint' and a lower line represents the 'Hysteresis' level. The curve crosses the setpoint line, and a shaded gray area labeled 'Delay' begins. When the curve falls below the hysteresis level, the delay is reset. When the curve crosses the setpoint line again, the delay begins once more. The time when the delay starts is marked as 'Setpoint active', and the time when it ends is marked as 'Setpoint not active'. The delay period is labeled 'Delay time is reset'. A0010193-EN

Factory setting Switched off

Identifier

Navigation	 Expert → Application → Limits → Limit x → Identifier Direct access code: 450015-0xx Examples: Set point 1: 450015-000; Set point 30: 450015-029
Description	Name of the set point for identification purposes.
User entry	Text (max. 16 characters)
Factory setting	Limit x

Set point

Navigation	 Expert → Application → Limits → Limit x → Set point Direct access code: 450003-0xx Examples: Set point 1: 450003-000; Set point 30: 450003-029
Description	Limit value in the set process unit, e.g. in °C, m³/h
User entry	Number (max. 10 digits)
Factory setting	0

Set point 2

Navigation	 Expert → Application → Limits → Limit x → Limit 2 Direct access code: 450017-0xx Examples: Set point 1: 450017-000; Set point 30: 450017-029
Description	Enter the upper limit value for the band. Only visible if type = inband or outband
User entry	Number (max. 8 digits)
Factory setting	0

Time span dt

Navigation	 Expert → Application → Limits → Limit x → Time span dt Direct access code: 450014-0xx Examples: Set point 1: 450014-000; Set point 30: 450014-029
Description	Time span within which the signal must change by the specified value before it is recognized as a set point. Note: max. 60 seconds. Only visible if type = gradient dy/dt
User entry	0 ... 60 s
Factory setting	60 s

Hysteresis (abs.)

Navigation	 Expert → Application → Limits → Limit x → Hysteresis (abs.) Direct access code: 450004-0xx Examples: Set point 1: 450004-000; Set point 30: 450004-029
-------------------	--

Description	The alarm condition is only canceled when the signal has changed into the normal operation range by the preset value.
--------------------	---

User entry	Number (max. 8 digits)
-------------------	------------------------

Factory setting	0
------------------------	---

Time delay

Navigation	 Expert → Application → Limits → Limit x → Time delay Direct access code: 450005-0xx Examples: Set point 1: 450005-000; Set point 30: 450005-029
-------------------	---

Description	In order to be interpreted as an alarm the signal must exceed or undercut the preset value by at least the time set up.
--------------------	---

User entry	0 ... 99999 s
-------------------	---------------

Factory setting	0 s
------------------------	-----

Switches

Navigation	 Expert → Application → Limits → Limit x → Switches Direct access code: 450006-0xx Examples: Set point 1: 450006-000; Set point 30: 450006-029
-------------------	---

Description	Switches the appropriate output in the limit value state.
--------------------	---

Options	Not used, Relay x
----------------	-------------------

Factory setting	Not used
------------------------	----------

LV messages

Navigation	 Expert → Application → Limits → Limit x → LV messages Direct access code: 450007-0xx Examples: Set point 1: 450007-000; Set point 30: 450007-029
-------------------	--

Description	"Do not acknowledge": Alarm condition is signaled by highlighting the tag name in red (no message is output). "Acknowledge": In the event of an alarm, a message is also displayed. This message then has to be acknowledged.
--------------------	--

Options Do not acknowledge, Acknowledge

Factory setting Do not acknowledge

Save event

Navigation  Expert → Application → Limits → Limit x → Save event
Direct access code: 450008-0xx
Examples: Set point 1: 450008-000; Set point 30: 450008-029

Description Stores a message in the event log on limit value violation.

Options No, Yes

Factory setting Yes

Event text LV on

Navigation  Expert → Application → Limits → Limit x → Event text LV on
Direct access code: 450009-0xx
Examples: Set point 1: 450009-000; Set point 30: 450009-029

Description This text (including date and time) is shown on the display and/or stored in the event log. Only available if "LV messages" is set to "Acknowledge" or "Save message" is set to "Yes". If no text is entered, the device generates its own text (e.g. Analog 1 > 100%).

User entry Text (max. 22 characters)

Event text LV off

Navigation  Expert → Application → Limits → Limit x → Event text LV off
Direct access code: 450010-0xx
Examples: Set point 1: 450010-000; Set point 30: 450010-029

Description The same as "Event text LV on", but on return from alarm to normal condition.

User entry Text (max. 22 characters)

Record duration of LV on

Navigation

Expert → Application → Limits → Limit x → Record duration of LV on
 Direct access code: 450011-0xx
 Examples: Set point 1: 450011-000; Set point 30: 450011-029

Description

The duration of a set point violation can be recorded. The duration is appended to the "limit value off" event text (format: <hhhh>h<mm>:<ss>).
 Power failure times do not affect the duration. If the set point was violated before the power failure and is still violated after the power failure, the duration continues.

Options

No, Yes

Factory setting

No

Reset relay**Navigation**

Expert → Application → Limits → Limit x → Reset relay
 Direct access code: 450016-0xx
 Examples: Set point 1: 450016-000; Set point 30: 450016-029

Description

If LV no longer violated: the relay is switched as long as the set point is violated.
 After acknowledging message: even if the set point is no longer violated, the relay remains switched until the message has been acknowledged. If the set point is still violated when the message is acknowledged, the relay stays switched until the set point is no longer violated.
 Up to message acknowledgment: the relay remains active until the message is acknowledged or the set point is no longer active.

Options

If LV no longer violated, After acknowledging message, Up to message acknowledgment

Factory setting

If LV no longer violated

Save cycle**Navigation**

Expert → Application → Limits → Limit x → Save cycle
 Direct access code: 450012-0xx
 Examples: Set point 1: 450012-000; Set point 30: 450012-029

Description

Normal: Save in normal store cycle.
 Alarm cycle: Fast storage during an alarm violation, e.g. every second. Attention: Requires higher memory capacity.



- The save cycle is set under signal groups → 232.
- In the event of an alarm violation, all the groups are saved in the alarm cycle.

Options

Normal, Alarm cycle

Factory setting

Normal

Draw help line

Navigation	 Expert → Application → Limits → Limit x → Draw help line Direct access code: 450013-0xx Examples: Set point 1: 450013-000; Set point 30: 450013-029
Description	The user can configure whether this set point should be displayed in the graphic as a help line (in the color of the channel). Note: 4 lines can be shown per channel in a single group.
Options	No, Yes
Factory setting	No

Copy settings

Navigation	 Expert → Application → Limits → Limit x → Copy settings Direct access code: 450200-0xx Examples: Set point 1: 450200-000; Set point 30: 450200-029
Description	Copies settings from actual channel to selected channel.
Options	No, in limit x (all the limits are displayed)
Factory setting	No

"Batch mode" submenu (option)

Navigation	 Expert → Application → Batch mode
Description	Contains settings for the batch mode.  Detailed descriptions of this device option can be found in the associated documentation.

"Signal groups" submenu

Navigation	 Expert → Application → Signal groups
Description	Group the analog, digital and/or mathematics channels such that you can call up important information at the press of a button during operation (e.g. temperatures, signals in plant unit 1).  ▪ Maximum 8 channels per group! ▪ Highspeed storage (100ms) is only available in group 1.

"Group x" submenu

Navigation	 Expert → Application → Signal groups → Group x
Description	 x = place holder for selected group Various general settings for measured value display of the device.

Identifier

Navigation	 Expert → Application → Signal groups → Group x → Identifier Direct access code: 460000-0xx Examples: Group 1: 460000-000; Group 4: 460000-003
Description	Enter a name for these groups.
User entry	Text (max. 20 characters)
Factory setting	Group x

Save cycle

Navigation	 Expert → Application → Signal groups → Group x → Save cycle Direct access code: 460001-0xx Examples: Group 1: 460001-000; Group 4: 460001-003
Description	Configure the save cycle with which this group should be saved in normal conditions (see also set point / save cycle).  The save cycle is independent of the measured value display (see Operating Instructions).
Options	Off, 100ms (only for group 1), 1s, 2s, 3s, 4s, 5s, 10s, 15s, 20s, 30s, 1min, 2min, 3min, 4min, 5min, 10min, 15min, 30min, 1h
Factory setting	1min

Alarm cycle

Navigation	 Expert → Application → Signal groups → Group x → Alarm cycle Direct access code: 460002-0xx Examples: Group 1: 460002-000; Group 4: 460002-003
Description	Configure the save cycle with which this group should be saved in an alarm condition (set point violation). Attention: Requires higher memory capacity.

Options Off, 100ms (only for group 1), 1s, 2s, 3s, 4s, 5s, 10s, 15s, 20s, 30s, 1min, 2min, 3min, 4min, 5min, 10min, 15min, 30min, 1h

Factory setting 1min

Display blue

Navigation  Expert → Application → Signal groups → Group x → Display blue
Direct access code: 460003-00x
Examples: Group 1: 460003-000; Group 4: 460003-003

Description Choose which input/calculate variable should be displayed in this group.

Options Switched off, Universal input x, Digital input x, Maths x

Factory setting Switched off

Display

Navigation  Expert → Application → Signal groups → Group x → Display
Direct access code: 460004-00x
Examples: Group 1: 460004-000; Group 4: 460004-003

Description Please select which data from the selected channel should be displayed.



If the "Everything" option is selected, the device switches cyclically between the various values of the channel (instantaneous value, analysis 1 etc.)

Options Instantaneous value/state, Analysis x, Totalizer, Everything

Factory setting Instantaneous value/state

Display black

Navigation  Expert → Application → Signal groups → Group x → Display black
Direct access code: 460005-00x
Examples: Group 1: 460005-000; Group 4: 460005-003

Description Choose which input/calculate variable should be displayed in this group.

Options Switched off, Universal input x, Digital input x, Maths x

Factory setting Switched off

Display	
Navigation	 Expert → Application → Signal groups → Group x → Display Direct access code: 460006-0xx Examples: Group 1: 460006-000; Group 4: 460006-003
Description	Please select which data from the selected channel should be displayed.
Options	Instantaneous value/state, Analysis x, Totalizer, Everything
Factory setting	Instantaneous value/state
Display red	
Navigation	 Expert → Application → Signal groups → Group x → Display red Direct access code: 460007-00x Examples: Group 1: 460007-000; Group 4: 460007-003
Description	Choose which input/calculate variable should be displayed in this group.
Options	Switched off, Universal input x, Digital input x, Maths x
Factory setting	Switched off
Display	
Navigation	 Expert → Application → Signal groups → Group x → Display Direct access code: 460008-0xx Examples: Group 1: 460008-000; Group 4: 460008-003
Description	Please select which data from the selected channel should be displayed.
Options	Instantaneous value/state, Analysis x, Totalizer, Everything
Factory setting	Instantaneous value/state
Display green	
Navigation	 Expert → Application → Signal groups → Group x → Display green Direct access code: 460009-00x Examples: Group 1: 460009-000; Group 4: 460009-003
Description	Choose which input/calculate variable should be displayed in this group.

Options Switched off, Universal input x, Digital input x, Maths x

Factory setting Switched off

Display

Navigation  Expert → Application → Signal groups → Group x → Display
Direct access code: 460010-0xx
Examples: Group 1: 460010-000; Group 4: 460010-003

Description Please select which data from the selected channel should be displayed.

Options Instantaneous value/state, Analysis x, Totalizer, Everything

Factory setting Instantaneous value/state

Display violet

Navigation  Expert → Application → Signal groups → Group x → Display violet
Direct access code: 460011-00x
Examples: Group 1: 460011-000; Group 4: 460011-003

Description Choose which input/calculate variable should be displayed in this group.

Options Switched off, Universal input x, Digital input x, Maths x

Factory setting Switched off

Display

Navigation  Expert → Application → Signal groups → Group x → Display
Direct access code: 460012-0xx
Examples: Group 1: 460012-000; Group 4: 460012-003

Description Please select which data from the selected channel should be displayed.

Options Instantaneous value/state, Analysis x, Totalizer, Everything

Factory setting Instantaneous value/state

Display orange

Navigation	 Expert → Application → Signal groups → Group x → Display orange Direct access code: 460013-00x Examples: Group 1: 460013-000; Group 4: 460013-003
Description	Choose which input/calculate variable should be displayed in this group.
Options	Switched off, Universal input x, Digital input x, Maths x
Factory setting	Switched off

Display

Navigation	 Expert → Application → Signal groups → Group x → Display Direct access code: 460014-0xx Examples: Group 1: 460014-000; Group 4: 460014-003
Description	Please select which data from the selected channel should be displayed.
Options	Instantaneous value/state, Analysis x, Totalizer, Everything
Factory setting	Instantaneous value/state

Display cyan

Navigation	 Expert → Application → Signal groups → Group x → Display cyan Direct access code: 460015-00x Examples: Group 1: 460015-000; Group 4: 460015-003
Description	Choose which input/calculate variable should be displayed in this group.
Options	Switched off, Universal input x, Digital input x, Maths x
Factory setting	Switched off

Display

Navigation	 Expert → Application → Signal groups → Group x → Display Direct access code: 460016-0xx Examples: Group 1: 460016-000; Group 4: 460016-003
Description	Please select which data from the selected channel should be displayed.
Options	Instantaneous value/state, Analysis x, Totalizer, Everything
Factory setting	Instantaneous value/state

Display brown

Navigation	 Expert → Application → Signal groups → Group x → Display brown Direct access code: 460017-00x Examples: Group 1: 460017-000; Group 4: 460017-003
Description	Choose which input/calculate variable should be displayed in this group.
Options	Switched off, Universal input x, Digital input x, Maths x
Factory setting	Switched off

Display

Navigation	 Expert → Application → Signal groups → Group x → Display Direct access code: 460018-0xx Examples: Group 1: 460018-000; Group 4: 460018-003
Description	Please select which data from the selected channel should be displayed.
Options	Instantaneous value/state, Analysis x, Totalizer, Everything
Factory setting	Instantaneous value/state

Grid divisions

Navigation	 Expert → Application → Signal groups → Group x → Grid divisions Direct access code: 460019-0xx Examples: Group 1: 460019-000; Group 4: 460019-003
Description	Indicates the number of lines ("amplitude grid") that should be displayed. Example: display of 0 ... 100%: select 10 divisions, display 0 ... 14pH: select 14 divisions.
Options	Logarithmic, 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20
Factory setting	10

Min. decade

Navigation	 Expert → Application → Signal groups → Group x → Min. decade Direct access code: 460020-0xx Examples: Group 1: 460020-000; Group 4: 460020-003
-------------------	--

Description	Set the decade from which the display should be split.
Options	1, 10, 100, 1000, 10000, 100000, 1000000, 10000000
Factory setting	1

Max. decade

Navigation	 Expert → Application → Signal groups → Group x → Max. decade Direct access code: 460021-0xx Examples: Group 1: 460021-000; Group 4: 460021-003
-------------------	--

Description	Set the decade up to which the display should be split.
Options	1, 10, 100, 1000, 10000, 100000, 1000000, 10000000
Factory setting	10000

Curve display

Navigation	 Expert → Application → Signal groups → Group x → Curve display Direct access code: 460022-0xx Examples: Group 1: 460022-000; Group 4: 460022-003
-------------------	--

Description	The instantaneous values are displayed as standard for the measured value curves. Alternatively, this current value display can also be disabled which means that more data can be shown on the display as a result.
Options	No instantaneous values, With instantaneous values
Factory setting	With instantaneous values

Curve display

Navigation	 Expert → Application → Signal groups → Group x → Curve display Direct access code: 460023-0xx Examples: Group 1: 460023-000; Group 4: 460023-003
-------------------	--

Description	Configure the background color for the curve display.
Options	White background, Black background
Factory setting	White background

Zoom

Navigation	 Expert → Application → Signal groups → Group x → Zoom Direct access code: 460028-0xx Examples: Group 1: 460028-000; Group 4: 460028-003
Description	Defines the zoom that is shown in "Curves" or "Waterfall" display mode. This setting does not affect other display modes (e.g. Curves in range, Bar graph etc.).
Options	Do not display, Scroll display, Display blue, Display black, Display red, Display green, Display violet, Display orange, Display cyan, Display brown
Factory setting	Do not display

Bargraph

Navigation	 Expert → Application → Signal groups → Group x → Bargraph Direct access code: 460024-0xx Examples: Group 1: 460024-000; Group 4: 460024-003
Description	Configure the direction in which the bar graphs should be drawn.
Options	Vertical (bottom->top), Vertical (top->bottom), Horizontal (left->right), Horizontal (right->left), Centered/vertical, Centered/horizontal
Factory setting	Vertical (bottom->top)

Batch assignment (option)

Navigation	 Expert → Application → Signal groups → Group x → Batch assignment Direct access code: 460025-0xx Examples: Group 1: 460025-000; Group 4: 460025-003
Description	Configure what batch this group belongs to.  - Channels can be assigned to multiple batches/groups. - Only relevant for batch printout.
Options	Do not assign any batch, Assign all batches, Batch x
Factory setting	Assign all batches

Save group (Batch option)

Navigation	 Expert → Application → Signal groups → Group x → Save group Direct access code: 460026-0xx Examples: Group 1: 460026-000; Group 4: 460026-003
Description	The group will always be saved or only when the allocated batch is active.
Options	Only when batch is active, Always
Factory setting	Always

"Circular chart" submenu

Navigation	 Expert → Application → Signal groups → Group x → Circular chart
Description	Contains settings for the circular chart.

1 revolution =

Navigation	 Expert → Application → Signal groups → Group x → Circular chart → 1 revolution = Direct access code: 460027-0xx Examples: Group 1: 460027-000; Group 4: 460027-003
Description	Configure how long it takes for the circular chart to be written to once completely (one complete revolution). Note: The device only ever shows 1/4 of the circular chart.
Options	1 hour , x hours , 1 day, x days
Factory setting	1 hour

"E-mail" submenu

Navigation	 Expert → Application → E-mail  With Tele-Alarm option under Expert → Application → Tele-Alarm → General → E-mail setup
Description	Contains settings required if alarms are to be transmitted by e-mail.  Test the e-mail settings under Diagnostics → Simulation → E-mail.

SMTP host

Navigation	 Expert → Application → E-mail → SMTP host Direct access code: 510062-000
Description	Enter your SMTP host here. If necessary, contact your network administrator or e-mail provider.

User entry Text (max. 40 characters)

Server requires SSL

Navigation  Expert → Application → E-mail → Server requires SSL
Direct access code: 510061-000

Description Specify whether the e-mail server requires a secure connection (SSL).
STARTTLS: Runs on the same TCP port as unencrypted SMTP (port 25 or 587).
SMTPS: Completely encrypted with own TCP port (465).
If necessary, contact your network administrator or e-mail provider.

Options No, Yes (SMTPS), Yes (STARTTLS)

Factory setting No

Port

Navigation  Expert → Application → E-mail → Port
Direct access code: 510063-000

Description Enter your SMTP port here. If necessary, contact your network administrator or e-mail provider.

User entry Number (max. 4 digits)

Factory setting 25

Sender

Navigation  Expert → Application → E-mail → Sender
Direct access code: 510064-000

Description Enter the e-mail address of the device here (this text appears as the sender of the e-mail).
If necessary, contact your network administrator or e-mail provider.



If a valid e-mail address is not configured this might cause e-mail transmission problems, depending on the particular provider.

User entry Text (max. 60 characters)

User name

Navigation	 Expert → Application → E-mail → User name Direct access code: 510066-000
Description	Configure the user name of the e-mail account here. If necessary, contact your network administrator or e-mail provider.
User entry	Text (max. 60 characters)

Password

Navigation	 Expert → Application → E-Mail → Password Direct access code: 510067-000
Description	Enter the password for authentication here. If necessary, contact your network administrator or e-mail provider.
User entry	Text (max. 22 characters)

"E-mail addresses" submenu

Navigation	 Expert → Application → E-mail → E-mail addresses
Description	Here, enter all the e-mail addresses messages should be sent to in the event of an alarm.  Assignment to the alarms is performed later on.

E-mail address x

Navigation	 Expert → Application → E-mail → E-mail addresses → E-mail address x Direct access code: E-mail address 1: 510080-000 ... E-mail address 5: 510084-000
Description	Here, enter an e-mail address a message should be sent to.  Assignment to the alarms is performed later on.
User entry	Text (max. 60 characters)

"Limit value violations" submenu

Navigation	 Expert → Application → E-mail → Limit value violations
-------------------	--

Description Specify who should receive e-mails when limit value violations occur (both on and off messages).



Only for limit values where "Save message" is set to "Yes".

Recipient x

Navigation Expert → Application → E-mail → Limit value violations → Recipient x
Direct access code:
Recipient 1: 510110-000; Recipient 2: 510111-000

Description Select who should receive the e-mail.

Options Not used, E-mail address x

Factory setting Not used

"On/off messages" submenu

Navigation Expert → Application → E-mail → On/off messages

Description Specify who should receive e-mails when "on"/"off" messages occur (for digital inputs or maths channels).



Only for inputs where "Save message" is set to "Yes".

Recipient x

Navigation Expert → Application → E-mail → On/off messages → Recipient x
Direct access code:
Recipient 1: 510115-000; Recipient 2: 510116-000

Description Select who should receive the e-mail.

Options Not used, E-mail address x

Factory setting Not used

"Errors (Fxxx/Sxxx)" submenu

Navigation Expert → Application → E-mail → Errors (Fxxx/Sxxx)

Description Specify who should receive e-mails when errors occur (Fxxx and Sxxx messages).

Recipient x

Navigation	 Expert → Application → E-mail → Errors → Recipient x Direct access code: Recipient 1: 510120-000; Recipient 2: 510121-000
Description	Select who should receive the e-mail.
Options	Not used, E-mail address x
Factory setting	Not used

"Maintenance required" (submenu)

Navigation	 Expert → Application → E-mail → Maintenance required
Description	Specify who should receive e-mails when maintenance is required (Mxxx messages).

Recipient x

Navigation	 Expert → Application → E-mail → Maintenance required → Recipient x Direct access code: Recipient 1: 510130-000; Recipient 2: 510131-000
Description	Select who should receive the e-mail.
Options	Not used, E-mail address x
Factory setting	Not used

"Printer" submenu

Navigation	 Expert → Application → Printer
Description	Contains printer settings.  Only relevant if a printer is directly connected to the device.

Parameter	Description	Direct access code
Printer	Please select the printer you wish to use. For supported printers please refer to the Operating Instructions.	540000-000
IP address	Enter the IP address of the network printer here. If you do not know the IP address, contact your network administrator. Note: A DNS name may also be used.	540001-000
Port	Please enter the port of your network printer (available from your network administrator). Note: Port 9100 is usually used.	540002-000
Color printer	Please specify whether you are using a black and white or color printer.	540003-000
Paper size	Please select the paper size of your printer.	540004-000
Print direction	Select the print direction as per the properties of the printer used.	540006-000

Parameter	Description	Direct access code
Characters/ line	Enter the maximum number of characters per line here.	540007-000
Blank rows at the end	Enter the number of blank lines required at the end of the printout to make it easier to tear off.	540008-000
Fault switches	You can switch a relay if an error occurs during the printout. The relay remains switched until the printer is ready again or the device is restarted.	540005-000
"Serial interface" submenu	Settings required if you are using the RS232 or RS485 interface of the device.	150101-000 150103-000

"Softkeys" submenu

Navigation	 Expert → Application → Softkeys
Description	You can configure the functions that are assigned to the softkeys of the device.

Softkey 1...3

Navigation	 Expert → Application → Softkeys → Softkey x Direct access code, softkey 1: 520000-000 Direct access code, softkey 2: 520001-000 Direct access code, softkey 3: 520002-000
Description	Specify the function to be assigned to this softkey.
Options	Not assigned, Safe SD Card removal, Remove USB stick safely, Printout, Enter batch info, Event log/audit trail, Historic measured values, Log on to the device (login), Log out of the device (logout), Screenshot, Search in trace, Show analyses, Change set point, Next group, Operation
Factory setting	Softkey 1: Event log/audit trail Softkey 2: Historic measured values Softkey 3: Search in trace

"Texts" submenu

Navigation	 Expert → Application → Texts
Description	Settings only needed if you want to save text for subsequent reporting. Here, configure the text that can be saved in the event log during operation.

Text 1...30

Navigation

 Expert → Application → Texts → Text x
Direct access code, text 1: 530000-000
...
Direct access code, text 30: 530029-000

Description

Generate or change the text.

User entry

Text (max. 22 characters)

"Wastewater" submenu (option)

Navigation

 Expert → Application → Wastewater

Description

Contains settings for using the device in the wastewater sector.
 Detailed descriptions of this device option can be found in the associated documentation.

"Tele-Alarm" submenu (option)

Navigation

 Expert → Application → Tele-Alarm

Description

Contains settings for alerts via a modem connected to the device or by e-mail.
 Detailed descriptions of this device option can be found in the associated documentation.

"WebDAV Client" submenu

Navigation

 Expert → Application → WebDAV Client

Description

All recorded data are transmitted to an external WebDAV server (e.g. NAS). The format can be specified or selected via **"Setup → Advanced setup → System → External memory -> Save as"**.

Parameter	Description	Direct access code
Enable	Switch the WebDAV Client functionality on/off. When active, the device copies the saved measured values automatically to the configured server.  Only possible using the Ethernet interface! Selection: No, Yes, Yes (SSL) Factory setting: No	472000-000
IP address	Enter the IP address of the WebDAV server here.  A DNS name can also be used. Entry: IP address Factory setting: 0.0.0.0	472001-000

Parameter	Description	Direct access code
Port	This communication port is used to communicate with the WebDAV Server.  If your network is protected by a firewall, this port may have to be enabled. Please contact your network administrator if this is the case. Entry: Numbers (max. 5 digits) Factory setting: 80	472002-000
User name	Input of the user name that can access the WebDAV server. Entry:Text (max. 20 characters)	472004-000
Password	Password for accessing the WebDAV server. Entry:Text (max. 20 characters)	472007-000
Directory	Enter the directory in which the data should be saved. Entry:Text (max. 120 characters)	472005-000
Save as	"Protected format": All data is stored in a manipulation protected encrypted format. They can be interpreted only by the PC analysis software provided. "Open format": data is stored in a CSV format, this can be opened by a number of different programs (e.g. MS Excel) (Attention: no manipulation security). Selection: protected format, open format (*.csv) Factory setting: protected format	472010-000

 Test of WebDAV Client settings under "**Diagnostics → Simulation → WebDAV Client**".

17.1.6 "Diagnostics" submenu

Device information and service functions for a swift device check.

 Only some of the diagnostic functions are available under Expert → Diagnostics. For other functions, see Main menu → Diagnostics

Actual diagnostics

Navigation  Expert → Diagnostics → Actual diagnostics
Direct access code: 050000-000

Description Displays the current diagnosis message.

Last diagnostics

Navigation  Expert → Diagnostics → Last diagnostics
Direct access code: 050005-000

Description Displays the last diagnosis message.

Last restart

Navigation	 Expert → Diagnostics → Last restart Direct access code: 050010-000
Description	Information as to when the device was last restarted (e.g. due to a power failure).

"Diagnosis list" submenu

Navigation	 Expert → Diagnostics → Diagnosis list
Description	All diagnosis messages are listed in chronological order.

"Event logbook" submenu

Navigation	 Expert → Diagnostics → Event logbook
Description	Events such as alarm set point infringement and power failure are listed in the correct time sequence.

"Device information" submenu

Navigation	 Expert → Diagnostics → Device information
Description	Displays important device information.

Device tag

Navigation	 Expert → Diagnostics → Device information → Device tag Direct access code: 000031-000
Description	Individual device tag name/unit identifier (max. 32 characters).

Serial number

Navigation	 Expert → Diagnostics → Device information → Serial number Direct access code: 000027-000
Description	Individual serial number of the device. Please provide these details when ordering spare parts or asking any questions about the unit.

Order code

Navigation

Expert → Diagnostics → Device information → Order code
Direct access code: 000029-000

Description

Displays the order code.

The order code indicates the attribute of all the features of the product structure for the device and thus uniquely identifies the device. It can also be found on the nameplate.

**Uses of the order code**

- To order an identical spare device.
- To check the ordered device features using the delivery note.

Firmware Version

Navigation

Expert → Diagnostics → Device information → Firmware Version
Direct access code: 000026-000

Description

Displays the installed firmware version of the device. Please send these details with any questions about the unit.

ENP version

Navigation

Expert → Diagnostics → Device information → ENP version
Direct access code: 000032-000

Description

Displays the version of the electronic nameplate. Please send these details with any questions about the unit.

ENP device name

Navigation

Expert → Diagnostics → Device information → ENP device name
Direct access code: 000020-000

Description

Displays the ENP device name (electronic name plate). Please send these details with any questions about the unit.

Device name

Navigation

Expert → Diagnostics → Device information → Device name
Direct access code: 000021-000

Description

Displays the device name. Please send these details with any questions about the unit.

Manufacturer ID

Navigation	 Expert → Diagnostics → Device information → Manufacturer ID Direct access code: 000022-000
Description	Displays the manufacturer ID. Please send these details with any questions about the unit.

Manufacturer name

Navigation	 Expert → Diagnostics → Device information → Manufacturer name Direct access code: 000023-000
Description	Displays the manufacturer name. Please send these details with any questions about the unit.

Firmware

Navigation	 Expert → Diagnostics → Device information → Firmware Direct access code: 009998-000
Description	Displays the installed firmware of the device. Please send these details with any questions about the unit.

"Simulation" submenu

Navigation	 Expert → Diagnostics → Simulation
Description	Settings for simulation mode.

Operating mode

Navigation	 Expert → Diagnostics → Simulation → Operating mode Direct access code: 010010-000
Description	Normal operation: Unit plots the signals from the connected measurement points. Simulation: Instead of operating with the real measurement points the signals are simulated (using the actual settings).
Options	Normal operation, Simulation
Factory setting	Normal operation

Index

Symbols

--> Profibus DP (parameter) 190

0 ... 9

1 hour= (parameter) 156

1 revolution = (parameter) 240

1 second= (parameter) 156

A

Access code (parameter) 119

Acknowledging messages (parameter) 124

Action (parameter) 156

Activation code (parameter) 128

Actual diagnostics (parameter) 247

Actual value (parameter) 146, 147, 164, 165

Add HART value (parameter) 180

Add input (parameter) 131, 153

Add limit value (parameter) 222

Admin ID (parameter) 175

Admin password (parameter) 175

Administrator (parameter) 175

Administrator, ID, password (parameter) 121

Alarm cycle (parameter) 232

Alarm response (parameter) 126

Alarm statistics (parameter) 220

Analysis x (parameter) 219

Analysis x for automatic printout (parameter) 221

Application (parameter) 130, 192

Application (submenu) 191

Authentication (submenu) 121

Automatic printout (submenu) 221

B

Barcode reader (submenu) 126

Bargraph (parameter) 239

Batch (parameter) 173

Batch assignment (parameter) 239

Batch mode (parameter) 231

Baudrate (parameter) 182

Begin summer time (parameter) 115

C

Cable open circuit detection (parameter) 150

Calc. factor (parameter) 137, 149, 214

CE mark (declaration of conformity) 9

CE-mark 106

Change date/time (submenu) 113

Change set points (parameter) 222

Channel ident. (parameter) 135, 154

Channel/value (parameter) 223

Character set (parameter) 127

Check table (parameter) 144

Check table for linearization (parameter) 216

Circular chart (submenu) 240

Clear memory (parameter) 112

Communication

 Ethernet TCP/IP 25

Communication (parameter) 129

Communication (submenu) 167

Comparison point (parameter) 141

Comparison temp. (parameter) 141

Configuration Web server (submenu) 172

Connection quality (parameter) 176

Connection type (parameter) 133

Control relays (parameter) 173

Copy settings (parameter) 152, 161, 218, 231

Correction RPT (parameter) 146

Counter engineering unit (parameter) 136

CSV settings (parameter) 123

Current date/time (parameter) 113

Curve display (parameter) 238

D

d at 20 °C (Parameter) 208

D at 20 °C (parameter) 208

Damping (parameter) 141

Damping/filter (parameter) 162

Data type (parameter) 135

Date (parameter) 116, 117

Date format (parameter) 112

Date/time (parameter) 114, 124

Date/time (submenu) 113

Date/time setup (submenu) 112

Day (parameter) 115, 117

Decimal point (parameter) 138, 155

Decimal separator (parameter) 110

Declaration of Conformity 9

Delete HART value (parameter) 180

Delete input (parameter) 131, 153

Delete limit value (parameter) 222

Density (parameter) 209

Density unit (parameter) 210

Description 'H' (parameter) 158, 199

Description 'L' (parameter) 158, 199

Design density (parameter) 210

Device info (submenu) 248

Device name 249

Device options (submenu) 128

Device tag 248

Device tag (parameter) 109

Device type (parameter) 192

DHCP (parameter) 168

Diagnosis list (submenu) 248

Diagnostic messages 67

Diagnostics (submenu) 247

Diameter unit (parameter) 208

Differential pressure (parameter) 207

Digital inputs (submenu) 153

Dim. linearized value (parameter) 143, 215

Direct access (parameter) 109

Disable port (parameter) 170

Display (parameter) 233, 234, 235, 236, 237

Display black (parameter) 233

Display blue (parameter) 233
 Display brown (parameter) 237
 Display cyan (parameter) 236
 Display green (parameter) 234
 Display orange (parameter) 235
 Display red (parameter) 234
 Display violet (parameter) 235
 Domain Name System (DNS) (parameter) 170
 DP flow (submenu) 207
 DP unit (parameter) 208
 Draw help line (parameter) 231

E

E-mail (submenu) 240
 E-mail address x (parameter) 242
 E-mail addresses (submenu) 242
 End summer time (parameter) 116
 End value range (parameter) 138
 Engineering unit (parameter) 136, 154
 ENP device name 249
 ENP version 249
 Error (Fxxx/Sxxx) (submenu) 243
 Error messages 67
 Error value (parameter) 152, 166, 218
 Ethernet 38
 Ethernet (submenu) 168
 Event logbook (submenu) 248
 Event message (parameter) 159, 200
 Event text H->L (parameter) 160, 200
 Event text L->H (parameter) 159, 200
 Event text LV off (parameter) 229
 Event text LV on (parameter) 229
 Expert (Menu) 109
 External memory (submenu) 122

F

Failure mode (parameter) 179
 Fault mode (submenu) 150, 165, 217
 Fault switching (parameter) 110
 FDA 21 CFR Part 11 107
 Field Data Manager (FDM) analysis software
 Function scope 36
 Fieldbus (parameter) 130
 FieldCare configuration software 44
 FieldCare/DeviceCare configuration software
 Function scope 37
 Firmware (parameter) 250
 Firmware update (parameter) 172
 Firmware Version (parameter) 249
 Flow (parameter) 192
 Flow engineering unit (parameter) 193
 Flow installation point (parameter) 193
 Formula (parameter) 191
 Formula editor (parameter) 202
 Formula editor (submenu) 202
 Full scale value (parameter) 162
 Function (parameter) 153, 154

G

Gateway (parameter) 169
 Get timeout (parameter) 177
 Grid divisions (parameter) 237
 Group (parameter) 157
 Group days (parameter) 220
 Group x (submenu) 232

H

HART (submenu) 179
 HART attempts on error (parameter) 179
 HART channel ident. (parameter) 181
 HART connection (parameter) 180
 HART device address (parameter) 180
 HART IP port (parameter) 171
 HART master type (parameter) 179
 HART process variable (parameter) 181
 Hysteresis (abs.) (parameter) 227

I

Identifier (parameter) 167, 226, 232
 Input factor in (parameter) 155
 Inputs (submenu) 130
 IP address (parameter) 120, 133, 169
 Isentropic exponent (parameter) 210

K

K-factor (parameter) 209
 Keyboard layout (parameter) 110

L

Language (parameter) 109
 Last diagnostics (parameter) 247
 Last restart (parameter) 247
 LED operating mode (parameter) 111
 Limit value violations (submenu) 242
 Limit x (submenu) 223
 Limits (submenu) 222
 Linearization (parameter) 142, 215
 Linearization (submenu) 142, 214
 Lock hardware (parameter) 120
 Lock operation (parameter) 111
 Low flow cut off (parameter) 148, 213
 Lower correction value (parameter) 164
 Lower error value (parameter) 150
 Lower frequency (parameter) 139
 LV messages (parameter) 228

M

MAC-address (parameter) 168
 Maintenance required (submenu) 244
 Manufacturer ID (parameter) 250
 Manufacturer name 250
 Maths (submenu) 191
 Maths x action (parameter) 197
 Maths x channel ident. (parameter) 191
 Maths x decimal point (parameter) 197
 Maths x engineering unit (parameter) 196, 197
 Maths x function (parameter) 191

Maths x plot type (parameter) 196
 Maths x set point (parameter) 198
 Max. decade (parameter) 238
 Measured value correction (submenu) 145, 163
 Measured value type (parameter) 133
 Medium (parameter) 195
 Memory build-up (parameter) 122
 Messages (submenu) 124
 Min. decade (parameter) 237
 Modbus (parameter) 183
 Modbus Master (parameter) 130, 185
 Modbus Master (submenu) 185
 Modbus Master baudrate (parameter) 187
 Modbus Master command distribution (parameter) . 187
 Modbus Master connection attempts (parameter) . 186
 Modbus Master parity (parameter) 188
 Modbus Master scan cycle (parameter) 185
 Modbus Master serial interface (submenu) 187
 Modbus Master stop bits (parameter) 188
 Modbus RTU/(TCP/IP) 38
 Modbus Slave (submenu) 183
 Modbus Slave baudrate (parameter) 184
 Modbus Slave parity (parameter) 184
 Modbus Slave serial interface (submenu) 184
 Modbus Slave stop bits (parameter) 185
 Month (parameter) 115, 117

N

NAMUR NE 43 (parameter) 150, 165
 NT/ST changeover (parameter) 114
 NT/ST changeover (submenu) 114
 NT/ST region (parameter) 115
 Number of support points (parameter) 143
 Number of support points for linearization
 (parameter) 215

O

Occurrence (parameter) 115, 116
 OFF daily from (parameter) 126
 Offset (parameter) 145
 ON daily from (parameter) 126
 On error (parameter) 151, 165, 218
 On/off messages (submenu) 243
 OPC port (parameter) 171
 OPC server
 Function scope 37
 Operating mode (parameter) 166, 250
 Operating time (Parameter) 124
 Operation options
 Local operation 30
 Operating tool 30
 Overview 30
 Operational safety 9
 Operator (parameter) 174
 Operator ID (parameter) 174
 Operator password (parameter) 174
 Operator, ID, password (parameter) 121
 Order code 248
 Other standards and guidelines 107

Outputs (submenu) 161
 Overview of symbols 34

P

Paper size (parameter) 111
 Parity (parameter) 182
 Password (parameter) 242
 Pause between Modbus Master commands
 (parameter) 187
 Ping interval (parameter) 177
 Ping retry (parameter) 178
 Ping timeout (parameter) 178
 Pipe material (parameter) 209
 Plot type (parameter) 136
 Poll timeout (parameter) 178
 Port (parameter) 120, 134, 170, 172, 184, 241
 PRESET (parameter) 112
 Pressure (parameter) 193
 Pressure engineering unit (parameter) 194
 Printer (submenu) 244
 Product safety 9
 Profibus DP (submenu) 188
 Profibus DP bit 0.0 ... 0.7 (parameter) 190
 Profibus DP byte x...y (parameter) 189
 Profibus DP Master in/out (parameter) 189
 Profibus DP Slave address (parameter) 188
 Profibus DP slot x (submenu) 189
 Protected by (parameter) 119
 Protocol (parameter) 182
 Pulse counter (parameter) 137
 Pulse width (parameter) 163
 Put timeout (parameter) 177

R

Range (parameter) 132
 Range start (parameter) 139, 146
 Readout function (parameter) 134
 Recipient x (parameter) 243, 244
 Record duration (parameter) 160, 201
 Record duration of LV on (parameter) 229
 Reference channel (parameter) 161
 Register address (parameter) 135
 Registered trademarks 7
 Registers per Modbus Master command (parameter) 186
 Relay (submenu) 166
 Remote control (parameter) 173
 Remote controlled (parameter) 167
 Reset channel (parameter) 221
 Reset relay (parameter) 230
 Reset to zero (parameter) 220
 Response timeout from Modbus Master (parameter) 186
 Return 77

S

Save as (parameter) 122
 Save as event (parameter) 127
 Save cycle (parameter) 230, 232
 Save event (parameter) 152, 159, 199, 229
 Save group (parameter) 239

Screen saver (parameter)	125
Screen saver (submenu)	125
SD card (parameter)	122
Security (submenu)	119
Sender (parameter)	241
Separator for CSV (parameter)	124
Serial interface (submenu)	181
Serial number	248
Server requires SSL (parameter)	241
Service (parameter)	175
Service ID (parameter)	175
Service password (parameter)	176
Service, ID, password (parameter)	122
Set point (parameter)	157, 227
Set point 2 (parameter)	227
Set point code (parameter)	119
Set timeout (parameter)	177
Setup (parameter)	172
Setup via Web server	43
Show Profibus DP status (parameter)	189
Signal (parameter)	131, 161
Signal analysis (submenu)	219
Signal groups (submenu)	231
Simulation (submenu)	250
Slave address (parameter)	134
Slot 1 (parameter)	128
Slot 2 (parameter)	128
Slot 3 (parameter)	129
Slot 4 (parameter)	129
Slot 5 (parameter)	129
SMTP host (parameter)	240
SNTP (parameter)	118
SNTP (submenu)	118
SNTP server 1 (parameter)	118
SNTP server 2 (parameter)	118
Softkey 1...3 (parameter)	245
Softkeys (submenu)	245
Sort table (parameter)	144
Sort table for linearization (parameter)	216
Staff	
Requirements	8
Start value (parameter)	162
Start value range (parameter)	138
Stop bits (parameter)	182
Structure of the operating menu	30, 31
Subnetmask (parameter)	169
Support point 1 viscosity (parameter)	211
Support point 2 viscosity (parameter)	211
Support points (submenu)	144
Support points for linearization (submenu)	216
Swap mouse buttons (parameter)	111
Switches (parameter)	168, 228
Switches relay (parameter)	123, 125, 158, 198
Symbols	
Event logbook	35
Operating menus	35
Synchron. time (parameter)	219
System (submenu)	109

T

Target value (parameter)	146, 147, 164
Tele-Alarm (submenu)	246
Temperature (parameter)	211
Temperature (steam/cold) (heat difference) (parameter)	194
Temperature (water/steam/warm) (parameter)	194
Temperature unit (parameter)	110
Text 1...30 (parameter)	245
Text entry	35
Texts (submenu)	245
The result is (parameter)	195
Time (parameter)	116, 117
Time base (parameter)	136
Time delay (parameter)	151, 156, 228
Time format (parameter)	113
Time span dt (parameter)	227
Timeout (parameter)	167
Timeout fieldbus (parameter)	168
Timeout sequences (parameter)	127
Timeouts (submenu)	176
Totalization (parameter)	148, 212
Totalization (submenu)	147, 212
Totalization base (parameter)	148, 212
Totalization Engineering unit (parameter)	213
Totalizer (parameter)	142, 149, 160, 202, 214
Transmission protocol (parameter)	133
Troubleshooting	
Alarm relay	66
Type (parameter)	223
Type RS232/RS485 (parameter)	181

U

UL approval	107
Unit (parameter)	148, 213
Unit address (parameter)	183
Universal input x (submenu)	131
Universal inputs (submenu)	130
Universal output (submenu)	161
Upper correction value (parameter)	164
Upper error value (parameter)	151
Upper frequency (parameter)	139
Upper range value (parameter)	140, 147
User name (parameter)	241
UTC time zone (parameter)	113, 114

V

Value (parameter)	132
Value per pulse (parameter)	137, 155, 162
Value x HART (submenu)	180
Viscosity (parameter)	211, 212
Viscosity (submenu)	211

W

Warning at (parameter)	123
Wastewater (submenu)	246
Water/glycol concentration (parameter)	195
Water/steam temperature engineering unit (parameter)	195

Web server 53
 Function scope 37
Web server (parameter) 171
Web server authentication (submenu) 174
WebDAV Client (submenu) 246
WebDAV server (parameter) 173
Week starting on (parameter) 220
Wet steam alarm (parameter) 218
Workplace safety 9

X

x-value (1...32) (parameter) 145
x-value (1...32) for linearization (parameter) 217

Y

y-value (1...32) (parameter) 145
y-value (1...32) for linearization (parameter) 217

Z

Zoom (parameter) 239
Zoom end (parameter) 140, 143, 201
Zoom end for linearization (parameter) 216
Zoom start (parameter) 140, 143, 201
Zoom start for linearization (parameter) 215

www.addresses.endress.com
