



## Manufacturer Information

for users regarding software updates  
(following the NAMUR recommendation 53)

### Field Xpert / Device Xpert - Package V1.05.00 (SFX100)

incl. new Device Xpert HART 1.07.00 and Device Xpert FF 1.01.00 software

#### 1 Type of Product

- Field device / signal processing device
- Software application for device configuration / handheld terminal / device drivers etc.
- Modem / interface

Manufacturer : Endress+Hauser Process Solutions AG  
 Product : **Field Xpert - Device Xpert**  
 Type and order code : **SFX100**

#### 2 Software

Previous software version : Package V1.04.00:  
 Device Xpert HART 1.06.03 - English/German  
 Device Xpert FF 1.00.00 - English

New software version : **Package V1.05.00:**  
**Device Xpert HART 1.07.00 - English/German**  
**Device Xpert FF 1.01.00 - English/German**

How can the previous software version number be identified? : Printed on delivered Field Xpert CD-ROM or within the Device Xpert software, menu item **Help => About**

Description of the modification in comparison with the predecessor version : **The modifications of Device Xpert HART software extends the Field Xpert handheld usage to new HART 7 devices. Device Xpert FF software is now also available in a german version.**

Where to get the new Software? The recommended and fastest update procedure is:  
(possible since Device Xpert HART v1.6.x and Device Xpert FF 1.00.00)

1. Precondition: Connect the Field Xpert handheld to the Internet, done via USB connection to the PC/Laptop with installed ActiveSync (Windows XP) or Windows Mobile Device Center (Windows 7) software and Internet access. Consider a possible necessary proxy).
2. Start Device Xpert HART or Device Xpert FF software on Field Xpert.

The new software versions are automatically recognized after a



## Manufacturer Information

for users regarding software updates  
(following the NAMUR recommendation 53)

few seconds on the Field Xpert handheld and can then be downloaded. Follow the instructions on the screen. The new Device Xpert HART version needs a complete new set of Device Descriptions (DDs), which are also synchronized via Internet (possible for 8 days after new Device Xpert HART 1.07.00 software is installed).

Alternative way:

The new software is also available as download on the product website: <http://www.products.endress.com/sfx100> tab "Documents/software" and on the product CD "Field Xpert - Device Xpert Package V1.05.00".

### 3 Compatibility

Is the new product software compatible with the previous version, installed device driver components and operating tools?

Yes

Device Xpert HART 1.07.00 needs due to the new HART 7 Manufacturer IDs (6 byte instead of 2 byte) and Device IDs (4 byte instead of 2 byte) a complete **new set of Device Descriptions (DDs)**. **It is recommended to have a fast Internet connection to update to the new Device Xpert HART 1.07.00 version.**

Device Reports and Device Images are compatible with the previous Device Xpert HART version.

No, reason:

--

Is a software update generally recommended?

Yes, reason:

To use the actual Field Xpert HART Device Descriptions (DD-Library) from HART Communication Foundation (2012-02) it is recommended to update to the new software version (meanwhile more than 1250 HART DDs are included).

No, reason:

--

### 4 Instruction manual

Is a new instruction manual necessary due to the software modification?

Yes

No



## Manufacturer Information

for users regarding software updates  
(following the NAMUR recommendation 53)

The manual that corresponds to the actual software version is:

Product	Communication	Manual type	Document identifier
Field Xpert	HART + FOUNDATION fieldbus	Opererating Instructions Field Xpert Device Configurator	BA00060S/04/en/14.12

Remarks:

The instruction manuals can be downloaded from the Internet:

<http://www.products.endress.com/sfx100> -> Tab "Documents/Software"

### 5 Price

Change in price in comparison with the predecessor version?

- Yes, new list price and update costs (without installation)  
 No

# Device Xpert HART V1.07.00 - DD Library List

Status dated 2012.08.07

R09

DDs for Language:

EN

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Device Revision	DD Revision
ABB	0x00001a	2600T 266 Pressure	0x0007	1	1
ABB	0x00001a	2600T-262/264	0x0004	1	1
ABB	0x00001a	2600T-262/264	0x0004	2	2
ABB	0x00001a	2600T-266 MV	0x008e	1	1
ABB	0x00001a	2600T-268	0x0003	1	1
ABB	0x00001a	2600T-268	0x0003	3	1
ABB	0x00001a	2600T-364	0x0005	1	2
ABB	0x00001a	261	0x008c	1	1
ABB	0x00001a	263/265, 2000T	0x0089	2	2
ABB	0x00001a	263/265, 2000T	0x0089	2	3
ABB	0x000012	50SM1000	0x001a	4	1
ABB	0x000012	50VM1000	0x000f	0	4
ABB	0x000012	50VT1000	0x000e	0	5
ABB	0x000012	50XE4000	0x0008	0	6
ABB	0x000012	50XM1000	0x0019	4	2
ABB	0x000012	50XM2000	0x0007	0	5
ABB	0x00001a	600T	0x0002	1	2
ABB	0x00001a	600T	0x0002	2	3
ABB	0x00001a	600T	0x0002	3	4
ABB	0x00001a	652/653S	0x000c	1	2
ABB	0x00001a	658T	0x000a	1	2
ABB	0x00001a	ACA592EC	0x0031	1	1
ABB	0x00001a	ACA592TC	0x0033	1	1
ABB	0x00001a	ACA592TE	0x0032	1	1
ABB	0x00001a	APA592PH	0x0030	1	1
ABB	0x000016	AS800	0x0085	2	2
ABB	0x000016	Confrac	0x0087	1	1
ABB	0x00001a	EDP300	0x008d	1	1
ABB	0x00001a	EDP300_EXP	0x1a8d	2	1
ABB	0x00001a	FEX100	0x001f	0	1
ABB	0x00001a	FEX300	0x001e	0	1
ABB	0x00001a	FieldKey NHU200-WL	0x1a99	1	2
ABB	0x00001a	FSM4000	0x001d	0	0
ABB	0x00001a	FSM4000	0x001d	1	1
ABB	0x00001a	FVS4000	0x001a	0	11
ABB	0x00001a	KST	0x0008	1	2
ABB	0x00001a	KSX	0x0001	5	2
ABB	0x000012	PTH	0x0042	1	1
ABB	0x000012	TB82EC CONC	0x0055	1	1
ABB	0x000012	TB82EC COND	0x0054	1	1
ABB	0x00001a	TB82EC-Combined	0x0024	1	1
ABB	0x000012	TB82PH IConc	0x0053	1	1
ABB	0x000012	TB82PH ORP	0x0051	1	1
ABB	0x000012	TB82PH pH	0x0050	1	1
ABB	0x000012	TB82PH pION	0x0052	1	1
ABB	0x00001a	TB82PH-Combined	0x0023	1	1
ABB	0x000012	TB82TC CONC	0x0059	1	1
ABB	0x000012	TB82TC COND	0x0058	1	1
ABB	0x00001a	TB82TC-Combined	0x0026	1	1
ABB	0x000012	TB82TE CONC	0x0057	1	1
ABB	0x000012	TB82TE COND	0x0056	1	1
ABB	0x00001a	TB82TE-Combined	0x0025	1	1
ABB	0x000016	TEU 211	0x0005	1	2
ABB	0x000016	TEU 211	0x0005	2	2
ABB	0x000016	TEU 211	0x0005	3	2
ABB	0x000016	TH 02	0x0008	1	1
ABB	0x000016	TS 11	0x0006	1	2
ABB	0x000016	TS 11	0x0006	2	2
ABB	0x000016	TS 11	0x0006	3	2
ABB	0x00001a	TTX200	0x000d	2	2
ABB	0x00001a	TTX300 series	0x000b	2	3
ABB	0x000016	TZID	0x0040	1	1
ABB	0x000016	TZIDC	0x0041	1	1
ABB	0x00001a	VA Master FAM540	0x001b	0	3
Accutech	0x00005e	AI1500	0x00ef	1	1

# Device Xpert HART V1.07.00 - DD Library List

Status dated 2012.08.07

R09

DDs for Language:

EN

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Device Revision	DD Revision
Accutech	0x00005e	VR-1500	0x00ee	1	1
Actaris Neptune	0x000028	NEXGEN	0x0001	1	1
Actaris Neptune	0x000028	NEXGEN	0x0001	1	2
Action Instruments	0x000089	T798	0x00ef	1	1
American Level	0x0000b2	Model_32E	0x007f	1	1
Ametek	0x000003	NEWTHERMOX	0x0004	1	1
Ametek	0x000003	NEWTHERMOX	0x0004	2	1
Ametek	0x000003	NEWTHERMOX	0x0004	3	1
Analytical Technology	0x00009f	D12	0x007f	2	0
Anderson Instrument Company	0x00005a	ANDRSN1	0x00c8	1	3
APLISENS	0x0000bc	APC-2000ALW	0x007b	1	1
APLISENS	0x0000bc	LI-24	0x007a	1	1
Apparatebau Hundsbach	0x000071	MT115	0x00ee	1	1
Badger Meter	0x0000bd	M2000	0xbd02	1	1
Badger Meter	0x0000bd	Primo Advanced	0x0001	1	1
BD Sensors	0x0000b9	D331A	0x007f	4	2
BERTHOLD	0x0000a1	LB460	0x007e	1	1
BERTHOLD	0x0000a1	LB490	0x007f	1	1
BERTHOLD	0x0000a1	LB490	0x007f	2	2
BERTHOLD	0x0000a1	LB490	0x007f	3	3
BERTHOLD	0x0000a1	LB490	0x007f	3	4
BERTHOLD	0x0000a1	LB491	0x007d	1	2
BERTHOLD	0x0000a1	LB491	0x007d	2	3
BERTHOLD	0x0000a1	LB491	0x007d	2	4
Besta	0x000066	CLS 4-20	0x00ef	1	1
BIFFI	0x0000b7	HRT2000v4	0xb77e	1	1
BIFFI	0x0000b7	HRTIMVS2000	0x007d	1	1
Bopp & Reuther Messtechnik	0x00006c	DIMF	0x00ee	7	1
Bopp & Reuther Messtechnik	0x00006c	ES	0x00ec	2	1
Bopp & Reuther Messtechnik	0x00006c	UMC2	0x00eb	3	1
Bopp & Reuther Messtechnik	0x00006c	UST 1	0x00ef	1	2
Bopp & Reuther Messtechnik	0x00006c	UST 1	0x00ef	7	1
Bopp & Reuther Messtechnik	0x00006c	VTX	0x00ed	7	1
Bourdon Haenni	0x000060	FLEXBAR 3501	0x00ed	1	3
Bourdon Haenni	0x000060	FLEXBAR HRT	0x00ee	1	4
Bourdon Haenni	0x000060	FLEXTOP HRT	0x00ef	1	1
Bourdon Haenni	0x000060	FLEXTOP HRT	0x00ef	2	1
Brooks Instrument	0x00000a	38XXVA	0x0002	1	1
Brooks Instrument	0x00000a	QUANTIM	0x0004	1	1
Brooks Instrument	0x00000a	TRI20	0x0001	1	1
BTG	0x000055	HCM-8000	0x00de	1	1
Daehan Control	0x006003	SS	0xe084	1	1
Danfoss	0x000080	MAGFLO	0x0003	1	1
DDTOP	0x006034	DLT9000	0xe0e1	1	1
Detcon	0x006007	700 Bridge	0xe08b	1	4
Det-Tronics	0x00008f	Eclipse	0x007f	1	1
Det-Tronics	0x00008f	GT3000	0x007b	1	1
Det-Tronics	0x00008f	OPECL_RX	0x007e	1	1
Det-Tronics	0x00008f	OPECL_RX	0x007e	1	2
Det-Tronics	0x00008f	UD10	0x007a	1	1
Det-Tronics	0x00008f	UD10	0x007a	2	1
Det-Tronics	0x00008f	X2200	0x0076	1	1
Det-Tronics	0x00008f	X3301	0x007c	1	1
Det-Tronics	0x00008f	X3302	0x0079	1	1
Det-Tronics	0x00008f	X5200	0x0077	1	1
Det-Tronics	0x00008f	X9800	0x0078	1	1
DeZurik	0x000091	Positioner	0x00ef	1	4
Direct Measurement	0x000074	RMSA	0x00ef	1	1
Draeger	0x000052	Polytron 7000	0x00eb	1	1
Draeger	0x000052	Polytron2	0x00f7	1	1
Draeger	0x000052	Polytron2	0x00f7	1	2
Draeger	0x000052	Polytron2	0x00f7	3	1
Draeger	0x000052	Polytron2	0x00f7	3	2
Draeger	0x000052	Polytron2 IR	0x00ed	0	5
Draeger	0x000052	Polytron2 IR	0x00ed	1	1

# Device Xpert HART V1.07.00 - DD Library List

Status dated 2012.08.07

R09

DDs for Language:

EN

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Device Revision	DD Revision
Drexelbrook	0x00004e	UNIVERSAL III	0x0002	5	3
Drexelbrook	0x00004e	USonic	0x00eb	2	2
Druck	0x000047	RTX1000H ABS	0x00ef	1	1
Druck	0x000047	RTX1000H Gauge	0x00e9	1	1
Druck	0x000047	RTX1000H SG	0x00ec	1	1
Duon System	0x000086	APT3100	0x006b	2	2
Duon System	0x000086	APT3100	0x006b	4	1
Duon System	0x000086	APT3200	0x0061	2	2
Duon System	0x000086	APT3200	0x0061	4	1
Duon System	0x000086	APT3700N	0x0067	4	1
Duon System	0x000086	ATT2100S	0x0075	2	2
Duon System	0x000086	ATT2100S	0x0075	3	1
Dynisco	0x000072	IPX	0x00e0	1	3
Dynisco	0x000072	IPXII	0x00df	1	1
Dynisco	0x000072	SPX	0x00de	16	2
Dynisco	0x000072	SPX	0x00de	17	3
Endress+Hauser	0x000011	AT70	0x0064	2	2
Endress+Hauser	0x000011	AT70	0x0064	3	1
Endress+Hauser	0x000011	AT70	0x0064	4	1
Endress+Hauser	0x000011	CCM2x3	0x0096	1	3
Endress+Hauser	0x000011	Cerabar M	0x000e	1	1
Endress+Hauser	0x000011	Cerabar M 5x	0x0019	1	1
Endress+Hauser	0x000011	CerabarS	0x0018	10	1
Endress+Hauser	0x000011	CerabarS	0x0018	20	1
Endress+Hauser	0x000011	CerabarS	0x0018	21	1
Endress+Hauser	0x000011	CerabarS	0x0018	21	2
Endress+Hauser	0x000011	CerabarS	0x0018	21	3
Endress+Hauser	0x000011	CERABS /Cerabar S	0x0007	1	1
Endress+Hauser	0x000011	CERABS /Cerabar S	0x0007	2	2
Endress+Hauser	0x000011	CERABS /Cerabar S	0x0007	3	2
Endress+Hauser	0x000011	CERABS /Cerabar S	0x0007	4	1
Endress+Hauser	0x000011	CERABS /Cerabar S	0x0007	5	1
Endress+Hauser	0x000011	CERABS /Cerabar S	0x0007	6	1
Endress+Hauser	0x000011	CERABS /Cerabar S	0x0007	7	1
Endress+Hauser	0x000011	CERABS /Cerabar S	0x0007	7	2
Endress+Hauser	0x000011	CERABS /Cerabar S	0x0007	7	3
Endress+Hauser	0x000011	CLC2x3	0x0093	1	3
Endress+Hauser	0x000011	CLD132	0x0097	1	1
Endress+Hauser	0x000011	CL12x3	0x0092	1	3
Endress+Hauser	0x000011	CM44	0x119c	1	1
Endress+Hauser	0x000011	CNGmass DCI	0x0055	9	1
Endress+Hauser	0x000011	COM2x3	0x0094	1	4
Endress+Hauser	0x000011	CPM2x3	0x0091	1	5
Endress+Hauser	0x000011	Cubemass DCI	0x0049	9	1
Endress+Hauser	0x000011	CUM2x3	0x0095	1	4
Endress+Hauser	0x000011	Deltabar M 5x	0x0021	1	1
Endress+Hauser	0x000011	DeltabarS	0x0017	10	1
Endress+Hauser	0x000011	DeltabarS	0x0017	20	1
Endress+Hauser	0x000011	DeltabarS	0x0017	21	1
Endress+Hauser	0x000011	DeltabarS	0x0017	21	2
Endress+Hauser	0x000011	DeltabarS	0x0017	21	3
Endress+Hauser	0x000011	Deltapilot M 5x	0x0023	1	1
Endress+Hauser	0x000011	DeltapilotS	0x001a	21	1
Endress+Hauser	0x000011	DeltapilotS	0x001a	21	2
Endress+Hauser	0x000011	DeltapilotS	0x001a	21	3
Endress+Hauser	0x000011	DELTAPS/ Deltapilot	0x000b	1	2
Endress+Hauser	0x000011	DELTAPS/ Deltapilot	0x000b	2	2
Endress+Hauser	0x000011	DELTBS/Deltabar S	0x0009	1	2
Endress+Hauser	0x000011	DELTBS/Deltabar S	0x0009	2	2
Endress+Hauser	0x000011	DELTBS/Deltabar S	0x0009	3	1
Endress+Hauser	0x000011	DELTBS/Deltabar S	0x0009	5	1
Endress+Hauser	0x000011	DELTBS/Deltabar S	0x0009	6	1
Endress+Hauser	0x000011	DELTBS/Deltabar S	0x0009	7	1
Endress+Hauser	0x000011	DELTBS/Deltabar S	0x0009	7	2
Endress+Hauser	0x000011	DELTBS/Deltabar S	0x0009	7	3

# Device Xpert HART V1.07.00 - DD Library List

Status dated 2012.08.07

R09

DDs for Language:

EN

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Device Revision	DD Revision
Endress+Hauser	0x000011	FEC12	0x0008	1	2
Endress+Hauser	0x000011	FMG60	0x0013	1	1
Endress+Hauser	0x000011	FMG60	0x0013	2	1
Endress+Hauser	0x000011	FMG60	0x0013	2	2
Endress+Hauser	0x000011	FMG60	0x0013	3	1
Endress+Hauser	0x000011	FMI5x	0x001d	3	1
Endress+Hauser	0x000011	FMP200	0x000d	1	1
Endress+Hauser	0x000011	FMP200	0x000d	2	1
Endress+Hauser	0x000011	FMP4x	0x0012	2	1
Endress+Hauser	0x000011	FMP4x	0x0012	4	1
Endress+Hauser	0x000011	FMP4x I	0x0020	8	1
Endress+Hauser	0x000011	FMR130/Micropilot	0x0006	1	1
Endress+Hauser	0x000011	FMR130/Micropilot	0x0006	2	1
Endress+Hauser	0x000011	FMR130/Micropilot	0x0006	3	1
Endress+Hauser	0x000011	FMR130/Micropilot	0x0006	4	1
Endress+Hauser	0x000011	FMR23x	0x000c	1	1
Endress+Hauser	0x000011	FMR23x	0x000c	2	1
Endress+Hauser	0x000011	FMR25x	0x001e	1	1
Endress+Hauser	0x000011	FMR25x	0x001e	4	1
Endress+Hauser	0x000011	FMR25x	0x001e	5	1
Endress+Hauser	0x000011	FMR2xx	0x000f	1	2
Endress+Hauser	0x000011	FMR2xx	0x000f	2	1
Endress+Hauser	0x000011	FMR2xx	0x000f	4	1
Endress+Hauser	0x000011	FMR53x	0x0010	1	2
Endress+Hauser	0x000011	FMR53x	0x0010	2	1
Endress+Hauser	0x000011	FMR53x	0x0010	3	1
Endress+Hauser	0x000011	FMR54x	0x001f	1	1
Endress+Hauser	0x000011	FMR54x	0x001f	1	2
Endress+Hauser	0x000011	FMU231/FMU13x	0x000a	1	2
Endress+Hauser	0x000011	FMU231/FMU13x	0x000a	2	2
Endress+Hauser	0x000011	FMU4x	0x0011	2	2
Endress+Hauser	0x000011	FMU4x	0x0011	4	1
Endress+Hauser	0x000011	FMU860	0x0003	1	2
Endress+Hauser	0x000011	FMU860	0x0003	2	3
Endress+Hauser	0x000011	FMU860	0x0003	3	1
Endress+Hauser	0x000011	FMU861	0x0004	1	1
Endress+Hauser	0x000011	FMU861	0x0004	2	2
Endress+Hauser	0x000011	FMU861	0x0004	3	1
Endress+Hauser	0x000011	FMU862	0x0005	1	1
Endress+Hauser	0x000011	FMU862	0x0005	2	2
Endress+Hauser	0x000011	FMU862	0x0005	3	1
Endress+Hauser	0x000011	FMU9x	0x001b	1	1
Endress+Hauser	0x000011	FMU9x	0x001b	2	1
Endress+Hauser	0x000011	FMU9x	0x001b	3	1
Endress+Hauser	0x000011	Levellflex FMP5x	0x0022	1	1
Endress+Hauser	0x000011	Levellflex FMP5x	0x0022	2	1
Endress+Hauser	0x000011	Liquiline M Cci	0x0090	15	1
Endress+Hauser	0x000011	Liquiline M Cci	0x0090	16	1
Endress+Hauser	0x000011	Liquiline M DO	0x009b	22	1
Endress+Hauser	0x000011	Liquiline M pH-ORP	0x008f	12	1
Endress+Hauser	0x000011	Mycom LFC	0x0099	1	1
Endress+Hauser	0x000011	MyPro LFC	0x008d	1	2
Endress+Hauser	0x000011	MyPro LFC	0x008d	2	1
Endress+Hauser	0x000011	MyPro LFI	0x008e	2	1
Endress+Hauser	0x000011	MyPro pH	0x008c	1	2
Endress+Hauser	0x000011	MyPro pH	0x008c	2	1
Endress+Hauser	0x000011	NMS530	0x00b6	2	1
Endress+Hauser	0x000011	NMT530	0x00b5	4	1
Endress+Hauser	0x000011	P_FLOW90	0x0058	1	1
Endress+Hauser	0x000011	P_FLOW90	0x0058	2	1
Endress+Hauser	0x000011	P_FLOW90	0x0058	3	1
Endress+Hauser	0x000011	P_FLOW90	0x0058	4	1
Endress+Hauser	0x000011	P_FLOW90	0x0058	5	1
Endress+Hauser	0x000011	P_FLOW91	0x0062	1	1
Endress+Hauser	0x000011	P_FLOW91	0x0062	2	1

# Device Xpert HART V1.07.00 - DD Library List

Status dated 2012.08.07

R09

DDs for Language:

EN

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Device Revision	DD Revision
Endress+Hauser	0x000011	P_FLOW91	0x0062	3	1
Endress+Hauser	0x000011	P_FLOW92	0x0061	1	1
Endress+Hauser	0x000011	P_FLOW92	0x0061	2	1
Endress+Hauser	0x000011	P_FLOW93	0x0059	1	2
Endress+Hauser	0x000011	P_FLOW93	0x0059	2	2
Endress+Hauser	0x000011	P_FLOW93	0x0059	3	2
Endress+Hauser	0x000011	P_FLOW93	0x0059	4	1
Endress+Hauser	0x000011	P_FLOW93	0x0059	5	1
Endress+Hauser	0x000011	P_FLOW93	0x0059	6	1
Endress+Hauser	0x000011	P_FLOW93	0x0059	7	1
Endress+Hauser	0x000011	P_FLOW93	0x0059	8	1
Endress+Hauser	0x000011	PROMAG10	0x0045	1	1
Endress+Hauser	0x000011	PROMAG10	0x0045	2	1
Endress+Hauser	0x000011	PROMAG10	0x0045	3	1
Endress+Hauser	0x000011	PROMAG10	0x0045	4	1
Endress+Hauser	0x000011	PROMAG10	0x0045	4	2
Endress+Hauser	0x000011	PROMAG23	0x0046	1	1
Endress+Hauser	0x000011	PROMAG23	0x0046	2	1
Endress+Hauser	0x000011	PROMAG33	0x0032	1	2
Endress+Hauser	0x000011	PROMAG33	0x0032	2	1
Endress+Hauser	0x000011	PROMAG35S	0x0036	1	1
Endress+Hauser	0x000011	PROMAG39	0x0035	1	1
Endress+Hauser	0x000011	PROMAG50	0x0041	1	2
Endress+Hauser	0x000011	PROMAG50	0x0041	2	1
Endress+Hauser	0x000011	PROMAG50	0x0041	3	1
Endress+Hauser	0x000011	PROMAG50	0x0041	4	1
Endress+Hauser	0x000011	PROMAG50	0x0041	5	1
Endress+Hauser	0x000011	PROMAG50	0x0041	6	1
Endress+Hauser	0x000011	PROMAG50	0x0041	7	1
Endress+Hauser	0x000011	PROMAG50	0x0041	8	1
Endress+Hauser	0x000011	PROMAG50	0x0041	9	1
Endress+Hauser	0x000011	PROMAG51	0x0043	2	1
Endress+Hauser	0x000011	PROMAG51	0x0043	3	1
Endress+Hauser	0x000011	PROMAG51	0x0043	4	1
Endress+Hauser	0x000011	PROMAG51	0x0043	5	1
Endress+Hauser	0x000011	PROMAG51	0x0043	6	1
Endress+Hauser	0x000011	PROMAG51	0x0043	7	1
Endress+Hauser	0x000011	PROMAG51	0x0043	8	1
Endress+Hauser	0x000011	PROMAG51	0x0043	9	1
Endress+Hauser	0x000011	PROMAG53	0x0042	1	1
Endress+Hauser	0x000011	PROMAG53	0x0042	2	2
Endress+Hauser	0x000011	PROMAG53	0x0042	3	2
Endress+Hauser	0x000011	PROMAG53	0x0042	4	1
Endress+Hauser	0x000011	PROMAG53	0x0042	5	1
Endress+Hauser	0x000011	PROMAG53	0x0042	6	1
Endress+Hauser	0x000011	PROMAG53	0x0042	7	1
Endress+Hauser	0x000011	PROMAG53	0x0042	8	1
Endress+Hauser	0x000011	PROMAG55	0x0044	1	1
Endress+Hauser	0x000011	PROMAG55	0x0044	2	1
Endress+Hauser	0x000011	PROMAG55	0x0044	3	1
Endress+Hauser	0x000011	PROMAG55	0x0044	4	1
Endress+Hauser	0x000011	Promass 200	0x0054	1	1
Endress+Hauser	0x000011	Promass 200	0x0054	2	1
Endress+Hauser	0x000011	PROMASS40	0x0053	1	1
Endress+Hauser	0x000011	PROMASS40	0x0053	2	1
Endress+Hauser	0x000011	PROMASS40	0x0053	3	1
Endress+Hauser	0x000011	PROMASS40	0x0053	4	1
Endress+Hauser	0x000011	PROMASS40	0x0053	5	1
Endress+Hauser	0x000011	PROMASS40	0x0053	6	1
Endress+Hauser	0x000011	PROMASS40	0x0053	7	1
Endress+Hauser	0x000011	PROMASS40	0x0053	8	1
Endress+Hauser	0x000011	PROMASS40	0x0053	9	1
Endress+Hauser	0x000011	PROMASS60	0x0039	1	1
Endress+Hauser	0x000011	PROMASS60	0x0039	2	2
Endress+Hauser	0x000011	PROMASS60	0x0039	3	1



# Device Xpert HART V1.07.00 - DD Library List

Status dated 2012.08.07

R09

DDs for Language:

EN

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Device Revision	DD Revision
Endress+Hauser	0x000011	PROMASS63	0x0034	1	3
Endress+Hauser	0x000011	PROMASS63	0x0034	2	1
Endress+Hauser	0x000011	PROMASS63	0x0034	3	3
Endress+Hauser	0x000011	PROMASS63	0x0034	4	1
Endress+Hauser	0x000011	PROMASS80	0x0050	1	1
Endress+Hauser	0x000011	PROMASS80	0x0050	2	1
Endress+Hauser	0x000011	PROMASS80	0x0050	3	1
Endress+Hauser	0x000011	PROMASS80	0x0050	4	1
Endress+Hauser	0x000011	PROMASS80	0x0050	5	1
Endress+Hauser	0x000011	PROMASS80	0x0050	6	1
Endress+Hauser	0x000011	PROMASS80	0x0050	7	1
Endress+Hauser	0x000011	PROMASS80	0x0050	8	1
Endress+Hauser	0x000011	PROMASS80	0x0050	9	1
Endress+Hauser	0x000011	PROMASS83	0x0051	1	2
Endress+Hauser	0x000011	PROMASS83	0x0051	2	3
Endress+Hauser	0x000011	PROMASS83	0x0051	3	2
Endress+Hauser	0x000011	PROMASS83	0x0051	4	2
Endress+Hauser	0x000011	PROMASS83	0x0051	5	1
Endress+Hauser	0x000011	PROMASS83	0x0051	6	1
Endress+Hauser	0x000011	PROMASS83	0x0051	7	1
Endress+Hauser	0x000011	PROMASS83	0x0051	8	1
Endress+Hauser	0x000011	PROMASS83	0x0051	9	1
Endress+Hauser	0x000011	PROMASS84	0x0052	6	1
Endress+Hauser	0x000011	PROMASS84	0x0052	7	1
Endress+Hauser	0x000011	PROMASS84	0x0052	8	1
Endress+Hauser	0x000011	PROMASS84	0x0052	9	1
Endress+Hauser	0x000011	PROSON F	0x0040	1	1
Endress+Hauser	0x000011	PROSON F	0x0040	2	1
Endress+Hauser	0x000011	PROSONIC FLOW B200	0x005a	1	1
Endress+Hauser	0x000011	PROWIRL70	0x0033	1	2
Endress+Hauser	0x000011	PROWIRL72	0x0056	1	1
Endress+Hauser	0x000011	PROWIRL72	0x0056	2	1
Endress+Hauser	0x000011	PROWIRL72	0x0056	3	1
Endress+Hauser	0x000011	PROWIRL72	0x0056	4	1
Endress+Hauser	0x000011	PROWIRL72	0x0056	5	1
Endress+Hauser	0x000011	PROWIRL72	0x0056	6	1
Endress+Hauser	0x000011	PROWIRL72	0x0056	7	1
Endress+Hauser	0x000011	PROWIRL73	0x0057	1	1
Endress+Hauser	0x000011	PROWIRL73	0x0057	2	1
Endress+Hauser	0x000011	PROWIRL73	0x0057	3	1
Endress+Hauser	0x000011	PROWIRL73	0x0057	4	1
Endress+Hauser	0x000011	PROWIRL73	0x0057	5	1
Endress+Hauser	0x000011	PROWIRL73	0x0057	6	1
Endress+Hauser	0x000011	PROWIRL73	0x0057	7	1
Endress+Hauser	0x000011	PROWIRL77	0x0037	1	2
Endress+Hauser	0x000011	T-MASS	0x0066	1	1
Endress+Hauser	0x000011	T-MASS65	0x0065	1	1
Endress+Hauser	0x000011	T-MASS65	0x0065	2	1
Endress+Hauser	0x000011	TMD832	0x0078	1	1
Endress+Hauser	0x000011	TMD832	0x0078	2	1
Endress+Hauser	0x000011	TMD833	0x0079	1	1
Endress+Hauser	0x000011	TMD842	0x007c	1	1
Endress+Hauser	0x000011	TMT122	0x00c9	2	1
Endress+Hauser	0x000011	TMT122	0x00c9	2	2
Endress+Hauser	0x000011	TMT142	0x00cb	2	2
Endress+Hauser	0x000011	TMT162	0x00ca	1	1
Endress+Hauser	0x000011	TMT162	0x00ca	2	1
Endress+Hauser	0x000011	TMT162	0x00ca	2	2
Endress+Hauser	0x000011	TMT182	0x00c8	1	2
Endress+Hauser	0x000011	TMT182	0x00c8	2	1
Endress+Hauser	0x000011	TMT82	0x00cc	1	2
Endress+Hauser	0x000011	Waterpilot 2x	0x0024	1	1
ENOTEC GmbH	0x00602d	COMTEC 6000	0xe0d4	1	1
ENOTEC GmbH	0x00602d	OXITEC 5000	0xe0d3	1	1
ESP Safety	0x006053	SGOES	0xe19c	1	1

# Device Xpert HART V1.07.00 - DD Library List

Status dated 2012.08.07

R09

DDs for Language:

EN

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Device Revision	DD Revision
FINT	0x0000a0	OXI5000	0x00ed	1	1
FINT	0x0000a0	PIR 2000	0x0002	1	1
Fisher Controls	0x000013	Position Xmitter	0x0000	1	1
FLEXIM	0x006021	FLUXUS	0xe0bd	1	1
Flowserve	0x000030	K A-ümmer C2100	0x0002	1	1
Flowserve	0x000030	Logix 12xx	0x0001	1	4
Flowserve	0x000030	Logix 12xx	0x0001	1	5
Flowserve	0x000030	Logix 12xx	0x0001	2	5
Flowserve	0x000030	Logix 12xx	0x0001	2	6
Flowserve	0x000030	Logix 12xx	0x0001	3	1
Flowserve	0x000030	Logix 12xx	0x0001	3	3
Flowserve	0x000030	Logix 520	0x0003	1	1
Flowserve	0x000030	Logix 520	0x0003	1	2
Flowserve	0x000030	Logix 520	0x0003	2	2
Flowserve	0x000030	Logix3200-IQ	0x0004	1	2
Flowserve	0x000030	Logix3200-IQ	0x0004	2	1
Flowserve	0x000030	Logix3200-IQ	0x0004	2	2
Flowserve	0x000030	Logix3200MD	0x0005	2	3
Flowserve	0x000030	Logix3200MD	0x0005	5	2
Flowserve	0x000030	Logix520MD	0x0006	2	1
Fluid Components	0x0000a6	ST100	0xa67f	1	1
Fluid Components	0x0000a6	ST98	0x0078	1	2
Foxboro	0x000014	875CR	0x0035	2	3
Foxboro	0x000014	875CR	0x0035	2	4
Foxboro	0x000014	875CR	0x0035	3	1
Foxboro	0x000014	875EC	0x0036	2	2
Foxboro	0x000014	875EC	0x0036	2	3
Foxboro	0x000014	875EC	0x0036	3	1
Foxboro	0x000014	875PH	0x0030	2	1
Foxboro	0x000014	875PH	0x0030	2	2
Foxboro	0x000014	875PH	0x0030	2	3
Foxboro	0x000014	875PH	0x0030	3	1
Foxboro	0x000014	876 pH	0x0005	2	1
Foxboro	0x000014	876 pH	0x0005	2	2
Foxboro	0x000014	876 pH	0x0005	66	1
Foxboro	0x000014	876 pH	0x0005	66	2
Foxboro	0x000014	876 pH	0x1405	130	1
Foxboro	0x000014	876 pH	0x1405	130	2
Foxboro	0x000014	CFT 30 x	0x007d	3	1
Foxboro	0x000014	CFT50	0x0034	2	1
Foxboro	0x000014	CFT50	0x0034	3	1
Foxboro	0x000014	ECS Pressure	0x0008	1	1
Foxboro	0x000014	I/A Pressure	0x002e	1	2
Foxboro	0x000014	I/A Pressure	0x002e	1	3
Foxboro	0x000014	I/A Pressure	0x002e	1	4
Foxboro	0x000014	I/A Pressure	0x002e	2	1
Foxboro	0x000014	I/A Pressure	0x002e	2	2
Foxboro	0x000014	I/A Pressure	0x002e	3	2
Foxboro	0x000014	IASPT Premium 2	0x0002	1	1
Foxboro	0x000014	IMT25	0x0029	1	2
Foxboro	0x000014	IMT96	0x0028	1	1
Foxboro	0x000014	IMV 25/30	0x002f	1	1
Foxboro	0x000014	IMV 25/30	0x002f	2	2
Foxboro	0x000014	IMV31	0x001d	2	1
Foxboro	0x000014	ITVORTEX	0x0033	1	2
Foxboro	0x000014	ITVORTEX	0x0033	1	3
Foxboro	0x000014	MAG2	0x0001	2	2
Foxboro	0x000014	RTT15	0x0038	1	1
Foxboro	0x000014	RTT15	0x0038	1	2
Foxboro	0x000014	RTT30	0x0007	2	1
Foxboro	0x000014	Vortex 84	0x001e	1	3
FOXBORO ECKARDT	0x00003f	DMU130	0x0002	1	2
FOXBORO ECKARDT	0x00003f	DMU140	0x0005	1	2
FOXBORO ECKARDT	0x00003f	SRD960	0x0006	1	1
FOXBORO ECKARDT	0x00003f	SRD991	0x0004	1	2

# Device Xpert HART V1.07.00 - DD Library List

Status dated 2012.08.07

R09

DDs for Language:

EN

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Device Revision	DD Revision
FOXBORO ECKARDT	0x00003f	TI/RTT20	0x0003	1	2
FOXBORO ECKARDT	0x00003f	TSV175	0x0001	1	1
Fuji	0x000015	FCX-A/C	0x0001	1	1
Fuji	0x000015	FCX-A2/C2	0x0002	1	1
Fuji	0x000015	FCX-A2/C2	0x0002	2	2
Fuji	0x000015	FCX-A2/C2	0x0002	2	3
Fuji	0x000015	FCX-A2/C2	0x0002	3	1
Fuji	0x000015	FRC	0x0081	1	1
General Monitors	0x0000df	S4000TH	0x0082	1	1
GP:50	0x0000bf	MDL 400	0x007c	1	1
HACH LANGE	0x0000d5	ANALOG_INPUT_MODULE_SC	0xd58d	1	1
HACH LANGE	0x0000d5	CONTACT_COND_MODULE	0xd588	1	1
HACH LANGE	0x0000d5	FLOW_MODULE_US	0xd58b	1	1
HACH LANGE	0x0000d5	INDUCT_COND_MODULE	0xd589	1	1
HACH LANGE	0x0000d5	LDO	0xd587	2	1
HACH LANGE	0x0000d5	pH_ORP_DO_Mod_DO_Config	0xd58a	1	1
HACH LANGE	0x0000d5	PH_ORP_MOD_pH_ORP_Config	0xd586	1	1
HACH LANGE	0x0000d5	pHD_ORP	0xd58e	1	1
HACH LANGE	0x0000d5	SC_1720E	0xd591	4	1
HACH LANGE	0x0000d5	SC_FP360	0xd58f	1	1
HACH LANGE	0x0000d5	SC_TSS	0xd590	1	1
HACH LANGE	0x0000d5	SI792C	0x0081	1	1
HACH LANGE	0x0000d5	SI792C	0x0081	1	2
HACH LANGE	0x0000d5	SI792D	0x0084	1	1
HACH LANGE	0x0000d5	SI792D	0x0084	1	2
HACH LANGE	0x0000d5	SI792E	0x0083	1	1
HACH LANGE	0x0000d5	SI792E	0x0083	1	2
HACH LANGE	0x0000d5	SI792P	0x0080	1	1
HACH LANGE	0x0000d5	SI792P	0x0080	1	2
HACH LANGE	0x0000d5	SI792T	0x0082	1	1
HACH LANGE	0x0000d5	SI792T	0x0082	1	2
HACH LANGE	0x0000d5	SS7_SC	0xd58c	1	1
Harold Beck and Sons	0x000068	BECK-DCM	0x000a	1	1
Harold Beck and Sons	0x000068	ESR-D	0x0001	1	2
HCF	0x0000f9	SDC625	0x0083	1	0
HCF	0x0000f9	SDC625	0x0083	1	1
HEINRICHS	0x0000d3	PAD	0x0080	2	2
HEINRICHS	0x0000d3	PAD-F	0x0082	3	1
HEINRICHS	0x0000d3	PAS	0x0081	2	2
Hengesbach	0x0000c2	TE 52	0x0021	2	1
Hitachi High-Tech	0x006037	N7	0xe0e6	1	1
HOFFER FLOW CNTRLS	0x006015	Freq --> mA	0xe0f1	1	2
HOFFER FLOW CNTRLS	0x006015	HRT1	0xe0a1	1	3
Honeywell	0x000017	HERCULINE	0x0005	1	3
Honeywell	0x000017	HERCULINE	0x0005	3	1
Honeywell	0x000017	HWFLOW/Mage W Plus	0x0003	1	1
Honeywell	0x000017	SmartCET	0x0006	1	1
Honeywell	0x000017	SmartLine Radar	0x0056	1	1
Honeywell	0x000017	SmartLine TDR	0x0057	1	1
Honeywell	0x000017	ST3000	0x0001	1	2
Honeywell	0x000017	ST3000	0x0001	2	1
Honeywell	0x000017	ST3000	0x0001	4	2
Honeywell	0x000017	ST3000	0x0001	5	1
Honeywell	0x000017	STT17H	0x0007	1	1
Honeywell	0x000017	STT25H	0x0004	1	5
Honeywell	0x000017	STT25H	0x0004	2	6
Honeywell	0x000017	STT25H	0x0004	2	7
Honeywell	0x000017	STT25H	0x0004	3	1
Honeywell	0x000017	STT25H6	0x000b	1	1
Honeywell	0x000017	STT25S	0x0009	1	1
Honeywell	0x000017	STT25S	0x0009	2	1
Honeywell	0x000017	STT25T	0x0002	1	1
Honeywell	0x000017	STT25T	0x0002	2	1
Honeywell	0x000017	STT25T6	0x000c	1	1

# Device Xpert HART V1.07.00 - DD Library List

Status dated 2012.08.07

R09

DDs for Language:

EN

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Device Revision	DD Revision
Honeywell	0x000017	TWC9000	0x0051	2	4
Honeywell	0x000017	TWM1000	0x0055	2	2
Honeywell	0x000017	TWM9000	0x0050	2	2
Honeywell	0x000017	TWV9000	0x0054	2	1
Huakong	0x000085	HK TT01	0x007f	5	1
INOR	0x00005b	C520/R520	0x00eb	1	1
INOR	0x00005b	MESO	0x00ef	1	4
InterCorr	0x0000a2	SMARTCET 18C	0x00ef	1	1
Invensys	0x0000a9	IA_PRESSURE	0x002e	1	2
ISE-Magtech	0x00008c	LTM-100	0x0088	1	1
ISE-Magtech	0x00008c	LTM-300	0x0089	2	1
ISE-Magtech	0x00008c	LTM-300	0x0089	3	1
J-Tec	0x0000ad	SERIES_0	0x0000	1	1
Kajaani Process Measurements	0x0000c5	KC/3	0x0080	1	1
Kajaani Process Measurements	0x0000c5	KC/5	0x0081	1	1
Klay Instruments	0x000075	Klay 2000 Pressure/Level	0x00ef	1	1
Knick	0x000061	2211 Cond	0x00ea	1	1
Knick	0x000061	2211 Cond	0x00ea	2	1
Knick	0x000061	2211 Condl	0x00e8	1	1
Knick	0x000061	2211 Condl	0x00e8	2	1
Knick	0x000061	2211 Oxy	0x00e9	1	1
Knick	0x000061	2211 pH	0x00eb	1	1
Knick	0x000061	2211 pH	0x00eb	2	1
Knick	0x000061	A411-COND	0x00e1	1	1
Knick	0x000061	A411-CONDI	0x00e0	1	1
Knick	0x000061	A411-OXY	0x00e2	1	1
Knick	0x000061	A411-PH	0x00e3	1	1
Kongsberg Maritime	0x0000c0	GT400	0x00ef	1	1
KOSO	0x0000cf	EP1000/SPS2000	0x0080	1	1
KOSO	0x0000cf	EP1001	0x0081	1	1
Krohne	0x000045	BM100	0x00ee	1	4
Krohne	0x000045	BM100	0x00ee	1	5
Krohne	0x000045	BM102	0x00ec	1	1
Krohne	0x000045	BM70	0x00f9	1	1
Krohne	0x000045	BM70	0x00f9	11	2
Krohne	0x000045	ESK2A	0x00e2	1	1
Krohne	0x000045	ESK4	0x00d6	1	1
Krohne	0x000045	ESKII	0x00f2	1	1
Krohne	0x000045	IFC 100	0x00d9	2	1
Krohne	0x000045	IFC 300	0x00e3	1	2
Krohne	0x000045	IFC 300	0x00e3	2	1
Krohne	0x000045	IFC040	0x00e9	2	1
Krohne	0x000045	IFC080	0x00f8	1	1
Krohne	0x000045	IFC080	0x00f8	2	3
Krohne	0x000045	IFC090	0x00f4	1	2
Krohne	0x000045	IFC090	0x00f4	2	1
Krohne	0x000045	IFC110	0x00f3	1	2
Krohne	0x000045	IFC110	0x00f3	2	1
Krohne	0x000045	M10	0x00ea	2	1
Krohne	0x000045	M8E	0x00e6	1	1
Krohne	0x000045	MAC100	0x00cf	1	1
Krohne	0x000045	MFC 300	0x00dd	2	1
Krohne	0x000045	MFC05x	0x00e8	1	1
Krohne	0x000045	MFC08x	0x00f7	2	3
Krohne	0x000045	MFC08x	0x00f7	3	1
Krohne	0x000045	Optiflex 1300C	0x00e4	1	2
Krohne	0x000045	Optiwave 7300C	0x00e5	1	2
Krohne	0x000045	TT50C/R	0x00db	1	4
Krohne	0x000045	TT51C/R	0x00d3	1	1
Krohne	0x000045	UFC030	0x00e7	2	2
Krohne	0x000045	UFC500	0x00f5	1	2
Krohne	0x000045	VFC 070	0x00de	1	1
Krohne	0x000045	VFC 070	0x00de	2	1

# Device Xpert HART V1.07.00 - DD Library List

Status dated 2012.08.07

R09

DDs for Language:

EN

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Device Revision	DD Revision
Krohne	0x000045	VFM31	0x00ed	1	2
Kurz Instruments	0x00602f	MFT B-Series	0xe0d7	1	1
LABOM	0x00007f	IPX	0x00e0	1	2
LABOM	0x00007f	PASCAL CI	0x003c	1	2
LABOM	0x00007f	Pascal CV	0x00ef	1	1
Lanlian Instruments	0x0000c3	LSIII Pressure	0x0074	1	1
Mactek	0x006019	VIATOR_VWA	0xe0ac	2	1
Magnetrol	0x000056	E3 Modulelevel	0x00e3	1	1
Magnetrol	0x000056	E3 Modulelevel	0x00e3	2	1
Magnetrol	0x000056	Jupiter	0x00e8	2	1
Magnetrol	0x000056	Jupiter	0x00e8	3	2
Magnetrol	0x000056	Model 355	0x00e4	1	1
Magnetrol	0x000056	Model 355	0x00e4	1	2
Magnetrol	0x000056	Model 704	0x00e7	1	1
Magnetrol	0x000056	Model 705	0x00ee	1	2
Magnetrol	0x000056	Model 705	0x00ee	3	1
Magnetrol	0x000056	Model 705	0x00ee	4	1
Magnetrol	0x000056	Model 705 2.x	0x00eb	1	1
Magnetrol	0x000056	Model 705 2.x	0x00eb	2	1
Magnetrol	0x000056	Model 705 2.x	0x00eb	3	1
Magnetrol	0x000056	Model 705 2.x	0x00eb	4	1
Magnetrol	0x000056	Model 705 3.x	0x00e5	1	1
Magnetrol	0x000056	Model 705 3.x	0x00e5	1	2
Magnetrol	0x000056	Model 705 3.x	0x00e5	2	1
Magnetrol	0x000056	Model 707	0x00ea	2	1
Magnetrol	0x000056	Model 707	0x00ea	3	1
Magnetrol	0x000056	Model 708	0x00ec	1	1
Magnetrol	0x000056	Model 708	0x00ec	2	1
Magnetrol	0x000056	Model 708	0x00ec	3	1
Magnetrol	0x000056	Model 708	0x00ec	4	1
Magnetrol	0x000056	Model 805	0x00ed	1	2
Magnetrol	0x000056	Model R82	0x00e2	1	1
Magnetrol	0x000056	Model R82	0x00e2	2	2
Magnetrol	0x000056	Model R82	0x00e2	3	1
Magnetrol	0x000056	Model RX5	0x00e6	2	1
Magnetrol	0x000056	Model RX5	0x00e6	4	1
Magnetrol	0x000056	Model TA2	0x00e9	1	2
Magnetrol	0x000056	Model TA2	0x00e9	2	1
Magnetrol	0x000056	Model TA2	0x00e9	3	1
Magnetrol	0x000056	Model TA2 2.x	0x00e1	1	1
Magnetrol	0x000056	MODEL_706	0x56e0	1	1
Magnetrol	0x000056	SMARTEZ	0x00ef	1	2
Magnetrol	0x000056	SMARTEZ	0x00ef	2	1
Masonellan-Dresser	0x000065	HDLT	0x0064	1	2
Masonellan-Dresser	0x000065	SVI	0x00c8	2	2
Masonellan-Dresser	0x000065	SVI II AP	0x00ca	1	2
Masonellan-Dresser	0x000065	SVI2	0x00c9	2	1
Masonellan-Dresser	0x000065	SVI2	0x00c9	2	2
Meriam Instrument	0x0000a8	M3500	0x007f	1	1
Metran	0x000099	METRAN-100	0x007f	1	1
Metran	0x000099	METRAN-100	0x007f	1	2
Metran	0x000099	Metran-150	0x0079	2	1
Metran	0x000099	Metran-150	0x0079	2	2
Metran	0x000099	METRAN-280	0x007e	1	1
Metran	0x000099	METRAN-280	0x007e	1	2
Metran	0x000099	METRAN-303PR	0x0077	1	1
Metso Automation	0x00002f	MCA	0x0040	1	2
Metso Automation	0x00002f	MCAi	0x003e	1	1
Metso Automation	0x000057	ND820	0x00ef	1	3
Metso Automation	0x000057	ND820	0x00ef	2	3
Metso Automation	0x000057	ND820	0x00ef	3	3
Metso Automation	0x000057	ND820	0x00ef	4	2
Metso Automation	0x000057	ND820	0x00ef	5	1
Metso Automation	0x000057	ND820	0x00ef	6	1
Metso Automation	0x000057	ND820	0x00ef	7	1

# Device Xpert HART V1.07.00 - DD Library List

Status dated 2012.08.07

R09

DDs for Language:

EN

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Device Revision	DD Revision
Metso Automation	0x000057	ND820/T	0x00ee	1	3
Metso Automation	0x000057	ND820/T	0x00ee	2	3
Metso Automation	0x000057	ND820/T	0x00ee	3	3
Metso Automation	0x000057	ND820/T	0x00ee	4	2
Metso Automation	0x000057	ND820/T	0x00ee	5	1
Metso Automation	0x000057	ND820/T	0x00ee	6	1
Metso Automation	0x000057	ND820/T	0x00ee	7	1
Metso Automation	0x000057	ND9100H	0x00e5	1	1
Metso Automation	0x000057	ND9100H	0x00e5	2	1
Metso Automation	0x000057	ND9100H	0x00e5	2	2
Metso Automation	0x000057	ND9100H	0x00e5	2	3
Metso Automation	0x000057	ND9100H	0x00e5	3	2
Metso Automation	0x000057	ND9100H	0x00e5	3	3
Metso Automation	0x000057	ND9100H	0x00e5	3	4
Metso Automation	0x000057	ND9100HT	0x00e4	1	1
Metso Automation	0x000057	ND9100HT	0x00e4	2	1
Metso Automation	0x000057	ND9100HT	0x00e4	2	2
Metso Automation	0x00002f	PSMART	0x0001	2	1
Metso Automation	0x000057	SG9000H	0x00d5	1	1
Metso Automation	0x00002f	SMARTLC	0x003f	1	1
Metso Automation	0x00002f	SMARTLX	0x003d	3	1
Metso Automation	0x00002f	SMARTPULP	0x003c	2	2
Metso Automation	0x00002f	SMARTPULP	0x003c	3	1
Metso Automation	0x000057	ValvGuard	0x00eb	2	1
Metso Automation	0x000057	ValvGuard	0x00eb	6	1
Metso Automation	0x000057	VG9000H	0x00d9	1	1
Metso Automation	0x000057	VG9000H	0x00d9	2	1
Mettler Toledo	0x00008e	Cond7100	0x007a	1	1
Mettler Toledo	0x00008e	Cond7100	0x007a	2	1
Mettler Toledo	0x00008e	CondI7100	0x0078	1	1
Mettler Toledo	0x00008e	CondI7100	0x0078	2	1
Mettler Toledo	0x00008e	O2 4100e	0x0079	1	1
Mettler Toledo	0x00008e	pH 2100	0x007b	1	1
Mettler Toledo	0x00008e	pH 2100	0x007b	2	1
Micro Motion	0x00001f	2200S Analog	0x003a	1	1
Micro Motion	0x00001f	2400S Mass flo	0x0034	1	2
Micro Motion	0x00001f	2400S Mass flo	0x0034	1	4
Micro Motion	0x00001f	2400S Mass flo	0x0034	2	2
Micro Motion	0x00001f	2400S Mass flo	0x0034	2	3
Micro Motion	0x00001f	2400S Mass flo	0x0034	3	1
Micro Motion	0x00001f	9701	0x001e	1	3
Micro Motion	0x00001f	9701	0x001e	1	4
Micro Motion	0x00001f	9712 Mass flo	0x0007	2	6
Micro Motion	0x00001f	9739 Mass flo	0x0015	1	5
Micro Motion	0x00001f	9739 Mass flo	0x0015	2	5
Micro Motion	0x00001f	9739 Mass flo	0x0015	3	5
Micro Motion	0x00001f	9739 Mass flo	0x0015	4	1
Micro Motion	0x00001f	9739 Mass flo	0x0015	4	2
Micro Motion	0x00001f	MVD Series 1000 Analog Output	0x0029	2	1
Micro Motion	0x00001f	MVD Series 1000 Analog Output	0x0029	3	1
Micro Motion	0x00001f	MVD Series 1000 Analog Output	0x0029	3	2
Micro Motion	0x00001f	MVD Series 1000 Analog Output	0x0029	4	1
Micro Motion	0x00001f	MVD Series 1000 Analog Output	0x0029	5	4
Micro Motion	0x00001f	MVD Series 1000 Analog Output	0x0029	5	5
Micro Motion	0x00001f	MVD Series 1000 Config I/O	0x0025	4	1
Micro Motion	0x00001f	MVD Series 1000 Config I/O	0x0025	5	4
Micro Motion	0x00001f	MVD Series 1000 Config I/O	0x0025	5	5
Micro Motion	0x00001f	MVD Series 1000 IS Output	0x0027	2	1
Micro Motion	0x00001f	MVD Series 1000 IS Output	0x0027	3	1
Micro Motion	0x00001f	MVD Series 1000 IS Output	0x0027	3	2
Micro Motion	0x00001f	MVD Series 1000 IS Output	0x0027	4	1
Micro Motion	0x00001f	MVD Series 1000 IS Output	0x0027	5	4
Micro Motion	0x00001f	MVD Series 1000 IS Output	0x0027	5	5
Micro Motion	0x00001f	MVD Series 2000 Analog Output	0x002a	1	1
Micro Motion	0x00001f	MVD Series 2000 Analog Output	0x002a	2	1

# Device Xpert HART V1.07.00 - DD Library List

Status dated 2012.08.07

R09

DDs for Language:

EN

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Device Revision	DD Revision
Micro Motion	0x00001f	MVD Series 2000 Analog Output	0x002a	2	2
Micro Motion	0x00001f	MVD Series 2000 Analog Output	0x002a	3	1
Micro Motion	0x00001f	MVD Series 2000 Analog Output	0x002a	3	2
Micro Motion	0x00001f	MVD Series 2000 Analog Output	0x002a	4	1
Micro Motion	0x00001f	MVD Series 2000 Analog Output	0x002a	5	4
Micro Motion	0x00001f	MVD Series 2000 Analog Output	0x002a	5	5
Micro Motion	0x00001f	MVD Series 2000 Config I/O	0x0024	3	1
Micro Motion	0x00001f	MVD Series 2000 Config I/O	0x0024	3	2
Micro Motion	0x00001f	MVD Series 2000 Config I/O	0x0024	4	2
Micro Motion	0x00001f	MVD Series 2000 Config I/O	0x0024	5	4
Micro Motion	0x00001f	MVD Series 2000 Config I/O	0x0024	5	5
Micro Motion	0x00001f	MVD Series 2000 IS Output	0x0026	2	1
Micro Motion	0x00001f	MVD Series 2000 IS Output	0x0026	2	2
Micro Motion	0x00001f	MVD Series 2000 IS Output	0x0026	3	1
Micro Motion	0x00001f	MVD Series 2000 IS Output	0x0026	3	2
Micro Motion	0x00001f	MVD Series 2000 IS Output	0x0026	4	1
Micro Motion	0x00001f	MVD Series 2000 IS Output	0x0026	5	4
Micro Motion	0x00001f	MVD Series 2000 IS Output	0x0026	5	5
Micro Motion	0x00001f	MVD Series 3000	0x0041	6	1
Micro Motion	0x00001f	MVD Series 3000	0x0041	6	2
Micro Motion	0x00001f	MVD Series 3000	0x0041	7	3
Micro Motion	0x00001f	MVD Series 3000	0x0041	7	4
Mobrey	0x00003b	3300	0x0021	2	1
Mobrey	0x00003b	4301	0x0013	3	3
Mobrey	0x00003b	4301	0x0013	3	4
Mobrey	0x00003b	MLT100	0x0029	1	1
Mobrey	0x00003b	MLT100	0x0029	1	2
Mobrey	0x00003b	MLT100	0x0029	1	3
Mobrey	0x00003b	MRL700	0x002f	1	1
Mobrey	0x00003b	MRL700	0x002f	1	2
Mobrey	0x00003b	MSM400	0x002b	2	1
Mobrey	0x00003b	MSP100	0x0015	2	2
Mobrey	0x00003b	MSP100	0x0015	2	3
Mobrey	0x00003b	MSP900/400	0x002e	3	1
Mobrey	0x00003b	MSP900/400	0x002e	3	5
Mobrey	0x00003b	MSP900/400	0x002e	4	1
Mobrey	0x00003b	MSP900/400	0x002e	4	5
Mobrey	0x00003b	MSP900/400	0x002e	5	5
Mobrey	0x00003b	MSP900/400	0x002e	5	6
Moore Industries	0x000020	888	0x0007	1	1
Moore Industries	0x000020	HTZ	0x0005	1	1
Moore Industries	0x000020	TCM	0x0006	1	1
Moore Industries	0x000020	THZ	0x0003	1	1
Moore Industries	0x000020	THZ2	0x0004	1	1
Moore Industries	0x000020	TRZ	0x0001	1	1
Moore Industries	0x000020	TRZ	0x0001	2	1
Moore Industries	0x000020	TRZ	0x0001	3	1
Moore Products	0x000021	330	0x0005	1	2
Moore Products	0x000021	340_A2	0x0006	2	3
Moore Products	0x000021	340_S	0x000a	1	2
Moore Products	0x000021	343	0x000b	1	2
Moore Products	0x000021	345	0x000d	1	2
M-System Co.	0x00001d	27HU	0x0003	1	1
M-System Co.	0x00001d	B3HU	0x0002	1	1
M-System Co.	0x00001d	B6U	0x0001	1	1
MTS Systems Corp.	0x000063	M-Series	0x00ed	0	1
NET SAFETY	0x00600e	JB-MPHF Series	0xe0df	0	1
NET SAFETY	0x00600e	Millennium 2 Basic	0xe09e	0	2
Ohmart	0x000067	DSTH/LSTH	0x00e0	1	4
Ohmart	0x000067	DSTH/LSTH Comp	0x00e1	1	1
OLDHAM	0x00604d	ONG	0xe198	1	1
Open Field Communications	0x0000dd	FMP4x Envelope Curve	0x0003	1	1
Open Field Communications	0x0000dd	FMP5x Envelope Curve	0x0006	2	1
Open Field Communications	0x0000dd	FMR2xx Envelope Curve	0x0002	1	1
Open Field Communications	0x0000dd	FMU4x Envelope Curve	0x0001	1	1

# Device Xpert HART V1.07.00 - DD Library List

Status dated 2012.08.07

R09

DDs for Language:

EN

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Device Revision	DD Revision
Open Field Communications	0x0000dd	OFC Software Component	0x0000	1	1
ORANGE INST. UK	0x006005	EX200H Positioner	0xe088	1	1
Oval	0x000064	9201 Mass flo	0x0070	2	1
Oval	0x000064	9401 Mass flo	0x006e	2	1
Oval	0x000064	9431 Mass flo	0x007b	2	1
Oval	0x000064	9801 Mass flo	0x006f	2	1
Oval	0x000064	ExDelta	0x0065	1	1
Oval	0x000064	ULTRAOVAL	0x0064	2	1
Panametrics	0x00009d	x868	0x0070	1	1
Paper Machine Components	0x00007e	SMT-EL	0x00e0	1	1
Peek Measurement	0x000027	900 Densitometer	0x0000	0	1
Peek Measurement	0x000027	900 Densitometer	0x0000	1	1
Pepperl+Fuchs	0x00005d	Barcon	0x000e	1	1
Pepperl+Fuchs	0x00005d	CorrTran	0x00e8	1	1
Pepperl+Fuchs	0x00005d	FMU4x	0x0011	2	2
Pepperl+Fuchs	0x00005d	Pulscon	0x0012	2	1
Phase Dynamics	0x000092	Analyzer	0x007f	1	1
Phoenix_Contact	0x0000b0	MCR-HT-TS	0x0002	2	2
Phoenix_Contact	0x0000b0	MCR-TS-LP	0x0001	2	2
PMV	0x00009b	D3	0x00d3	1	2
PMV	0x00009b	D3	0x00d3	1	3
PR Electronics	0x00006d	PR5337	0x6deb	1	1
PR Electronics	0x00006d	PR6337	0x6dea	1	1
PR Electronics	0x00006d	Pretop 5335	0x00ef	1	1
PR Electronics	0x00006d	PRetrans 6335	0x00ee	1	1
PR Electronics	0x00006d	T55	0x00df	1	1
Pyromation	0x0000b5	Series442	0x007f	2	1
Pyromation	0x0000b5	Series642	0x0080	2	2
Pyromation	0x0000b5	Series642	0x0080	2	3
Robert Shaw	0x00005c	Excalibur 7000	0x00c8	1	2
Ronan	0x000025	X96 D	0x0002	1	1
Ronan	0x000025	X96 D	0x0002	1	2
Ronan	0x000025	X96 L	0x0003	1	1
Ronan	0x000025	X96 L	0x0003	1	2
Ronan	0x000025	X96 LD	0x0005	1	1
Ronan	0x000025	X96 LD	0x0005	1	2
Ronan	0x000025	X96 W	0x0004	1	1
Ronan	0x000025	X96 W	0x0004	1	2
Ronan	0x000025	X99 MD	0x0006	1	1
Roost	0x0000ce	EPP300	0x0080	1	1
Rosemount	0x000026	1151	0x0003	1	1
Rosemount	0x000026	1151	0x0003	2	1
Rosemount	0x000026	1151	0x0003	3	1
Rosemount	0x000026	1151	0x0003	4	2
Rosemount	0x000026	1151	0x0003	5	4
Rosemount	0x000026	1151	0x0003	6	1
Rosemount	0x000026	1810	0x0036	3	1
Rosemount	0x000026	2051	0x0055	3	1
Rosemount	0x000026	2051	0x0055	3	2
Rosemount	0x000026	2088 Smart	0x0023	3	2
Rosemount	0x000026	2088 Smart	0x0023	3	3
Rosemount	0x000026	2088LP	0x0040	1	1
Rosemount	0x000026	2090 Smart	0x0027	3	1
Rosemount	0x000026	248 Temperature	0x003b	1	1
Rosemount	0x000026	248 Temperature	0x003b	2	1
Rosemount	0x000026	3001C HTG	0x000e	1	2
Rosemount	0x000026	3001C HTG	0x000e	2	1
Rosemount	0x000026	3001C HTG	0x000e	3	1
Rosemount	0x000026	3001S HTG	0x0014	2	1
Rosemount	0x000026	3044 Temp	0x0002	3	3
Rosemount	0x000026	3044C Temp	0x000d	1	3
Rosemount	0x000026	3044C Temp	0x000d	2	3
Rosemount	0x000026	3051C	0x0006	1	2
Rosemount	0x000026	3051C	0x0006	2	6
Rosemount	0x000026	3051C	0x0006	3	2



# Device Xpert HART V1.07.00 - DD Library List

Status dated 2012.08.07

R09

DDs for Language:

EN

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Device Revision	DD Revision
Rosemount	0x000026	3051C	0x0006	3	6
Rosemount	0x000026	3051C	0x0006	3	7
Rosemount	0x000026	3051C	0x0006	6	3
Rosemount	0x000026	3051C	0x0006	6	4
Rosemount	0x000026	3051C	0x0006	7	5
Rosemount	0x000026	3051C	0x0006	7	7
Rosemount	0x000026	3051C LP	0x000f	1	1
Rosemount	0x000026	3051S	0x005e	1	1
Rosemount	0x000026	3051S Diag	0x004a	1	2
Rosemount	0x000026	3051S Diag	0x004a	2	1
Rosemount	0x000026	3051S Diag	0x004a	3	1
Rosemount	0x000026	3051S SIS	0x0044	1	1
Rosemount	0x000026	3051S SIS	0x0044	1	2
Rosemount	0x000026	3095C	0x001e	5	3
Rosemount	0x000026	3095MV	0x0016	1	8
Rosemount	0x000026	3095MV	0x0016	2	2
Rosemount	0x000026	3095MV	0x0016	2	3
Rosemount	0x000026	3100	0x0050	5	5
Rosemount	0x000026	3100	0x0050	5	6
Rosemount	0x000026	3144 Temp	0x0019	1	8
Rosemount	0x000026	3144 Temp	0x0019	2	1
Rosemount	0x000026	3144 Temp	0x0019	3	2
Rosemount	0x000026	3144 Temp	0x0019	3	3
Rosemount	0x000026	3144 Temp	0x0019	3	7
Rosemount	0x000026	3144 Temp	0x0019	4	1
Rosemount	0x000026	3144 Temp	0x0019	4	3
Rosemount	0x000026	3144 Temp	0x0019	4	4
Rosemount	0x000026	3144P SIS	0x0045	1	1
Rosemount	0x000026	3144P SIS	0x0045	2	1
Rosemount	0x000026	3201 SAM	0x0011	1	2
Rosemount	0x000026	3201 SAM	0x0011	1	3
Rosemount	0x000026	3202 SAM	0x0013	1	3
Rosemount	0x000026	3244 Temp	0x001a	1	8
Rosemount	0x000026	3244 Temp	0x001a	2	1
Rosemount	0x000026	3300	0x0021	1	1
Rosemount	0x000026	3300	0x0021	2	1
Rosemount	0x000026	3300	0x0021	3	2
Rosemount	0x000026	3440	0x006b	2	1
Rosemount	0x000026	3750	0x001c	1	2
Rosemount	0x000026	3750	0x001c	2	2
Rosemount	0x000026	4500	0x0047	7	1
Rosemount	0x000026	4600	0x0038	1	2
Rosemount	0x000026	5300	0x0051	1	1
Rosemount	0x000026	5300	0x0051	1	2
Rosemount	0x000026	5300	0x0051	3	2
Rosemount	0x000026	5400	0x0043	1	1
Rosemount	0x000026	5400	0x0043	1	3
Rosemount	0x000026	5400	0x0043	1	4
Rosemount	0x000026	5400	0x0043	2	1
Rosemount	0x000026	5400	0x0043	2	2
Rosemount	0x000026	644 Temp	0x0018	3	1
Rosemount	0x000026	644 Temp	0x0018	4	1
Rosemount	0x000026	644 Temp	0x0018	5	4
Rosemount	0x000026	644 Temp	0x0018	6	2
Rosemount	0x000026	644 Temp	0x0018	7	1
Rosemount	0x000026	644 Temp	0x0018	7	2
Rosemount	0x000026	702 H7	0x265a	3	2
Rosemount	0x000026	848T Wireless	0x0053	3	1
Rosemount	0x000026	848T Wireless	0x2653	3	1
Rosemount	0x000026	8600D	0x003f	1	1
Rosemount	0x000026	8712D	0x0037	1	2
Rosemount	0x000026	8712D	0x0037	2	1
Rosemount	0x000026	8712E	0x0057	1	1
Rosemount	0x000026	8712E	0x0057	3	1
Rosemount	0x000026	8712E	0x0057	3	2

# Device Xpert HART V1.07.00 - DD Library List

Status dated 2012.08.07

R09

DDs for Language:

EN

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Device Revision	DD Revision
Rosemount	0x000026	8712E	0x0057	3	3
Rosemount	0x000026	8732	0x003c	1	1
Rosemount	0x000026	8732	0x003c	2	1
Rosemount	0x000026	8732	0x003c	2	2
Rosemount	0x000026	8732	0x003c	3	1
Rosemount	0x000026	8732	0x003c	4	1
Rosemount	0x000026	8732	0x003c	4	2
Rosemount	0x000026	8800D	0x003a	1	2
Rosemount	0x000026	8800D	0x003a	2	1
Rosemount	0x000026	951	0x0042	6	3
Rosemount	0x000026	951	0x0042	7	5
Rosemount	0x000026	Generic	0x0080	3	4
Rosemount	0x000026	Generic	0x0080	3	5
Rosemount	0x000026	Generic	0x0080	4	4
Rosemount	0x000026	Generic	0x0080	4	5
Rosemount	0x000026	Generic	0x0080	5	4
Rosemount	0x000026	Generic	0x0080	5	5
Rosemount	0x000026	Generic	0x0080	6	2
Rosemount	0x000026	Generic	0x0080	7	2
Rosemount	0x000026	Mag HS	0x000c	1	5
Rosemount	0x000026	Mag HS	0x000c	1	6
Rosemount	0x000026	Magmeter	0x0004	10	1
Rosemount	0x000026	Magmeter	0x0004	3	3
Rosemount	0x000026	Magmeter	0x0004	4	3
Rosemount	0x000026	Magmeter	0x0004	5	3
Rosemount	0x000026	Magmeter	0x0004	6	1
Rosemount	0x000026	Magmeter	0x0004	7	5
Rosemount	0x000026	Magmeter	0x0004	7	6
Rosemount	0x000026	Magmeter	0x0004	8	3
Rosemount	0x000026	Magmeter	0x0004	9	3
Rosemount	0x000026	Metran-150	0x0062	3	1
Rosemount	0x000026	Metran-75	0x006d	3	2
Rosemount	0x000026	ProBar	0x0024	2	2
Rosemount	0x000026	ProBar	0x0024	3	1
Rosemount	0x000026	ProBar	0x0024	4	1
Rosemount	0x000026	ProBar UC	0x0028	3	1
Rosemount	0x000026	ProBar UC	0x0028	4	1
Rosemount	0x000026	ProPlate UC	0x002f	3	1
Rosemount	0x000026	Tri-Loop	0x001d	1	2
Rosemount	0x000026	Vortex	0x0010	1	3
Rosemount	0x000026	Vortex	0x0010	2	1
Rosemount	0x000026	Vortex	0x0010	3	1
Rosemount Analytic	0x00002e	1056	0x0055	1	1
Rosemount Analytic	0x00002e	1066	0x0021	1	1
Rosemount Analytic	0x00002e	1066_EXP	0x2e21	2	1
Rosemount Analytic	0x00002e	2081 Cond	0x0007	1	1
Rosemount Analytic	0x00002e	2081 pH	0x0006	1	1
Rosemount Analytic	0x00002e	3081-81con	0x0016	1	1
Rosemount Analytic	0x00002e	3081-81con	0x0016	2	1
Rosemount Analytic	0x00002e	3081-81T	0x0017	1	1
Rosemount Analytic	0x00002e	3081C	0x0015	1	1
Rosemount Analytic	0x00002e	3081FG	0x000e	1	1
Rosemount Analytic	0x00002e	3081pH	0x0014	1	1
Rosemount Analytic	0x00002e	3081pH	0x0014	1	2
Rosemount Analytic	0x00002e	5081A	0x0018	1	1
Rosemount Analytic	0x00002e	5081A	0x0018	2	1
Rosemount Analytic	0x00002e	5081C/T	0x0019	1	1
Rosemount Analytic	0x00002e	5081FG	0x001e	1	1
Rosemount Analytic	0x00002e	5081pH	0x001a	1	1
Rosemount Analytic	0x00002e	5081pH	0x001a	2	1
Rosemount Analytic	0x00002e	52epH/ORP	0x0052	1	1
Rosemount Analytic	0x00002e	52epH/ORP	0x0052	2	1
Rosemount Analytic	0x00002e	54eA	0x0053	1	1
Rosemount Analytic	0x00002e	54eA	0x0053	2	1
Rosemount Analytic	0x00002e	54eC	0x0051	1	2

# Device Xpert HART V1.07.00 - DD Library List

Status dated 2012.08.07

R09

DDs for Language:

EN

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Device Revision	DD Revision
Rosemount Analytic	0x00002e	54eC	0x0051	2	1
Rosemount Analytic	0x00002e	54pH/ORP	0x0050	1	2
Rosemount Analytic	0x00002e	6888-O2	0x003a	1	1
Rosemount Analytic	0x00002e	MODEL_56	0x0056	1	2
Rosemount Analytic	0x00002e	MODEL_56_EXP	0x2e56	2	1
Rosemount Analytic	0x00002e	OCX-4000	0x0010	1	1
Rosemount Analytic	0x00002e	OCX-4000	0x0010	2	1
Rosemount Analytic	0x00002e	OCX-4000	0x0010	3	1
Rosemount Analytic	0x00002e	OCX-4000	0x0010	4	1
Rosemount Analytic	0x00002e	OPM-2000R	0x000f	1	1
Rosemount Analytic	0x00002e	Oxymitter 4000	0x000c	1	1
Rosemount Analytic	0x00002e	Oxymitter 4000	0x000c	2	1
Rosemount Analytic	0x00002e	Oxymitter 4000	0x000c	3	1
Rosemount Analytic	0x00002e	Oxymitter 4000	0x000c	4	1
Rosemount Analytic	0x00002e	WC_3000	0x000d	1	1
Rosemount Analytic	0x00002e	Xmt A	0x001b	1	1
Rosemount Analytic	0x00002e	Xmt C/T	0x001c	1	1
Rosemount Analytic	0x00002e	Xmt pH	0x001d	1	1
Rosemount Analytic	0x00002e	XS-O2	0x002b	1	1
Rueger	0x00008d	S95.3U_2	0x007f	1	1
Rueger	0x00008d	S95_HRT	0x0001	1	1
Saab Tank Control	0x00004f	5600	0x00ed	6	1
Saab Tank Control	0x00004f	5600	0x00ed	7	1
Saab Tank Control	0x00004f	TankRadarPro	0x00ef	2	1
Saab Tank Control	0x00004f	TankRadarPro	0x00ef	3	1
Saab Tank Control	0x00004f	TankRadarPro	0x00ef	5	1
Saab Tank Control	0x00004f	TankRadarPro	0x00ef	6	1
Samson	0x000042	3730-6	0x00ee	1	1
Samson	0x000042	373X-3	0x00ef	2	1
Samson	0x000042	373X-3	0x00ef	4	2
Samson	0x000042	373X-3	0x00ef	6	1
Samson	0x000042	3780	0x00f9	1	1
Samson	0x000042	3780	0x00f9	2	1
Satron Instruments	0x0000b6	V-series	0x007f	1	1
Shanghai Sinoto Instrument Co	0x00604a	FST-3000	0xe190	7	2
SIC	0x0000d4	FLOW MASTER	0x0086	5	1
SIC	0x0000d4	HVP	0x0082	5	1
SIC	0x0000d4	HVP1114	0x0085	1	1
SIC	0x0000d4	PES	0x0080	5	1
SICK MAIHAK	0x0000c7	FLAWSIC 100	0xc781	1	1
SICK MAIHAK	0x0000c7	FLAWSIC 600	0x0080	1	1
Siemens	0x00002a	SIPART PS2	0x0015	1	1
Siemens	0x00002a	SIPART PS2	0x0015	2	1
Siemens	0x00002a	SIPART PS2	0x0015	3	1
Siemens	0x00002a	SIPART PS2	0x0015	3	2
Siemens	0x00002a	SITRANS FC MASSFLO	0x0019	2	1
Siemens	0x00002a	SITRANS FM	0x0016	1	1
Siemens	0x00002a	SITRANS FM IT2 / TM2	0x001a	1	1
Siemens	0x00002a	SITRANS FM MAGFLO	0x0018	1	1
Siemens	0x00002a	SITRANS FM MAGFLO	0x0018	2	1
Siemens	0x00002a	SITRANS FUS	0x0004	1	1
Siemens	0x00002a	SITRANS LR	0x0007	1	1
Siemens	0x00002a	SITRANS P DS	0x000b	1	2
Siemens	0x00002a	SITRANS P DS	0x000b	2	1
Siemens	0x00002a	SITRANS P DS	0x000b	3	1
Siemens	0x00002a	SITRANS P DS	0x000b	3	2
Siemens	0x00002a	SITRANS P DS	0x000b	3	3
Siemens	0x00002a	SITRANS P ES	0x000c	1	1
Siemens	0x00002a	SITRANS P HS	0x000a	1	1
Siemens	0x00002a	SITRANS P MS	0x000d	1	1
Siemens	0x00002a	SITRANS P300	0x001d	1	1
Siemens	0x00002a	SITRANS P300	0x001d	2	1
Siemens	0x00002a	SITRANS P300	0x001d	3	2
Siemens	0x00002a	SITRANS TH300	0x0013	1	2

# Device Xpert HART V1.07.00 - DD Library List

Status dated 2012.08.07

R09

DDs for Language:

EN

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Device Revision	DD Revision
Siemens	0x00002a	SITRANS TH300	0x0013	1	4
Siemens	0x00002a	SITRANS TK H	0x0012	1	1
Siemens	0x00002a	SITRANS TK H	0x0012	2	1
Siemens	0x00002a	SITRANS TR300	0x001f	1	1
Siemens	0x00002a	SITRANS TR300	0x001f	1	3
Siemens	0x00002a	SITRANS TW	0x0010	1	1
Siemens	0x00002a	SITRANS_P500	0x0023	1	2
Siemens	0x00002a	SITRANS_VP300	0x0020	1	2
Siemens Milltronics PI	0x000058	86x PROBE	0x00c8	1	2
Siemens Milltronics PI	0x000058	LR 200	0x00ca	1	1
Siemens Milltronics PI	0x000058	LR 200	0x00ca	2	2
Siemens Milltronics PI	0x000054	MSP2002	0x00f8	0	1
Siemens Milltronics PI	0x000054	MSP2002	0x00f8	0	2
Siemens Milltronics PI	0x000054	MSP2002	0x00f8	1	1
Siemens Milltronics PI	0x000054	MST9500	0x00f9	0	1
Siemens Milltronics PI	0x000054	MST9500	0x00f9	1	2
Siemens Milltronics PI	0x000054	MST9500	0x00f9	2	3
Siemens Milltronics PI	0x000054	MST9500	0x00f9	3	4
Siemens Milltronics PI	0x000058	Probe LR	0x00cf	2	2
Siemens Milltronics PI	0x000058	SITRANS LR200	0x00d6	1	1
Siemens Milltronics PI	0x000058	SITRANS LR250	0x00d1	2	2
Siemens Milltronics PI	0x000058	SITRANS LR260	0x00d4	2	2
Siemens Milltronics PI	0x000058	SITRANS LR300	0x00c9	1	1
Siemens Milltronics PI	0x000058	SITRANS LR400	0x00cc	1	1
Siemens Milltronics PI	0x000058	SITRANS LR460	0x00d3	5	2
Siemens Milltronics PI	0x000058	Sitrans Probe LU 12m	0x00ce	1	1
Siemens Milltronics PI	0x000058	Sitrans Probe LU 6m	0x00cd	1	1
Smar	0x00003e	DT301	0x0006	3	2
Smar	0x00003e	FY301	0x0003	1	2
Smar	0x00003e	FY301	0x0003	2	1
Smar	0x00003e	LD291	0x0004	3	1
Smar	0x00003e	LD291	0x0004	4	1
Smar	0x00003e	LD301	0x0001	3	5
Smar	0x00003e	LD301	0x0001	3	6
Smar	0x00003e	LD301	0x0001	4	2
Smar	0x00003e	LD400	0x000a	1	1
Smar	0x00003e	TP301	0x0005	1	1
Smar	0x00003e	TT301	0x0002	2	2
Smar	0x00003e	TT301	0x0002	3	1
Smar	0x00003e	TT400	0x0009	1	1
SMC	0x000083	F793-E701	0x00ef	1	2
SMC	0x000083	IP8001	0x007d	1	1
SMC	0x000083	IP8101	0x007e	1	1
Sparling Instruments	0x000043	FM6XX	0x00ee	1	1
Spectrex	0x0000db	SafEye	0xdb81	1	1
Spectrex	0x0000db	SharpEye	0x0080	1	3
Spirax Sarco Plc	0x0000ca	SP301	0x0080	1	3
Standard	0x000000	Common Practice	0x0003	3	1
Standard	0x000000	Common Practice	0x0003	3	2
Standard	0x000000	Common Practice	0x0003	4	1
Standard	0x000000	Common Practice	0x0003	4	2
Standard	0x000000	Common Practice	0x0003	5	1
Standard	0x000000	Common Practice	0x0003	5	2
Standard	0x000000	Common Practice	0x0003	6	1
Standard	0x000000	Common Practice	0x0003	6	2
Standard	0x000000	Common Practice	0x0003	7	1
Standard	0x000000	Common Practice	0x0003	7	2
Standard	0x000000	Common Practice	0x0003	7	3
Standard	0x000000	Common Practice	0x0003	7	4
Standard	0x000000	Common Practice	0x0003	8	1
Standard	0x000000	Common Practice	0x0003	8	2
Standard	0x000000	Common Practice	0x0003	9	2
Standard	0x000000	Common Tables	0x0001	10	1
Standard	0x000000	Common Tables	0x0001	11	1
Standard	0x000000	Common Tables	0x0001	13	1

# Device Xpert HART V1.07.00 - DD Library List

Status dated 2012.08.07

R09

DDs for Language:

EN

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Device Revision	DD Revision
Standard	0x000000	Common Tables	0x0001	14	1
Standard	0x000000	Common Tables	0x0001	14	2
Standard	0x000000	Common Tables	0x0001	14	3
Standard	0x000000	Common Tables	0x0001	14	4
Standard	0x000000	Common Tables	0x0001	15	1
Standard	0x000000	Common Tables	0x0001	15	2
Standard	0x000000	Common Tables	0x0001	15	3
Standard	0x000000	Common Tables	0x0001	15	4
Standard	0x000000	Common Tables	0x0001	16	1
Standard	0x000000	Common Tables	0x0001	16	2
Standard	0x000000	Common Tables	0x0001	16	3
Standard	0x000000	Common Tables	0x0001	16	4
Standard	0x000000	Common Tables	0x0001	17	1
Standard	0x000000	Common Tables	0x0001	17	2
Standard	0x000000	Common Tables	0x0001	17	3
Standard	0x000000	Common Tables	0x0001	17	4
Standard	0x000000	Common Tables	0x0001	17	6
Standard	0x000000	Common Tables	0x0001	20	4
Standard	0x000000	Common Tables	0x0001	21	2
Standard	0x000000	Common Tables	0x0001	21	3
Standard	0x000000	Common Tables	0x0001	21	4
Standard	0x000000	Common Tables	0x0001	22	1
Standard	0x000000	Common Tables	0x0001	22	2
Standard	0x000000	Common Tables	0x0001	22	3
Standard	0x000000	Common Tables	0x0001	22	4
Standard	0x000000	Common Tables	0x0001	23	2
Standard	0x000000	Common Tables	0x0001	6	1
Standard	0x000000	Common Tables	0x0001	7	1
Standard	0x000000	Common Tables	0x0001	8	1
Standard	0x000000	Common Tables	0x0001	9	2
Standard	0x000000	Menu	0x0010	1	1
Standard	0x000000	Moore Products	0x0013	1	1
Standard	0x000000	Moore Products	0x0013	1	2
Standard	0x000000	Moore Products	0x0013	1	3
Standard	0x000000	Moore Products	0x0013	1	4
Standard	0x000000	P2 Common	0x0015	1	5
Standard	0x000000	P2 Common	0x0015	1	6
Standard	0x000000	P2 Common	0x0015	1	7
Standard	0x000000	Pressure Common	0x0008	1	1
Standard	0x000000	Pressure Common	0x0008	2	1
Standard	0x000000	Pressure Universal	0x0007	1	1
Standard	0x000000	Pressure Universal	0x0007	2	1
Standard	0x000000	PV	0x0016	1	1
Standard	0x000000	Rosemount Magflow	0x0011	3	3
Standard	0x000000	Rosemount Magflow	0x0011	4	3
Standard	0x000000	Rosemount Magflow	0x0011	5	2
Standard	0x000000	Rosemount Magflow	0x0011	5	3
Standard	0x000000	Rosemount Pressure	0x0012	1	1
Standard	0x000000	Rosemount Pressure	0x0012	4	1
Standard	0x000000	Rosemount Pressure	0x0012	5	1
Standard	0x000000	Rosemount Pressure	0x0012	5	2
Standard	0x000000	Rosemount Pressure	0x0012	5	4
Standard	0x000000	Rosemount Pressure	0x0012	6	2
Standard	0x000000	Rosemount Pressure	0x0012	7	2
Standard	0x000000	Rosemount Pressure	0x0012	7	3
Standard	0x000000	Rosemount Pressure	0x0012	7	4
Standard	0x000000	Siemens Pressure	0x0014	1	1
Standard	0x000000	Universal	0x0002	3	1
Standard	0x000000	Universal	0x0002	3	2
Standard	0x000000	Universal	0x0002	4	1
Standard	0x000000	Universal	0x0002	4	2
Standard	0x000000	Universal	0x0002	5	1
Standard	0x000000	Universal	0x0002	5	2
Standard	0x000000	Universal	0x0002	6	1
Standard	0x000000	Universal	0x0002	6	2

# Device Xpert HART V1.07.00 - DD Library List

Status dated 2012.08.07

R09

DDs for Language:

EN

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Device Revision	DD Revision
Standard	0x000000	Universal	0x0002	7	2
Standard	0x000000	Wireless	0x0018	1	2
Status Instruments	0x000084	SEM 300	0x00ef	0	0
Status Instruments	0x000084	SEM 300	0x00ef	1	1
StoneL Corporation	0x006025	Axiom	0xe0c2	1	2
StoneL Corporation	0x006025	Axiom	0xe0c2	1	4
Thermo Measure Tech	0x000019	3680 Dens	0x0009	1	3
Thermo Measure Tech	0x000019	3680 Dens	0x0009	2	3
Thermo Measure Tech	0x000019	3680 Dens	0x0009	2	4
Thermo Measure Tech	0x000019	4790	0x000a	1	1
Thermo Measure Tech	0x000019	4790	0x000a	2	2
Thermo Measure Tech	0x000019	Accu-Pulse PRO	0x000b	1	1
Thermo Measure Tech	0x000090	Accu-Wave	0x007e	1	4
Thermo Measure Tech	0x000090	NCMi	0x007f	2	2
Thermo Measure Tech	0x000090	NCMi	0x007f	3	1
Thermo Measure Tech	0x000090	NDMi	0x007d	1	3
TOKYO KEISO	0x000082	AM/H	0x0065	1	1
TOKYO KEISO	0x000082	AM/H	0x0065	1	2
TOKYO KEISO	0x000082	AM_T	0x0063	1	1
TOKYO KEISO	0x000082	AM_T	0x0063	1	2
TOKYO KEISO	0x000082	FST-3000	0x007f	3	1
TOKYO KEISO	0x000082	FST-3000	0x007f	4	1
TOKYO KEISO	0x000082	FST4000	0x0061	3	1
TOKYO KEISO	0x000082	FST4000	0x0061	3	2
TOKYO KEISO	0x000082	FW-9000	0x007b	1	1
TOKYO KEISO	0x000082	UME1000	0x0062	1	1
Toshiba	0x00002c	AP3100	0x0002	4	2
Toshiba	0x00002c	LF220	0x000a	5	3
Toshiba	0x00002c	LF220	0x000a	6	1
Toshiba	0x00002c	LF220	0x000a	8	1
Toshiba	0x00002c	LF220	0x000a	8	2
TRACERCO	0x0000ae	PRI-150	0x007f	0	1
Turbo	0x000081	Intermag-Transmag	0x007f	2	3
Turbo	0x000081	Intermag-Transmag	0x007f	3	4
Turck	0x00009c	KMU_HLI	0x0001	1	1
Tyco Valves & Controls	0x0000ab	SmartCal	0x0001	1	1
VEGA	0x000062	FIBERTRAC 31	0x00c8	2	1
VEGA	0x000062	FIBERTRAC 32	0x00c9	2	1
VEGA	0x000062	MINITRAC 31	0x00cb	2	1
VEGA	0x000062	MINITRAC 32	0x00cc	2	1
VEGA	0x000062	MINITRAC 33	0x00cd	2	1
VEGA	0x000062	POINTRAC 31	0x00c5	2	1
VEGA	0x000062	SOLITRAC 31	0x00ca	2	1
VEGA	0x000062	VEGABAR 5x/6x	0x00e2	2	1
VEGA	0x000062	VEGABAR 5x/6x	0x00e2	2	2
VEGA	0x000062	VEGADIF 65	0x00e1	2	1
VEGA	0x000062	VEGADIF 65	0x00e1	2	2
VEGA	0x000062	VEGAPULS 61	0x62dc	4	1
VEGA	0x000062	VEGAPULS 61	0x62dc	5	1
VEGA	0x000062	VEGAPULS 62	0x62db	4	1
VEGA	0x000062	VEGAPULS 62	0x62db	5	1
VEGA	0x000062	VEGAPULS 63	0x62da	4	1
VEGA	0x000062	VEGAPULS 63	0x62da	5	1
VEGA	0x000062	VEGAPULS 65	0x62d9	4	1
VEGA	0x000062	VEGAPULS 65	0x62d9	5	1
VEGA	0x000062	VEGAPULS 66	0x62d8	4	1
VEGA	0x000062	VEGAPULS 66	0x62d8	5	1
VEGA	0x000062	VEGAPULS 67	0x62d7	4	1
VEGA	0x000062	VEGAPULS 67	0x62d7	5	1
VEGA	0x000062	VEGAPULS 68	0x62d6	4	1
VEGA	0x000062	VEGAPULS 68	0x62d6	5	1
VEGA	0x000062	VEGAPULS SR 68	0x62c6	4	1
VEGA	0x000062	VEGAPULS SR 68	0x62c6	5	1
VEGA	0x000062	VEGAPULS WL 61	0x62c7	4	1
VEGA	0x000062	VEGAPULS WL 61	0x62c7	5	1

# Device Xpert HART V1.07.00 - DD Library List

Status dated 2012.08.07

R09

DDs for Language:

EN

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Device Revision	DD Revision
Viatran	0x000032	970	0x0001	1	2
Viatran	0x000032	970	0x0001	2	3
Viatran	0x000032	I/A Pressure	0x002e	1	3
Vortek Instruments	0x000087	Innova-Mass	0x0001	5	1
WELLTECH SHANGHAI	0x000093	WT2000	0x007c	5	1
Westlock Controls	0x00004d	D-EPIC	0x0003	1	1
Westlock Controls	0x00004d	D-EPIC ESD	0x0004	1	1
Westlock Controls	0x00004d	ICOT	0x0001	4	1
Westlock Controls	0x00004d	ICOT	0x0001	5	2
WIKA	0x00006b	T32	0x00ef	0	2
WIKA	0x00006b	T32	0x00ef	1	1
WIKA	0x00006b	T32	0x00ef	2	1
WIKA	0x00006b	T32	0x00ef	3	1
WIKA	0x00006b	UniTrans	0x00ee	5	1
Yamatake	0x000036	AT9000	0x000d	1	1
Yamatake	0x000036	AT9000	0x000d	1	2
Yamatake	0x000036	AT9000	0x000d	1	3
Yamatake	0x000036	AT9000	0x000d	1	4
Yamatake	0x000036	MagneW	0x0001	1	2
Yamatake	0x000036	MagneW 2W	0x0008	1	1
Yamatake	0x000036	MagneW 2W	0x0008	2	1
Yamatake	0x000036	MagneW 2W	0x0008	2	2
Yamatake	0x000036	MagneW 2W	0x0008	2	3
Yamatake	0x000036	MAGNEW4W	0x000c	1	1
Yamatake	0x000036	MAGNEW4W	0x000c	1	2
Yamatake	0x000036	PTG	0x0005	1	1
Yamatake	0x000036	ST3000	0x0002	1	2
Yamatake	0x000036	ST3000	0x0002	2	1
Yamatake	0x000036	SVP	0x0003	1	1
Yamatake	0x000036	SVP	0x0003	2	1
Yamatake	0x000036	SVP	0x0003	2	4
Yamatake	0x000036	ThermoPlus ATT	0x0004	1	2
Yamatake	0x000036	ThermoPlus ATT	0x0004	1	3
Yamatake	0x000036	YSVP2	0x0014	1	2
Yokogawa	0x000037	ADMAG AE	0x0005	1	1
Yokogawa	0x000037	ADMAG AE	0x0005	2	1
Yokogawa	0x000037	ADMAG SE	0x0008	1	1
Yokogawa	0x000037	ADMAG SE	0x0008	2	1
Yokogawa	0x000037	AM11	0x0006	1	1
Yokogawa	0x000037	AV550G	0x0053	1	1
Yokogawa	0x000037	AXFA11	0x0050	1	1
Yokogawa	0x000037	AXFA11	0x0050	1	2
Yokogawa	0x000037	AXFA14	0x0052	1	1
Yokogawa	0x000037	AXFA14	0x0052	1	2
Yokogawa	0x000037	AXR	0x0057	1	2
Yokogawa	0x000037	AXR	0x0057	1	3
Yokogawa	0x000037	AXR	0x0057	2	1
Yokogawa	0x000037	AXR	0x0057	2	2
Yokogawa	0x000037	AXR_EXP	0x3757	10	1
Yokogawa	0x000037	DO202	0x0018	1	1
Yokogawa	0x000037	DYF	0x000b	1	1
Yokogawa	0x000037	DYF	0x000b	2	1
Yokogawa	0x000037	DYF	0x000b	3	1
Yokogawa	0x000037	DYF	0x000b	3	2
Yokogawa	0x000037	DYF	0x000b	4	1
Yokogawa	0x000037	DYF	0x000b	4	2
Yokogawa	0x000037	DYF_EXP	0x370b	10	1
Yokogawa	0x000037	DYF_EXP	0x370b	10	2
Yokogawa	0x000037	EJA	0x0004	1	2
Yokogawa	0x000037	EJA	0x0004	2	1
Yokogawa	0x000037	EJA	0x0004	3	1
Yokogawa	0x000037	EJX	0x0051	1	1
Yokogawa	0x000037	EJX	0x0051	1	2
Yokogawa	0x000037	EJX	0x0051	2	2
Yokogawa	0x000037	EJX	0x0051	3	2

# Device Xpert HART V1.07.00 - DD Library List

Status dated 2012.08.07

R09

DDs for Language:

EN

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Device Revision	DD Revision
Yokogawa	0x000037	EJX	0x3751	10	1
Yokogawa	0x000037	EJX-MV	0x0054	1	1
Yokogawa	0x000037	EJX-MV	0x0054	2	1
Yokogawa	0x000037	ISC202	0x0014	1	2
Yokogawa	0x000037	ISC450	0x002d	1	1
Yokogawa	0x000037	ISC450	0x002d	2	1
Yokogawa	0x000037	PH150	0x0027	1	1
Yokogawa	0x000037	PH150	0x0027	2	1
Yokogawa	0x000037	PH202	0x0015	1	3
Yokogawa	0x000037	PH450	0x002b	1	1
Yokogawa	0x000037	PH450	0x002b	2	1
Yokogawa	0x000037	RAMC	0x0041	1	2
Yokogawa	0x000037	RCCT_F3	0x0042	1	1
Yokogawa	0x000037	RCCT_F3	0x0042	1	3
Yokogawa	0x000037	RCCT_F3	0x0042	2	1
Yokogawa	0x000037	RCCT_F3	0x0042	3	1
Yokogawa	0x000037	ROTAMASS	0x0040	1	2
Yokogawa	0x000037	SC150	0x0028	1	1
Yokogawa	0x000037	SC150	0x0028	2	1
Yokogawa	0x000037	SC202	0x0016	1	2
Yokogawa	0x000037	SC450	0x002c	1	1
Yokogawa	0x000037	SC450	0x002c	2	1
Yokogawa	0x000037	UNICOM	0x0003	1	1
Yokogawa	0x000037	YEWFLO	0x0001	1	4
Yokogawa	0x000037	YEWFLO	0x0001	2	2
Yokogawa	0x000037	YT200	0x0002	1	1
Yokogawa	0x000037	YTA	0x0009	1	2
Yokogawa	0x000037	YTA	0x0009	2	1
Yokogawa	0x000037	YTA	0x0009	3	1
Yokogawa	0x000037	YTA70E	0x000a	1	1
Yokogawa	0x000037	YTA70E/Z	0x003c	1	1
Yokogawa	0x000037	ZR202	0x000c	1	1
Yokogawa	0x000037	ZR402	0x000d	1	1
YTC	0x0000b4	YT-2300	0x0001	10	1
YTC	0x0000b4	YT-2400	0x0002	10	1



# Device Xpert FF V1.01.00 - DD Library List

Status dated 2012.08.07

R01

Foundation Fieldbus DDs for Language:

EN

Manufacturer Name	Manufacturer ID	Device Type	Device ID	Dev Revision	DD Revision
ABB Automation Products GmbH	0x000320	600T_EN	0x0002	2	2
ABB Automation Products GmbH	0x000320	2600T Series - Models 262/264	0x0004	1	1
ABB Automation Products GmbH	0x000320	2600T Series - Models 262/264	0x0004	2	1
ABB Automation Products GmbH	0x000320	2600T Series - Model 264IB	0x0006	1	1
ABB Automation Products GmbH	0x000320	Flow Meter 20VT1000	0x0014	1	3
ABB Automation Products GmbH	0x000320	TRIO-WIRL FV4000 / FS4000	0x0015	1	1
ABB Automation Products GmbH	0x000320	TRIO-WIRL FV4000 / FS4000	0x0015	1	2
ABB Automation Products GmbH	0x000320	TRIO-WIRL FV4000 / FS4000	0x0015	2	1
ABB Automation Products GmbH	0x000320	FXE4000	0x0016	1	2
ABB Automation Products GmbH	0x000320	FXE4000	0x0016	2	1
ABB Automation Products GmbH	0x000320	FXE4000	0x0016	2	2
ABB Automation Products GmbH	0x000320	FSM4000	0x0017	1	1
ABB Automation Products GmbH	0x000320	FSM4000	0x0017	2	1
ABB Automation Products GmbH	0x000320	FCM2000	0x0018	1	1
ABB Automation Products GmbH	0x000320	Temperature Puck TF02	0x001e	1	1
ABB Automation Products GmbH	0x000320	TTX300	0x001f	1	1
ABB Automation Products GmbH	0x000320	TZID-C120/220	0x0028	1	1
ABB Automation Products GmbH	0x000320	TZID-C120/220	0x0028	2	1
ABB Automation Products GmbH	0x000320	TB82PH	0x0050	1	1
ABB Automation Products GmbH	0x000320	TB82EC	0x0051	1	1
ABB Automation Products GmbH	0x000320	TB82TE	0x0052	1	1
ABB Automation Products GmbH	0x000320	TB82TC	0x0053	1	1
ABB Automation Products GmbH	0x000320	2600T Series 263/265	0x0089	1	1
ABB Automation Products GmbH	0x000320	2600T Series 263/265	0x0089	2	1
ABB Automation Products GmbH	0x000320	2600T Series 267/269	0x008a	2	1
Anderson Instrument Co.	0x000a1c	FPP	0x1000	1	1
Anderson Instrument Co.	0x000a1c	FPT	0x2000	1	1
ASCO Controls; LP	0x41434c	ASCO Controls 4449	0x4449	1	1
AUMA	0x0a01ff	AUMATIC FF H1	0x01f8	1	1
BEKA Associates Ltd.	0x004241	BA414DF Series	0x0414	1	1
BEKA Associates Ltd.	0x004241	BA488CF Series	0x0488	1	1
BEKA Associates Ltd.	0x004241	BA488CF Series	0x0488	1	2
BEKA Associates Ltd.	0x004241	BA488CF Series	0x0488	2	1
BEKA Associates Ltd.	0x004241	BA488CF Series	0x0488	2	2
Berthold Technologies GmbH & Co. KG	0x00a1ff	Uniprobe LB491	0x007d	1	1
Berthold Technologies GmbH & Co. KG	0x00a1ff	Uniprobe LB491	0x007d	1	2
Berthold Technologies GmbH & Co. KG	0x00a1ff	Uniprobe LB491	0x007d	2	1
Berthold Technologies GmbH & Co. KG	0x00a1ff	Uniprobe LB491	0x007d	2	2
Berthold Technologies GmbH & Co. KG	0x00a1ff	Uniprobe LB490	0x007f	1	1
Berthold Technologies GmbH & Co. KG	0x00a1ff	Uniprobe LB490	0x007f	1	2
Berthold Technologies GmbH & Co. KG	0x00a1ff	Uniprobe LB490	0x007f	2	1
Berthold Technologies GmbH & Co. KG	0x00a1ff	Uniprobe LB490	0x007f	2	2
Biffi Italia srl	0x424946	FF 2000 v4	0x0001	1	1
Biffi Italia srl	0x424946	FF 2000 v4	0x0001	2	1
Biffi Italia srl	0x424946	F02-FF	0x0200	1	4
Biffi Italia srl	0x424946	F02-FF	0x0200	1	6
Buerkert Werke GmbH & Co.	0x0021c3	8643 (4-wire version)	0x21c3	1	1
Buerkert Werke GmbH & Co.	0x0021c3	8643 (4-wire version)	0x21c3	2	2
Buerkert Werke GmbH & Co.	0x0021c3	8643 (4-wire version)	0x21c3	4	1
Chemtrac Systems; Inc.	0x77e1a5	PC 2400 D	0x0001	1	1
ChongQing ChuanYi Automation Co.; Ltd.	0x000212	FlowMaster EM Flow Meter	0x0001	1	1
CiDRA Corporate Services; Inc.	0x0c1dc0	SONARtrac	0x0001	1	1
CiDRA Corporate Services; Inc.	0x0c1dc0	SONARtrac	0x0001	2	1
Draeger Safety AG&Co. KGaA	0x520000	Polytron 7xxx	0x00eb	1	1
Draeger Safety AG&Co. KGaA	0x520000	Polytron 7xxx	0x00eb	1	2
Dresser Italia S.p.A.	0x4c444e	LEDEENLD-Series1.0	0x0001	1	1
Dresser Valve Division	0x445644	FVP	0x0001	3	1
Dresser Valve Division	0x445644	FVP	0x0001	3	3
Dresser Valve Division	0x445644	FVP	0x0001	3	6
Dresser Valve Division	0x445644	FVP	0x0001	4	1
Dresser Valve Division	0x445644	FVP (Software Download)	0x0007	1	1
Dresser Valve Division	0x445644	FVP (Software Download)	0x0007	1	5
Dresser Valve Division	0x445644	FVP (Software Download)	0x0007	2	1
Dresser Valve Division	0x445644	FVP (Software Download)	0x0007	2	2
Dresser Valve Division	0x445644	FVP (Software Download)	0x0007	3	1
Duon System Co.; Ltd.	0x445343	Test	0x2300	1	1
Dynisco	0x44594e	FFX Pressure Transmitter	0x3031	1	1

# Device Xpert FF V1.01.00 - DD Library List

Status dated 2012.08.07

R01

Foundation Fieldbus DDs for Language:

EN

Manufacturer Name	Manufacturer ID	Device Type	Device ID	Dev Revision	DD Revision
EIM Controls Inc.	0x002000	EA00 Positioner	0xea00	1	1
EIM Controls Inc.	0x002000	ED00 Fieldbus OnOff Valve	0xed00	1	1
EIM Controls Inc.	0x002000	DCM Fieldbus Actuator	0xedc2	1	1
EIM Controls Inc.	0x002000	DCM Fieldbus Actuator	0xedc2	1	2
Emerson Process Management	0x001151	Rosemount 644	0x0644	1	1
Emerson Process Management	0x001151	Rosemount 644	0x0644	1	5
Emerson Process Management	0x001151	Rosemount 644	0x0644	1	7
Emerson Process Management	0x001151	Rosemount 644	0x0644	2	1
Emerson Process Management	0x001151	Rosemount 752 Fieldbus Remote Display	0x0752	2	1
Emerson Process Management	0x001151	Rosemount 752 Fieldbus Remote Display	0x0752	2	5
Emerson Process Management	0x001151	Rosemount 848T	0x0848	4	4
Emerson Process Management	0x001151	Rosemount 848T	0x0848	5	11
Emerson Process Management	0x001151	Rosemount 848T	0x0848	5	4
Emerson Process Management	0x001151	Rosemount 848T	0x0848	5	9
Emerson Process Management	0x001151	Rosemount 848T	0x0848	6	1
Emerson Process Management	0x0b87a3	990 Fieldbus	0x0990	4	1
Emerson Process Management	0x000246	Brooks Instrument SLA Series; AM	0x1000	1	1
Emerson Process Management	0x000246	Brooks Instrument SLA Series; AM	0x1000	1	3
Emerson Process Management	0x524149	Rosemount Analytical 1000	0x1000	3	1
Emerson Process Management	0x524149	Rosemount Analytical MLT	0x1100	1	1
Emerson Process Management	0x000310	Micro Motion MVD 2700	0x2000	1	1
Emerson Process Management	0x000310	Micro Motion MVD 2700	0x2000	2	1
Emerson Process Management	0x000310	Micro Motion MVD 2700	0x2000	3	1
Emerson Process Management	0x000310	Micro Motion MVD 2700	0x2000	3	2
Emerson Process Management	0x000310	Micro Motion MVD 2700	0x2000	4	1
Emerson Process Management	0x000310	Micro Motion MVD 2700	0x2000	4	2
Emerson Process Management	0x000310	Micro Motion MVD 2700	0x2000	5	1
Emerson Process Management	0x000310	Micro Motion MVD 2700	0x2000	5	2
Emerson Process Management	0x524149	Rosemount Analytical 700XA	0x2001	1	1
Emerson Process Management	0x524149	Rosemount Analytical 700XA	0x2001	1	3
Emerson Process Management	0x524149	Rosemount Analytical 700XA	0x2001	1	4
Emerson Process Management	0x524149	Rosemount Analytical 1500XA	0x2002	1	1
Emerson Process Management	0x001151	Rosemount 2051	0x2051	1	1
Emerson Process Management	0x001151	Fieldbus Pressure Transmitter 2088	0x2088	1	1
Emerson Process Management	0x0b87a3	EL-O-MATIC 22C0	0x22c0	4	1
Emerson Process Management	0x0b87a3	EL-O-MATIC 22C0	0x22c0	5	1
Emerson Process Management	0x005100	Fisher DLC3020f Digital Level	0x3020	1	1
Emerson Process Management	0x001151	Rosemount 3051 Series	0x3051	20	1
Emerson Process Management	0x001151	Rosemount 3051 Series	0x3051	20	3
Emerson Process Management	0x001151	Rosemount 3051 Series	0x3051	22	1
Emerson Process Management	0x001151	Rosemount 3051 Series	0x3051	23	3
Emerson Process Management	0x001151	Rosemount 3051 Series	0x3051	23	5
Emerson Process Management	0x001151	Rosemount 3051 Series	0x3051	23	7
Emerson Process Management	0x001151	Rosemount 3051 Series	0x3051	7	2
Emerson Process Management	0x001151	Rosemount 3051 Series	0x3051	7	3
Emerson Process Management	0x001151	Rosemount 3095 MultiVariable Transmitter	0x3095	1	1
Emerson Process Management	0x001151	Rosemount 3095 MultiVariable Transmitter	0x3095	1	3
Emerson Process Management	0x001151	Rosemount 3144P	0x3144	1	1
Emerson Process Management	0x001151	Rosemount 3144P	0x3144	1	5
Emerson Process Management	0x001151	Rosemount 3144P	0x3144	2	1
Emerson Process Management	0x001151	Fieldbus Temperature Transmitter 3244	0x3244	4	1
Emerson Process Management	0x001151	Fieldbus Temperature Transmitter 3244	0x3244	5	1
Emerson Process Management	0x001151	Rosemount 3900 Tank Radar REX	0x3900	1	1
Emerson Process Management	0x524149	Rosemount Analytical Oxymitter 5000	0x4000	3	1
Emerson Process Management	0x524149	Rosemount Analytical Oxymitter 5000	0x4000	3	3
Emerson Process Management	0x001151	Rosemount Oxymitter 5000	0x4000	4	1
Emerson Process Management	0x524149	Rosemount Analytical 4001	0x4001	2	1
Emerson Process Management	0x524149	Rosemount Analytical 4081PH	0x4081	3	1
Emerson Process Management	0x524149	Rosemount Analytical 4082CT	0x4082	2	1
Emerson Process Management	0x524149	Rosemount Analytical 5081-A-FF	0x4083	1	1
Emerson Process Management	0x524149	Rosemount Analytical 5081-A-FF	0x4083	2	1
Emerson Process Management	0x524149	Rosemount Analytical 5081-A-FF	0x4083	2	6
Emerson Process Management	0x524149	Rosemount Analytical 5081-C/T-FF	0x4084	1	1
Emerson Process Management	0x524149	Rosemount Analytical 5081-C/T-FF	0x4084	2	1
Emerson Process Management	0x524149	Rosemount Analytical 5081-C/T-FF	0x4084	2	6
Emerson Process Management	0x524149	Rosemount Analytical 5081-pH/ORP-FF	0x4085	1	1
Emerson Process Management	0x524149	Rosemount Analytical 5081-pH/ORP-FF	0x4085	2	1

# Device Xpert FF V1.01.00 - DD Library List

Status dated 2012.08.07

R01

Foundation Fieldbus DDs for Language:

EN

Manufacturer Name	Manufacturer ID	Device Type	Device ID	Dev Revision	DD Revision
Emerson Process Management	0x524149	Rosemount Analytical 5081-pH/ORP-FF	0x4085	2	4
Emerson Process Management	0x524149	Rosemount Analytical Xmt-A-FF	0x4086	1	1
Emerson Process Management	0x524149	Rosemount Analytical Xmt-C/T-FF	0x4087	1	1
Emerson Process Management	0x524149	Rosemount Analytical Xmt-P-FF	0x4088	1	1
Emerson Process Management	0x005100	Fisher DVC6000f	0x4601	1	1
Emerson Process Management	0x005100	Fisher DVC6000f	0x4601	1	2
Emerson Process Management	0x005100	Fisher DVC6000f	0x4601	1	3
Emerson Process Management	0x005100	Fisher DVC6000f	0x4601	1	4
Emerson Process Management	0x005100	Fisher DVC6000f	0x4601	1	6
Emerson Process Management	0x005100	Fisher DVC6200f / DVC6000f	0x4602	2	3
Emerson Process Management	0x4e554d	Numatics Inc. FF Valve Manifold	0x4732	1	1
Emerson Process Management	0x001151	Rosemount 5300 Series	0x5300	1	1
Emerson Process Management	0x001151	Rosemount 5300 Series	0x5300	1	3
Emerson Process Management	0x001151	Rosemount 5300 Series	0x5300	1	7
Emerson Process Management	0x001151	Rosemount 5300 Series	0x5300	2	1
Emerson Process Management	0x001151	Rosemount 5300 Series	0x5300	2	3
Emerson Process Management	0x001151	Rosemount 5400 Series	0x5400	1	1
Emerson Process Management	0x524149	Rosemount Analytical OCX 8800	0x5400	1	1
Emerson Process Management	0x001151	Rosemount 5400 Series	0x5400	2	1
Emerson Process Management	0x524149	Rosemount Analytical OCX 8800	0x5400	2	1
Emerson Process Management	0x001151	Rosemount 5400 Series	0x5400	2	3
Emerson Process Management	0x005100	DVC5000f ao/pid/is	0x5420	8	3
Emerson Process Management	0x005100	DVC5000f ao/pid/is	0x5420	9	3
Emerson Process Management	0x001151	Rosemount 5600 TankRadar PRO	0x5600	1	1
Emerson Process Management	0x001151	Rosemount 5600 TankRadar PRO	0x5600	1	3
Emerson Process Management	0x005100	DVC5000f do/di	0x5900	8	3
Emerson Process Management	0x0b87a3	7360 Fieldbus	0x7360	4	1
Emerson Process Management	0x524149	Rosemount Analytical 8000	0x8000	2	1
Emerson Process Management	0x0b87a3	8000 Fieldbus	0x8000	4	1
Emerson Process Management	0x001151	Rosemount 848L	0x848d	1	1
Emerson Process Management	0x001151	Rosemount 848L	0x848d	1	5
Emerson Process Management	0x001151	Rosemount 8732E	0x8732	1	1
Emerson Process Management	0x001151	Rosemount 8732E	0x8732	1	3
Emerson Process Management	0x001151	Rosemount 8732E	0x8732	2	1
Emerson Process Management	0x001151	Rosemount 8742C	0x8742	4	1
Emerson Process Management	0x001151	Rosemount 8742C	0x8742	5	1
Emerson Process Management	0x001151	Rosemount 8800	0x8800	4	1
Emerson Process Management	0x001151	Rosemount 8800	0x8800	5	1
Emerson Process Management	0x001151	Rosemount 8800	0x8800	5	2
Emerson Process Management	0x001151	Rosemount 8800	0x8800	6	1
Emerson Process Management	0x001151	Rosemount 8800	0x8800	6	3
Emerson Process Management	0x001151	Rosemount 8800	0x8800	7	1
Emerson Process Management	0x001151	Rosemount 8800	0x8800	9	1
Emerson Process Management	0x435349	CSI 9210	0x9210	1	1
Emerson Process Management	0x435349	CSI 9210	0x9210	2	11
Emerson Process Management	0x435349	CSI 9210	0x9210	2	1
Emerson Process Management	0x435349	CSI 9210	0x9210	3	7
Emerson Process Management	0x0b87a3	7556	0xa2c0	4	1
Emerson Process Management	0x564144	FieldQ	0xd3a0	1	3
Emerson Process Management	0x564144	FieldQ	0xd3a0	2	1
Emerson Process Management	0x564144	FieldQ	0xd3a0	2	3
Emerson Process Management	0x0b87a3	EL-O-MATIC DD30	0xdd30	4	1
Emerson Process Management	0x0b87a3	EL-O-MATIC DD30	0xdd30	5	1
Emerson Process Management	0x0b87a3	F800 Fieldbus	0xf800	4	1
Endress+Hauser	0x452b48	Cerabar S	0x1007	2	1
Endress+Hauser	0x452b48	Cerabar S	0x1007	2	3
Endress+Hauser	0x452b48	Cerabar S	0x1007	5	1
Endress+Hauser	0x452b48	Cerabar S	0x1007	6	1
Endress+Hauser	0x452b48	Cerabar S	0x1007	6	3
Endress+Hauser	0x452b48	Deltabar S	0x1009	2	1
Endress+Hauser	0x452b48	Deltabar S	0x1009	2	3
Endress+Hauser	0x452b48	Deltabar S	0x1009	5	1
Endress+Hauser	0x452b48	Deltabar S	0x1009	6	1
Endress+Hauser	0x452b48	Deltabar S	0x1009	6	3
Endress+Hauser	0x452b48	Deltapilot S	0x100b	1	1
Endress+Hauser	0x452b48	Deltapilot S	0x100b	1	2
Endress+Hauser	0x452b48	Deltapilot S	0x100b	6	1

# Device Xpert FF V1.01.00 - DD Library List

Status dated 2012.08.07

R01

Foundation Fieldbus DDs for Language:

EN

Manufacturer Name	Manufacturer ID	Device Type	Device ID	Dev Revision	DD Revision
Endress+Hauser	0x452b48	Deltapilot S	0x100b	6	3
Endress+Hauser	0x452b48	Micropilot M	0x100f	2	1
Endress+Hauser	0x452b48	Micropilot M	0x100f	2	2
Endress+Hauser	0x452b48	Micropilot M	0x100f	3	1
Endress+Hauser	0x452b48	Micropilot M	0x100f	3	3
Endress+Hauser	0x452b48	Micropilot M	0x100f	4	1
Endress+Hauser	0x452b48	Micropilot M	0x100f	4	2
Endress+Hauser	0x452b48	Micropilot M	0x100f	4	3
Endress+Hauser	0x452b48	Micropilot M	0x100f	5	1
Endress+Hauser	0x452b48	Micropilot M	0x100f	5	3
Endress+Hauser	0x452b48	Micropilot M	0x100f	5	4
Endress+Hauser	0x452b48	Prosonic M	0x1011	3	1
Endress+Hauser	0x452b48	Prosonic M	0x1011	3	3
Endress+Hauser	0x452b48	Prosonic M	0x1011	4	1
Endress+Hauser	0x452b48	Prosonic M	0x1011	4	2
Endress+Hauser	0x452b48	Prosonic M	0x1011	4	3
Endress+Hauser	0x452b48	Levelflex M	0x1012	3	1
Endress+Hauser	0x452b48	Levelflex M	0x1012	3	3
Endress+Hauser	0x452b48	Levelflex M	0x1012	4	1
Endress+Hauser	0x452b48	Levelflex M	0x1012	4	2
Endress+Hauser	0x452b48	Levelflex M	0x1012	4	3
Endress+Hauser	0x452b48	FMG60 Gammapilot M	0x1013	1	1
Endress+Hauser	0x452b48	FMG60 Gammapilot M	0x1013	1	3
Endress+Hauser	0x452b48	FMG60 Gammapilot M	0x1013	1	4
Endress+Hauser	0x452b48	FMG60 Gammapilot M	0x1013	3	1
Endress+Hauser	0x452b48	FMG60 Gammapilot M	0x1013	3	2
Endress+Hauser	0x452b48	FMG60 Gammapilot M	0x1013	3	4
Endress+Hauser	0x452b48	Cerabar M 5x	0x1019	1	1
Endress+Hauser	0x452b48	Deltabar M 5x	0x1021	1	1
Endress+Hauser	0x452b48	Deltapilot M 5x	0x1023	1	1
Endress+Hauser	0x452b48	PROline Promag 53/55	0x1042	2	1
Endress+Hauser	0x452b48	PROline Promag 53/55	0x1042	2	2
Endress+Hauser	0x452b48	PROline Promag 53/55	0x1042	3	1
Endress+Hauser	0x452b48	PROline Promag 53/55	0x1042	4	1
Endress+Hauser	0x452b48	PROline Promass 83	0x1051	1	1
Endress+Hauser	0x452b48	PROline Promass 83	0x1051	2	1
Endress+Hauser	0x452b48	PROline Promass 83	0x1051	2	2
Endress+Hauser	0x452b48	PROline Promass 83	0x1051	3	1
Endress+Hauser	0x452b48	PROline Promass 83	0x1051	4	1
Endress+Hauser	0x452b48	Prowirl 72	0x1056	1	1
Endress+Hauser	0x452b48	Prowirl 73	0x1057	1	1
Endress+Hauser	0x452b48	PROline Prosonic Flow 93	0x1059	1	1
Endress+Hauser	0x452b48	PROline Prosonic Flow 93	0x1059	1	2
Endress+Hauser	0x452b48	PROline Prosonic Flow 93	0x1059	1	3
Endress+Hauser	0x452b48	PROline Prosonic Flow 93	0x1059	2	1
Endress+Hauser	0x452b48	PROline Prosonic Flow 93	0x1059	3	1
Endress+Hauser	0x452b48	Prosonic Flow 92	0x1061	1	1
Endress+Hauser	0x452b48	PROline t-mass 65	0x1065	1	1
Endress+Hauser	0x452b48	Liquiline M CM42 pH/ORP	0x108f	1	1
Endress+Hauser	0x452b48	Liquiline M CM42 pH/ORP	0x108f	1	3
Endress+Hauser	0x452b48	Liquiline M CM42 Cond	0x1090	1	1
Endress+Hauser	0x452b48	Liquiline M CM42 Cond	0x1090	1	3
Endress+Hauser	0x452b48	Liquiline M CM42 Doxygen	0x109b	1	1
Endress+Hauser	0x452b48	Liquiline M CM42 Doxygen	0x109b	1	2
Endress+Hauser	0x452b48	TMT162	0x10cc	1	1
Endress+Hauser	0x452b48	TMT162	0x10cc	1	2
Endress+Hauser	0x452b48	TMT125	0x10cd	1	6
Endress+Hauser	0x452b48	TMT125	0x10cd	1	7
Endress+Hauser	0x452b48	TMT85	0x10ce	1	1
Endress+Hauser	0x452b48	TMT85	0x10ce	1	3
Endress+Hauser	0x452b48	RID1x (RID14/RID16)	0x10cf	1	1
Endress+Hauser	0x452b48	TMT165	0x1200	4	1
Endress+Hauser	0x452b48	TMT165	0x1200	4	3
ENOTEC GmbH	0x454e4f	OXITEC 5000	0x0001	1	1
ENOTEC GmbH	0x454e4f	COMTEC 6000	0x0002	1	1
Enraf Terminal Automation	0x4e5246	854 ATG Servo Series	0x0320	1	1
Enraf Terminal Automation	0x4e5246	97x SmartRadar Series	0x0384	1	1

# Device Xpert FF V1.01.00 - DD Library List

Status dated 2012.08.07

R01

Foundation Fieldbus DDs for Language:

EN

Manufacturer Name	Manufacturer ID	Device Type	Device ID	Dev Revision	DD Revision
EnVision Instruments	0x004549	ENVISION-CD	0x0101	1	1
Fieldbus International	0x00a000	LEVEL_RADAR_DEVICE	0x0010	1	1
Fieldbus International	0x00a000	LEVEL_TDR_DEVICE	0x0011	1	1
Flowserve Corporation	0x464c53	PMV D3	0x00d3	1	1
Flowserve Corporation	0x464c53	PMV D3	0x00d3	2	2
Flowserve Corporation	0x464c53	LOGIX 3400IQ/1400	0x0202	5	1
Flowserve Corporation	0x464c53	LOGIX 3400IQ/1400	0x0202	6	1
Flowserve Corporation	0x464c53	LOGIX 3400IQ/1400	0x0202	6	2
Flowserve Corporation	0x464c53	Logix 3400MD	0x0203	1	1
Flowserve Corporation	0x464c53	Logix 3400MD	0x0203	1	2
Flowserve Corporation	0x464c53	Accutronix MX	0x4d58	2	1
Flowserve Corporation	0x464c53	Accutronix MX	0x4d58	2	2
Flowserve Corporation	0x464c53	Accutronix MX	0x4d58	3	1
Flowserve Corporation	0x464c53	Accutronix MX	0x4d58	3	2
Flowserve Corporation	0x464c4f	BUSwitch	0x5053	3	1
Flowserve Corporation	0x464c4f	BUSwitch	0x5053	4	1
Foxboro (and Foxboro-Eckardt)	0x385884	RTT25-F2	0x0034	1	1
Foxboro (and Foxboro-Eckardt)	0x385884	RTT25-F2	0x0034	2	1
Foxboro (and Foxboro-Eckardt)	0x385884	RTT25-F2	0x0034	3	1
Foxboro (and Foxboro-Eckardt)	0x385884	RTT25-F1	0x0035	2	1
Foxboro (and Foxboro-Eckardt)	0x385884	RTT25-F1	0x0035	3	1
Foxboro (and Foxboro-Eckardt)	0x385884	RTT15-F	0x1036	1	1
Foxboro (and Foxboro-Eckardt)	0x385884	SRD 991	0x2401	16	1
Foxboro (and Foxboro-Eckardt)	0x385884	SRD 991	0x2401	4	1
Foxboro (and Foxboro-Eckardt)	0x385884	SRD 991	0x2401	9	2
Foxboro (and Foxboro-Eckardt)	0x385884	SRD 960	0x2481	16	1
Foxboro (and Foxboro-Eckardt)	0x385884	SRD 960	0x2481	9	2
Foxboro (and Foxboro-Eckardt)	0x385884	240FF	0x2506	1	1
Foxboro (and Foxboro-Eckardt)	0x385884	IASPT10	0xba2e	20	1
Foxboro (and Foxboro-Eckardt)	0x385884	IASPT10	0xba2e	21	1
Foxboro (and Foxboro-Eckardt)	0x385884	I/A Series IMV25 Pressure Transmitter	0xba2f	16	1
Foxboro (and Foxboro-Eckardt)	0x385884	I/A Series IMV25 Pressure Transmitter	0xba2f	5	1
Foxboro (and Foxboro-Eckardt)	0x385884	I Series	0xba30	21	1
Foxboro (and Foxboro-Eckardt)	0x385884	I Series	0xba30	23	1
Foxboro (and Foxboro-Eckardt)	0x385884	I Series	0xba30	32	1
Foxboro (and Foxboro-Eckardt)	0x385884	I Series	0xba30	48	1
Foxboro (and Foxboro-Eckardt)	0x385884	IMT25	0xbc29	1	1
Foxboro (and Foxboro-Eckardt)	0x385884	I/A Series IMT25 Magnetic Flowmeter	0xbd29	2	1
Foxboro (and Foxboro-Eckardt)	0x385884	83	0xbd33	1	1
Foxboro (and Foxboro-Eckardt)	0x385884	83	0xbd33	2	2
Foxboro (and Foxboro-Eckardt)	0x385884	83	0xbd33	3	1
Fuji Electric Corporation	0x000309	FLOWMETER	0x0001	1	2
Fuji Electric Corporation	0x000309	FFX-T Series	0x0003	1	2
Fuji Electric Corporation	0x000309	FCX-A2 Series	0x0032	1	1
Fuji Electric Corporation	0x000309	FCX-AIII Series	0x0033	1	1
GE Sensing	0x004745	XMT868i Liquid Flow Transmitter	0x0001	1	1
GE Sensing	0x004745	GE Flow Gas 868	0x0002	1	1
Hach Company	0x001d6d	SI 792X P-FF	0x0064	1	1
Hach Company	0x001d6d	SI 792X C-FF	0x0065	1	1
Hach Company	0x001d6d	SI 792X T-FF	0x0066	1	1
Hach Company	0x001d6d	SI 792X E-FF	0x0067	1	1
Hach Company	0x001d6d	SI 792X D-FF	0x0068	1	1
Harold Beck & Sons; Inc.	0x001000	DCM	0x0001	1	1
Hawk Measurement Systems	0x001988	Hawk FF Level Series	0x0001	1	1
Heinrichs Messtechnik GmbH	0x000211	ES-FF	0x0001	1	1
HMS Industrial Networks	0x003000	ABX-DP-FF	0x0001	1	1
Honeywell Field Solutions	0x48574c	ST3000FF	0x0002	8	1
Honeywell Field Solutions	0x48574c	ST3000FF	0x0002	9	1
Honeywell Field Solutions	0x48574c	STT35F	0x0101	2	1
Honeywell Field Solutions	0x48574c	STT35F	0x0101	4	1
Honeywell Field Solutions	0x48574c	STT40F	0x0102	2	1
Honeywell Field Solutions	0x48574c	STT40F	0x0102	2	2
Honeywell Field Solutions	0x48574c	TWM9000	0x0500	1	1
Honeywell Field Solutions	0x48574c	TWC9000	0x0501	1	1
Honeywell Field Solutions	0x48574c	STT17F	0x1101	1	1
HuaKong Technology	0x0022b8	HK-F102TT	0x5454	1	1
ISE-Magtech	0x000108	LTM-300FF	0x0101	1	1

# Device Xpert FF V1.01.00 - DD Library List

Status dated 2012.08.07

R01

Foundation Fieldbus DDs for Language:

EN

Manufacturer Name	Manufacturer ID	Device Type	Device ID	Dev Revision	DD Revision
ISE-Magtech	0x000108	LTM-300FF	0x0101	1	4
Knick Elektronische Messgerate GmbH & Co.KG	0x000102	Stratos FF 2231 X pH	0x08b7	1	1
Knick Elektronische Messgerate GmbH & Co.KG	0x000102	Stratos FF 2232 X CONDI	0x08b8	1	1
Knick Elektronische Messgerate GmbH & Co.KG	0x000102	COMFF 3400-085	0x0d48	1	1
Knick Elektronische Messgerate GmbH & Co.KG	0x000102	Stratos FF 2231X OXY	0x5727	1	1
Knick Elektronische Messgerate GmbH & Co.KG	0x000102	Stratos FF 2231 X COND	0x5728	1	1
KOSO America Inc.	0x00094b	Xpac X2 Model Series	0x0001	1	1
KOSO America Inc.	0x00094b	Xpac X2 Model Series	0x0001	2	1
KOSO	0x002379	XPAC_Actuator	0x0001	1	1
Krohne Messtechnik GmbH	0x00012c	OPTIFLUX IFC300	0x0300	1	1
Krohne Messtechnik GmbH	0x00012c	OPTIFLUX IFC300	0x0300	2	1
Krohne Messtechnik GmbH	0x00012c	OPTIFLUX IFC300	0x0300	3	1
Krohne Messtechnik GmbH	0x00012c	OPTIMASS MFC300	0x0320	1	1
Krohne Messtechnik GmbH	0x00012c	OPTIMASS MFC300	0x0320	2	1
Krohne Messtechnik GmbH	0x00012c	OPTIMASS MFC300	0x0320	3	1
Krohne Messtechnik GmbH	0x00012c	OPTISONIC UFC300-IL	0x0350	1	1
Krohne Messtechnik GmbH	0x00012c	BM100A	0xee01	2	1
Krohne Messtechnik GmbH	0x00012c	IFC090	0xf401	1	1
Krohne Messtechnik GmbH	0x00012c	BM70A/P	0xf901	1	1
Krohne Messtechnik GmbH	0x00012c	BM70A/P	0xf901	3	1
K-TEK	0x000101	AT100; AT100S; AT200	0x0100	1	1
K-TEK	0x000101	AT100; AT100S; AT200	0x0100	2	1
K-TEK	0x000101	AT100; AT100S; AT200	0x0100	3	1
K-TEK	0x000101	MT5000; MT5100; MT5200	0x5000	1	1
K-TEK	0x000101	MT5000; MT5100; MT5200	0x5000	2	1
L. Bernard S. A.	0x004000	BERNARD_ACTUATOR	0x0001	1	1
Limitorque Corporation	0x385885	LIMITORQUE MX QX	0x4d58	1	1
Limitorque Corporation	0x385885	LIMITORQUE MX QX	0x4d58	1	2
Magnetrol	0x000156	Eclipse Enhanced Model 705 3x	0x0001	1	1
Magnetrol	0x000156	Eclipse Enhanced Model 705 3x	0x0001	2	1
Magnetrol	0x000156	Orion Jupiter Model 2xx	0x0002	1	1
Magnetrol	0x000156	E3 Modulelevel	0x0003	1	1
Magnetrol	0x000156	705	0x0705	1	1
Metroval Controle de Fluidos Ltda.	0x000104	CMM-01	0x0001	1	1
Metso Automation	0x000e05	ND800FF	0x0320	3	1
Metso Automation	0x000e05	ND9000F	0x2328	1	1
Metso Automation	0x000e05	ND9000F	0x2328	2	1
Metso Automation	0x000e05	ND9000F	0x2328	3	1
Metso Automation	0x000e05	ND9000F	0x2328	4	1
Metso Automation	0x000e05	ND9000F	0x2328	5	1
Metso Automation	0x000e05	ND9000F	0x2328	5	2
Metso Automation	0x000e05	ND9000F	0x2328	5	3
Metso Automation	0x000e05	VG9000F	0x2329	1	7
Metso Automation	0x000e05	LCP9000F	0x232a	1	1
Mettler-Toledo GmbH	0x465255	M700 FF 700	0x00f0	1	1
Mettler-Toledo GmbH	0x465255	pH 2100e FF	0x0834	1	1
Mettler-Toledo GmbH	0x465255	O2 4100e FF	0x1004	1	1
Mettler-Toledo GmbH	0x465255	Cond 7100e FF	0x1bbc	1	1
Mettler-Toledo GmbH	0x465255	Cond Ind 7100e FF	0x1bbd	1	1
Microcyber Inc. (Shenyang Bowei)	0x000105	NCS-IF105	0x0001	1	1
Microcyber Inc. (Shenyang Bowei)	0x000105	NCS-FI105	0x0002	1	1
Microcyber Inc. (Shenyang Bowei)	0x000105	NCS-FI105	0x0002	2	2
Microcyber Inc. (Shenyang Bowei)	0x000105	NCS-PT105	0x0003	2	2
Moore Industries-International; Inc.	0x0007b0	TFZ	0x0001	1	1
MORGAN KOREA LTD.	0x000106	MK-FF-H1	0x0001	1	1
MTL Instruments	0x0be0ec	F809F	0x0001	1	1
MTL Instruments	0x0be0ec	F809F	0x0001	1	2
MTL Instruments	0x0be0ec	F809F	0x0001	2	1
MTL Instruments	0x0be0ec	9331-T1	0x9331	1	1
MTS System Corporation; Sensor Division	0x0bde31	MTS_LEVELPLUS_MG	0x0001	1	1
National Instruments	0x4e4943	FP-3000	0x4005	3	1
Ohmart / VEGA	0x000457	GEN2000	0x0003	1	1
Ohmart / VEGA	0x000457	GEN2000	0x0003	3	1
Ohmart / VEGA	0x000457	GEN2000	0x0003	3	2
Ohmart / VEGA	0x000457	GEN2000 Density	0x0004	3	2
Oval Corporation	0x00043e	EX-DELTA	0x0065	1	1
Oval Corporation	0x00043e	EX-DELTA	0x0065	1	2

# Device Xpert FF V1.01.00 - DD Library List

Status dated 2012.08.07

R01

Foundation Fieldbus DDs for Language:

EN

Manufacturer Name	Manufacturer ID	Device Type	Device ID	Dev Revision	DD Revision
Oval Corporation	0x00043e	EX-DELTA	0x0065	2	1
Oval Corporation	0x00043e	EX-DELTA	0x0075	1	1
Oval Corporation	0x00043e	CT9401	0x24b9	1	1
Oval Corporation	0x00043e	CT9401	0x24b9	2	1
Pepperl+Fuchs GmbH	0x502b46	FD0-VC-Ex4.FF	0x0001	1	1
Pepperl+Fuchs GmbH	0x502b46	FD0-VC-Ex4.FF	0x0001	2	1
Pepperl+Fuchs GmbH	0x502b46	FD0-VC-Ex4.FF	0x0001	2	2
Pepperl+Fuchs GmbH	0x502b46	F2D0-TI-Ex8.FF	0x0003	1	1
Pepperl+Fuchs GmbH	0x502b46	F2D0-TI-Ex8.FF	0x0003	1	5
Pepperl+Fuchs GmbH	0x502b46	F2D0-TI-Ex8.FF	0x0003	1	7
Pepperl+Fuchs GmbH	0x502b46	LB 8110 - FB 8210	0x8010	1	1
Pepperl+Fuchs GmbH	0x502b46	LB 8110 - FB 8210	0x8010	2	1
PR Electronics	0x0007d0	PRetop 5350	0x0080	1	1
PR Electronics	0x0007d0	PRetop 5350	0x0080	2	1
PR Electronics	0x0007d0	PRetrans 6350	0x0081	1	1
PR Electronics	0x0007d0	PRetrans 6350	0x0081	1	2
R. Stahl Schaltgerate GmbH	0x0001f4	9413 (4-wire version)	0x24c5	1	1
R. Stahl Schaltgerate GmbH	0x0001f4	9413 (4-wire version)	0x24c5	3	1
Ronan Engineering	0x31ff52	Density Gage	0x0001	1	1
Ronan Engineering	0x31ff52	X96S Standard Level	0x0002	1	1
Ronan Engineering	0x31ff52	X96S Weight Scale	0x0003	1	1
Ronan Engineering	0x31ff52	X96SSLVDC Gage	0x0004	1	1
Ronan Engineering	0x31ff52	X96S Mass Flow	0x0005	1	1
Rotork Controls Ltd	0x00ff01	FF01	0x0001	2	1
Rotork Controls Ltd	0x00ff01	Actuator	0x0002	1	1
Rotork Controls Ltd	0x00ff01	Actuator	0x0002	1	2
Rotork Controls Ltd	0x00ff01	Actuator	0x0002	2	1
SAMSON AG	0x00e099	Positioner 3787	0x0001	2	1
SAMSON AG	0x00e099	373x-5	0x0002	1	1
SAMSON AG	0x00e099	373x-5	0x0002	2	1
Shanghai Automation Instrumentation Co.; Ltd. (SAIC)	0x000109	3151F	0x0001	1	1
Shanghai Welltech Automation Co.; Ltd.	0x005754	WT-XE4000	0x0016	1	1
Siemens AG	0x534147	SITRANS P DSIII FF and SITRANS P300 FF	0x000b	1	1
Siemens AG	0x534147	SIPART PS2 FF	0x0015	1	1
Siemens AG	0x534147	SIPART PS2 FF	0x0015	2	1
Siemens AG	0x534147	SITRANS F M MAG6000	0x0018	1	1
Siemens AG	0x534147	SITRANS F C MASS6000	0x0019	1	1
Siemens AG	0x534147	TH400	0x8157	1	1
Smar International Co.	0x000302	LD302	0x0001	4	1
Smar International Co.	0x000302	LD302	0x0001	4	7
Smar International Co.	0x000302	TT302	0x0002	4	1
Smar International Co.	0x000302	TT302	0x0002	4	2
Smar International Co.	0x000302	IF302	0x0003	4	1
Smar International Co.	0x000302	IF302	0x0003	4	7
Smar International Co.	0x000302	FP302	0x0004	4	1
Smar International Co.	0x000302	FP302	0x0004	4	7
Smar International Co.	0x000302	FI302	0x0005	4	1
Smar International Co.	0x000302	FI302	0x0005	4	7
Smar International Co.	0x000302	FY302	0x0006	4	1
Smar International Co.	0x000302	FY302	0x0006	4	7
Smar International Co.	0x000302	FB700	0x0009	4	1
Smar International Co.	0x000302	FB700	0x0009	4	7
Smar International Co.	0x000302	LD292	0x000d	4	7
Smar International Co.	0x000302	DT302	0x000e	7	1
Smar International Co.	0x000302	HI302-I 8AI+8HART	0x0015	5	1
Smar International Co.	0x000302	HI302-O 8AO+8HART	0x0016	5	1
Smar International Co.	0x000302	HI302-N 8HART	0x0017	5	1
Softing AG	0x1e6d11	Foundation Fieldbus H1 / Modbus/TCP Gateway	0x7c00	1	1
Spirax Sarco S.R.L.	0x00f302	SP302	0x0006	7	1
StoneL Corporation	0x005774	93/94 VCT	0x0051	1	1
StoneL Corporation	0x005774	93/94 VCT	0x0051	2	1
StoneL Corporation	0x005774	VCT / I/O Module (2DI; 2DO)	0x0052	1	1
StoneL Corporation	0x005774	VCT / I/O Module (2DI; 2DO)	0x0052	2	1
StoneL Corporation	0x005774	I/O Module (2DI; 2DO; 1AI; 1AO)	0x00f2	1	1
StoneL Corporation	0x005774	I/O Module (2DI; 2DO; 1AI; 1AO)	0x00f2	2	1
Tefulong Group Co.; Ltd.	0x000188	AVA03	0x0001	1	1
TopWorx; Inc.	0x545758	SCM-FF	0x0100	1	1

# Device Xpert FF V1.01.00 - DD Library List

Status dated 2012.08.07

R01

Foundation Fieldbus DDs for Language:

EN

Manufacturer Name	Manufacturer ID	Device Type	Device ID	Dev Revision	DD Revision
TopWorx; Inc.	0x545758	SCM-FF	0x0100	2	3
TURCK	0x000111	KMU40-EX	0xff9c	1	1
Tyco Valves & Controls	0x575353	AVID ZR-F	0x0001	3	2
Tyco Valves & Controls	0x575353	AVID SmartCal FF	0x1100	2	1
VEGA Grieshaber KG	0x56474b	VEGACAL	0x076e	1	1
VEGA Grieshaber KG	0x56474b	VEGACAL	0x076e	3	1
VEGA Grieshaber KG	0x56474b	VEGACAL	0x076e	4	1
VEGA Grieshaber KG	0x56474b	VEGABAR	0x076f	1	1
VEGA Grieshaber KG	0x56474b	VEGABAR	0x076f	3	1
VEGA Grieshaber KG	0x56474b	VEGABAR	0x076f	4	1
VEGA Grieshaber KG	0x56474b	VEGASON	0x0770	1	1
VEGA Grieshaber KG	0x56474b	VEGASON	0x0770	3	1
VEGA Grieshaber KG	0x56474b	VEGASON	0x0770	4	1
VEGA Grieshaber KG	0x56474b	VEGAFLEX	0x0771	1	1
VEGA Grieshaber KG	0x56474b	VEGAFLEX	0x0771	3	1
VEGA Grieshaber KG	0x56474b	VEGAFLEX	0x0771	4	1
VEGA Grieshaber KG	0x56474b	VEGAPULS	0x0772	1	1
VEGA Grieshaber KG	0x56474b	VEGAPULS	0x0772	3	1
VEGA Grieshaber KG	0x56474b	VEGAPULS	0x0772	4	1
VEGA Grieshaber KG	0x56474b	VEGADIF	0x0bfb	4	1
Westlock Controls	0x574343	EL40106	0x0001	1	1
Westlock Controls	0x574343	EL40106	0x0001	3	1
Westlock Controls	0x574343	FF-EPIC	0x0002	1	1
Westlock Controls	0x574343	FPAC-ESD	0x0003	1	1
Westlock Controls	0x574343	FF EPIC ESD	0x0004	1	1
Westlock Controls	0x574343	Icon 2000	0x0100	1	1
Westlock Controls	0x574343	Icon 2000	0x0100	2	1
Westlock Controls	0x574343	FF_EPI	0x0200	1	1
Westlock Controls	0x574343	Intellis ICot FF	0x1100	1	1
Westlock Controls	0x574343	Intellis ICot FF	0x1100	2	1
WIKA Alexander Wiegand SE & Co. KG.	0x0006b0	IPT-1x-4	0x00ec	3	1
WIKA Alexander Wiegand SE & Co. KG.	0x0006b0	T53.10	0x5310	1	1
Yamatake Corporation	0x0dfc96	MagneW	0x0001	2	1
Yamatake Corporation	0x0dfc96	ST3000 S900	0x0103	1	1
Yamatake Corporation	0x0dfc96	ST3000 S900	0x0103	1	3
Yamatake Corporation	0x0dfc96	SVP3000 AVP203/AVP303	0x0203	1	1
Yamatake Corporation	0x0dfc96	SVP3000 AVP203/AVP303	0x0203	2	1
Yamatake Corporation	0x0dfc96	DSTJ	0x0401	1	1
Yamatake Corporation	0x0dfc96	MagneWHENRI	0x0c01	1	1
Yamatake Corporation	0x0dfc96	SVP3000 AVP204/AVP304	0x1101	2	1
Yamatake Corporation	0x0dfc96	DSTJ 3000 NewAce	0x1203	1	4
Yamatake Corporation	0x0dfc96	SLD	0x2001	1	1
Yokogawa Electric Corporation	0x594543	YVP	0x0001	3	1
Yokogawa Electric Corporation	0x594543	YVP	0x0001	3	3
Yokogawa Electric Corporation	0x594543	YVP	0x0001	3	6
Yokogawa Electric Corporation	0x594543	YVP	0x0001	4	1
Yokogawa Electric Corporation	0x594543	EJA	0x0003	2	2
Yokogawa Electric Corporation	0x594543	EJA	0x0003	2	5
Yokogawa Electric Corporation	0x594543	YTA-320	0x0005	2	3
Yokogawa Electric Corporation	0x594543	YTA-320	0x0005	3	1
Yokogawa Electric Corporation	0x594543	digital YEWFLOW	0x0006	1	2
Yokogawa Electric Corporation	0x594543	digital YEWFLOW	0x0006	1	4
Yokogawa Electric Corporation	0x594543	YVP (Software Download)	0x0007	1	1
Yokogawa Electric Corporation	0x594543	YVP (Software Download)	0x0007	1	5
Yokogawa Electric Corporation	0x594543	YVP (Software Download)	0x0007	2	1
Yokogawa Electric Corporation	0x594543	YVP (Software Download)	0x0007	2	2
Yokogawa Electric Corporation	0x594543	YVP (Software Download)	0x0007	3	1
Yokogawa Electric Corporation	0x594543	EJA (Software Download)	0x0008	1	1
Yokogawa Electric Corporation	0x594543	EJA (Software Download)	0x0008	1	5
Yokogawa Electric Corporation	0x594543	Digital YEWFLOW - Software Download	0x0009	1	1
Yokogawa Electric Corporation	0x594543	Digital YEWFLOW - Software Download	0x0009	2	1
Yokogawa Electric Corporation	0x594543	YPK	0x000a	1	1
Yokogawa Electric Corporation	0x594543	YPK	0x000a	1	5
Yokogawa Electric Corporation	0x594543	ADMAG AXF	0x000b	1	1
Yokogawa Electric Corporation	0x594543	ADMAG AXF	0x000b	1	2
Yokogawa Electric Corporation	0x594543	EJX	0x000c	1	1
Yokogawa Electric Corporation	0x594543	EJX	0x000c	2	2



# Device Xpert FF V1.01.00 - DD Library List

Status dated 2012.08.07

R01

Foundation Fieldbus DDs for Language:

EN

Manufacturer Name	Manufacturer ID	Device Type	Device ID	Dev Revision	DD Revision
Yokogawa Electric Corporation	0x594543	EJX	0x000c	3	1
Yokogawa Electric Corporation	0x594543	EJX	0x000c	3	2
Yokogawa Electric Corporation	0x594543	EJX	0x000c	3	3
Yokogawa Electric Corporation	0x594543	ROTAMASS / RCCT3	0x000d	1	1
Yokogawa Electric Corporation	0x594543	ROTAMASS / RCCT3	0x000d	1	2
Yokogawa Electric Corporation	0x594543	ROTAMASS / RCCT3	0x000d	2	1
Yokogawa Electric Corporation	0x594543	EJX910	0x000e	1	1
Yokogawa Electric Corporation	0x594543	EJX910	0x000e	1	2
Yokogawa Electric Corporation	0x594543	EJX910	0x000e	2	1
Yokogawa Electric Corporation	0x594543	AV550G	0x0401	1	1
Yokogawa Electric Corporation	0x594543	EXA PH202	0x0830	1	1
Yokogawa Electric Corporation	0x594543	EXA PH202	0x0830	2	1
Yokogawa Electric Corporation	0x594543	EXA PH202	0x0830	3	1
Yokogawa Electric Corporation	0x594543	EXA SC202	0x0831	1	1
Yokogawa Electric Corporation	0x594543	EXA SC202	0x0831	2	1
Yokogawa Electric Corporation	0x594543	EXA SC202	0x0831	3	1
Yokogawa Electric Corporation	0x594543	EXA ISC202	0x0832	1	1
Yokogawa Electric Corporation	0x594543	EXA ISC202	0x0832	2	1
Yokogawa Electric Corporation	0x594543	EXA ISC202	0x0832	3	1
Yokogawa Electric Corporation	0x594543	EXA DO202	0x0833	1	1
Yokogawa Electric Corporation	0x594543	EXA DO202	0x0833	3	1
Yokogawa Electric Corporation	0x594543	YTA80	0x0900	1	1