## Technical Information **Proline Promag W 300**

Electromagnetic flowmeter



## Specialist for demanding water and wastewater applications with a compact, easily accessible transmitter

#### Application

- The bidirectional measuring principle is virtually independent of pressure, density, temperature and viscosity
- Dedicated to the measurement of industrial or municipal water and wastewater

#### Device properties

- International drinking water approvals
- Compact dual-compartment housing with up to 3 I/Os
- Backlit display with touch control and WLAN access
- Remote display available

#### Ihre Vorteile

- Reliable measurement at constant accuracy with 0 x DN inlet run and no pressure loss
- Flexible engineering sensor with fixed or lap-joint process connections
- Long-term operation robust and completely welded sensor
- Improved plant availability sensor compliant with industry-specific requirements
- Full access to process and diagnostic information numerous, freely combinable I/Os and fieldbuses
- Reduced complexity and variety freely configurable I/O functionality
- Integrated verification Heartbeat Technology



## Table of contents

About this document		Electromagnetic compatibility (EMC)	55
		Process	55
Function and system design		Medium temperature range	
		Conductivity	
Measuring system		Pressure-temperature ratings	56
Equipment architecture		Pressure tightness	59
Safety		Flow limit	60
Safety		Pressure loss	60
		System pressure	61
Input			
Measured variable	0	Thermal insulation	61
Measuring range	9	Vibrations	61
Operable flow range			
Input signal		Mechanical construction	62
p ut 0.1g 1		Dimensions in SI units	62
	_	Dimensions in US units	
<b>T</b>	ן כו	Weight	
Output and input variants		Measuring tube specification	
Output signal		Materials	
Signal on alarm		Fitted electrodes	
Ex connection data	<i>) /</i> 1	Process connections	
	) L		
	25	Surface roughness	91
Protocol-specific data	26		
· · · · · · · · · · · · · · · · · · ·		Human interface	92
<b>.</b>		Operating concept	92
	ът	Languages	
Terminal assignment	21	Local operation	
Device plugs available		Remote operation	
Supply voltage	33	Service interface	99
Power consumption		Network integration	
Current consumption			101
		11 1 3	
	33	HistoROM data management	102
	43		
	45	Certificates and approvals	104
		CE mark	104
Pin assignment, device plug		RCM-tick symbol	
Cable specification	- 1		104
Cable specification		Drinking water approval	
		HART certification	
Performance characteristics 4			105
Reference operating conditions			105
Maximum measured error	iu i		105
Repeatability	-//		
			105
1		T.F.	105
T . 13		Other standards and guidelines	105
	51		
Mounting location		Ordering information	106
	52		
	53		
Adapters			106
	54	Diagnostics functions	106
- -			107
Furringument			107
	94		107
g	04		
	55	A	10-
3 1	-		107
		Device-specific accessories	
Mechanical load	55	Communication-specific accessories	108
	•		

Service-specific accessories	
System components	109
Supplementary documentation	110
Standard documentation	110
Device-dependent additional documentation	110
Registered trademarks	111

## About this document

#### Symbols Electrical symbols

Symbol	Meaning
	Direct current
~	Alternating current
$\overline{\sim}$	Direct current and alternating current
≐	Ground connection A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.
	Protective Earth (PE) A terminal which must be connected to ground prior to establishing any other connections.
	The ground terminals are situated inside and outside the device:  Inner ground terminal: Connects the protectiv earth to the mains supply.  Outer ground terminal: Connects the device to the plant grounding system.

#### Communication symbols

Symbol	Meaning
<b></b>	Wireless Local Area Network (WLAN) Communication via a wireless, local network.
•	LED Light emitting diode is off.
	LED Light emitting diode is on.
	LED Light emitting diode is flashing.

#### $Symbols \ for \ certain \ types \ of \ information$

Symbol	Meaning
<b>✓</b>	Permitted Procedures, processes or actions that are permitted.
	Preferred Procedures, processes or actions that are preferred.
X	Forbidden Procedures, processes or actions that are forbidden.
i	Tip Indicates additional information.
Ţ <u>i</u>	Reference to documentation.
A=	Reference to page.
	Reference to graphic.
	Visual inspection.


#### Symbols in graphics

Symbol	Meaning
1, 2, 3,	Item numbers
1., 2., 3.,	Series of steps
A, B, C,	Views
A-A, B-B, C-C,	Sections
EX	Hazardous area
×	Safe area (non-hazardous area)
≋➡	Flow direction

### Function and system design

#### Measuring principle

Following *Faraday's law of magnetic induction*, a voltage is induced in a conductor moving through a magnetic field.



A002896

- Ue Induced voltage
- B Magnetic induction (magnetic field)
- L Electrode spacing
- I Current
- v Flow velocity

In the electromagnetic measuring principle, the flowing medium is the moving conductor. The voltage induced  $(U_e)$  is proportional to the flow velocity (v) and is supplied to the amplifier by means of two measuring electrodes. The flow volume (Q) is calculated via the pipe cross-section (A). The DC magnetic field is created through a switched direct current of alternating polarity.

#### Formulae for calculation

- Induced voltage  $U_e = B \cdot L \cdot v$
- Volume flow  $Q = A \cdot v$

#### Measuring system

The device consists of a transmitter and a sensor.

The device is available as a compact version:

The transmitter and sensor form a mechanical unit.

A0026708

#### Transmitter

# Proline 300


Device versions and materials:

- Transmitter housing
- Aluminum, coated: aluminum, AlSi10Mg, coated
- Material of window in transmitter housing: Aluminum, coated: glass


#### Configuration:

- External operation via 4-line, backlit, graphic local display with touch control and guided menus ("Make-it-run" wizards) for applicationspecific commissioning.
- Via service interface or WLAN interface:
  - Operating tools (e.g. FieldCare, DeviceCare)
  - Web server (access via Web browser, e.g. Microsoft Internet Explorer, Microsoft Edge)

#### Sensor



#### Equipment architecture



 $\blacksquare$  1 Possibilities for integrating measuring devices into a system

- 1 Control system (e.g. PLC)
- 2 Connecting cable (0/4 to 20 mA HART etc.)
- 3 Fieldbus
- 4 Coupler
- 5 Non-hazardous area
- 6 Hazardous area: Zone 2; Class I, Division 2
- 7 Hazardous area: Zone 1; Class I, Division 1

#### Safety

#### IT security

Our warranty is valid only if the device is installed and used as described in the Operating Instructions. The device is equipped with security mechanisms to protect it against any inadvertent changes to the settings.

IT security measures, which provide additional protection for the device and associated data transfer, must be implemented by the operators themselves in line with their security standards.

#### **Device-specific IT security**

The device offers a range of specific functions to support protective measures on the operator's side. These functions can be configured by the user and guarantee greater in-operation safety if used correctly. An overview of the most important functions is provided in the following section.

Function/interface	Factory setting	Recommendation
Write protection via hardware write protection switch $\Rightarrow \triangleq 8$	Not enabled.	On an individual basis following risk assessment.
Access code (also applies for Web server login or FieldCare connection) → 🖺 8	Not enabled (0000).	Assign a customized access code during commissioning.
WLAN (order option in display module)	Enabled.	On an individual basis following risk assessment.
WLAN security mode	Enabled (WPA2- PSK)	Do not change.
WLAN passphrase (password) → 🖺 8	Serial number	Assign an individual WLAN passphrase during commissioning.
WLAN mode	Access Point	On an individual basis following risk assessment.
Web server→ 🖺 8	Enabled.	On an individual basis following risk assessment.
CDI-RJ45 service interface → 🖺 9	-	On an individual basis following risk assessment.

Protecting access via hardware write protection

Write access to the device parameters via the local display, Web browser or operating tool (e.g. FieldCare, DeviceCare) can be disabled via a write protection switch (DIP switch on the motherboard). When hardware write protection is enabled, only read access to the parameters is possible.

Hardware write protection is disabled when the device is delivered.

#### Protecting access via a password

Different passwords are available to protect write access to the device parameters or access to the device via the WLAN interface.

- User-specific access code
  - Protect write access to the device parameters via the local display, Web browser or operating tool (e.g. FieldCare, DeviceCare). Access authorization is clearly regulated through the use of a user-specific access code.
- WLAN passphrase
  - The network key protects a connection between an operating unit (e.g. notebook or tablet) and the device via the WLAN interface which can be ordered as an option.
- Infrastructure mode
  - When the device is operated in infrastructure mode, the WLAN passphrase corresponds to the WLAN passphrase configured on the operator side.

User-specific access code

Write access to the device parameters via the local display, Web browser or operating tool (e.g. FieldCare, DeviceCare) can be protected by the modifiable, user-specific access code.

WLAN passphrase: Operation as WLAN access point

A connection between an operating unit (e.g. notebook or tablet) and the device via the WLAN interface, which can be ordered as an optional extra, is protected by the network key. The WLAN authentication of the network key complies with the IEEE 802.11 standard.

When the device is delivered, the network key is pre-defined depending on the device. It can be changed via the **WLAN settings** submenu in the **WLAN passphrase** parameter.

Infrastructure mode

A connection between the device and WLAN access point is protected by means of an SSID and passphrase on the system side. Please contact the relevant system administrator for access.

General notes on the use of passwords

- The access code and network key supplied with the device should be changed during commissioning.
- Follow the general rules for generating a secure password when defining and managing the access code or network key.
- The user is responsible for the management and careful handling of the access code and network key.

#### Access via Web server

The device can be operated and configured via a Web browser with the integrated Web server. The connection is via the service interface (CDI-RJ45) or the WLAN interface. For device versions with the EtherNet/IP and PROFINET communication protocols, the connection can also be established via the terminal connection for signal transmission with EtherNet/IP or PROFINET (RJ45 connector).

The Web server is enabled when the device is delivered. The Web server can be disabled if necessary (e.g. after commissioning) via the **Web server functionality** parameter.

The device and status information can be hidden on the login page. This prevents unauthorized access to the information.

Access via OPC-UA



The "OPC UA Server" application package is available in the device version with the HART communication protocol  $\rightarrow \blacksquare 107$ .

The device can communicate with OPC UA clients using the "OPC UA Server" application package.

The OPC UA server integrated in the device can be accessed via the WLAN access point using the WLAN interface - which can be ordered as an optional extra - or the service interface (CDI- RJ45) via Ethernet network. Access rights and authorization as per separate configuration.

The following Security Modes are supported as per the OPC UA Specification (IEC 62541):

- None
- Basic128Rsa15 signed
- Basic128Rsa15 signed and encrypted

Access via service interface (CDI-RJ45)

The device can be connected to a network via the service interface (CDI-RJ45). Device-specific functions quarantee the secure operation of the device in a network.

The use of relevant industrial standards and guidelines that have been defined by national and international safety committees, such as IEC/ISA62443 or the IEEE, is recommended. This includes organizational security measures such as the assignment of access authorization as well as technical measures such as network segmentation.

- Transmitters with an Ex de approval may not be connected via the service interface (CDI-RJ45)!

  Order code for "Approval transmitter + sensor", options (Ex de): BA, BB, C1, C2, GA, GB, MA, MB, NA, NB
- The device can be integrated in a ring topology. The device is integrated via the terminal connection for signal transmission (output 1) and the connection to the service interface (CDI-RI45).

#### Input

#### Measured variable

#### Direct measured variables

- Volume flow (proportional to induced voltage)
- Electrical conductivity

#### Calculated measured variables

Mass flow

#### Measuring range

Typically v = 0.01 to 10 m/s (0.03 to 33 ft/s) with the specified accuracy

Electrical conductivity:  $\geq 5 \mu S/cm$  for liquids in general

Flow characteristic values in SI units: DN 25 to 125 (1 to 4")

Nominal	diameter	Recommended flow	Factory settings			
		min./max. full scale value (v ~ 0.3/10 m/s)	Full scale value current output (v ~ 2.5 m/s)  Pulse value (~ 2 pulse/s)		Low flow cut off (v ~ 0.04 m/s)	
[mm]	[in]	[dm³/min]	[dm³/min]	[dm³]	[dm³/min]	
25	1	9 to 300	75	0.5	1	
32	-	15 to 500	125	1	2	
40	1 ½	25 to 700	200	1.5	3	
50	2	35 to 1100	300	2.5	5	
65	-	60 to 2 000	500	5	8	
80	3	90 to 3 000	750	5	12	
100	4	145 to 4700	1200	10	20	
125	-	220 to 7500	1850	15	30	

Flow characteristic values in SI units: DN 150 to 2400 (6 to 90")

Nominal diameter		Recommended flow	Factory settings		
		min./max. full scale value (v ~ 0.3/10 m/s)	Full scale value current output (v ~ 2.5 m/s)	Pulse value (~ 2 pulse/s)	Low flow cut off (v ~ 0.04 m/s)
[mm]	[in]	[m³/h]	[m <sup>3</sup> /h]	[m³]	[m <sup>3</sup> /h]
150	6	20 to 600	150	0.025	2.5
200	8	35 to 1100	300	0.05	5
250	10	55 to 1700	500	0.05	7.5
300	12	80 to 2 400	750	0.1	10
350	14	110 to 3 300	1000	0.1	15
375	15	140 to 4200	1200	0.15	20
400	16	140 to 4200	1200	0.15	20
450	18	180 to 5 400	1500	0.25	25
500	20	220 to 6600	2000	0.25	30
600	24	310 to 9600	2500	0.3	40
700	28	420 to 13500	3500	0.5	50
750	30	480 to 15 000	4000	0.5	60
800	32	550 to 18000	4500	0.75	75
900	36	690 to 22 500	6000	0.75	100
1000	40	850 to 28000	7000	1	125
-	42	950 to 30 000	8000	1	125
1200	48	1250 to 40 000	10000	1.5	150
-	54	1550 to 50 000	13000	1.5	200
1400	-	1700 to 55 000	14000	2	225
-	60	1950 to 60 000	16000	2	250
1600	-	2 200 to 70 000	18000	2.5	300
-	66	2 500 to 80 000	20500	2.5	325
1800	72	2 800 to 90 000	23000	3	350
-	78	3 300 to 100 000	28500	3.5	450
2000	-	3 400 to 110 000	28500	3.5	450
-	84	3 700 to 125 000	31000	4.5	500
2200	-	4 100 to 136 000	34000	4.5	540
-	90	4300 to 143000	36000	5	570
2400	-	4800 to 162 000	40000	5.5	650

Flow characteristic values in SI units: DN 50 to 300 (2 to 12") for order code for "Design", option C "Fixed flange, without inlet/outlet runs"

	ninal neter	Recommended flow	Factory settings		
		min./max. full scale value (v ~ 0.12/5 m/s)	Full scale value current output (v ~ 2.5 m/s)	Pulse value (~ 4 pulse/s)	Low flow cut off (v ~ 0.01 m/s)
[mm]	[in]	[m³/h]	[m <sup>3</sup> /h]	[m³]	[m <sup>3</sup> /h]
50	2	15 to 600 dm <sup>3</sup> /min	300 dm <sup>3</sup> /min	1.25 dm <sup>3</sup>	1.25 dm <sup>3</sup> /min
65	-	25 to 1000 dm <sup>3</sup> /min	500 dm <sup>3</sup> /min	2 dm <sup>3</sup>	2 dm³/min
80	3	35 to 1500 dm <sup>3</sup> /min	750 dm <sup>3</sup> /min	3 dm <sup>3</sup>	3.25 dm <sup>3</sup> /min
100	4	60 to 2 400 dm <sup>3</sup> /min	1200 dm <sup>3</sup> /min	5 dm <sup>3</sup>	4.75 dm <sup>3</sup> /min
125	-	90 to 3700 dm <sup>3</sup> /min	1850 dm <sup>3</sup> /min	8 dm <sup>3</sup>	7.5 dm <sup>3</sup> /min
150	6	145 to 5 400 dm <sup>3</sup> /min	2500 dm <sup>3</sup> /min	10 dm <sup>3</sup>	11 dm³/min
200	8	220 to 9 400 dm <sup>3</sup> /min	5000 dm <sup>3</sup> /min	20 dm <sup>3</sup>	19 dm <sup>3</sup> /min
250	10	20 to 850	500	0.03	1.75
300	12	35 to 1300	750	0.05	2.75

#### Flow characteristic values in US units: 1 to 48" (DN 25 to 1200)

Nominal	diameter	Recommended flow	Factory settings		
		min./max. full scale value (v ~ 0.3/10 m/s)	Full scale value current output (~ 2 pulse/s)		Low flow cut off (v ~ 0.04 m/s)
[in]	[mm]	[gal/min]	[gal/min]	[gal]	[gal/min]
1	25	2.5 to 80	18	0.2	0.25
_	32	4 to 130	30	0.2	0.5
1 ½	40	7 to 185	50	0.5	0.75
2	50	10 to 300	75	0.5	1.25
-	65	16 to 500	130	1	2
3	80	24 to 800	200	2	2.5
4	100	40 to 1250	300	2	4
_	125	60 to 1950	450	5	7
6	150	90 to 2 650	600	5	12
8	200	155 to 4850	1200	10	15
10	250	250 to 7500	1500	15	30
12	300	350 to 10600	2400	25	45
14	350	500 to 15000	3600	30	60
15	375	600 to 19000	4800	50	60
16	400	600 to 19000	4800	50	60
18	450	800 to 24000	6000	50	90
20	500	1000 to 30000	7500	75	120
24	600	1400 to 44000	10500	100	180
28	700	1900 to 60000	13500	125	210
30	750	2 150 to 67 000	16500	150	270
32	800	2 450 to 80 000	19500	200	300

Nominal	diameter	Recommended flow	Factory settings			
		min./max. full scale value (v ~ 0.3/10 m/s)	Full scale value current output (v ~ 2.5 m/s)  Pulse value (~ 2 pulse/s)		Low flow cut off (v ~ 0.04 m/s)	
[in]	[mm]	[gal/min]	[gal/min]	[gal]	[gal/min]	
36	900	3 100 to 100 000	24000	225	360	
40	1000	3 800 to 125 000	30000	250	480	
42	_	4 200 to 135 000	33000	250	600	
48	1200	5 500 to 175 000	42000	400	600	

Flow characteristic values in US units: 54 to 90" (DN 1400 to 2400)

Nominal	diameter	Recommended flow	Factory settings					
		min./max. full scale value (v ~ 0.3/10 m/s)	Full scale value current output (v ~ 2.5 m/s)	Pulse value (~ 2 pulse/s)	Low flow cut off (v ~ 0.04 m/s)			
[in]	[mm]	[Mgal/d]	[Mgal/d]	[Mgal]	[Mgal/d]			
54	-	9 to 300	75	0.0005	1.3			
-	1400	10 to 340	85	0.0005	1.3			
60	-	12 to 380	95	0.0005	1.3			
-	1600	13 to 450	110	0.0008	1.7			
66	-	14 to 500	120	0.0008	2.2			
72	1800	16 to 570	140	0.0008	2.6			
78	-	18 to 650	175	0.0010	3.0			
-	2000	20 to 700	175	0.0010	2.9			
84	-	24 to 800	190	0.0011	3.2			
-	2200	26 to 870	210	0.0012	3.4			
90	-	27 to 910	220	0.0013	3.6			
-	2400	31 to 1030	245	0.0014	4.1			

Flow characteristic values in US units: 2 to 12" (DN 50 to 300) for order code for "Design", option C "Fixed flange, without inlet/outlet runs"

	ninal neter	Recommended flow	Factory settings		
		min./max. full scale value (v ~ 0.12/5 m/s)	Full scale value current output (~ 4 pulse/s)		Low flow cut off (v ~ 0.01 m/s)
[in]	[mm]	[gal/min]	[gal/min]	[gal]	[gal/min]
2	50	4 to 160	75	0.3	0.35
-	65	7 to 260	130	0.5	0.6
3	80	10 to 400	200	0.8	0.8
4	100	16 to 650	300	1.2	1.25
-	125	24 to 1000	450	1.8	2
6	150	40 to 1400	600	2.5	3
8	200	60 to 2 500	1200	5	5

Nominal diameter		Recommended flow	Factory settings				
		min./max. full scale value (v ~ 0.12/5 m/s)	Full scale value current output (v ~ 2.5 m/s)	Pulse value (~ 4 pulse/s)	Low flow cut off (v ~ 0.01 m/s)		
[in]	[mm]	[gal/min]	[gal/min]	[gal]	[gal/min]		
10	250	90 to 3 700	1500	6	8		
12	300	155 to 5700	2 400	9	12		

#### Recommended measuring range



Flow limit  $\rightarrow \triangleq 60$ 

#### Operable flow range

Over 1000:1

#### Input signal


#### Input and output versions

→ 🖺 15

#### External measured values

To increase the accuracy of certain measured variables or to calculate the mass flow, the automation system can continuously write different measured values to the measuring device:

- Medium temperature enables temperature-compensated conductivity measurement (e.g. iTEMP)
- Reference density for calculating the mass flow



It is recommended to read in external measured values to calculate the corrected volume flow.

#### HART protocol

The measured values are written from the automation system to the measuring device via the HART protocol. The pressure transmitter must support the following protocol-specific functions:

- HART protocol
- Burst mode

#### Current input

#### Digital communication

The measured values can be written from the automation system to the measuring via:

- FOUNDATION Fieldbus
- PROFIBUS DP
- PROFIBUS PA
- Modbus RS485
- EtherNet/IP
- PROFINET

#### Current input 0/4 to 20 mA

Current input	0/4 to 20 mA (active/passive)
Current span	<ul> <li>4 to 20 mA (active)</li> <li>0/4 to 20 mA (passive)</li> </ul>
Resolution	1 μΑ
Voltage drop	Typically: 0.6 to 2 V for 3.6 to 22 mA (passive)
Maximum input voltage	≤ 30 V (passive)

Open-circuit voltage	≤ 28.8 V (active)
Possible input variables	<ul><li>Temperature</li><li>Density</li></ul>

#### Status input

Maximum input values	■ DC $-3$ to 30 V ■ If status input is active (ON): $R_i > 3 \text{ k}\Omega$
Response time	Configurable: 5 to 200 ms
Input signal level	<ul> <li>Low signal: DC -3 to +5 V</li> <li>High signal: DC 12 to 30 V</li> </ul>
Assignable functions	<ul> <li>Off</li> <li>Reset the individual totalizers separately</li> <li>Reset all totalizers</li> <li>Flow override</li> </ul>

## Output

#### Output and input variants

Depending on the option selected for output/input 1, different options are available for the other outputs and inputs. Only one option can be selected for each output/input 1 to 3. The following tables must be read vertically  $(\downarrow)$ .

Example: If the option BA "4-20 mA HART" was selected for output/input 1, one of the options A, B, D, E, F, H, I or J is available for output 2 and one of the options A, B, D, E, F, H, I or J is available for output 3.

#### Output/input 1 and options for output/input 2



Options for output/input 3

Order code for "Output; input 1" (020) →			Possible options										
Current output 4 to 20 mA HART	ВА												
Current output 4 to 20 mA HART Ex i passive	1	CA											
Current output 4 to 20 mA HART Ex i active		<b>4</b>	СС										
FOUNDATION Fieldbus			<b>4</b>	SA									
FOUNDATION Fieldbus Ex i				<b>4</b>	TA								
PROFIBUS DP					4	LA							
PROFIBUS PA						4	GA						
PROFIBUS PA Ex i							<b>\</b>	НА					
Modbus RS485								4	MA				
EtherNet/IP 2-port switch integrated									<b>\</b>	NA			
PROFINET 2-port switch integrated										<b>\</b>	RA		
Order code for "Output; input 2" (021) →	4	<b>\</b>	<b>\</b>	<b>\</b>	4	<b>\</b>	<b>\</b>	4	<b>\</b>	<b>\</b>	4		
Not assigned	Α	Α	Α	Α	Α	Α	Α	Α	Α	Α	Α		
Current output 4 to 20 mA	В			В		В	В		В	В	В		
Current output 4 to 20 mA Ex i passive		С	С		С			С					
User-configurable input/output <sup>1)</sup>	D			D		D	D		D	D	D		
Pulse/frequency/switch output	Е			Е		Е	Е		Е	Е	Е		
Double pulse output <sup>2)</sup>	F								F				
Pulse/frequency/switch output Ex i passive		G	G		G			G					
Relay output	Н			Н		Н	Н		Н	Н	Н		
Current input 0/4 to 20 mA	I			I		I	I		I	I	I		
Status input	J			J		J	J		J	J	J		

<sup>2)</sup> If double pulse output (F) is selected for output/input 2 (021), only the double pulse output (F) option is available for selection for output/input 3 (022).

#### Output/input 1 and options for output/input 3 $\,$

Options for output/input  $2 \rightarrow \stackrel{\triangle}{=} 15$ 

Order code for "Output; input 1" (020) →			Possible options										
Current output 4 to 20 mA HART	BA												
Current output 4 to 20 mA HART Ex i passive	1	CA											
Current output 4 to 20 mA HART Ex i active		1	СС										
FOUNDATION Fieldbus			<b>\</b>	SA									
FOUNDATION Fieldbus Ex i				4	TA								
PROFIBUS DP					<b>\</b>	LA							
PROFIBUS PA						4	GA						
PROFIBUS PA Ex i							<b>4</b>	НА					
Modbus RS485								<b>\</b>	MA				
EtherNet/IP 2-port switch integrated									<b>\</b>	NA			
PROFINET 2-port switch integrated										4	RA		
Order code for "Output; input 3" (022) →	4	1	4	<b>4</b>	<b>\</b>	4	4	<b>\</b>	<b>\</b>	<b>\</b>	4		
Not assigned	A	A	Α	Α	Α	Α	Α	Α	Α	Α	Α		
Current output 4 to 20 mA	В					В			В	В	В		
Current output 4 to 20 mA Ex i passive		С	С										
User-configurable input/output	D					D			D	D	D		
Pulse/frequency/switch output	E					Е			Е	Е	Е		
Double pulse output (slave) 1)	F								F				
Pulse/frequency/switch output Ex i passive		G	G										
Relay output	Н					Н			Н	Н	Н		
Current input 0/4 to 20 mA	I					I			I	I	I		
Status input	J					J			J	J	J		

<sup>1)</sup> If double pulse output (F) is selected for output/input 2 (021), only the double pulse output (F) option is available for output/input 3 (022).

#### Output signal

#### Current output 4 to 20 mA HART

Order code	"Output; Input 1" (20): Option BA: current output 4 to 20 mA HART
Signal mode	Can be set to: Active Passive
Current range	Can be set to:  4 to 20 mA NAMUR  4 to 20 mA US  4 to 20 mA  0 to 20 mA (only with signal mode active)  Fixed current value
Open-circuit voltage	DC 28.8 V (active)
Maximum input voltage	DC 30 V (passive)
Load	250 to 700 Ω
Resolution	0.38 μΑ
Damping	Configurable: 0 to 999 s
Assignable measured variables	<ul> <li>Volume flow</li> <li>Mass flow</li> <li>Corrected volume flow</li> <li>Flow velocity</li> <li>Conductivity</li> <li>Electronics temperature</li> </ul>

#### Current output 4 to 20 mA HART Ex i

Order code	"Output; Input 1" (20) can be set to:  Option CA: current output 4 to 20 mA HART Ex i passive  Option CC: current output 4 to 20 mA HART Ex i active
Signal mode	Depending on the ordered variant.
Current range	Can be set to:  4 to 20 mA NAMUR  4 to 20 mA US  4 to 20 mA  0 to 20 mA (only with signal mode active)  Fixed current value
Open-circuit voltage	DC 21.8 V (active)
Maximum input voltage	DC 30 V (passive)
Load	<ul> <li>250 to 400 Ω (active)</li> <li>250 to 700 Ω (passive)</li> </ul>
Resolution	0.38 μΑ
Damping	Configurable: 0 to 999 s
Assignable measured variables	<ul> <li>Volume flow</li> <li>Mass flow</li> <li>Corrected volume flow</li> <li>Flow velocity</li> <li>Conductivity</li> <li>Electronics temperature</li> </ul>

#### FOUNDATION Fieldbus

FOUNDATION Fieldbus	H1, IEC 61158-2, galvanically isolated
Data transfer	31.25 kbit/s

Current consumption	10 mA
Permitted supply voltage	9 to 32 V
Bus connection	With integrated reverse polarity protection

#### PROFIBUS DP

Signal encoding	NRZ code
Data transfer	9.6 kBaud12 MBaud

#### PROFIBUS PA

PROFIBUS PA	In accordance with EN 50170 Volume 2, IEC 61158-2 (MBP), galvanically isolated
Data transmission	31.25 kbit/s
<b>Current consumption</b>	10 mA
Permitted supply voltage	9 to 32 V
Bus connection	With integrated reverse polarity protection

#### Modbus RS485

Physical interface	RS485 in accordance with EIA/TIA-485 standard
Terminating resistor	Integrated, can be activated via DIP switches

#### EtherNet/IP

Standards	In accordance with IEEE 802.3
-----------	-------------------------------

#### PROFINET

Standards	In accordance with IEEE 802.3
-----------	-------------------------------

#### Current output 4 to 20 mA $\,$

Order code	"Output; Input 2" (21), "Output; Input 3" (022): Option B: current output 4 to 20 mA
Signal mode	Can be set to: Active Passive
Current range	Can be set to:  4 to 20 mA NAMUR  4 to 20 mA US  4 to 20 mA  0 to 20 mA  richtical control of the second of the se
Maximum output values	22.5 mA
Open-circuit voltage	DC 28.8 V (active)
Maximum input voltage	DC 30 V (passive)
Load	$0$ to $700~\Omega$
Resolution	0.38 μΑ

Damping	Configurable: 0 to 999 s
Assignable measured variables	<ul> <li>Volume flow</li> <li>Mass flow</li> <li>Corrected volume flow</li> <li>Flow velocity</li> <li>Conductivity</li> <li>Electronics temperature</li> </ul>

#### Current output 4 to 20 mA Ex i passive

Order code	"Output; Input 2" (21), "Output; Input 3" (022): Option C: current output 4 to 20 mA Ex i passive
Signal mode	Passive
Current range	Can be set to:  4 to 20 mA NAMUR  4 to 20 mA US  4 to 20 mA  Fixed current value
Maximum output values	22.5 mA
Maximum input voltage	DC 30 V
Load	0 to 700 $\Omega$
Resolution	0.38 μΑ
Damping	Configurable: 0 to 999 s
Assignable measured variables	<ul> <li>Volume flow</li> <li>Mass flow</li> <li>Corrected volume flow</li> <li>Flow velocity</li> <li>Conductivity</li> <li>Electronics temperature</li> </ul>

#### Pulse/frequency/switch output

Function	Can be set to pulse, frequency or switch output
Version	Open collector
	Can be set to:
	■ Active
	Passive
	Passive NAMUR
	Ex-i, passive
Maximum input values	DC 30 V, 250 mA (passive)
Open-circuit voltage	DC 28.8 V (active)
Voltage drop	For 22.5 mA: ≤ DC 2 V
Pulse output	
Maximum input values	DC 30 V, 250 mA (passive)
Maximum output current	22.5 mA (active)
Open-circuit voltage	DC 28.8 V (active)
Pulse width	Configurable: 0.05 to 2 000 ms
Maximum pulse rate	10 000 Impulse/s
Pulse value	Adjustable
Assignable measured	■ Volume flow
variables	Mass flow
	Corrected volume flow

Frequency output	
Maximum input values	DC 30 V, 250 mA (passive)
Maximum output current	22.5 mA (active)
Open-circuit voltage	DC 28.8 V (active)
Output frequency	Adjustable: end value frequency 2 to $10000Hz$ (f $_{max}$ = $12500Hz$ )
Damping	Configurable: 0 to 999 s
Pulse/pause ratio	1:1
Assignable measured variables	<ul> <li>Volume flow</li> <li>Mass flow</li> <li>Corrected volume flow</li> <li>Flow velocity</li> <li>Conductivity</li> <li>Electronics temperature</li> </ul>
Switch output	
Maximum input values	DC 30 V, 250 mA (passive)
Open-circuit voltage	DC 28.8 V (active)
Switching behavior	Binary, conductive or non-conductive
Switching delay	Configurable: 0 to 100 s
Number of switching cycles	Unlimited
Assignable functions	<ul> <li>Off</li> <li>On</li> <li>Diagnostic behavior</li> <li>Limit value: <ul> <li>Off</li> <li>Volume flow</li> <li>Mass flow</li> <li>Corrected volume flow</li> <li>Flow velocity</li> <li>Conductivity</li> <li>Totalizer 1-3</li> <li>Electronics temperature</li> </ul> </li> <li>Flow direction monitoring</li> <li>Status</li> <li>Empty pipe detection</li> <li>Low flow cut off</li> </ul>

#### Double pulse output

Function	Double pulse
Version	Open collector
	Can be set to:  Active Passive Passive NAMUR
Maximum input values	DC 30 V, 250 mA (passive)
Open-circuit voltage	DC 28.8 V (active)
Voltage drop	For 22.5 mA: ≤ DC 2 V
Output frequency	Configurable: 0 to 1000 Hz
Damping	Configurable: 0 to 999 s

Pulse/pause ratio	1:1
Assignable measured variables	<ul> <li>Volume flow</li> <li>Mass flow</li> <li>Corrected volume flow</li> <li>Flow velocity</li> <li>Conductivity</li> <li>Electronics temperature</li> </ul>

#### Relay output

Function	Switch output
Version	Relay output, galvanically isolated
Switching behavior	Can be set to:  NO (normally open), factory setting NC (normally closed)
Maximum switching capacity (passive)	■ DC 30 V, 0.1 A ■ AC 30 V, 0.5 A
Assignable functions	<ul> <li>Off</li> <li>On</li> <li>Diagnostic behavior</li> <li>Limit value: <ul> <li>Off</li> <li>Volume flow</li> <li>Mass flow</li> <li>Corrected volume flow</li> <li>Flow velocity</li> <li>Conductivity</li> <li>Totalizer 1-3</li> <li>Electronic temperature</li> </ul> </li> <li>Flow direction monitoring</li> <li>Status <ul> <li>Empty pipe detection</li> <li>Low flow cut off</li> </ul> </li> </ul>

#### User-configurable input/output

**One** specific input or output is assigned to a user-configurable input/output (configurable I/O) during device commissioning.

The following inputs and outputs are available for assignment:

- Choice of current output: 4 to 20 mA (active), 0/4 to 20 mA (passive)
- Pulse/frequency/switch output
- Choice of current input: 4 to 20 mA (active), 0/4 to 20 mA (passive)
- Status input

The technical values correspond to those of the inputs and outputs described in this section.

#### Signal on alarm

Depending on the interface, failure information is displayed as follows:

#### HART current output

Device diagnostics	Device condition can be read out via HART Command 48
--------------------	--

#### **PROFIBUS PA**

Status and alarm messages	Diagnostics in accordance with PROFIBUS PA Profile 3.02
Failure current FDE (Fault Disconnection Electronic)	0 mA

#### PROFIBUS DP

Status and alarm	Diagnostics in accordance with PROFIBUS PA Profile 3.02
messages	

#### EtherNet/IP

Device diagnostics	Device condition can be read out in Input Assembly
--------------------	--

#### **PROFINET**

<b>Device diagnostics</b> According to "Application"	ation Layer protocol for decentralized periphery", Version 2.3
--	--

#### FOUNDATION Fieldbus

Status and alarm messages	Diagnostics in accordance with FF-891
Failure current FDE (Fault Disconnection Electronic)	0 mA

#### Modbus RS485

Failure mode	Choose from:
	■ NaN value instead of current value
	■ Last valid value

#### Current output 0/4 to 20 mA

#### 4 to 20 mA

Choose from:  4 to 20 mA in accordance with NAMUR recommendation NE 43  4 to 20 mA in accordance with US  Min. value: 3.59 mA  Max. value: 22.5 mA  Freely definable value between: 3.59 to 22.5 mA  Actual value
---

#### 0 to 20 mA

Failure mode	Choose from:
	■ Maximum alarm: 22 mA
	■ Freely definable value between: 0 to 20.5 mA

#### Pulse/frequency/switch output

Pulse output	
Failure mode	Choose from:  Actual value  No pulses
Frequency output	
Failure mode	Choose from:  • Actual value  • 0 Hz  • Defined value (f max 2 to 12 500 Hz)

Switch output	
Failure mode	Choose from:  Current status  Open Closed

#### Relay output

Failure mod	le	Choose from:
		Current status
		■ Open
		■ Closed

#### Local display

Plain text display	With information on cause and remedial measures
Backlight	Red backlighting indicates a device error.



Status signal as per NAMUR recommendation NE 107

#### Interface/protocol

- Via digital communication:
  - HART protocol
  - FOUNDATION Fieldbus
  - PROFIBUS PA
  - PROFIBUS DP
  - Modbus RS485
  - EtherNet/IP
  - PROFINET
- Via service interface
  - CDI-RJ45 service interface
  - WLAN interface

Plain text display	With information on cause and remedial measures



#### Web browser

Plain text display	With information on cause and remedial measures
--------------------	---

#### Light emitting diodes (LED)

Status information	Status indicated by various light emitting diodes	
	The following information is displayed depending on the device version:  Supply voltage active	
	Data transmission active	
	<ul> <li>Device alarm/error has occurred</li> </ul>	
	<ul><li>EtherNet/IP network available</li></ul>	
	<ul> <li>EtherNet/IP connection established</li> </ul>	
	<ul> <li>PROFINET network available</li> </ul>	
	<ul> <li>PROFINET connection established</li> </ul>	
	<ul> <li>PROFINET blinking feature</li> </ul>	

#### Ex connection data

#### Safety-related values

Order code for "Output; input 1"	Output type	Safety-related values "Output; input 1"		
		26 (+)	27 (-)	
Option <b>BA</b>	Current output 4 to 20 mA HART	$U_{N} = 30 V_{DC}$ $U_{M} = 250 V_{AC}$		
Option <b>GA</b>	PROFIBUS PA	$U_{N} = 30 V_{DC}$ $U_{M} = 250 V_{AC}$		
Option <b>LA</b>	PROFIBUS DP	$U_{N} = 30 V_{DC}$ $U_{M} = 250 V_{AC}$		
Option MA	Modbus RS485	$U_{N} = 30 V_{DC}$ $U_{M} = 250 V_{AC}$		
Option <b>SA</b>	FOUNDATION Fieldbus	$U_{N} = 30 V_{DC}$ $U_{M} = 250 V_{AC}$		
Option <b>NA</b>	EtherNet/IP	$U_{N} = 30 V_{DC}$ $U_{M} = 250 V_{AC}$		
Option <b>RA</b>	PROFINET	$U_{N} = 30 V_{DC}$ $U_{M} = 250 V_{AC}$		

Order code for Output type Safety-related		ited values			
"Output; input 2"; "Output; input 3"		Output; input 2 Output; input 3		input 3	
• ′ •		24 (+)	25 (-)	22 (+)	23 (-)
Option <b>B</b>	Current output 4 to 20 mA	$U_{\rm N} = 30 \ V_{\rm DC}$ $U_{\rm M} = 250 \ V_{\rm Ad}$	2		
Option <b>D</b>	User-configurable input/output	$U_{\rm N} = 30 \ V_{\rm DC}$ $U_{\rm M} = 250 \ V_{\rm Ad}$	2		
Option <b>E</b>	Pulse/frequency/switch output	$U_{\rm N} = 30 \ V_{\rm DC}$ $U_{\rm M} = 250 \ V_{\rm Ad}$	2		
Option <b>F</b>	Double pulse output	$U_{\rm N} = 30 \ V_{\rm DC}$ $U_{\rm M} = 250 \ V_{\rm Ad}$	2		
Option <b>H</b>	Relay output	$U_{N} = 30 V_{DC}$ $I_{N} = 100 \text{ mA}_{D}$ $U_{M} = 250 V_{AG}$	0 110		
Option I	Current input 4 to 20 mA	$U_{\rm N} = 30 \ V_{\rm DC}$ $U_{\rm M} = 250 \ V_{\rm Ad}$	C		
Option <b>J</b>	Status input	$U_{\rm N} = 30 \ V_{\rm DC}$ $U_{\rm M} = 250 \ V_{\rm A0}$	3		

#### Intrinsically safe values

Order code for "Output; input 1"	Output type	Intrinsically safe values "Output; input 1"		
		26 (+)	27 (-)	
Option CA	Current output 4 to 20 mA HART Ex i passive	$\begin{split} &U_{i} = 30 \text{ V} \\ &l_{i} = 100 \text{ mA} \\ &P_{i} = 1.25 \text{ W} \\ &L_{i} = 0  \mu\text{H} \\ &C_{i} = 6 \text{ nF} \end{split}$		
Option CC	Current output 4 to 20 mA HART Ex i active	$ \begin{array}{llllllllllllllllllllllllllllllllllll$		
Option <b>HA</b>	PROFIBUS PA Ex i (FISCO Field Device)	$\begin{aligned} &\textbf{Ex ia}^{\ 3)} \\ &U_i = 30 \ V \\ &l_i = 570 \ mA \\ &P_i = 8.5 \ W \\ &L_i = 10 \ \mu H \\ &C_i = 5 \ nF \end{aligned}$	Ex ic $^{4)}$ $U_i = 32 \text{ V}$ $l_i = 570 \text{ mA}$ $P_i = 8.5 \text{ W}$ $L_i = 10 \mu\text{H}$ $C_i = 5 \text{ nF}$	
Option TA	FOUNDATION Fieldbus Ex i	$\begin{aligned} &\textbf{Ex ia}^{3)} \\ &\textbf{U}_i = 30 \text{ V} \\ &\textbf{l}_i = 570 \text{ mA} \\ &\textbf{P}_i = 8.5 \text{ W} \\ &\textbf{L}_i = 10  \mu\text{H} \\ &\textbf{C}_i = 5 \text{ nF} \end{aligned}$	Ex ic $^{4)}$ $U_i = 32 \text{ V}$ $l_i = 570 \text{ mA}$ $P_i = 8.5 \text{ W}$ $L_i = 10 \mu\text{H}$ $C_i = 5 \text{ nF}$	

- Only available for the Zone 1; Class I, Division 1 version
- 2) Only available for the Zone 2; Class I, Division 2 version transmitter  $% \left( 1\right) =\left( 1\right) \left( 1\right) \left($
- Only available for the Zone 1; Class I, Division 1 version
- 3) 4) Only available for the Zone 2; Class I, Division 2 version transmitter

Order code for	Output type	Intrinsically safe values or NIFW values			
"Output; input 2"; "Output; input 3"		Output; input 2		Output; input 3	
		24 (+)	25 (-)	22 (+)	23 (-)
Option C	Current output 4 to 20 mA Ex i	$U_{i} = 30 \text{ V}$ $l_{i} = 100 \text{ mA}$ $P_{i} = 1.25 \text{ W}$ $L_{i} = 0$ $C_{i} = 0$			
Option <b>G</b>	Pulse/frequency/switch output Ex i	$\begin{aligned} &U_{i} = 30 \text{ V} \\ &l_{i} = 100 \text{ mA} \\ &P_{i} = 1.25 \text{ W} \\ &L_{i} = 0 \\ &C_{i} = 0 \end{aligned}$			

Low flow cut off

The switch points for low flow cut off are user-selectable.

Galvanic isolation

The outputs are galvanically isolated from one another and from earth (PE).

#### Protocol-specific data

#### HART

Manufacturer ID	0x11
Device type ID	0x3C
HART protocol revision	7
Device description files (DTM, DD)	Information and files under: www.endress.com
HART load	Min. 250 $\Omega$
System integration	Information on system integration: Operating Instructions → 🗎 110.  ■ Measured variables via HART protocol  ■ Burst Mode functionality

#### FOUNDATION Fieldbus

Manufacturer ID       0x452B48 (hex)         Ident number       0x103C (hex)         Device revision       1         CFF revision       Information and files under:	
Device revision  Information and files under:  www.endress.com www.fieldbus.org  Interoperability Test Kit (ITK)  ITK Test Campaign Number  Information: www.endress.com www.fieldbus.org  Link Master capability (LAS)  Choice of "Link Master" and "Basic Device"  Node address  Factory setting: Basic Device  Node address  Factory setting: 247 (0xF7)  The following methods are supported: Restart ENP Restart Diagnostic	
DD revision  CFF revision  Information and files under:  www.endress.com www.fieldbus.org  Interoperability Test Kit (ITK)  ITK Test Campaign Number  Information: www.endress.com www.endress.com www.fieldbus.org  Link Master capability (LAS)  Yes  Choice of "Link Master" and "Basic Device"  Node address  Factory setting: Basic Device  Node address  Factory setting: 247 (0xF7)  The following methods are supported: Restart ENP Restart Diagnostic	
CFF revision  ■ www.endress.com ■ www.fieldbus.org  Interoperability Test Kit (ITK) Version 6.2.0  ITK Test Campaign Number  Information: ■ www.endress.com ■ www.fieldbus.org  Link Master capability (LAS) Yes  Choice of "Link Master" and "Basic Device"  Node address  Factory setting: Basic Device  Node address  Factory setting: 247 (0xF7)  Supported functions  The following methods are supported: ■ Restart ■ ENP Restart ■ Diagnostic	
CFF revision       ■ www.fieldbus.org         Interoperability Test Kit (ITK)       Version 6.2.0         ITK Test Campaign Number       Information:	
Information:  www.endress.com www.fieldbus.org  Link Master capability (LAS)  Choice of "Link Master" and "Basic Device"  Node address  Factory setting: 247 (0xF7)  Supported functions  The following methods are supported: Restart ENP Restart Diagnostic	
<ul> <li>www.endress.com</li> <li>www.fieldbus.org</li> <li>Link Master capability (LAS)</li> <li>Yes</li> <li>Choice of "Link Master" and "Basic Device"</li> <li>Node address</li> <li>Factory setting: Basic Device</li> <li>Node address</li> <li>Factory setting: 247 (0xF7)</li> <li>Supported functions</li> <li>The following methods are supported:         <ul> <li>Restart</li> <li>ENP Restart</li> <li>Diagnostic</li> </ul> </li> </ul>	
Choice of "Link Master" and "Basic Device"  Node address  Factory setting: Basic Device  Factory setting: 247 (0xF7)  Supported functions  The following methods are supported:  Restart  ENP Restart  Diagnostic	
"Basic Device"       Factory setting: Basic Device         Node address       Factory setting: 247 (0xF7)         Supported functions       The following methods are supported: <ul> <li>Restart</li> <li>ENP Restart</li> <li>Diagnostic</li> </ul> ** Restart     ** Diagnostic	
Supported functions  The following methods are supported:  Restart  ENP Restart  Diagnostic	
<ul><li>Restart</li><li>ENP Restart</li><li>Diagnostic</li></ul>	
<ul> <li>Set to AUTO</li> <li>Read trend data</li> <li>Read event logbook</li> </ul>	
Virtual Communication Relationships (VCRs)	
Number of VCRs 44	
Number of link objects in VFD 50	
Permanent entries 1	
Client VCRs 0	
Server VCRs 10	
Source VCRs 43	
Sink VCRs 0	
Subscriber VCRs 43	
Publisher VCRs 43	
Device Link Capabilities	
Slot time 4	
Min. delay between PDU 8	

Max. response delay	16
System integration	Information regarding system integration: Operating Instructions → 🗎 110.  Cyclic data transmission Description of the modules Execution times Methods

#### PROFIBUS DP

Manufacturer ID	0x11						
Ident number	0x1570						
Profile version	3.02						
Device description files (GSD, DTM, DD)	Information and files under:  ■ www.endress.com  On the product page for the device: Documents/Software → Device drivers  ■ www.profibus.org						
Supported functions	<ul> <li>Identification &amp; Maintenance         Simplest device identification on the part of the control system and         nameplate</li> <li>PROFIBUS upload/download         Reading and writing parameters is up to ten times faster with PROFIBUS         upload/download</li> <li>Condensed status         Simplest and self-explanatory diagnostic information by categorizing         diagnostic messages that occur</li> </ul>						
Configuration of the device address	<ul> <li>DIP switches on the I/O electronics module</li> <li>Via operating tools (e.g. FieldCare)</li> </ul>						
Compatibility with earlier model	If the device is replaced, the measuring device Promag 300 supports the compatibility of the cyclic data with previous models. It is not necessary to adjust the engineering parameters of the PROFIBUS network with the Promag 300 GSD file.						
	Earlier models:  Promag 50 PROFIBUS DP  ID No.: 1546 (hex)  Extended GSD file: EH3x1546.gsd  Standard GSD file: EH3_1546.gsd  Promag 53 PROFIBUS DP  ID No.: 1526 (hex)  Extended GSD file: EH3x1526.gsd  Standard GSD file: EH3x1526.gsd						
	Description of the function scope of compatibility: Operating Instructions $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $						
System integration	Information regarding system integration: Operating Instructions → 🗎 110.  Cyclic data transmission  Block model  Description of the modules						

#### PROFIBUS PA

Manufacturer ID	0x11
Ident number	0x156C
Profile version	3.02
Device description files (GSD, DTM, DD)	Information and files under:  www.endress.com www.profibus.org

Supported functions	<ul> <li>Identification &amp; Maintenance         Simplest device identification on the part of the control system and         nameplate</li> <li>PROFIBUS upload/download         Reading and writing parameters is up to ten times faster with PROFIBUS         upload/download</li> <li>Condensed status         Simplest and self-explanatory diagnostic information by categorizing         diagnostic messages that occur</li> </ul>						
Configuration of the device address	<ul> <li>DIP switches on the I/O electronics module</li> <li>Local display</li> <li>Via operating tools (e.g. FieldCare)</li> </ul>						
Compatibility with earlier model	If the device is replaced, the measuring device Promag 300 supports the compatibility of the cyclic data with previous models. It is not necessary to adjust the engineering parameters of the PROFIBUS network with the Promag 300 GSD file.  Earlier models:  Promag 50 PROFIBUS PA  ID No.: 1525 (hex)  Extended GSD file: EH3x1525.gsd  Standard GSD file: EH3_1525.gsd  Promag 53 PROFIBUS PA  ID No.: 1527 (hex)  Extended GSD file: EH3x1527.gsd  Standard GSD file: EH3x1527.gsd  Description of the function scope of compatibility: Operating Instructions →  110.						
System integration	Information regarding system integration: Operating Instructions → 🖺 110.  Cyclic data transmission  Block model  Description of the modules						

#### Modbus RS485

Protocol	Modbus Applications Protocol Specification V1.1						
Response times	<ul> <li>Direct data access: typically 25 to 50 ms</li> <li>Auto-scan buffer (data range): typically 3 to 5 ms</li> </ul>						
Device type	Slave						
Slave address range	1 to 247						
Broadcast address range	0						
Function codes	<ul> <li>03: Read holding register</li> <li>04: Read input register</li> <li>06: Write single registers</li> <li>08: Diagnostics</li> <li>16: Write multiple registers</li> <li>23: Read/write multiple registers</li> </ul>						
Broadcast messages	Supported by the following function codes:  • 06: Write single registers  • 16: Write multiple registers  • 23: Read/write multiple registers						
Supported baud rate	<ul> <li>1200 BAUD</li> <li>2400 BAUD</li> <li>4800 BAUD</li> <li>9600 BAUD</li> <li>19200 BAUD</li> <li>38400 BAUD</li> <li>57600 BAUD</li> <li>115200 BAUD</li> </ul>						
Data transfer mode	ASCII     RTU						

Data access	Each device parameter can be accessed via Modbus RS485.  For Modbus register information					
Compatibility with earlier model	If the device is replaced, the measuring device Promag 300 supports the compatibility of the Modbus registers for the process variables and the diagnostic information with the previous model Promag 53. It is not necessary to change the engineering parameters in the automation system.  □ Description of the function scope of compatibility:  Operating Instructions → ■ 110.					
System integration	Information on system integration: Operating Instructions → 🗎 110.  ■ Modbus RS485 information  ■ Function codes  ■ Register information  ■ Response time  ■ Modbus data map					

#### EtherNet/IP

Protocol	■ The CIP Networks Library Volume 1: Common Industrial Protocol ■ The CIP Networks Library Volume 2: EtherNet/IP Adaptation of CIP				
Communication type	■ 10Base-T ■ 100Base-TX				
Device profile	Generic device (product type: 0x2B)				
Manufacturer ID	0x11				
Device type ID	0x103C				
Baud rates	Automatic 10/100 Mbit with half-duplex and full-duplex detection				
Polarity	Auto-polarity for automatic correction of crossed TxD and RxD pairs				
Supported CIP connections	Max. 3 connections				
Explicit connections	Max. 6 connections				
I/O connections	Max. 6 connections (scanner)				
Configuration options for measuring device	<ul> <li>DIP switches on the electronics module for IP addressing</li> <li>Manufacturer-specific software (FieldCare)</li> <li>Add-on Profile Level 3 for Rockwell Automation control systems</li> <li>Web browser</li> <li>Electronic Data Sheet (EDS) integrated in the measuring device</li> </ul>				
Configuration of the EtherNet interface	<ul> <li>Speed: 10 MBit, 100 MBit, auto (factory setting)</li> <li>Duplex: half-duplex, full-duplex, auto (factory setting)</li> </ul>				
Configuration of the device address	<ul> <li>DIP switches on the electronics module for IP addressing (last octet)</li> <li>DHCP</li> <li>Manufacturer-specific software (FieldCare)</li> <li>Add-on Profile Level 3 for Rockwell Automation control systems</li> <li>Web browser</li> <li>EtherNet/IP tools, e.g. RSLinx (Rockwell Automation)</li> </ul>				
Device Level Ring (DLR)	Yes				
System integration	Information regarding system integration: Operating Instructions $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $				
	<ul> <li>Cyclic data transmission</li> <li>Block model</li> <li>Input and output groups</li> </ul>				

#### PROFINET

Protocol	Application layer protocol for decentral device periphery and distributed automation, Version 2.3
Communication type	100 MBit/s

Conformity class	Conformance Class B					
Conformity class						
Netload Class	Netload Class II					
Baud rates	Automatic 100 Mbit/s with full-duplex detection					
Cycle times	From 8 ms					
Polarity	Auto-polarity for automatic correction of crossed TxD and RxD pairs					
Media Redundancy Protocol (MRP)	Yes					
System redundancy support	System redundancy S2 (2 AR with 1 NAP)					
Device profile	Application interface identifier 0xF600 Generic device					
Manufacturer ID	0x11					
Device type ID	0x843C					
Device description files (GSD, DTM, DD)	Information and files under:  ■ www.endress.com  On the product page for the device: Documents/Software → Device drivers  ■ www.profibus.org					
Supported connections	<ul> <li>2 x AR (IO Controller AR)</li> <li>1 x AR (IO-Supervisor Device AR connection allowed)</li> <li>1 x Input CR (Communication Relation)</li> <li>1 x Output CR (Communication Relation)</li> <li>1 x Alarm CR (Communication Relation)</li> </ul>					
Configuration options for measuring device	<ul> <li>DIP switches on the electronics module, for device name assignment (last part)</li> <li>Manufacturer-specific software (FieldCare, DeviceCare)</li> <li>Web browser</li> <li>Device master file (GSD), can be read out via the integrated Web server of the measuring device</li> </ul>					
Configuration of the device name	<ul> <li>DIP switches on the electronics module, for device name assignment (last part)</li> <li>DCP protocol</li> <li>Process Device Manager (PDM)</li> <li>Integrated Web server</li> </ul>					
Supported functions	<ul> <li>Identification &amp; Maintenance         Simple device identification via:         <ul> <li>Control system</li> <li>Nameplate</li> </ul> </li> <li>Measured value status         The process variables are communicated with a measured value status</li> <li>Blinking feature via the onsite display for simple device identification and assignment</li> <li>Device operation via operating tools (e.g. FieldCare, DeviceCare, SIMATIC PDM)</li> </ul>					
System integration	Information regarding system integration: Operating Instructions → 🖺 110.  Cyclic data transmission Overview and description of the modules Status coding Startup configuration Factory setting					

## **Power supply**

#### Terminal assignment

#### Transmitter: supply voltage, input/outputs

#### **HART**

Supply voltage		Input/o	utput 1	Input/c	output 2	Input/c	output 3	
1 (+)	2 (-)	26 (+)	27 (-)	24 (+)	25 (-)	22 (+)	23 (-)	
		The terminal assignment depends on the specific device version ordered $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $						

#### FOUNDATION Fieldbus

Supply voltage		Input/o	utput 1	Input/o	output 2	Input/o	output 3	
1 (+)	2 (-)	26 (A)	27 (B)	24 (+)	25 (-)	22 (+)	23 (-)	
		The terminal assignment depends on the specific device version ordered $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $						

#### PROFIBUS PA

Supply voltage		Input/o	utput 1	Input/o	utput 2	Input/o	output 3	
1 (+)	2 (-)	26 (B)	27 (A)	24 (+)	25 (-)	22 (+)	23 (-)	
		The terminal assignment depends on the specific device version ordered $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $						

#### PROFIBUS DP

Supply voltage		Input/o	utput 1	Input/o	utput 2	Input/o	output 3	
1 (+)	2 (-)	26 (B)	27 (A)	24 (+)	25 (-)	22 (+)	23 (-)	
		The terminal assignment depends on the specific device version ordered $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $						

#### Modbus RS485

Supply	voltage	Input/o	utput 1	Input/o	utput 2	Input/o	output 3
1 (+)	2 (-)	26 (B)	27 (A)	24 (+)	25 (-)	22 (+)	23 (-)
		The terminal assignment depends on the specific device version ordered $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $					

#### PROFINET

Supply voltage		Input/output 1	Input/o	output 2	Input/o	output 3
1 (+)	2 (-)	PROFINET (RJ45 connector)	24 (+) The termin	25 (–) nal assignmen	22 (+) t depends on t	23 (–) he specific
			de	evice version o	rdered $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $	5.

#### EtherNet/IP

Supply	voltage	Input/output 1	Input/o	output 2	Input/o	output 3
1 (+)	2 (-)	EtherNet/IP	24 (+)	25 (-)	22 (+)	23 (-)
		(RJ45 connector)			t depends on t rdered → 🖺 1	*

Device plugs available

Pevice plugs may not be used in hazardous areas!

#### Device plugs for fieldbus systems:

Order code for "Input; output 1"

- Option **GA** "PROFIBUS PA" → 🖺 32
- Option **NA** "EtherNet/IP"  $\rightarrow$   $\stackrel{\triangle}{=}$  32
- Option **RA** "PROFINET" → 🗎 32

#### Device plug for connecting to the service interface:

Order code for "Accessory mounted"

option NB, adapter RJ45 M12 (service interface) → 🖺 46

#### Order code for "Input; output 1", option SA "FOUNDATION Fieldbus"

Order code for	Cable entry/connection → 🖺 33		
"Electrical connection"	2	3	
M, 3, 4, 5	7/8" connector	-	

#### Order code for "Input; output 1", option GA "PROFIBUS PA"

Order code for	Cable entry/connection → 🖺 33		
"Electrical connection"	2	3	
L, N, P, U	Connector M12 × 1	-	

#### Order code for "Input; output 1", option NA "EtherNet/IP"

Order code for	Cable entry/connection → 🖺 33		
"Electrical connection"	2	3	
L, N, P, U	Connector M12 × 1	-	
R <sup>1) 2)</sup> , S <sup>1) 2)</sup> , T <sup>1) 2)</sup> , V <sup>1) 2)</sup>	Connector M12 × 1	Connector M12 × 1	

- Cannot be combined with an external WLAN antenna (order code for "Enclosed accessories", option P8) of an RJ45 M12 adapter for the service interface (order code for "Accessories mounted", option NB) or of the remote display and operating module DKX001
- 2) Suitable for integrating the device in a ring topology.

#### Order code for "Input; output 1", option RA "PROFINET"

Order code for	Cable entry/connection → 🖺 33		
"Electrical connection"	2	3	
L, N, P, U	Connector M12 × 1	-	
R <sup>1) 2)</sup> , S <sup>1) 2)</sup> , T <sup>1) 2)</sup> , V <sup>1) 2)</sup>	Connector M12 × 1	Connector M12 × 1	

- Cannot be combined with an external WLAN antenna (order code for "Enclosed accessories", option P8) of an RJ45 M12 adapter for the service interface (order code for "Accessories mounted", option NB) or of the remote display and operating module DKX001.
- 2) Suitable for integrating the device in a ring topology.

#### Order code for "Accessory mounted", option NB "Adapter RJ45 M12 (service interface)"

Order code	Cable entry/coupling → 🗎 33	
"Accessory mounted"	Cable entry 2	Cable entry 3
NB	Plug M12 × 1	-

#### Supply voltage

Order code for "Power supply"	Terminal voltage		Frequency range
Option <b>D</b>	DC24 V	±20%	-
Option <b>E</b>	AC100 to 240 V	-15+10%	50/60 Hz, ±4 Hz
Option I	DC24 V	±20%	-
Орион 1	AC100 to 240 V	-15+10%	50/60 Hz, ±4 Hz

#### Power consumption

#### Transmitter

Max. 10 W (active power)

switch-on current	Max. 36 A (<5 ms) as per NAMUR Recommendation NE 21
	, <u>I</u>

#### **Current consumption**

#### Transmitter

- Max. 400 mA (24 V)
- Max. 200 mA (110 V, 50/60 Hz; 230 V, 50/60 Hz)

#### Power supply failure


- Totalizers stop at the last value measured.
- Depending on the device version, the configuration is retained in the device memoryor in the pluggable data memory (HistoROM DAT).
- Error messages (incl. total operated hours) are stored.

#### **Electrical connection**

#### Connecting the transmitter



- Device plugs available → 31



A002678

- 1 Terminal connection for supply voltage
- 2 Terminal connection for signal transmission, input/output
- 3 Terminal connection for signal transmission, input/output or terminal for network connection via service interface (CDI-RJ45); Optional: terminal connection for external WLAN antenna or connection for remote display and operating module DKX001
- 4 Protective ground (PE)



An adapter for RJ45 and the M12 connector is optionally available: Order code for "Accessories", option **NB**: "Adapter RJ45 M12 (service interface)"

The adapter connects the service interface (CDI-RJ45) to an M12 connector mounted in the cable entry. Therefore the connection to the service interface can be established via an M12 connector without opening the device.

Network connection via service interface (CDI-RJ45)  $\rightarrow$   $\stackrel{\triangle}{=}$  99

#### Connecting in a ring topology

Device versions with EtherNet/IP and PROFINET communication protocols can be integrated into a ring topology. The device is integrated via the terminal connection for signal transmission (output 1) and the connection to the service interface (CDI-RJ45).




Integrate the transmitter into a ring topology:

- EtherNet/IP
- PROFINET

Endress+Hauser 33


11002070



- 1 Terminal connection for supply voltage
- Terminal connection for signal transmission: PROFINET or EtherNet/IP (RJ45 connector) 2
- 3 Connection to service interface (CDI-RJ45)
- Protective ground (PE)
- If the device has additional input/outputs, these are routed via the cable entry for the connection to the service interface (CDI-RJ45).

#### Connecting the remote display and operating module DKX001


- The remote display and operating module DKX001 is available as an optional extra  $\rightarrow \triangleq 107$ .
  - The measuring device is always supplied with a dummy cover when the remote display and operating module DKX001 is ordered directly with the measuring device. Display or operation at the transmitter is not possible in this case.
  - If ordered subsequently, the remote display and operating module DKX001 may not be connected at the same time as the existing measuring device display module. Only one display or operation unit may be connected to the transmitter at any one time.



- Remote display and operating module DKX001
- 2 Protective earth (PE)
- 3 Connecting cable
- Measuring device
- Protective earth (PE)


#### **Connection examples**

Current output 4 to 20 mA HART



A00290


- 2 Connection example for 4 to 20 mA HART current output (active)
- 1 Automation system with current input (e.g. PLC)
- 2 Cable shield provided at one end. The cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications → 🖺 46
- 4 Resistor for HART communication ( $\geq 250 \Omega$ ): observe maximum load  $\Rightarrow \square 17$
- 5 Analog display unit: observe maximum load → 🗎 17
- 6 Transmitter



A002876

- 3 Connection example for 4 to 20 mA HART current output (passive)
- 1 Automation system with current input (e.g. PLC)
- 2 Power supply
- 4 Analog display unit: observe maximum load → 🖺 17
- 5 Transmitter


#### HART input



A00287

- 4 Connection example for HART input with a common negative (passive)
- 1 Automation system with HART output (e.g. PLC)
- 2 Active barrier for power supply (e.g. RN221N)
- 3 Cable shield provided at one end. The cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications
- 4 Analog display unit: observe maximum load  $\rightarrow \blacksquare 17$
- 5 Pressure measuring device (e.g. Cerabar M, Cerabar S): see requirements
- 6 Transmitter

#### PROFIBUS PA




A002876

#### ■ 5 Connection example for PROFIBUS PA


- 1 Control system (e.g. PLC)
- 2 PROFIBUS PA segment coupler
- 3 Cable shield provided at one end. The cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications
- 4 T-box
- 5 Measuring device
- 6 Local grounding
- 7 Bus terminator
- 8 Potential matching line

# PROFIBUS DP



- $\blacksquare$  6 Connection example for PROFIBUS DP, non-hazardous area and Zone 2/Div. 2
- 1 Control system (e.g. PLC)
- 2 Cable shield provided at one end. The cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications
- 3 Distribution box
- 4 Transmitter
- If baud rates > 1.5 MBaud an EMC cable entry must be used and the cable shield must continue as far as the terminal wherever possible.


# EtherNet/IP



A002876


- 7 Connection example for EtherNet/IP
- 1 Control system (e.g. PLC)
- 2 Ethernet switch
- 3 Observe cable specifications
- 4 Device plug
- 5 Transmitter

# EtherNet/IP: DLR (Device Level Ring)



- 1 Control system (e.g. PLC)
- 2 Ethernet switch
- 4 Transmitter
- 5 Connecting cable between the two transmitters


#### **PROFINET**



■ 8 Connection example for PROFINET

- 1 Control system (e.g. PLC)
- 2 Ethernet switch
- 3 Observe cable specifications
- 4 Device plug
- 5 Transmitter


# PROFINET: MRP (Media Redundancy Protocol)



1 Control system (e.g. PLC)


- 2 Ethernet switch
- 3 Observe cable specifications  $\rightarrow$   $<math> \bigcirc$  46
- 4 Transmitter
- 5 Connecting cable between the two transmitters

# PROFINET: system redundancy S2



- **₽** 9  $Connection\ example\ for\ system\ redundancy\ S2$
- Control system 1 (e.g. PLC)
- Synchronization of control systems 2
- Control system 2 (e.g. PLC)
- Industrial Ethernet Managed Switch 4
- Transmitter


# FOUNDATION Fieldbus



**■** 10 Connection example for FOUNDATION Fieldbus


- 1
- Control system (e.g. PLC) Power Conditioner (FOUNDATION Fieldbus) 2
- 3 Cable shield provided at one end. The cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications
- T-box
- Measuring device
- Local grounding 6
- Bus terminator
- Potential matching line

# Modbus RS485




- **■** 11 Connection example for Modbus RS485, non-hazardous area and Zone 2/Div. 2
- Control system (e.g. PLC)
- 2 Cable shield provided at one end. The cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications
- 3 Distribution box
- Transmitter

#### Current output 4-20 mA




- 12 Connection example for 4-20 mA current output (active)
- Automation system with current input (e.g. PLC) 1
- 2 Analog display unit: observe maximum load  $\rightarrow = 17$
- 3 Transmitter




- **■** 13 Connection example for 4-20 mA current output (passive)
- Automation system with current input (e.g. PLC)
- Active barrier for power supply (e.g. RN221N) 2 3
- Transmitter

# Pulse/frequency output



- $\blacksquare$  14 Connection example for pulse/frequency output (passive)
- 1 Automation system with pulse/frequency input (e.g. PLC)
- 2 Power supply
- 3 Transmitter: Observe input values → 🖺 19


# Switch output



■ 15 Connection example for switch output (passive)

- 1 Automation system with switch input (e.g. PLC)
- 2 Power supply

# Double pulse output




■ 16 Connection example for double pulse output (active)

- 1 Automation system with double pulse input (e.g. PLC)
- 2 Transmitter: Observe input values → 🖺 20
- 3 Double pulse output
- 4 Double pulse output (slave), phase-shifted

Endress+Hauser 41


.....



■ 17 Connection example for double pulse output (passive)

- 1 Automation system with double pulse input (e.g. PLC)
- 2 Power supply
- 4 Double pulse output
- 5 Double pulse output (slave), phase-shifted


# Relay output



■ 18 Connection example for relay output (passive)

- 1 Automation system with relay input (e.g. PLC)
- 2 Power supply


# Current input



■ 19 Connection example for 4 to 20 mA current input

- 1 Power supply
- 2 Terminal box
- 3 External measuring device (to read in pressure or temperature, for instance)
- 4 Transmitter

# Status input



A002876

■ 20 Connection example for status input

- 1 Automation system with status output (e.g. PLC)
- 2 Power supply
- 3 Transmitter

# Potential equalization


# Requirements

Please consider the following to ensure correct measurement:

- Same electrical potential for the fluid and sensor
- Company-internal grounding concepts
- Pipe material and grounding

# Connection example, standard scenario

Metal, grounded pipe



A0016315

■ 21 Potential equalization via measuring tube


# Connection example in special situations

Unlined and ungrounded metal pipe

This connection method also applies in situations where:

- $\ \ \, \blacksquare$  The customary potential equalization is not used
- Equalizing currents are present

Ground cable Copper wire, at least 6 mm<sup>2</sup> (0.0093 in<sup>2</sup>)



A0029338

■ 22 Potential equalization via ground terminal and pipe flanges

Note the following when installing:


- Connect both sensor flanges to the pipe flange via a ground cable and ground them.
- Connect the connection housing of the transmitter or sensor to ground potential by means of the ground terminal provided for the purpose. To mount the ground cable:
  - If  $DN \le 300$  (12"): Mount the ground cable directly on the conductive flange coating of the sensor with the flange screws.
  - If DN  $\geq$  350 (14"): Mount the ground cable directly on the metal transport bracket.

Plastic pipe or pipe with insulating liner

This connection method also applies in situations where:

- The customary potential equalization is not used
- Equalizing currents are present

Ground cable Copper wire, at least 6 mm<sup>2</sup> (0.0093 in<sup>2</sup>)



A002933

■ 23 Potential equalization via ground terminal and ground disks

Note the following when installing:

The ground disks must be connected to the ground terminal via the ground cable and be connected to ground potential.


The ground cable and ground disks can be ordered from Endress+Hauser  $\rightarrow \triangleq 107$ .

Pipe with a cathodic protection unit

- This connection method is only used if the following two conditions are met:

  Metal pipe without liner or pipe with electrically conductive liner
- Cathodic protection is integrated in the personal protection equipment

Ground cable Copper wire, at least 6 mm² (0.0093 in²)



A003032

- 1 Connection of the two flanges of the pipe via a ground cable
- 2 Signal line shielding via a capacitor
- 3 Measuring device connected to power supply such that it is floating in relation to the protective ground (isolation transformer)

Note the following when installing:

The sensor is installed in the pipe in a way that provides electrical insulation.

# terminals


Spring-loaded terminals: Suitable for strands and strands with ferrules. Conductor cross-section 0.2 to 2.5 mm<sup>2</sup> (24 to 12 AWG).

#### Cable entries

- Cable gland: M20  $\times$  1.5 with cable Ø 6 to 12 mm (0.24 to 0.47 in)
- Thread for cable entry:
  - NPT ½"
  - G ½"
  - M20
- Device plug for digital communication: M12

# Pin assignment, device plug

#### **FOUNDATION Fieldbus**



# PROFIBUS PA

		Pin		Assignment	Coding	Plug/socket
2 /	3	1	+	PROFIBUS PA +	A	Plug
1	<del></del>	2		Grounding		
	7/	3	-	PROFIBUS PA -		
		4		Not assigned		

# **PROFINET**


2	Pin		Assignment
	1	+	TD +
1 3	2	+	RD +
	3	-	TD -
	4	-	RD -
4 A0032047	Cod	ling	Plug/socket
	I	)	Socket



Recommended plug:

- Binder, series 763, part no. 99 3729 810 04
- Phoenix, part no. 1543223 SACC-M12MSD-4Q

#### EtherNet/IP




Recommended plug:

- Binder, series 763, part no. 99 3729 810 04
- Phoenix, part no. 1543223 SACC-M12MSD-4Q

#### Service interface

Order code for "Accessories mounted", option NB: Adapter RJ45 M12 (service interface)





Recommended plug:

- Binder, series 763, part no. 99 3729 810 04
- Phoenix, part no. 1543223 SACC-M12MSD-4Q

# Cable specification

#### Permitted temperature range

- The installation guidelines that apply in the country of installation must be observed.
- The cables must be suitable for the minimum and maximum temperatures to be expected.

#### Power supply cable

Standard installation cable is sufficient.

#### Signal cable

Current output 4 to 20 mA HART

A shielded cable is recommended. Observe grounding concept of the plant.

#### PROFIBUS PA

Twisted, shielded two-wire cable. Cable type A is recommended.



For further information on planning and installing PROFIBUS networks see:

- Operating Instructions "PROFIBUS DP/PA: Guidelines for planning and commissioning" (BA00034S)
- PNO Directive 2.092 "PROFIBUS PA User and Installation Guideline"
- IEC 61158-2 (MBP)

#### PROFIBUS DP

The IEC 61158 standard specifies two types of cable (A and B) for the bus line which can be used for every transmission rate. Cable type A is recommended.

Cable type	A
Characteristic impedance	135 to 165 $\Omega$ at a measuring frequency of 3 to 20 MHz
Cable capacitance	< 30 pF/m
Wire cross-section	> 0.34 mm <sup>2</sup> (22 AWG)
Cable type	Twisted pairs
Loop resistance	≤110 Ω/km

Signal damping	Max. 9 dB over the entire length of the cable cross-section
Shield	Copper braided shielding or braided shielding with foil shield. When grounding the cable shield, observe the grounding concept of the plant.



For further information on planning and installing PROFIBUS networks see:

- Operating Instructions "PROFIBUS DP/PA: Guidelines for planning and commissioning" (BA00034S)
- PNO Directive 2.092 "PROFIBUS PA User and Installation Guideline"
- IEC 61158-2 (MBP)

#### EtherNet/IP

The standard ANSI/TIA/EIA-568-B.2 Annex specifies CAT 5 as the minimum category for a cable used for EtherNet/IP. CAT 5e and CAT 6 are recommended.



For more information on planning and installing EtherNet/IP networks, please refer to the "Media Planning and Installation Manual. EtherNet/IP" of ODVA Organization

#### **PROFINET**

Standard IEC 61156-6 specifies CAT 5 as the minimum category for a cable used for PROFINET. CAT 5e and CAT 6 are recommended.



For more information on planning and installing PROFINET networks, see: "PROFINET Cabling and Interconnection Technology", Guideline for PROFINET

#### FOUNDATION Fieldbus

Twisted, shielded two-wire cable.



For further information on planning and installing FOUNDATION Fieldbus networks see:

- Operating Instructions for "FOUNDATION Fieldbus Overview" (BA00013S)
- FOUNDATION Fieldbus Guideline
- IEC 61158-2 (MBP)

#### Modbus RS485

The EIA/TIA-485 standard specifies two types of cable (A and B) for the bus line which can be used for every transmission rate. Cable type A is recommended.

Cable type	A		
Characteristic impedance	135 to 165 $\Omega$ at a measuring frequency of 3 to 20 MHz		
Cable capacitance	< 30 pF/m		
Wire cross-section	> 0.34 mm <sup>2</sup> (22 AWG)		
Cable type	Twisted pairs		
Loop resistance	≤110 Ω/km		
Signal damping	Max. 9 dB over the entire length of the cable cross-section		
Shield	Copper braided shielding or braided shielding with foil shield. When grounding the cable shield, observe the grounding concept of the plant.		

Current output 0/4 to 20 mA

Standard installation cable is sufficient.

Pulse/frequency/switch output

Standard installation cable is sufficient.

Double pulse output

Standard installation cable is sufficient.

Relay output

Standard installation cable is sufficient.

Current input 0/4 to 20 mA

Standard installation cable is sufficient.

Status input

Standard installation cable is sufficient.

# Connecting cable for transmitter - remote display and operating module DKX001 $\,$

# Standard cable

A standard cable can be used as the connecting cable.

Standard cable	4 cores (2 pairs); pair-stranded with common shield
Shielding	Tin-plated copper-braid, optical cover $\geq$ 85 %
Capacitance: core/shield	Maximum 1000 nF for Zone 1; Class I, Division 1
L/R	Maximum 24 $\mu$ H/ $\Omega$ for Zone 1; Class I, Division 1
Cable length	Maximum 300 m (1000 ft), see the following table

Cross-section	Cable length for use in:  Non-hazardous area Hazardous area: Zone 2; Class I, Division 2 Hazardous area: Zone 1; Class I, Division 1
0.34 mm <sup>2</sup> (22 AWG)	80 m (270 ft)
0.50 mm <sup>2</sup> (20 AWG)	120 m (400 ft)
0.75 mm <sup>2</sup> (18 AWG)	180 m (600 ft)
1.00 mm <sup>2</sup> (17 AWG)	240 m (800 ft)
1.50 mm <sup>2</sup> (15 AWG)	300 m (1000 ft)

# Optionally available connecting cable

Standard cable	$2\times2\times0.34~\text{mm}^2$ (22 AWG) PVC cable $^{1)}$ with common shield (2 pairs, pair-stranded)		
Flame resistance According to DIN EN 60332-1-2			
Oil-resistance	According to DIN EN 60811-2-1		
Shielding	Tin-plated copper-braid, optical cover ≥ 85 %		
Capacitance: core/shield	≤200 pF/m		
L/R	<24 μH/Ω		
Available cable length	10 m (35 ft)		
Operating temperature	When mounted in a fixed position: $-50$ to $+105$ °C ( $-58$ to $+221$ °F); when cable can move freely: $-25$ to $+105$ °C ( $-13$ to $+221$ °F)		

1) UV radiation can impair the cable outer sheath. Protect the cable from direct sunshine where possible.

# Performance characteristics

# Reference operating conditions

- Error limits following DIN EN 29104, in future ISO 20456
- Water, typically: +15 to +45 °C (+59 to +113 °F); 0.5 to 7 bar (73 to 101 psi)
- Data as indicated in the calibration protocol
- Accuracy based on accredited calibration rigs according to ISO 17025

#### Maximum measured error

o.r. = of reading


# Error limits under reference operating conditions

# Volume flow

- $\bullet$  ±0.5 % o.r. ± 1 mm/s (0.04 in/s)
- Optional: ±0.2 % o.r. ± 2 mm/s (0.08 in/s)

	Installation with inlet and outlet runs max. measured error		Installation without inlet and outlet runs max. measured error	
Order code for "Design"	0.5 %	0.2 %	0.5 %	
Options D, E, F, G (standard)	<b>~</b>	<b>V</b>	not recommended	
Options C, H, I (0 x DN)	<b>~</b>	<b>V</b>	☑	


Fluctuations in the supply voltage do not have any effect within the specified range.



€ 24 Maximum measured error in % o.r.

Flat Spec

For Flat Spec in the range  $v_{0.5}\ (v_{0.2})$  up to  $v_{\text{max}}$  the measured error is constant.



■ 25 Flat Spec in % o.r.

Flat Spec flow values 0.5 %

Nominal diameter		v <sub>(</sub>	).5	v <sub>max</sub>	
[mm]	[in]	[m/s]	[ft/s]	[m/s]	[ft/s]
25 to 600	1 to 24	0.5	1.64	10	32
50 to 300 <sup>1)</sup>	2 to 12	0.25	0.82	5	16

1) Order code for "Design", option C

Flat Spec flow values 0.2 %

Nominal	diameter	v <sub>(</sub>	).2	<b>v</b> <sub>max</sub>		
[mm]	[in]	[m/s]	[ft/s]	[m/s]	[ft/s]	
25 to 600	1 to 24	1.5	4.92	10	32	
50 to 300 <sup>1)</sup>	2 to 12	0.6	1.97	4	13	

1) Order code for "Design", option C

Electrical conductivity

Max. measured error not specified.

# Accuracy of outputs

The outputs have the following base accuracy specifications.

Current output

Accuracy	±5 μA
----------	-------

Pulse/frequency output

o.r. = of reading

Accuracy Max. ±50 ppm o.r. (over the entire ambient temperature range)	
--	--

Repeatability

o.r. = of reading

Volume flow

Max.  $\pm 0.1$  % o.r.  $\pm$  0.5 mm/s (0.02 in/s)

**Electrical conductivity** 

Max. ±5 % o.r.

# Influence of ambient temperature

# **Current output**

Temperature coefficient	Max. 1 μA/°C
-------------------------	--------------


#### Pulse/frequency output

Temperature coefficient	No additional effect. Included in accuracy.
-------------------------	---

# Installation

No special measures such as supports etc. are necessary. External forces are absorbed by the construction of the device.

# Mounting location




A0029343

Preferably install the sensor in an ascending pipe, and ensure a sufficient distance to the next pipe elbow:  $h \ge 2 \times DN$ .



Distance  $h \ge 2 \times DN$  not necessary with order code for "Design", option C, H, I.




A003301

 $\blacksquare$  26 Installation of the sensor after a control valve is not recommended

1 Control valve

# Installation in down pipes

Install a siphon with a vent valve downstream of the sensor in down pipes whose length h  $\geq$  5 m (16.4 ft). This precaution is to avoid low pressure and the consequent risk of damage to the measuring tube. This measure also prevents the system losing prime.




■ 27 Installation in a down pipe

- 1 Vent valve
- 2 Pipe siphon
- h Length of down pipe


# Installation in partially filled pipes

A partially filled pipe with a gradient necessitates a drain-type configuration.

No inlet runs necessary with order code for "Design", option C, H, I



# For heavy sensors DN ≥ 350 (14")



A0016276

# Orientation

The direction of the arrow on the sensor nameplate helps you to install the sensor according to the flow direction (direction of medium flow through the piping).


	Orientatio	n	Recommendation
A	Vertical orientation	A0015591	
В	Horizontal orientation, transmitter at top	A0015589	<b>√ √</b> 1)

	Orientation							
С	Horizontal orientation, transmitter at bottom	A0015590	(4) (2) 3) (4)					
D	Horizontal orientation, transmitter at side	A0015592	×					

- 1) Applications with low process temperatures may decrease the ambient temperature. To maintain the minimum ambient temperature for the transmitter, this orientation is recommended.
- Applications with high process temperatures may increase the ambient temperature. To maintain the maximum ambient temperature for the transmitter, this orientation is recommended.
- 3) To prevent the electronics module from overheating in the case of a sharp rise in temperature (e.g. CIP or SIP processes), install the device with the transmitter component pointing downwards.
- With the empty pipe detection function switched on: empty pipe detection only works if the transmitter housing is pointing upwards.

#### Horizontal

- Ideally, the measuring electrode plane should be horizontal. This prevents brief insulation of the measuring electrodes by entrained air bubbles.
- Empty pipe detection only works if the transmitter housing is pointing upwards as otherwise there
  is no guarantee that the empty pipe detection function will actually respond to a partially filled or
  empty measuring tube.




A0029344

- 1 EPD electrode for empty pipe detection
- 2 Measuring electrodes for signal detection
- 3 Reference electrode for potential equalization

# Inlet and outlet runs

If possible, install the sensor upstream from fittings such as valves, T-pieces or elbows.

Observe the following inlet and outlet runs to comply with accuracy specifications:



A0028997


For sensors with the order code for "Design", option C, H, I, no inlet or outlet runs need to be taken into account.

# **Adapters**

Suitable adapters to DIN EN 545 (double-flange reducers) can be used to install the sensor in larger-diameter pipes. The resultant increase in the rate of flow improves measuring accuracy with very slow-moving fluids.


The nomogram shown here can be used to calculate the pressure loss caused by reducers and expanders:

- Calculate the ratio of the diameters d/D.
- From the nomogram read off the pressure loss as a function of flow velocity (downstream from the reduction) and the d/D ratio.
- The nomogram only applies to liquids with a viscosity similar to that of water.



# Special mounting instructions

# Protective cover



# **Environment**

# Ambient temperature range

Transmitter	Standard: -40 to +60 °C (-40 to +140 °F)
Local display	-20 to $+60$ °C ( $-4$ to $+140$ °F), the readability of the display may be impaired at temperatures outside the temperature range.
Sensor	<ul> <li>Process connection material, carbon steel:         <ul> <li>10 to +60 °C (+14 to +140 °F)</li> </ul> </li> <li>Process connection material, stainless steel:         <ul> <li>40 to +60 °C (-40 to +140 °F)</li> </ul> </li> </ul>
Liner	Do not exceed or fall below the permitted temperature range of the liner .

If operating outdoors:

- Install the measuring device in a shady location.
- Avoid direct sunlight, particularly in warm climatic regions.
- Avoid direct exposure to weather conditions.



You can order a weather protection cover from Endress+Hauser.  $\rightarrow \blacksquare 107$ .

# Storage temperature

The storage temperature corresponds to the operating temperature range of the transmitter and the sensor  $\rightarrow \blacksquare 54$ .

- Protect the measuring device against direct sunlight during storage in order to avoid unacceptably high surface temperatures.
- Select a storage location where moisture cannot collect in the measuring device as fungus or bacteria infestation can damage the liner.
- If protection caps or protective covers are mounted these should never be removed before installing the measuring device.

#### Degree of protection

#### Measuring device

- As standard: IP66/67, type 4X enclosure
- When housing is open: IP20, type 1 enclosure
- Display module: IP20, type 1 enclosure

#### External WLAN antenna

**IP67** 

#### Vibration- and shockresistance

#### Vibration sinusoidal, in accordance with IEC 60068-2-6

- 2 to 8.4 Hz, 3.5 mm peak
- 8.4 to 2000 Hz, 1 g peak

#### Vibration broad-band random, according to IEC 60068-2-64

- 10 to 200 Hz, 0.003 q<sup>2</sup>/Hz
- 200 to 2000 Hz, 0.001 g<sup>2</sup>/Hz
- Total: 1.54 g rms

#### Shock half-sine, according to IEC 60068-2-27

6 ms 30 q


#### Rough handling shocks according to IEC 60068-2-31

#### Mechanical load

- Protect the transmitter housing against mechanical effects, such as shock or impact; the use of the remote version is sometimes preferable.
- Never use the transmitter housing as a ladder or climbing aid.

# Electromagnetic compatibility (EMC)

- As per IEC/EN 61326 and NAMUR Recommendation 21 (NE 21)
- Device version with PROFIBUS DP: Complies with emission limits for industry as per EN 50170 Volume 2, IEC 61784
  - The following applies for PROFIBUS DP: If baud rates > 1.5 MBaud, an EMC cable entry must be used and the cable shield must continue as far as the terminal wherever possible.




Details are provided in the Declaration of Conformity.

# **Process**

#### Medium temperature range

- 0 to +80 °C (+32 to +176 °F) for hard rubber, DN 50 to 2400 (2 to 90")
- -20 to +50 °C (-4 to +122 °F) for polyurethane, DN 25 to 1200 (1 to 48")
- -20 to +90 °C (-4 to +194 °F) for PTFE, DN 25 to 300 (1 to 12")



- $T_A$  Ambient temperature range
- *T<sub>F</sub>* Medium temperature
- Colored area: the ambient temperature range of -10 to -40 °C (+14 to -40 °F) and the fluid temperature range of -10 to -20 °C (+14 to -4 °F) applies to stainless flanges only


# Conductivity

 $\geq$  5 µS/cm for liquids in general.

# Pressure-temperature ratings

The following pressure/temperature diagrams apply to all pressure-bearing parts of the device and not just the process connection. The diagrams show the maximum permissible medium pressure depending on the specific medium temperature.

# Process connection: fixed flange according to EN 1092-1 (DIN 2501)




■ 28 Process connection material: stainless steel ( $-20 \,^{\circ}\text{C}$  ( $-4 \,^{\circ}\text{F}$ )); carbon steel ( $-10 \,^{\circ}\text{C}$  ( $14 \,^{\circ}\text{F}$ ))

# Process connection: fixed flange according to ASME B16.5




■ 29 Process connection material: stainless steel




**■** 30 Process connection material: carbon steel

# Process connection: fixed flange according to JIS B2220




■ 31 Process connection material: stainless steel (-20 °C (-4 °F)); carbon steel (-10 °C (14 °F))

# Process connection: fixed flange according to AWWA C207




■ 32 Process connection material: carbon steel

# Process connection: fixed flange according to AS 2129



■ 33 Process connection material: carbon steel

# Process connection: fixed flange according to AS 4087




■ 34 Process connection material: carbon steel

58 Endress+Hauser

A0038128-EN

# Process connection: lap joint flange/lap joint flange, stamped plate according to EN 1092-1 (DIN 2501) and ASME B16.5; DN 25 to 300 (1 to 12")



A0038

- 35 Process connection material: stainless steel ( $-20 \,^{\circ}\text{C}$  ( $-4 \,^{\circ}\text{F}$ )); carbon steel ( $-10 \,^{\circ}\text{C}$  ( $14 \,^{\circ}\text{F}$ ))
- 1 Lap joint flange PN16/ Class150
- 2 Lap joint flange, stamped plate PN10, lap joint flange PN10

# Pressure tightness

Liner: hard rubber

Nominal	diameter	Limit values for absolute pressure in [mbar] ([psi]) for medium temperatures:				
[mm] [in]		+25 °C (+77 °F) +50 °C (+122 °F)		+80 °C (+176 °F)		
50 2400	50 2400 2 90		0 (0)	0 (0)		

Liner: polyurethane

Nominal diameter		Limit values for absolute pressure in [mbar] ([psi]) for medium temperatures				
[mm]	[in]	+25 °C (+77 °F)	+50 °C (+122 °F)			
25 1200	1 48	0 (0)	0 (0)			

Liner: PTFE

Nominal diameter		Limit values for absolute pressure in [1	mbar] ([psi]) for medium temperatures:			
[mm]	[in]	+25 °C (+77 °F)	+90 °C (+194 °F)			
25	1	0 (0)	0 (0)			
40	2	0 (0)	0 (0)			
50	2	0 (0)	0 (0)			
65	2 1/2	0 (0)	40 (0.58)			
80	3	0 (0)	40 (0.58)			
100	4	0 (0) 135 (2.0)				
125	5	135 (2.0)	240 (3.5)			
150	6	135 (2.0)	240 (3.5)			
200	8	200 (2.9)	290 (4.2)			
250	10	330 (4.8)	400 (5.8)			
300	12	400 (5.8)	500 (7.3)			


#### Flow limit

The diameter of the pipe and the flow rate determine the nominal diameter of the sensor. The optimum velocity of flow is between 2 to 3 m/s (6.56 to 9.84 ft/s). Also match the velocity of flow (v) to the physical properties of the fluid:


- v < 2 m/s (6.56 ft/s): for abrasive fluids (e.g. potter's clay, lime milk, ore slurry)
- v > 2 m/s (6.56 ft/s): for fluids producing buildup (e.g. wastewater sludge)
- A necessary increase in the flow velocity can be achieved by reducing the sensor nominal diameter.
- For an overview of the full scale values for the measuring range, see the "Measuring range" section

#### Pressure loss

- No pressure loss occurs if the sensor is installed in a pipe with the same nominal diameter.




■ 36 Pressure loss DN 50 to 80 (2 to 3") for order code for "Design", option C "fixed flange, without inlet/outlet runs"



■ 37 Pressure loss DN 100 to 300 (4 to 12") for order code for "Design", option C "fixed flange, without inlet/ outlet runs"

# System pressure



Never install the sensor on the pump suction side in order to avoid the risk of low pressure, and thus damage to the liner.

Furthermore, install pulse dampers if reciprocating, diaphragm or peristaltic pumps are used.



- Information on the liner's resistance to partial vacuum  $\rightarrow$   $\stackrel{\triangle}{=}$  59
- Information on the shock resistance of the measuring system
- Information on the vibration resistance of the measuring system


#### Thermal insulation

If process fluids are very hot, it is necessary to insulate pipes in order to reduce energy loss and to prevent individuals from accidentally coming into contact with hot pipes. Please observe the applicable standards and guidelines for insulating pipes.


# **WARNING**

#### Electronics overheating on account of thermal insulation!

► The housing support is used for heat dissipation and must be completely free (i.e. uncovered). At the very maximum, the sensor insulation may extend as far as the upper edge of the two sensor half-shells.



Vibrations



■ 38 Measures to prevent vibration of the device

In the event of very strong vibrations, the pipe and sensor must be supported and fixed.

It is also advisable to mount the sensor and transmitter separately.


i

- Information on the shock resistance of the measuring system
- Information on the vibration resistance of the measuring system

# Mechanical construction

# Dimensions in SI units

# **Compact version**



Order code for "Housing", option A "Aluminum, coated"

A 1)	B 1) C		G <sup>2)</sup>	Н	I 2)	
[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	
169	68	101	200	59	141	

- 1) Depending on the cable gland used: values up to + 30 mm
- 2) For version without local display: values 30 mm

Order code for "Housing", option A "Aluminum, coated"; Ex d or XP

A 1)	В	B C G <sup>2)</sup>		Н	I	
[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	
188	85	103	217	58	148	

- 1) Depending on the cable gland used: values up to  $\pm$  30 mm
- 2) For version without local display: values 49 mm

DN 25 to 300 (1 to 12"): sensor with aluminum half-shell housing

DN	I		Order code for "Design"								L
		Options D, E, H, I			Option C						
		D 1)	E 1) 2) 3)	F 1) 2) 3)	M 1)	D 1)	E 1) 2) 3)	F <sup>1)2)3)</sup>	M 1)		
[mm]	[in]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]
25	1	84	271	355	120	-	-	-	-	4)	200
32	-	84	271	355	120	-	-	-	-	4)	200
40	1 ½	84	271	355	120	-	-	-	-	4)	200
50	2	84	271	355	120	84	271	355	120	4)	200
65	-	109	296	405	180	84	271	355	120	4)	200
80	3	109	296	405	180	84	271	355	120	4)	200
100	4	109	296	405	180	109	296	405	180	4)	250
125	-	150	336	486	260	109	296	405	180	4)	250
150	6	150	336	486	260	109	296	405	180	4)	300

62

DN	ſ		Order code for "Design"							К	L
			Options D, E, H, I				Option C				
		D 1)	E 1) 2) 3)	F 1) 2) 3)	M 1)	D 1)	E 1) 2) 3)	F 1) 2) 3)	M 1)		
[mm]	[in]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]
200	8	180	361	541	324	150	336	486	260	4)	350
250	10	205	386	591	400	150	336	486	260	4)	450
300	12	230	411	641	460	180	361	541	324	4)	500

- 1) The dimensions are reference values. They may vary depending on the pressure rating, design and order option.
- 2) With the order code for "Sensor option", option CG "Sensor extended neck for insulation": values + 110 mm
- 3) With Ex d or XP versions: values + 30 mm
- 4) Depends on the liner→ 🖺 87

# DN 350 to 900 (14 to 36")

				Ord	er code	for "Desi	ign"					
			Option	ns E, F			Opti	on G				
Di	N	D 1)	E 1) 2)	F 1) 2) 3)	M 1)	D 1)	E 1) 2)	F 1) 2)	M 1)	К	]	L
[mm]	[in]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[m	m]
350	14	245	482	728	490	-	-	-	-	4)	55	50
375	15	271	508	779	542	-	-	-	-	4)	55	50
400	16	271	508	779	542	-	-	-	-	4)	60	00
450	18	299	536	835	598	333	520	853	666	4)	600 <sup>5)</sup>	650 <sup>6)</sup>
500	20	324	561	885	648	359	545	904	717	4)	600 <sup>5)</sup>	650 <sup>6)</sup>
600	24	365	612	977	730	411	598	1009	821	4)	600 <sup>5)</sup>	780 <sup>6)</sup>
700	28	430	673	1103	860	512	700	1212	1024	4)	700 <sup>5)</sup>	910 <sup>6)</sup>
750	30	467	711	1178	934	512	700	1212	1024	4)	700 <sup>5)</sup>	910 <sup>6)</sup>
800	32	486	730	1216	972	534	720	1254	1065	4)	800 <sup>5)</sup>	1040 <sup>6)</sup>
900	36	536	780	1316	1072	610	797	1407	1218	4)	900 <sup>5)</sup>	1170 <sup>6)</sup>

- 1) The dimensions are reference values. They may be different than indicated, depending on the pressure rating, design and order code.
- 2) With order code for "Sensor option", option CG "Sensor extended neck for insulation": values + 110 mm
- 3) With Ex d or XP versions: values + 30 mm
- 4) Depends on the liner→ 🖺 87
- 5) Order code for "Design", option F "Fixed flange, short installation length"
- 6) Order code for "Design", option G "Fixed flange, long installation length"

# DN 1000 to 2400 (40 to 90")

D	N	D 1)	E 1) 2) 3)	F 1) 2) 3)	K	I	L			
[mm]	[in]	[mm]	[mm]	[mm]	[mm]	[mm]		[mm]		[mm]
1000	40	686	873	1559	4)	1000 5)	1300 <sup>6)</sup>	1370		
-	42	712	898	1610	4)	1050 <sup>5)</sup>	1365 <sup>6)</sup>	1420		
1200	48	811	999	1810	4)	1 200 <sup>5)</sup>	1560 <sup>6)</sup>	1620		
_	54	912	1099	2011	4)	1350 <sup>5)</sup>	1755 <sup>6)</sup>	1820		
1400	-	987	1174	2 2 6 1	4)	1 400 <sup>5)</sup>	1820 <sup>6)</sup>	1970		
-	60	1011	1 198	2 2 0 9	4)	1500 <sup>5)</sup>	1950 <sup>6)</sup>	2018		
1600	-	1056	1243	2 299	4)	1600 <sup>5)</sup>	2 080 <sup>6)</sup>	2 108		


D	N	D 1)	E 1) 2) 3)	F 1) 2) 3)	К	]	L	M 1)		
[mm]	[in]	[mm]	[mm]	[mm]	[mm]	[mm]		[mm]		[mm]
_	66	1093	1279	2 372	4)	1650 <sup>5)</sup>	2 145 <sup>6)</sup>	2 180		
1800	72	1 188	1374	2 562	4)	1800 <sup>5)</sup>	2340 <sup>6)</sup>	2370		
_	78	1238	1424	2 662	4)	2 000 5)	2 600 <sup>6)</sup>	2 470		
2000	-	1238	1424	2 6 6 2	4)	2 000 5)	2 600 <sup>6)</sup>	2 470		
_	84	1238	1424	2 662	4)	2 20	)0 <sup>5)</sup>	2 470		
2200	-	1227	1416	2 643	4)	2 20	)0 <sup>5)</sup>	2 454		
_	90	1227	1416	2 643	4)	2 40	)0 <sup>5)</sup>	2 454		
2400	_	1332	1521	2853	4)	2 40	)0 <sup>5)</sup>	2 6 6 4		

- The dimensions are reference values. They may be different than indicated, depending on the pressure 1) rating, design and order code.
- With order code for "Sensor option", option CG "Sensor extended neck for insulation": values + 110 mm With Ex d or XP versions: values + 30 mm Depends on the liner → 18 87 2)
- 3)

- 4) 5) 6) Order code for "Design", option F "Fixed flange, short installation length" Order code for "Design", option G "Fixed flange, long installation length"

# Flange connections

# Fixed flange



Carbon steel:	order code for "P	rocess connectio	<b>2501 / DIN 2512N)</b> on", option <b>D1K</b> tion", option <b>D1S</b>	: PN 6		
DN	A	В	С	D	E	L
[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]
350	490	445	12 × Ø22	22	1)	2)
400	540	495	16 × Ø22	22		
450	595	565	20 × Ø26	26		
500	645	600	20 × Ø22	24		
600	755	705	20 × Ø26	30		
700	860	810	24 × Ø26	30		
800	975	920	24 × Ø30	30		
900	1075	1020	24 × Ø30	34		
1000	1175	1120	28 × Ø30	38		
1200	1405	1340	32 × Ø33	42		
1400	1630	1560	36 × Ø36	56		
1600	1830	1760	40 × Ø36	63		
1800	2 045	1970	44 × Ø39	69		
2000	2 2 6 5	2 180	48 × Ø42	74	1	
2200	2 475	2 390	52 × Ø42	81	1	
2400	2 685	2 600	56 × Ø42	87	1	
	ness (flange): EN	N 1092-1 Form	B1 (DIN 2526 Form	C), Ra 6.3 to 12	2.5 µm	

1) 2)

	1		tion", option <b>D2S</b>			1
DN	A	В	С	D	E	L
[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]
200	340	295	8 × Ø22	26	1)	2)
250	395	350	12 × Ø22	28		
300	445	400	12 × Ø22	28		
350	505	460	16 × Ø22	26		
400	565	515	16 × Ø26	26		
450	615	565	20 × Ø26	26		
500	670	620	20 × Ø26	28		
600	780	725	20 × Ø30	30		
700	895	840	24 × Ø30	35		
800	1015	950	24 × Ø33	38		
900	1115	1050	28 × Ø33	38		
1000	1230	1160	28 × Ø36	44		
1200	1455	1380	32 × Ø39	55		
1400	1675	1590	36 × Ø42	65		
1600	1915	1820	40 × Ø48	75		
1800	2 1 1 5	2 020	44 × Ø48	85		
2000	2325	2 2 3 0	48 × Ø48	90		
2200	2 5 5 0	2 440	52 × Ø56	100		
2400	2760	2 650	56 × Ø56	110		

- 1) 2)

Carbon steel:	Flange in accordance with EN 1092-1 (DIN 2501 / DIN 2512N): PN 16 Carbon steel: order code for "Process connection", option D3K Stainless steel: order code for "Process connection", option D3S										
DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	L [mm]					
65	185	145	8 × Ø18	20	1)	2)					
80	200	160	8 × Ø18	20							
100	220	180	8 × Ø18	22							
125	250	210	8 × Ø18	24							
150	285	240	8 × Ø22	24							
200	340	295	12 × Ø22	26							
250	405	355	12 × Ø26	32							
300	460	410	12 × Ø26	32							
350	520	470	16 × Ø26	30							
400	580	525	16 × Ø30	32							
450	640	585	20 × Ø30	34							
500	715	650	20 × Ø33	36							

Carbon steel:	Flange in accordance with EN 1092-1 (DIN 2501 / DIN 2512N): PN 16 Carbon steel: order code for "Process connection", option D3K Stainless steel: order code for "Process connection", option D3S										
DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	L [mm]					
600	840	770	20 × Ø36	40							
700	910	840	24 × Ø36	40							
800	1025	950	24 × Ø39	41							
900	1125	1050	28 × Ø39	48							
1000	1255	1170	28 × Ø42	59							
1200	1485	1390	32 × Ø48	78							
1400	1685	1590	36 × Ø48	84							
1600	1930	1820	40 × Ø56	102							
1800	2 130	2 020	44 × Ø56	110							
2000 2345 2230 48 × Ø62 124											
Surface roughr	ness (flange): EN	N 1092-1 Form	B1 (DIN 2526 Form	C), Ra 6.3 to 12	5 μm						

- 1) Depends on the liner→ 🖺 87

Carbon steel:	Flange in accordance with EN 1092-1 (DIN 2501 / DIN 2512N): PN 25 Carbon steel: order code for "Process connection", option D4K Stainless steel: order code for "Process connection", option D4S										
DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	L [mm]					
200	360	310	12 × Ø26	32	1)	2)					
250	425	370	12 × Ø30	36							
300	485	430	16 × Ø30	40							
350	555	490	16 × Ø33	38							
400	620	550	16 × Ø36	40							
450	670	600	20 × Ø36	46							
500	730	660	20 × Ø36	48							
600	845	770	20 × Ø39	48							
700	960	875	24 × Ø42	50							
800	1085	990	24 × Ø48	53							
900	1185	1090	28 × Ø48	57							
1000 1320 1210 28 × Ø56 63											
Surface roughr	ness (flange): EN	l 1092-1 Form	B1 (DIN 2526 Form	C), Ra 6.3 to 12	2.5 µm						

- 1) Depends on the liner → 🖺 87
- 70 Total length is independent of the process connections. Length according to DVGW (German Technical and Scientific Association for Gas and Water)  $\Rightarrow \triangleq 62$

Carbon steel:	Flange in accordance with EN 1092-1 (DIN 2501 / DIN 2512N): PN 40 Carbon steel: order code for "Process connection", option D5K Stainless steel: order code for "Process connection", option D5S										
DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	L [mm]					
25	115	85	4 × Ø14	16	1)	2)					
32	140	100	4 × Ø18	18							
40	150	110	4 × Ø18	18							
50	165	125	4 × Ø18	20							
65	185	145	8 × Ø18	24							
80	200	160	8 × Ø18	26							
100	235	190	8 × Ø22	26							
125	270	220	8 × Ø26	28							
150	300	250	8 × Ø26	30							
Surface roughn	ness (flange): EN	I 1092-1 Form I	B1 (DIN 2526 Form	n C), Ra 6.3 to 1	2.5 µm						

- 1) 2)

Carbon steel	Flange according to ASME B16.5, Class 150 Carbon steel: order code for "Process connection", option A1K Stainless steel: order code for "Process connection", option A1S											
D	N	Α	В	С	D	E	L					
[mm]	[in]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]					
25	1	108	79.2	4 × Ø16	12.6	1)	2)					
40	1 ½	127	98.6	4 × Ø16	15.9							
50	2	152.4	120.7	4 × Ø19.1	17.5							
80	3	190.5	152.4	4 × Ø19.1	22.3							
100	4	228.6	190.5	8 × Ø19.1	22.3							
150	6	279.4	241.3	8 × Ø22.4	23.8							
200	8	342.9	298.5	8 × Ø22.4	26.8							
250	10	406.4	362	12 × Ø25.4	29.6							
300	12	482.6	431.8	12 × Ø25.4	30.2							
350	14	535	476.3	12 × Ø28.6	35.4							
400	16	595	539.8	16 × Ø28.6	37							
450	18	635	577.9	16 × Ø31.8	40.1							
500	20	700	635	20 × Ø31.8	43.3							
600	24	815	749.3	20 × Ø34.9	48.1							
Surface rough	nness (flange):	Ra 6.3 to 12.5	μm									

- 1) Depends on the liner  $\rightarrow$   $\blacksquare$  87
- 2)

Carbon steel	Flange according to ASME B16.5, Class 300 Carbon steel: order code for "Process connection", option A2K Stainless steel: order code for "Process connection", option A2S											
D	N	A	В	С	D	E	L					
[mm]	[in]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]					
25	1	123.9	88.9	4 × Ø19.1	15.9	1)	2)					
40	1 ½	155.4	114.3	4 × Ø22.4	19							
50	2	165.1	127	8 × Ø19.1	20.8							
80	3	209.6	168.1	8 × Ø22.4	26.8							
100	4	254	200.2	8 × Ø22.4	30.2							
150 6 317.5 269.7 12 × Ø22.4 35												
Surface rough	nness (flange):	Ra 6.3 to 12.5	μm									

- Depends on the liner  $\rightarrow$   $\ \ \,$  87
- 1) 2)  $\begin{tabular}{ll} \hline \textbf{Total length is independent of the process connections. Length according to DVGW (German Technical and the process connections).} \\ \hline \end{tabular}$ Scientific Association for Gas and Water) → 🖺 62

Carbon steel:	Flange according to JIS B2220, 10K Carbon steel: order code for "Process connection", option N3K Stainless steel: order code for "Process connection", option N3S											
DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	L [mm]						
50	155	120	4 × Ø19	16	1)	2)						
65	175	140	4 × Ø19	18								
80	185	150	8 × Ø19	18								
100	210	175	8 × Ø19	18								
125	250	210	8 × Ø23	20								
150	280	240	8 × Ø23	22								
200	330	290	12 × Ø23	22								
250	400	355	12 × Ø25	24								
300	445	400	16 × Ø25	24								
Surface roughi	ness (flange): R	a 6.3 to 12.5 µr	n	1								

- Depends on the liner  $\rightarrow$   $\ \ \,$  87
- 1) 2) Total length is independent of the process connections. Length according to DVGW (German Technical and Scientific Association for Gas and Water)  $\rightarrow \blacksquare 62$

Carbon steel:	Flange according to JIS B2220, 20K Carbon steel: order code for "Process connection", option N4K Stainless steel: order code for "Process connection", option N4S												
DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	L [mm]							
25	125	90	4 × Ø19	16	1)	2)							
32	135	100	4 × Ø19	18									
40	140	105	4 × Ø19	18									
50	155	120	8 × Ø19	18									
65	175	140	8 × Ø19	20									
80	200	160	8 × Ø23	22									
100	225	185	8 × Ø23	24									

Carbon steel:	Flange according to JIS B2220, 20K Carbon steel: order code for "Process connection", option N4K Stainless steel: order code for "Process connection", option N4S											
DN         A         B         C         D         E         E           [mm]         [mm]         [mm]         [mm]         [mm]         [mm]												
125	270	225	8 × Ø25	26								
150	305	260	12 × Ø25	28								
200	350	305	12 × Ø25	30								
250	430	380	12 × Ø27	34								
300 480 430 16 × Ø27 36												
Surface rough	ness (flange): R	a 6.3 to 12.5 µr	n									

- 1)
- Total length is independent of the process connections. Length according to DVGW (German Technical and 2)

Flange according to AWWA, Class D Order code for "Process connection", option W1K											
D	N	A	В	С	D	E	L				
[mm]	[in]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]				
700	28	927	863.6	28 × Ø35	33.4	1)	2)				
750	30	984	914.4	28 × Ø35	35						
800	32	1060	977.9	28 × Ø42	38.1						
900	36	1168	1085.9	32 × Ø42	41.3						
1000	40	1289	1200.2	36 × Ø42	41.3						
-	42	1346	1257.3	36 × Ø42	44.5						
1200	48	1511	1422.4	44 × Ø42	47.7						
-	54	1683	1593.9	44 × Ø48	54						
_	60	1855	1759	52 × Ø48	57.2						
_	66	2 032	1930.4	52 × Ø48	63.5						
1800	72	2 197	2 095.5	60 × Ø48	66.7						
-	78	2 362	2 2 6 0 . 6	64 × Ø54	69.9						
_	84	2 535	2 425.7	64 × Ø54	73.1						
_	90	2 705	2717.8	68 × Ø60	76.2						
Surface rough	nness (flange):	Ra 6.3 to 12.5	5 μm								

- 1)
- Scientific Association for Gas and Water)  $\rightarrow \triangleq 62$

	Flange according to AS 2129, Tab. E Order code for "Process connection", option M2K												
DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	L [mm]							
80	185	146	4 × Ø18	12	1)	2)							
100	215	178	8 × Ø18	13									
150	280	235	8 × Ø22	17									
200	335	292	8 × Ø22	19									
250	405	356	12 × Ø22	22									

Flange according to AS 2129, Tab. E Order code for "Process connection", option M2K											
DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	L [mm]					
300	455	406	12 × Ø26	25							
350	525	470	12 × Ø26	30							
400	580	521	12 × Ø26	32							
450	640	584	16 × Ø26	35							
500	705	641	16 × Ø26	38							
600	825	756	16 × Ø33	48							
700	910	845	20 × Ø33	51							
750	995	927	20 × Ø36	54							
800	1060	984	20 × Ø36	54							
900	1175	1092	24 × Ø36	64							
1000	1255	1175	24 × Ø39	67							
1200	1490	1410	32 × Ø39	79							
	ness (flange): R	a 6.3 to 12.5 μι	n	1		1					


- 1)
- 2)

	ling to AS 4087		ЗК			
DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	L [mm]
80	185	146	4 × Ø18	12	1)	2)
100	215	178	4 × Ø18	13		
150	280	235	8 × Ø18	13		
200	335	292	8 × Ø18	19		
250	405	356	8 × Ø22	19		
300	455	406	12 × Ø22	23		
350	525	470	12 × Ø26	30		
375	550	495	12 × Ø26	30		
400	580	521	12 × Ø26	32		
450	640	584	12 × Ø26	30		
500	705	641	16 × Ø26	38		
600	825	756	16 × Ø30	48		
700	910	845	20 × Ø30	56		
750	995	927	20 × Ø33	56		
800	1060	984	20 × Ø36	56		
900	1175	1092	24 × Ø36	66		
1000	1255	1175	24 × Ø36	66		

Flange according to AS 4087, PN 16 Order code for "Process connection", option M3K										
DN         A         B         C         D         E         L           [mm]         [mm]         [mm]         [mm]         [mm]										
1200 1490 1410 32 × Ø36 76										
Surface rough	Surface roughness (flange): Ra 6.3 to 12.5 µm									

- 1) Depends on the liner  $\rightarrow$   $\bigcirc$  87

# Lap joint flange



Lap joint flange in accordance with EN 1092-1 (DIN 2501 / DIN 2512N): PN 10 Carbon steel: order code for "Process connection", option D22 Stainless steel: order code for "Process connection", option D24											
DN											
[mm]	[mm] [in] [mm] [mm] [mm] [mm] [mm] [mm]										
200	8	340	295	8 × Ø22	24	264	1)	2)			
250 10 395 350 12 × Ø22 26 317											
300 12 445 400 12 × Ø22 26 367											
Surface rou	ghness (flan	ge): Ra 6.3 to	o 12.5 µm			·					

- 1) Depends on the liner  $\rightarrow$   $\bigcirc$  87

Carbon ste	Lap joint flange in accordance with EN 1092-1 (DIN 2501 / DIN 2512N): PN 16 Carbon steel: order code for "Process connection", option D32 Stainless steel: order code for "Process connection", option D34												
D	DN A B C D E												
[mm]	[in]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]					
25	1	115	85	4 × Ø14	16	49	1)	2)					
32	-	140	100	4 × Ø18	18	65							
40	1 ½	150	110	4 × Ø18	18	71							
50	2	165	125	4 × Ø18	20	88							
65	-	185	145	8 × Ø18	20	103							
80	3	200	160	8 × Ø18	20	120							
100	4	220	180	8 × Ø18	22	148							
125	-	250	210	8 × Ø18	22	177							


Carbon ste	Lap joint flange in accordance with EN 1092-1 (DIN 2501 / DIN 2512N): PN 16 Carbon steel: order code for "Process connection", option D32 Stainless steel: order code for "Process connection", option D34													
DN A B C D E F L														
[mm]	[in]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]						
150	6	285	240	8 × Ø22	24	209								
200	8	340	295	12 × Ø22	26	264								
250	10	405	355	12 × Ø26	29	317								
300	300 12 460 410 12 × Ø26 32 367													
Surface rou	Surface roughness (flange): Ra 6.3 to 12.5 μm													

- 1) Depends on the liner→ 🖺 87

Carbon ste	Lap joint flange according to ASME B16.5, Class 150 Carbon steel: order code for "Process connection", option A12 Stainless steel: order code for "Process connection", option A14														
D	N	A	В	С	D	E	F	L							
[mm]	[in]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]							
25	1	110	80	4 × Ø16	14	49	1)	2)							
40	1 1/2	125	98	4 × Ø16	17.5	71									
50	2	150	121	4 × Ø19	19	88									
80	3	190	152	4 × Ø19	24	120									
100	4	230	190	8 × Ø19	24	148									
150	6	280	241	8 × Ø23	25	209									
200	8	345	298	8 × Ø23	29	264									
250	10	405	362	12 × Ø25	30	317									
300 12 485 432 12 × Ø25 32 378															
Surface rou	Surface roughness (flange): Ra 6.3 to 12.5 μm														

- 1) Depends on the liner  $\rightarrow$   $\bigcirc$  87
- 2) Total length is independent of the process connections. Length according to DVGW (German Technical and Scientific Association for Gas and Water)  $\Rightarrow \triangleq 62$

# Lap joint flange, stamped plate



Endress+Hauser 73

A003786

Carbon stee	Lap joint flange, stamped plate in accordance with EN 1092-1 (DIN 2501 / DIN 2512N): PN 10 Carbon steel: order code for "Process connection", option D21 Stainless steel: order code for "Process connection", option D23													
DN	A	В	С	D	E	F	L							
[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]							
25	115	85	4 x Ø13.5	16.5	49	1)	2)							
32	140	100	4 x Ø17.5	17	65									
40	150	110	4 x Ø17.5	16.5	71									
50	165	125	4 x Ø17.5	18.5	88									
65	185	145	4 x Ø17.5	20	103									
80	200	160	8 x Ø17.5	23.5	120									
100	220	180	8 x Ø17.5	24.5	148									
125	250	210	8 x Ø17.5	24	177									
150	285	240	8 x Ø21.5	25	209									
200	340	295	8 x Ø21.5	27.5	264									
250	405	350	12 x Ø21.5	30.5	317									
300	445	400	12 x Ø21.5	34.5	367									
Surface roug	hness (flange)	: Ra 6.3 to 12	.5 μm											

- 1) Depends on the liner → 🖺 87
- 2) Total length is independent of the process connections. Length according to DVGW (German Technical and Scientific Association for Gas and Water) → 🖺 62


# Accessories

External WLAN antenna

i

The external WLAN antenna is not suitable for use in hygienic applications.


External WLAN antenna mounted on device



■ 39 Engineering unit mm (in)


External WLAN antenna mounted with cable

The external WLAN antenna can be mounted separately from the transmitter if the transmission/reception conditions at the transmitter mounting location are poor.



■ 40 Engineering unit mm (in)

# *Ground disks for flange connections*



D	N	Pressure rating		A	1	В	]	D	1	Н
[mm]	[inch]		[mm]	[inch]	[mm]	[inch]	[mm]	[inch]	[mm]	[inch]
25	1"	1)	26	1.02	62	2.44	77.5	3.05	87.5	3.44
32	1 1/4"	1)	35	1.38	80	3.15	87.5	3.44	94.5	3.72
40	1 1/2"	1)	41	1.61	82	3.23	101	3.98	103	4.06
50	2"	1)	52	2.05	101	3.98	115.5	4.55	108	4.25
65	2 1/2"	1)	68	2.68	121	4.76	131.5	5.18	118	4.65
80	3"	1)	80	3.15	131	5.16	154.5	6.08	135	5.31
100	4"	1)	104	4.09	156	6.14	186.5	7.34	153	6.02
125	5"	1)	130	5.12	187	7.36	206.5	8.13	160	6.30
150	6"	1)	158	6.22	217	8.54	256	10.08	184	7.24
200	8"	1)	206	8.11	267	10.51	288	11.34	205	8.07
250	10"	1)	260	10.24	328	12.91	359	14.13	240	9.45
300	12"	PN 10 PN 16 Cl. 150	312	12.28	375	14.76	413	16.26	273	10.75
300	12	PN 25 JIS 10K JIS 20K	310	12.20	375	14.76	404	15.91	268	10.55


DN		Pressure rating	A		]	В	]	D	Н	
[mm]	[inch]		[mm]	[inch]	[mm]	[inch]	[mm]	[inch]	[mm]	[inch]
		PN 6								
350	14"	PN 10	343	13.50	420	16.54	479	18.86	365	14.37
		PN 16								
375	15"	PN 16	393	15.5	461	18.2	523	20.6	395	15.6
		PN 6								
400	16"	PN 10	393	15.5	470	18.50	542	21.34	395	15.55
		PN 16								
		PN 6								
450	18"	PN 10	439	17.28	525	20.67	583	22.95	417	16.42
		PN 16	-							
		PN 6								
500	20"	PN 10	493	19.41	575	22.64	650	25.59	460	18.11
		PN 16								
		PN 6								
600	24"	PN 10	593	23.35	676	26.61	766	30.16	522	20.55
		PN 16								
		PN 6	697	27.44	-	-	786	30.94	460	18.11
700	2.01	PN10	693	27.28	-	-	813	32.01	480	18.9
700	28"	PN16	687	27.05	-	-	807	31.77	490	19.29
		Cl, D	693	27.28	-	-	832	32.76	494	19.45
750	30"	Cl, D	743	29.25	-	-	833	32.8	523	20.59
		PN 6	799	31.46	-	-	893	35.16	520	20.47
000	2.21	PN 10	795	31.3	-	-	920	36.22	540	21.26
800	32"	PN 16	789	31.06	-	-	914	35.98	550	21.65
		Cl, D	795	31.3	-	-	940	37.01	561	22.09
		PN 6	897	35.31	-	-	993	39.09	570	22.44
000	26"	PN 10	893	35.16	-	-	1020	40.16	590	23.23
900	36"	PN 16	886	34.88	-	-	1014	39.92	595	23.43
		Cl, D	893	35.16	-	-	1048	41.26	615	24.21
		PN 6	999	39.33	-	-	1093	43.03	620	24.41
1000	/ <sub>1</sub> OII	PN 10	995	39.17	-	-	1127	44.37	650	25.59
1000	40"	PN 16	988	38.9	-	-	1131	44.53	660	25.98
		Cl, D	995	39.17	-	-	1163	45.79	675	26.57
-	42"	PN 6	1044	41.1	-	-	1220	48.03	704	27.72
		PN 6	1203	47.36	-	-	1310	51.57	733	28.86
1200	/: O"	PN 10	1196	47.09	-	-	1344	52.91	760	29.92
1200	48"	PN 16	1196	47.09	-	-	1385	54.53	786	30.94
		Cl, D	1188	46.77	-	-	1345	52.95	775	30.51

<sup>1)</sup> In the case of DN 25 to 250, ground disks can be used for all the flange standards/pressure ratings which can be supplied in the standard version  $\frac{1}{2}$ 

76

# Dimensions in US units

# **Compact version**



Order code for "Housing", option A "Aluminum, coated"

A 1)	B 1)	С	G <sup>2)</sup>	Н	I 2)
[in]	[in]	[in]	[in]	[in]	[in]
6.65	2.68	3.98	7.87	2.32	5.55

- Depending on the cable gland used: values up to + 1.18 in For version without local display: values 1.18 in 1)
- 2)

Order code for "Housing", option A "Aluminum, coated"; Ex d or XP

A 1)	В	С	G <sup>2)</sup>	Н	I
[in]	[in]	[in]	[in]	[in]	[in]
7.4	3.35	4.06	8.54	2.28	5.83

- Depending on the cable gland used: values up to + 1.18 in 1)
- 2) For version without local display: values – 1.93 in

DN 25 to 300 (1 to 12"): sensor with aluminum half-shell housing

DN	Ī			Or	der code	for "Des	ign"			K	L
			Options	5 D, E, H, I			Opt	ion C			
		D 1)	E 1) 2) 3)	F 1) 2) 3)	M 1)	D 1)	E 1) 2) 3)	F 1) 2) 3)	M 1)		
[mm]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]
25	1	3.31	10.67	13.98	4.72	-	-	-	-	4)	7.87
32	-	3.31	10.67	13.98	4.72	-	-	-	-	4)	7.87
40	1 1/2	3.31	10.67	13.98	4.72	-	-	-	-	4)	7.87
50	2	3.31	10.67	13.98	4.72	3.31	10.67	13.98	4.72	4)	7.87
65	-	4.29	11.65	15.94	7.09	3.31	10.67	13.98	4.72	4)	7.87
80	3	4.29	11.65	15.94	7.09	3.31	10.67	13.98	4.72	4)	7.87
100	4	4.29	11.65	15.94	7.09	4.29	11.65	15.94	7.09	4)	9.84
125	-	5.91	13.23	19.13	10.24	4.29	11.65	15.94	7.09	4)	9.84
150	6	5.91	13.23	19.13	10.24	4.29	11.65	15.94	7.09	4)	11.81
200	8	7.09	14.21	21.3	12.76	5.91	13.23	19.13	10.24	4)	13.78

DN	ſ			Or	der code	for "Des	ign"			K	L
			Options	D, E, H, I			Opt	ion C			
		D 1)	$D^{(1)} \mid E^{(1)(2)(3)} \mid F^{(1)(2)(3)} \mid M^{(1)} \mid D^{(1)} \mid E^{(1)(2)(3)} \mid F^{(1)(2)(3)} \mid M^{(1)}$								
[mm]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]
250	10	8.07	15.2	23.27	15.75	5.91	13.23	19.13	10.24	4)	17.72
300	12	9.06	16.18	25.24	18.11	7.09	14.21	21.3	12.76	4)	19.69

- The dimensions are reference values. They may vary depending on the pressure rating, design and order option.
- 2) With the order code for "Sensor option", option CG "Sensor extended neck for insulation": values + 4.33 in
- 3) With Ex d or XP versions: values + 1.18 in
- 4) Depends on the liner → 🖺 87

# DN 350 to 900 (14 to 36")

				Ord	er code	for "Desi	ign"					
			Option	ns E, F			Opti	on G				
D	N	D 1)	E 1) 2)	F 1) 2)	M 1)	D 1)	E 1) 2)	F 1) 2)	M 1)	К	L	
[mm]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[i:	n]
350	14	9.65	18.98	28.66	19.29	-	-	-	-	4)	21	.65
375	15	10.67	20	30.67	21.34	-	-	-	-	4)	21	.65
400	16	10.67	20	30.67	21.34	-	-	-	-	4)	23	.62
450	18	11.77	21.1	32.87	23.54	13.11	20.47	33.58	26.22	4)	23.62 <sup>5)</sup>	25.59 <sup>6)</sup>
500	20	12.76	22.09	34.84	25.51	14.13	21.46	35.59	28.23	4)	23.62 <sup>5)</sup>	25.59 <sup>6)</sup>
600	24	14.37	24.09	38.46	28.74	16.18	23.54	39.72	32.32	4)	23.62 <sup>5)</sup>	30.71 <sup>6)</sup>
700	28	16.93	26.5	43.43	33.86	20.16	27.56	47.72	40.31	4)	27.56 <sup>5)</sup>	35.83 <sup>6)</sup>
750	30	18.39	27.99	46.38	36.77	20.16	27.56	47.72	40.31	4)	27.56 <sup>5)</sup>	35.83 <sup>6)</sup>
800	32	19.13	28.74	47.87	38.27	21.02	28.35	49.37	41.93	4)	31.5 <sup>5)</sup>	40.94 <sup>6)</sup>
900	36	21.1	30.71	51.81	42.2	24.02	31.38	55.39	47.95	4)	35.43 <sup>5)</sup>	46.06 <sup>6)</sup>

- 1) The dimensions are reference values. They may be different than indicated, depending on the pressure rating, design and order code.
- 2) With order code for "Sensor option", option CG "Sensor extended neck for insulation": values + 4.33 in
- 3) With Ex d or XP versions: values + 1.18 in
- 4) Depends on the liner → 🖺 87
- 5) Order code for "Design", option F "Fixed flange, short installation length"
- 6) Order code for "Design", option G "Fixed flange, long installation length"

# DN 1000 to 2400 (40 to 90")


D	N	D 1)	E 1) 2) 3)	F 1) 2) 3)	К	1	L	M 1)		
[mm]	[in]	[in]	[in]	[in]	[in]	[in]		[in]		[in]
1000	40	27.01	34.37	61.38	4)	39.37 <sup>5)</sup>	51.18 <sup>6)</sup>	53.94		
-	42	28.03	35.35	63.39	4)	41.34 <sup>5)</sup>	53.74 <sup>6)</sup>	55.91		
1200	48	31.93	39.33	71.26	4)	47.24 <sup>5)</sup>	61.42 <sup>6)</sup>	63.78		
_	54	35.91	43.27	79.17	4)	53.15 <sup>5)</sup>	69.09 <sup>6)</sup>	71.65		
1400	_	38.86	46.22	89.02	4)	55.12 <sup>5)</sup>	71.65 <sup>6)</sup>	77.56		
-	60	39.8	47.17	86.97	4)	59.06 <sup>5)</sup>	76.77 <sup>6)</sup>	79.45		
1600	-	41.57	48.94	90.51	4)	62.99 <sup>5)</sup>	81.89 <sup>6)</sup>	82.99		
-	66	43.03	50.35	93.39	4)	64.96 <sup>5)</sup>	84.45 <sup>6)</sup>	85.83		

D	N	D 1)	E 1) 2) 3)	F 1) 2) 3)	К	]	Ĺ	M 1)		
[mm]	[in]	[in]	[in]	[in]	[in]	[in]		[in]		[in]
1800	72	46.77	54.09	100.87	4)	70.87 <sup>5)</sup>	92.13 <sup>6)</sup>	93.31		
-	78	48.74	56.06	104.8	4)	78.74 <sup>5)</sup>	102.36 <sup>6)</sup>	97.24		
2000	-	48.74	56.06	104.8	4)	78.74 <sup>5)</sup>	102.36 <sup>6)</sup>	97.24		
_	84	48.74	56.06	104.8	4)	86.6	61 <sup>5)</sup>	97.24		
2200	-	48.31	55.75	104.06	4)	86.61 <sup>5)</sup>		96.61		
-	90	48.31	55.75	104.06	4)	94.49 <sup>5)</sup>		96.61		
2400	-	52.44	59.88	112.32	4)	94.49 <sup>5)</sup>		104.88		

- 1) The dimensions are reference values. They may be different than indicated, depending on the pressure rating, design and order code.
- 2) With order code for "Sensor option", option CG "Sensor extended neck for insulation": values + 4.33 in
- With Ex d or XP versions: values + 1.18 in
- 3) 4)
- Order code for "Design", option F "Fixed flange, short installation length"
- 5) 6) Order code for "Design", option G "Fixed flange, long installation length"

# Flange connections

# Fixed flange



D	N	Α	В		D	E	L
[mm]	[in]	[in]	[in]	[in]	[in]	[in]	[in]
25	1	4.25	3.12	4 × Ø0.63	0.5	1)	2)
40	1 1/2	5	3.88	4 × Ø0.63	0.63		
50	2	6	4.75	4 × Ø0.75	0.69	-	
80	3	7.5	6	4 × Ø0.75	0.88		
100	4	9	7.5	8 × Ø0.75	0.88		
150	6	11	9.5	8 × Ø0.88	0.94		
200	8	13.5	11.75	8 × Ø0.88	1.06		
250	10	16	14.25	12 × Ø1	1.17		
300	12	19	17	12 × Ø1	1.19		
350	14	21.06	18.75	12 × Ø1.13	1.39		
400	16	23.43	21.25	16 × Ø1.13	1.46		
450	18	25	22.75	16 × Ø1.25	1.58		
500	20	27.56	25	20 × Ø1.25	1.7		
600	24	32.09	29.5	20 × Ø1.37	1.89		

- 1) 2)

Flange according to ASME B16.5, Class 300 Carbon steel: order code for "Process connection", option A2K Stainless steel: order code for "Process connection", option A2S							
D	N	Α	В	С	D	E	L
[in]	[mm]	[in]	[in]	[in]	[in]	[in]	[in]
1	25	4.88	3.5	4 × Ø0.75	0.63	1)	2)
1 1/2	40	6.12	4.5	4 × Ø0.88	0.75		
2	50	6.5	5	8 × Ø0.75	0.82		


Flange according to ASME B16.5, Class 300 Carbon steel: order code for "Process connection", option A2K Stainless steel: order code for "Process connection", option A2S							
DN		A	В	С	D	E	L
[in]	[mm]	[in]	[in]	[in]	[in]	[in]	[in]
3	80	8.25	6.62	8 × Ø0.88	1.06		
4	100	10	7.88	8 × Ø0.88	1.19		
6	150	12.5	10.62	12 × Ø0.88	1.38		
Surface rough	nness (flange):	Ra 250 to 492	 2 μm				

- 1) Depends on the liner→ 🖺 87
- 2) Total length is independent of the process connections. Length according to DVGW (German Technical and Scientific Association for Gas and Water)  $\rightarrow$   $\bigcirc$  77

Ι	N	A	В	С	D	E	L
[in]	[mm]	[in]	[in]	[in]	[in]	[in]	[in]
28	700	36.5	34	28 × Ø1.38	1.31	1)	2)
30	-	38.74	36	28 × Ø1.38	1.38		
32	800	41.73	38.5	28 × Ø1.65	1.5		
36	900	45.98	42.75	32 × Ø1.65	1.63		
40	1000	50.75	47.25	36 × Ø1.65	1.63		
42	-	52.99	49.5	36 × Ø1.65	1.75		
48	1200	59.49	56	44 × Ø1.65	1.88		
54	_	66.26	62.75	44 × Ø1.89	2.13		
60	-	73.03	69.25	52 × Ø1.89	2.25		
66	-	80	76	52 × Ø48	2.5		
72	1800	86.5	82.5	60 × Ø48	2.63		
78	_	92.99	89	64 × Ø54	2.75		
84	_	99.8	95.5	64 × Ø54	2.88		
90	_	106.5	107	68 × Ø60	3		

- 1) Depends on the liner  $\rightarrow$   $\bigcirc$  87
- 2) Total length is independent of the process connections. Length according to DVGW (German Technical and Scientific Association for Gas and Water) → 🖺 77

# Lap joint flange



A0037862

Lap joint flange according to ASME B16.5, Class 150 Carbon steel: order code for "Process connection", option A12 Stainless steel: order code for "Process connection", option A14								
D	N	Α	В		D	E	F	L
[mm]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]
25	1	4.33	3.15	4 × Ø0.63	0.55	1.93	1)	2)
40	1 ½	4.92	3.86	4 × Ø0.63	0.69	2.8		
50	2	5.91	4.76	4 × Ø0.75	0.75	3.46		
80	3	7.48	5.98	4 × Ø0.75	0.94	4.72		
100	4	9.06	7.48	8 × Ø0.75	0.94	5.83		
150	6	11.02	9.49	8 × Ø0.91	0.98	8.23		
200	8	13.58	11.73	8 × Ø0.91	1.14	10.39		
250	10	15.94	14.25	12 × Ø0.98	1.18	12.48		
300	12	19.09	17.01	12 × Ø0.98	1.26	14.88		
Surface rou	ghness (flan	ge): Ra 248 1	to 492 µin	'		1		1

- 1) Depends on the liner  $\rightarrow$   $\bigcirc$  87
- 2) Total length is independent of the process connections. Length according to DVGW (German Technical and Scientific Association for Gas and Water)  $\rightarrow$   $\bigcirc$  77


# Accessories

External WLAN antenna

÷

The external WLAN antenna is not suitable for use in hygienic applications.


External WLAN antenna mounted on device



■ 41 Engineering unit mm (in)

External WLAN antenna mounted with cable

The external WLAN antenna can be mounted separately from the transmitter if the transmission/reception conditions at the transmitter mounting location are poor.



■ 42 Engineering unit mm (in)

# Weight

All values (weight exclusive of packaging material) refer to devices with flanges of the standard pressure rating.

The weight may be lower than indicated depending on the pressure rating and design.

Weight specifications including transmitter as per order code for "Housing", option A "Aluminum, coated".

Different values due to different transmitter versions:

Transmitter version for the hazardous area

(Order code for "Housing", option A "Aluminum, coated"; Ex d): +2 kg (+4.4 lbs)

# Weight in SI units

	Order code for "Design", options C, D, E DN 25 to 400, DN 1" to 16"						
Nominal	diameter	Reference values					
		EN	(DIN), AS, JIS	ASME (Class 150)			
[mm]	[in]	Pressure rating	[kg]	[kg]			
25	1	PN 40	10	5			
32	-	PN 40	11	-			
40	1 ½	PN 40	12	7			
50	2	PN 40	13	9			
65	-	PN 16	13	-			
80	3	PN 16	15	14			
100	4	PN 16	18	19			
125	-	PN 16	25	-			
150	6	PN 16	31	33			
200	8	PN 10	52	52			
250	10	PN 10	81	90			
300	12	PN 10	95	129			
350	14	PN 6	106	172			
375	15	PN 6	121	_			
400	16	PN 6	121	203			

	Order code for "Design", options F ≥ DN 450 (18")						
			Reference values				
Non dian	inal ieter	EN (DIN) (PN16) AS (PN 16)		ASME (Class 150), AWWA (Class D)			
[mm]	[in]	[kg]	[kg]	[kg]			
450	18	142	138	191			
500	20	182	186	228			
600	24	227	266	302			
700	28	291	369	266			
	30	-	447	318			
800	32	353	524	383			
900	36	444	704	470			
1000	40	566	785	587			
-	42	_	-	670			
1200	48	843	1229	901			

Order coo ≥ DN 450	Order code for "Design", options F ≥ DN 450 (18")						
			Reference values				
	ninal neter	EN (DIN) (PN16) AS (PN 16)		ASME (Class 150), AWWA (Class D)			
[mm]	[in]	[kg]	[kg]	[kg]			
-	54	_	-	1273			
1400	-	1204	-	-			
-	60	-	-	1594			
1600	-	1845	-	-			
-	66	_	-	2 131			
1800	72	2357	-	2 568			
-	78	2 929	-	3113			
2000	-	2 929	-	3113			
-	84	_	-	3755			
2200	-	3 422	-	-			
-	90	_	_	4797			
2400	-	4094	_	_			

	Order code for "Design", options G 2 DN 450 (18")					
		Reference values				
Nominal	diameter	EN (DIN) (PN 6)	ASME (Class 150), AWWA (Class D)			
[mm]	[in]	[kg]	[kg]			
450	18	161	255			
500	20	156	285			
600	24	208	405			
700	28	304	400			
_	30	-	460			
800	32	357	550			
900	36	485	800			
1000	40	589	900			
-	42	-	1100			
1200	48	850	1400			
-	54	850	2 200			
1400	-	1300	-			
_	60	_	2 700			
1600	-	1845	-			
-	66	-	3700			
1800	72	2357	4100			
-	78	2 929	4600			
2000	-	2 929	-			

# Weight in US units

Order code for "Design", options C, D, E DN 25 to 400, DN 1" to 16"				
Nominal diameter		Reference values ASME (Class 150)		
[mm]	[in]	[16]		
25	1	11		
32	-	-		
40	1 ½	15		
50	2	20		
65	-	-		
80	3	31		
100	4	42		
125	-	-		
150	6	73		
200	8	115		
250	10	198		
300	12	284		
350	14	379		
375	15	-		
400	16	448		

Order code for "Design", options F ≥ DN 450 (18")				
Nominal	diameter	Reference values ASME (Class 150), AWWA (Class D)		
[mm]	[in]	[lb]		
450	18	421		
500	20	503		
600	24	666		
700	28	587		
-	30	701		
800	32	845		
900	36	1036		
1000	40	1294		
-	42	1477		
1200	48	1987		
-	54	2 807		
1400	_	-		
-	60	3515		
1600	-	-		
-	66	4699		
1800	72	5 662		
-	78	6864		
2000	-	6864		

Order code for "Design", options F ≥ DN 450 (18")					
Nominal diameter		Reference values ASME (Class 150), AWWA (Class D)			
[mm]	[in]	[lb]			
_	84	8280			
2200	_	-			
-	90	10577			
2400	-	-			

Order code for "Design", options G ≥ DN 450 (18")				
Nominal	diameter	Reference values ASME (Class 150), AWWA (Class D)		
[mm]	[in]	[lb]		
450	18	562		
500	20	628		
600	24	893		
700	28	882		
-	30	1014		
800	32	1213		
900	36	1764		
1000	40	1984		
-	42	2 426		
1200	48	3 087		
-	54	4851		
1400	-	-		
-	60	5 9 5 4		
1600	-	-		
-	66	8158		
1800	72	9040		
-	78	10143		
2000	-	-		

# Measuring tube specification

Nominal	Nominal diameter Pressure rating			Measuring tube internal diameter							
		EN (DIN)	ASME	AS 2129	JIS	Hard 1	rubber	Polyur	ethane	PT	FE
			AWWA	AS 4087							
[mm]	[in]					[mm]	[in]	[mm]	[in]	[mm]	[in]
25	1	PN 40	Class 150	-	20K	-	-	24	0.94	25	0.98
32	-	PN 40	-	-	20K	-	-	32	1.26	34	1.34
40	1 ½	PN 40	Class 150	-	20K	-	_	38	1.50	40	1.57
50	2	PN 40	Class 150	Table E, PN 16	10K	50	1.97	50	1.97	52	2.05
50 <sup>1)</sup>	2	PN 40	Class 150	Table E, PN 16	10K	32	1.26	-	-	-	-
65	-	PN 16	-	-	10K	66	2.60	66	2.60	68	2.68

Nominal diameter			Pressure rating					Measuring tube internal diameter				
		EN (DIN)	ASME	AS 2129	JIS	Hard	rubber	Polyur	ethane	РТ	FE	
			AWWA	AS 4087								
[mm]	[in]					[mm]	[in]	[mm]	[in]	[mm]	[in]	
65 <sup>1)</sup>	_	PN 16	_	_	10K	38	1.50	_	_	_	_	
80	3	PN 16	Class 150	Table E, PN 16	10K	79	3.11	79	3.11	80	3.15	
80 <sup>1)</sup>	3	PN 16	Class 150	Table E, PN 16	10K	50	1.97	_	_	_	_	
100	4	PN 16	Class 150	Table E, PN 16	10K	102	4.02	102	4.02	104	4.09	
100 <sup>1)</sup>	4	PN 16	Class 150	Table E, PN 16	10K	66	2.60	_	_	_	_	
125	-	PN 16	-	-	10K	127	5.00	127	5.00	130	5.12	
125 <sup>1)</sup>	-	PN 16	-	-	10K	79	3.11	-	-	-	_	
150	6	PN 16	Class 150	Table E, PN 16	10K	156	6.14	156	6.14	156	6.14	
150 <sup>1)</sup>	6	PN 16	Class 150	Table E, PN 16	10K	102	4.02	-	-	-	-	
200	8	PN 10	Class 150	Table E, PN 16	10K	204	8.03	204	8.03	202	7.95	
200 1)	8	PN 16	Class 150	Table E, PN 16	10K	127	5.00	-	-	_	_	
250	10	PN 10	Class 150	Table E, PN 16	10K	258	10.2	258	10.2	256	10.08	
250 <sup>1)</sup>	10	PN 16	Class 150	Table E, PN 16	10K	156	6.14	-	-	-	_	
300	12	PN 10	Class 150	Table E, PN 16	10K	309	12.2	309	12.2	306	12.05	
300 <sup>1)</sup>	12	PN 16	Class 150	Table E, PN 16	10K	204	8.03	-	-	-	_	
350	14	PN 6	Class 150	Table E, PN 16	10K	337	13.3	342	13.5	-	_	
375	15	-	-	PN 16	10K	389	15.3	-	-	-	_	
400	16	PN 6	Class 150	Table E, PN 16	10K	387	15.2	392	15.4	-	_	
450	18	PN 6	Class 150	-	10K	436	17.1	437	17.2	_	_	
500	20	PN 6	Class 150	Table E, PN 16	10K	487	19.1	492	19.4			
600	24	PN 6	Class 150	Table E, PN 16	10K	589	23.0	594	23.4	-	-	
700	28	PN 6	Class D	Table E, PN 16	10K	688	27.1	692	27.2	-	-	
750	30	-	Class D	Table E, PN 16	10K	737	29.1	742	29.2			
800	32	PN 6	Class D	Table E, PN 16	-	788	31.0	794	31.3	-	-	
900	36	PN 6	Class D	Table E, PN 16	-	889	35.0	891	35.1	-	-	
1000	40	PN 6	Class D	Table E, PN 16	_	991	39.0	994	39.1	-	_	
-	42	-	Class D	-	-	1043	41.1	1043	41.1	-	_	
1200	48	PN 6	Class D	Table E, PN 16	-	1191	46.9	1197	47.1	-	_	
-	54	-	Class D	-	-	1339	52.7	-	-	-	-	
1400	-	PN 6	-	-	-	1402	55.2	-	-	-	_	
-	60	-	Class D	-	-	1492	58.7	_	-	-	_	
1600	-	PN 6	-	-	_	1600	63.0	-	-	-	_	
-	66	-	Class D	-	-	1638	64.5	-	-	-	-	
1800	72	PN 6	-	-	-	1786	70.3	-	-	-	-	
-	78	-	Class D	-	-	1989	78.3	-	-	-	-	
2000	-	PN 6	-	-	-	1989	78.3	-	-	-	-	
-	84	-	Class D	-	-	2 099	84.0	-	-	-	_	
2200	-	PN 6	-	-	-	2 194	87.8	-	-	-	-	

Nominal	diameter	Pressure rating			Measuring tube internal diameter						
		EN (DIN)	ASME	AS 2129	JIS	Hard 1	rubber	Polyur	ethane	PT	FE
			AWWA	AS 4087							
[mm]	[in]					[mm]	[in]	[mm]	[in]	[mm]	[in]
-	90	-	Class D	-	-	2 2 4 6	89.8	-	-	-	-
2400	-	PN 6	-	-	-	2391	94.1	-	-	-	-

1) Order code for "Design", option C

# Materials

# Transmitter housing

Order code for "Housing":


Option A "Aluminum, coated": aluminum, AlSi10Mg, coated

Window material

Order code for "Housing":

Option A "Aluminum, coated": glass

# Cable entries/cable glands



A002835

# ■ 43 Possible cable entries/cable glands

- 1 Female thread  $M20 \times 1.5$
- 2 Cable gland  $M20 \times 1.5$
- 3 Adapter for cable entry with internal thread G ½" or NPT ½"
- 4 Device plugs

Order code for "Housing", option A "Aluminum, coated"

The various cable entries are suitable for hazardous and non-hazardous areas.

Cable entry/cable gland	Material		
Coupling M20 × 1.5	Non-Ex: plastic		
Coupling M20 ^ 1.3	Z2, D2, Ex d/de: brass with plastic		
Adapter for cable entry with internal thread G ½"	Nickel-plated brass		
Adapter for cable entry with internal thread NPT ½"			

# Device plug

Electrical connection	Material
Plug M12x1	■ Socket: Stainless steel, 1.4404 (316L)
	Contact housing: Polyamide
	■ Contacts: Gold-plated brass

# Sensor housing

- DN 25 to 300 (1 to 12")
  - Aluminum half-shell housing, aluminum, AlSi10Mg, coated
- DN 350 to 2400 (14 to 90")
  - Fully welded carbon steel housing with protective varnish

#### Measuring tubes

- DN 25 to 600 (1 to 24")
  - Stainless steel: 1.4301, 1.4306, 304, 304L
- DN 700 to 2400 (28 to 90")
   Stainless steel: 1.4301, 304

#### Liner

- DN 25 to 300 (1 to 12"): PTFE
- DN 25 to 1200 (1 to 48"): polyurethane
- DN 50 to 2400 (2 to 90"): hard rubber

#### Electrodes

- Stainless steel, 1.4435 (316L)
- Alloy C22, 2.4602 (UNS N06022)
- Tantalum

#### **Process connections**

- For flanges made of carbon steel:
  - DN  $\leq$  300 (12"): with Al/Zn protective coating or protective varnish
  - DN  $\geq$  350 (14"): protective varnish
- All carbon steel lap joint flanges are supplied with a hot-dip galvanized finish.

# EN 1092-1 (DIN 2501)

#### Fixed flange

- Carbon steel:
  - DN ≤ 300: S235JRG2, S235JR+N, P245GH, A105, E250C
  - DN 350 to 2400: P245GH, S235JRG2, A105, E250C
- Stainless steel:
  - DN ≤ 300: 1.4404, 1.4571, F316L
  - DN 350 to 600: 1.4571, F316L, 1.4404
  - DN 700 to 1000: 1.4404, F316L

#### Lap joint flange

- Carbon steel DN ≤ 300: S235JRG2, A105, E250C
- Stainless steel DN  $\leq$  300: 1.4306,1.4404, 1.4571, F316L

#### Lap joint flange, stamped plate

- Carbon steel DN ≤ 300: S235JRG2 similar to S235JR+AR or 1.0038
- Stainless steel DN ≤ 300: 1.4301 similar to 304

# ASME B16.5

Fixed flange, lap joint flange

- Carbon steel: A105
- Stainless steel: F316L

# JIS B2220

- Carbon steel: A105, A350 LF2
- Stainless steel: F316L

#### AWWA C207

Carbon steel: A105, P265GH, A181 Class 70, E250C, S275JR

# AS 2129

Carbon steel: A105, E250C, P235GH, P265GH, S235JRG2

#### AS 4087

Carbon steel: A105, P265GH, S275JR

#### Seals

As per DIN EN 1514-1, form IBC

#### Accessories

#### Protective cover

Stainless steel, 1.4404 (316L)

#### External WLAN antenna

- Antenna: ASA plastic (acrylic ester-styrene-acrylonitrile) and nickel-plated brass
- Adapter: Stainless steel and nickel-plated brass
- Cable: Polyethylene
- Plug: Nickel-plated brass
- Angle bracket: Stainless steel

#### Ground disks

- Stainless steel, 1.4435 (316L)
- Alloy C22, 2.4602 (UNS N06022)
- Tantalum

#### Fitted electrodes

Measurement, reference and empty pipe detection electrodes available as standard with:

- 1.4435 (316L)
- Alloy C22, 2.4602 (UNS N06022)
- Tantalum

#### **Process connections**

- EN 1092-1 (DIN 2501)
  - DN ≤ 300: fixed flange (PN 10/16/25/40) = Form A, lap joint flange (PN 10/16), lap joint flange, stamped plate (PN 10) = Form A
  - DN  $\geq$  350: fixed flange (PN 6/10/16/25) = flat face (Form B)
  - DN 450 to 2400: fixed flange (PN 6/10/16) = flat face (Form B)
- ASME B16.5
  - DN 350 to 2400 (14 to 90"): fixed flange (Class 150)
  - DN 25 to 600 (1 to 24"): lap joint flange (Class 150)
  - DN 25 to 150 (1 to 6"): fixed flange (Class 300)
- JIS B2220
  - DN 50 to 750: fixed flange (10K)
  - DN 25 to 600: fixed flange (20K)
- AWWA C207

DN 48 to 90": fixed flange (Class D)

- AS 2129
  - DN 50 to 1200: fixed flange (Table E)
- AS 4087

DN 50 to 1200): fixed flange (PN 16)



For information on the different materials used in the process connections  $\rightarrow \, \stackrel{ riangle}{=} \, 90$ 

#### Surface roughness

Electrodes with 1.4435 (316L); Alloy C22, 2.4602 (UNS N06022); tantalum:  $\leq 0.3$  to 0.5  $\mu m$  (11.8 to 19.7  $\mu in)$ 

(All data relate to parts in contact with fluid)

# Human interface

#### Operating concept

#### Operator-oriented menu structure for user-specific tasks

- Commissioning
- Operation
- Diagnostics
- Expert level

#### Fast and safe commissioning

- Guided menus ("Make-it-run" wizards) for applications
- Menu guidance with brief descriptions of the individual parameter functions
- Access to the device via Web server → 🖺 109
- WLAN access to the device via mobile handheld terminal, tablet or smart phone

# Reliable operation

- Operation in local language → 🗎 92
- Uniform operating philosophy applied to device and operating tools
- If replacing electronic modules, transfer the device configuration via the integrated memory (HistoROM backup) which contains the process and measuring device data and the event logbook. No need to reconfigure.

#### Efficient diagnostics increase measurement availability

- Troubleshooting measures can be called up via the device and in the operating tools
- Diverse simulation options, logbook for events that occur and optional line recorder functions

#### Languages

Can be operated in the following languages:

- Via local operation
   English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Turkish, Chinese,
   Japanese, Korean, Bahasa (Indonesian), Vietnamese, Czech, Swedish
- Via Web browser
   English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Turkish, Chinese,
   Japanese, Korean, Bahasa (Indonesian), Vietnamese, Czech, Swedish
- Via "FieldCare", "DeviceCare" operating tool: English, German, French, Spanish, Italian, Chinese, Japanese

# Local operation


# Via display module

#### Equipment:

- Order code for "Display; operation", option F "4-line, illuminated, graphic display; touch control"
- Order code for "Display; operation", option G "4-line, illuminated, graphic display; touch control + W/I A N"



Information about WLAN interface → 🖺 99



A0026785

■ 44 Operation with touch control

# Display elements

- 4-line, illuminated, graphic display
- White background lighting; switches to red in event of device errors
- Format for displaying measured variables and status variables can be individually configured
- Permitted ambient temperature for the display: -20 to +60 °C (-4 to +140 °F)
  The readability of the display may be impaired at temperatures outside the temperature range.

# Operating elements


- External operation via touch control (3 optical keys) without opening the housing: ±, □, 国
- Operating elements also accessible in the various zones of the hazardous area

# Via remote display and operating module DKX001



The remote display and operating module DKX001 is available as an optional extra  $\rightarrow \triangleq 107$ .

- The measuring device is always supplied with a dummy cover when the remote display and operating module DKX001 is ordered directly with the measuring device. Display or operation at the transmitter is not possible in this case.
- If ordered subsequently, the remote display and operating module DKX001 may not be connected at the same time as the existing measuring device display module. Only one display or operation unit may be connected to the transmitter at any one time.



ightharpoons 45 Operation via remote display and operating module DKX001

A0026786

# Display and operating elements

#### Material

Transmitter housing	Remote display and operating module	
Order code for "Housing"	Material	Material
Option A "Aluminum, coated"	AlSi10Mg, coated	AlSi10Mg, coated

#### Cable entry

Corresponds to the choice of transmitter housing, order code for "Electrical connection".

#### Connecting cable


→ 🖺 48

Dimensions

#### Remote operation


#### Via HART protocol

This communication interface is available in device versions with a HART output.



■ 46 Options for remote operation via HART protocol (active)

- 1 Control system (e.g. PLC)
- 2 Field Communicator 475
- 3 Computer with Web browser (e.g. Internet Explorer) for access to the integrated device Web server or computer with an operating tool (e.g. FieldCare, DeviceCare, AMS Device Manager, SIMATIC PDM) with COM DTM "CDI Communication TCP/IP"
- 4 Commubox FXA195 (USB)
- 5 Field Xpert SFX350 or SFX370
- 6 Field Xpert SMT70
- 7 VIATOR Bluetooth modem with connecting cable
- 8 Transmitter




A002874

■ 47 Options for remote operation via HART protocol (passive)

- 1 Control system (e.g. PLC)
- 2 Transmitter power supply unit, e.g. RN221N (with communication resistor)
- 3 Connection for Commubox FXA195 and Field Communicator 475
- 4 Field Communicator 475
- 5 Computer with Web browser (e.g. Internet Explorer) for access to the integrated device Web server or computer with an operating tool (e.g. FieldCare, DeviceCare, AMS Device Manager, SIMATIC PDM) with COM DTM "CDI Communication TCP/IP"
- 6 Commubox FXA 195 (USB)
- 7 Field Xpert SFX350 or SFX370
- 8 Field Xpert SMT70
- 9 VIATOR Bluetooth modem with connecting cable
- 10 Transmitter

#### Via FOUNDATION Fieldbus network

This communication interface is available in device versions with FOUNDATION Fieldbus.




 $\blacksquare$  48 Options for remote operation via FOUNDATION Fieldbus network

- 1 Automation system
- 2 Computer with FOUNDATION Fieldbus network card
- 3 Industry network
- 4 High Speed Ethernet FF-HSE network
- 5 Segment coupler FF-HSE/FF-H1
- 6 FOUNDATION Fieldbus FF-H1 network
- 7 Power supply FF-H1 network
- 8 T-box
- 9 Measuring device

#### Via PROFIBUS DP network

This communication interface is available in device versions with PROFIBUS DP.




 $\blacksquare$  49 Options for remote operation via PROFIBUS DP network

- 1 Automation system
- 2 Computer with PROFIBUS network card
- 3 PROFIBUS DP network
- 4 Measuring device

# Via PROFIBUS PA network

This communication interface is available in device versions with PROFIBUS PA.




VUU38838

 $\blacksquare$  50 Options for remote operation via PROFIBUS PA network

- 1 Automation system
- 2 Computer with PROFIBUS network card
- 3 PROFIBUS DP network
- 4 Segment coupler PROFIBUS DP/PA
- 5 PROFIBUS PA network
- 6 T-box
- 7 Measuring device

# Via Modbus RS485 protocol

This communication interface is available in device versions with a Modbus-RS485 output.



A002943

■ 51 Options for remote operation via Modbus-RS485 protocol (active)


- 1 Control system (e.g. PLC)
- 2 Computer with Web browser (e.g. Internet Explorer) for accessing the integrated device Web server or with operating tool (e.g. FieldCare, DeviceCare) with COM DTM "CDI Communication TCP/IP" or Modbus DTM
- 3 Transmitter

# Via EtherNet/IP network

This communication interface is available in device versions with EtherNet/IP.

96


# Star topology



- **■** 52 Options for remote operation via EtherNet/IP network: star topology
- Automation system, e.g. "RSLogix" (Rockwell Automation)
- Workstation for measuring device operation: with Custom Add-On Profile for "RSLogix 5000" (Rockwell 2 Automation) or with Electronic Data Sheet (EDS)
- Computer with Web browser (e.g. Internet Explorer) for accessing the integrated device Web server or 3 computer with operating tool (e.g. FieldCare, DeviceCare) with COM DTM "CDI Communication TCP/IP"
- Ethernet switch
- Measuring device

# Ring topology

The device is integrated via the terminal connection for signal transmission (output 1) and the service interface (CDI-RJ45).




**№** 53 Options for remote operation via EtherNet/IP network: ring topology

- Automation system, e.g. "RSLogix" (Rockwell Automation)
- Workstation for measuring device operation: with Custom Add-On Profile for "RSLogix 5000" (Rockwell 2 Automation) or with Electronic Data Sheet (EDS)
- Computer with Web browser (e.g. Internet Explorer) for accessing the integrated device Web server or computer with operating tool (e.g. FieldCare, DeviceCare) with COM DTM "CDI Communication TCP/IP"
- Ethernet switch
- Measuring device

#### Via PROFINET network

This communication interface is available in device versions with PROFINET.

# Star topology




■ 54 Options for remote operation via PROFINET network: star topology

- 1 Automation system, e.g. Simatic S7 (Siemens)
- 2 Computer with Web browser (e.g. Internet Explorer) for accessing the integrated device Web server or computer with operating tool (e.g. FieldCare, DeviceCare, SIMATIC PDM) with COM DTM "CDI Communication TCP/IP"
- 3 Switch, e.g. Scalance X204 (Siemens)
- 4 Measuring device

# Ring topology

The device is integrated via the terminal connection for signal transmission (output 1) and the service interface (CDI-RJ45).



■ 55 Options for remote operation via PROFINET network: ring topology

- 1 Automation system, e.g. Simatic S7 (Siemens)
- 2 Computer with Web browser (e.g. Internet Explorer) for accessing the integrated device Web server or computer with operating tool (e.g. FieldCare, DeviceCare, SIMATIC PDM) with COM DTM "CDI Communication TCP/IP"
- 3 Switch, e.g. Scalance X204 (Siemens)
- 4 Measuring device


#### Service interface

#### Via service interface (CDI-RJ45)

A point-to-point connection can be established to configure the device onsite. With the housing open, the connection is established directly via the service interface (CDI-RJ45) of the device.

An adapter for RJ45 and the M12 connector is optionally available: Order code for "Accessories", option NB: "Adapter RJ45 M12 (service interface)"

The adapter connects the service interface (CDI-RJ45) to an M12 connector mounted in the cable entry. Therefore the connection to the service interface can be established via an M12connector without opening the device.




**■** 56 Connection via service interface (CDI-RJ45)

- Computer with Web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated device Web server or with "FieldCare", "DeviceCare" operating tool with COM DTM "CDI Communication TCP/IP" or Modhus DTM
- Standard Ethernet connecting cable with RJ45 connector
- Service interface (CDI-RJ45) of the measuring device with access to the integrated Web server

#### Via WLAN interface

The optional WLAN interface is available on the following device version: Order code for "Display; operation", option G "4-line, illuminated; touch control + WLAN"



A0034570

- 1 Transmitter with integrated WLAN antenna
- 2 Transmitter with external WLAN antenna
- 3 LED lit constantly: WLAN reception is enabled on measuring device
- LED flashing: WLAN connection established between operating unit and measuring device
- Computer with WLAN interface and Web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated device Web server or with operating tool (e.g. FieldCare, DeviceCare)
- Mobile handheld terminal with WLAN interface and Web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated device Web server or operating tool (e.g. FieldCare, DeviceCare)
- Smart phone or tablet (e.g. Field Xpert SMT70)

Function	WLAN: IEEE 802.11 b/g (2.4 GHz)  • Access point with DHCP server (default setting)  • Network
Encryption	WPA2-PSK AES-128 (in accordance with IEEE 802.11i)
Configurable WLAN channels	1 to 11
Degree of protection	IP67
Available antennas	<ul> <li>Internal antenna</li> <li>External antenna (optional)         In the event of poor transmission/reception conditions at the place of installation.         Available as an accessory → □ 107.     </li> <li>Only one antenna active in each case!</li> </ul>
Range	<ul> <li>Internal antenna: typically 10 m (32 ft)</li> <li>External antenna: typically 50 m (164 ft)</li> </ul>
Materials (external antenna)	<ul> <li>Antenna: ASA plastic (acrylic ester-styrene-acrylonitrile) and nickel-plated brass</li> <li>Adapter: Stainless steel and nickel-plated brass</li> <li>Cable: Polyethylene</li> <li>Connector: Nickel-plated brass</li> <li>Angle bracket: Stainless steel</li> </ul>


# **Network integration**

With the optional "OPC-UA Server" application package, the device can be integrated into an Ethernet network via the service interface (CDI-RJ45 and WLAN) and communicate with OPC-UA clients. If the device is used in this way, IT security must be considered.



Transmitters with an Ex de approval may **not** be connected via the service interface (CDI-RJ45)! Order code for "Approval transmitter + sensor", options (Ex de): BB, C2, GB, MB, NB

For permanent access to device data and for device configuration via the Web server, the device is incorporated directly in a network via the service interface (CDI-RJ45). In this way, the device can be accessed any time from the control station. The measured values are processed separately via the inputs and outputs through the automation system.



- Automation system, e.g. Simatic S7 (Siemens)
- 2 Ethernet switch
- 3 Edge Gateway
- Cloud
- 5 Measuring device
- Ethernet network
- Measured values via inputs and outputs
- Optional WLAN interface
- The optional WLAN interface is available on the following device version: Order code for "Display; operation", option **G** "4-line, illuminated, graphic display; touch control + WLAN"

# Supported operating tools

Different operating tools can be used for local or remote access to the measuring device. Depending on the operating tool used, access is possible with different operating units and via a variety of interfaces.

Supported operating tools	Operating unit	Interface	Additional information
Web browser	Notebook, PC or tablet with Web browser	<ul> <li>CDI-RJ45 service interface</li> <li>WLAN interface</li> <li>Ethernet-based fieldbus (EtherNet/IP, PROFINET)</li> </ul>	Special Documentation for device
DeviceCare SFE100	Notebook, PC or tablet with Microsoft Windows system	<ul><li>CDI-RJ45 service interface</li><li>WLAN interface</li><li>Fieldbus protocol</li></ul>	→ 🖺 109

Supported operating tools	Operating unit	Interface	Additional information
FieldCare SFE500	Notebook, PC or tablet with Microsoft Windows system	<ul><li>CDI-RJ45 service interface</li><li>WLAN interface</li><li>Fieldbus protocol</li></ul>	→ 🖺 109
Device Xpert	Field Xpert SFX 100/350/370	HART and FOUNDATION Fieldbus fieldbus protocol	Operating Instructions BA01202S Device description files: Use update function of handheld terminal



Other operating tools based on FDT technology with a device driver such as DTM/iDTM or DD/EDD can be used for device operation. These operating tools are available from the individual manufacturers. Integration into the following operating tools, among others, is supported:

- FactoryTalk AssetCentre (FTAC) by Rockwell Automation → www.rockwellautomation.com
- Process Device Manager (PDM) by Siemens → www.siemens.com
- Asset Management Solutions (AMS) by Emerson → www.emersonprocess.com
- FieldCommunicator 375/475 by Emerson → www.emersonprocess.com
- Field Device Manager (FDM) by Honeywell → www.honeywellprocess.com
- FieldMate by Yokogawa → www.yokogawa.com
- PACTWare → www.pactware.com

The associated device description files are available at: www.endress.com → Downloads

#### Web server

Thanks to the integrated Web server, the device can be operated and configured via a Web browser and via a service interface (CDI-RJ45) or via a WLAN interface. The structure of the operating menu is the same as for the local display. In addition to the measured values, status information on the device is also displayed and allows the user to monitor the status of the device. Furthermore the device data can be managed and the network parameters can be configured.

A device that has a WLAN interface (can be ordered as an option) is required for the WLAN connection: order code for "Display; operation", option G "4-line, illuminated; touch control + WLAN". The device acts as an Access Point and enables communication by computer or a mobile handheld terminal.

#### Supported functions

Data exchange between the operating unit (such as a notebook for example) and the measuring device:

- Upload the configuration from the measuring device (XML format, configuration backup)
- Save the configuration to the measuring device (XML format, restore configuration)
- Export event list (.csv file)
- Export parameter settings (.csv file or PDF file, document the measuring point configuration)
- Export the Heartbeat verification log (PDF file, only available with the "Heartbeat Verification" application package)
- Flash firmware version for device firmware upgrade, for instance
- Download driver for system integration



Web server special documentation  $\rightarrow \implies 111$ 

#### HistoROM data management

The measuring device features HistoROM data management. HistoROM data management comprises both the storage and import/export of key device and process data, making operation and servicing far more reliable, secure and efficient.



When the device is delivered, the factory settings of the configuration data are stored as a backup in the device memory. This memory can be overwritten with an updated data record, for example after commissioning.

# Additional information on the data storage concept

There are different types of data storage units in which device data are stored and used by the device:

	Device memory	T-DAT	S-DAT
Available data	<ul> <li>Event logbook such as diagnostic events for example</li> <li>Parameter data record backup</li> <li>Device firmware package</li> <li>Driver for system integration for exporting via Web server, e.g:         <ul> <li>GSD for PROFIBUS DP</li> <li>GSD for PROFIBUS PA</li> <li>GSDML for PROFINET</li> <li>EDS for EtherNet/IP</li> <li>DD for FOUNDATION Fieldbus</li> </ul> </li> </ul>	Measured value logging ("Extended HistoROM" order option)  Current parameter data record (used by firmware at run time)  Peakhold indicator (min/max values)  Totalizer values	<ul> <li>Sensor data: nominal diameter etc.</li> <li>Serial number</li> <li>Calibration data</li> <li>Device configuration (e.g. SW options, fixed I/O or multi I/O)</li> </ul>
Storage location	Fixed on the user interface board in the connection compartment	Attachable to the user interface board in the connection compartment	In the sensor plug in the transmitter neck part

#### Data backup

#### **Automatic**

- The most important device data (sensor and transmitter) are automatically saved in the DAT modules
- If the transmitter or measuring device is replaced: once the T-DAT containing the previous device data has been exchanged, the new measuring device is ready for operation again immediately without any errors
- If the sensor is replaced: once the sensor has been replaced, new sensor data are transferred from the S-DAT in the measuring device and the measuring device is ready for operation again immediately without any errors
- If exchanging the electronics module (e.g. I/O electronics module): Once the electronics module has been replaced, the software of the module is compared against the current device firmware. The module software is upgraded or downgraded where necessary. The electronics module is available for use immediately afterwards and no compatibility problems occur.

#### Manual

Additional parameter data record (complete parameter settings) in the integrated device memory HistoROM backup for:

- Data backup function
   Backup and subsequent restoration of a device configuration in the device memory HistoROM backup
- Data comparison function
   Comparison of the current device configuration with the device configuration saved in the device memory HistoROM backup

#### Data transfer

# Manual

- Transfer of a device configuration to another device using the export function of the specific operating tool, e.g. with FieldCare, DeviceCare or Web server: to duplicate the configuration or to store in an archive (e.g. for backup purposes)
- Transmission of the drivers for system integration via Web server, e.g.:
  - GSD for PROFIBUS DP
  - GSD for PROFIBUS PA
  - GSDML for PROFINET
  - EDS for EtherNet/IP
  - DD for FOUNDATION Fieldbus

#### Event list

# Automatic

- Chronological display of up to 20 event messages in the events list
- If the Extended HistoROM application package (order option) is enabled: up to 100 event messages are displayed in the events list along with a time stamp, plain text description and remedial measures
- The events list can be exported and displayed via a variety of interfaces and operating tools e.g. DeviceCare, FieldCare or Web server

# Data logging

#### Manual

If the **Extended HistoROM** application package (order option) is enabled:

- Record up to 1000 measured values via 1 to 4 channels
- User configurable recording interval
- Record up to 250 measured values via each of the 4 memory channels
- Export the measured value log via a variety of interfaces and operating tools e.g. FieldCare, DeviceCare or web server

# Certificates and approvals



Currently available certificates and approvals can be called up via the product configurator.

#### CE mark

The device meets the legal requirements of the applicable EU Directives. These are listed in the corresponding EU Declaration of Conformity along with the standards applied.

Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.

#### RCM-tick symbol

The measuring system meets the EMC requirements of the "Australian Communications and Media Authority (ACMA)".

# Ex approval

The measuring device is certified for use in hazardous areas and the relevant safety instructions are provided in the separate "Safety Instructions" (XA) document. Reference is made to this document on the nameplate.



The separate Ex documentation (XA) containing all the relevant explosion protection data is available from your Endress+Hauser sales center.

#### ATEX, IECEx

Currently, the following versions for use in hazardous areas are available:

#### Ex db eb

Category	Type of protection
II2G	Ex db eb ia IIC T6T1 Gb

#### Ex tb

Category	Type of protection
II2D	Ex tb IIIC Txxx Db

#### Ех ес

Category	Type of protection
II3G	Ex ec ic IIC T5T1 Gc

# cCSAus

Currently, the following versions for use in hazardous areas are available:

#### IS (Ex i) and XP (Ex d)

Class I, II, III Division 1 Groups A-G

# NI (Ex nA)

Class I Division 2 Groups A - D

#### Fy de

Class I, Zone 1 AEx/ Ex de ia IIC T6...T1 Gb

#### Ex nA

Class I, Zone 2 AEx/Ex nA ic IIC T5...T1 Gc

#### Ex tb

Zone 21 AEx/ Ex tb IIIC T\*\* °C Db

# Drinking water approval

- ACS
- KTW/W270
- NSF 61
- WRAS BS 6920

#### HART certification

#### **HART** interface

The measuring device is certified and registered by the FieldComm Group. The measuring system meets all the requirements of the following specifications:

- Certified according to HART 7
- The device can also be operated with certified devices of other manufacturers (interoperability)

# FOUNDATION Fieldbus certification

#### FOUNDATION Fieldbus interface

The measuring device is certified and registered by the FieldComm Group. The measuring system meets all the requirements of the following specifications:

- Certified in accordance with FOUNDATION Fieldbus H1
- Interoperability Test Kit (ITK), revision version 6.2.0 (certificate available on request)
- Physical Layer Conformance Test
- The device can also be operated with certified devices of other manufacturers (interoperability)

#### **Certification PROFIBUS**

#### **PROFIBUS** interface

The measuring device is certified and registered by the PNO (PROFIBUS User Organization Organization). The measuring system meets all the requirements of the following specifications:

- Certified in accordance with PROFIBUS PA Profile 3.02
- The device can also be operated with certified devices of other manufacturers (interoperability)

#### EtherNet/IP certification

The measuring device is certified and registered by the ODVA (Open Device Vendor Association). The measuring system meets all the requirements of the following specifications:

- Certified in accordance with the ODVA Conformance Test
- EtherNet/IP Performance Test
- EtherNet/IP PlugFest compliance
- The device can also be operated with certified devices of other manufacturers (interoperability)

# Certification PROFINET

#### **PROFINET** interface

The measuring device is certified and registered by the PNO (PROFIBUS User Organization). The measuring system meets all the requirements of the following specifications:

- Certified according to:
  - Test specification for PROFINET devices
  - PROFINET Security Level 2 Netload Class
- The device can also be operated with certified devices of other manufacturers (interoperability)
- The device supports PROFINET S2 system redundancy.

#### Radio approval

The measuring device has radio approval.



For detailed information regarding radio approval, see Special Documentation

# Other standards and guidelines

■ EN 60529

Degrees of protection provided by enclosures (IP code)

■ EN 61010-1

Safety requirements for electrical equipment for measurement, control and laboratory use - general requirements

■ IEC/EN 61326

Emission in accordance with Class A requirements. Electromagnetic compatibility (EMC requirements).

■ NAMUR NE 21

Electromagnetic compatibility (EMC) of industrial process and laboratory control equipment

NAMUR NE 32

Data retention in the event of a power failure in field and control instruments with microprocessors  $% \left( 1\right) =\left( 1\right) \left( 1\right) \left$ 

NAMUR NE 43

Standardization of the signal level for the breakdown information of digital transmitters with analog output signal.

■ NAMUR NE 53

Software of field devices and signal-processing devices with digital electronics

■ NAMUR NE 105

Specifications for integrating fieldbus devices in engineering tools for field devices

■ NAMUR NE 107

Self-monitoring and diagnosis of field devices

■ NAMUR NE 131

Requirements for field devices for standard applications

■ ETSI EN 300 328

Guidelines for 2.4 GHz radio components.

■ EN 301489

Electromagnetic compatibility and radio spectrum matters (ERM).

# Ordering information

Detailed ordering information is available for your nearest sales organization www.addresses.endress.com or in the Product Configurator under www.endress.com:

- 1. Click Corporate
- 2. Select the country
- 3. Click Products
- 4. Select the product using the filters and search field
- 5. Open the product page

The Configuration button to the right of the product image opens the Product Configurator.

# Product Configurator - the tool for individual product configuration

- Up-to-the-minute configuration data
- Depending on the device: Direct input of measuring point-specific information such as measuring range or operating language
- Automatic verification of exclusion criteria
- Automatic creation of the order code and its breakdown in PDF or Excel output format
- Ability to order directly in the Endress+Hauser Online Shop

# Application packages

Many different application packages are available to enhance the functionality of the device. Such packages might be needed to address safety aspects or specific application requirements.

The application packages can be ordered with the device or subsequently from Endress+Hauser. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: <a href="https://www.endress.com">www.endress.com</a>.

#### **Diagnostics functions**

Package	Description
Extended HistoROM	Comprises extended functions concerning the event log and the activation of the measured value memory.
	Event log: Memory volume is extended from 20 message entries (standard version) to up to 100 entries.
	<ul> <li>Data logging (line recorder):</li> <li>Memory capacity for up to 1000 measured values is activated.</li> <li>250 measured values can be output via each of the 4 memory channels. The recording interval can be defined and configured by the user.</li> <li>Measured value logs can be accessed via the local display or operating tool e.g. FieldCare, DeviceCare or Web server.</li> </ul>

Heartbeat Technology	Package	Description
	Heartbeat Verification +Monitoring	Heartbeat Verification Meets the requirement for traceable verification to DIN ISO 9001:2008 Chapter 7.6 a) "Control of monitoring and measuring equipment".  Functional testing in the installed state without interrupting the process.  Traceable verification results on request, including a report.  Simple testing process via local operation or other operating interfaces.  Clear measuring point assessment (pass/fail) with high test coverage within the framework of manufacturer specifications.  Extension of calibration intervals according to operator's risk assessment.
		Heartbeat Monitoring Continuously supplies data, which are characteristic of the measuring principle, to an external condition monitoring system for the purpose of preventive maintenance or process analysis. These data enable the operator to:  Draw conclusions - using these data and other information - about the impact process influences (such as corrosion, abrasion, buildup etc.) have on the measuring performance over time.  Schedule servicing in time.  Monitor the process or product quality, e.g. gas pockets.

# Cleaning

Package	Description
Electrode cleaning circuit (ECC)	The electrode cleaning circuit (ECC) function has been developed to have a solution for applications where magnetite ( $Fe_3O_4$ ) deposits frequently occur (e.g. hot water). Since magnetite is highly conductive this build up leads to measuring errors and ultimately to the loss of signal. The application package is designed to AVOID build up of highly conductive matter and thin layers (typical of magnetite).

# OPC-UA server

Package	Description
OPC-UA-Server	The application package provides the user with an integrated OPC-UA server for comprehensive instrument services for IoT and SCADA applications.
	Special Documentation for the "OPC-UA-Server" application package $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $

# Accessories

Various accessories, which can be ordered with the device or subsequently from Endress+Hauser, are available for the device. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.

# Device-specific accessories

# For the transmitter

Accessories	Description
Proline 300 transmitter	Transmitter for replacement or storage. Use the order code to define the following specifications:  Approvals  Output  Input  Display/operation  Housing  Software  Order code: 5X3BXX  Installation Instructions EA01263D

Remote display and	If ordered directly with the measuring device:
operating module DKX001	Order code for "Display; operation", option O "Remote display 4-line illum.; 10 m (30 ft) Cable; touch control"
	If ordered separately:
	<ul> <li>Measuring device: order code for "Display; operation", option M "W/o, prepared for remote display"</li> </ul>
	<ul> <li>DKX001: Via the separate product structure DKX001</li> </ul>
	<ul> <li>If ordered subsequently:</li> <li>DKX001: Via the separate product structure DKX001</li> </ul>
	Mounting bracket for DKX001
	If ordered directly: order code for "Accessory enclosed", option RA "Mounting
	bracket, pipe 1/2"  Kendenderbergersten ander wurden 713/0000
	If ordered subsequently: order number: 71340960  Connection and the formula support and the support and the support and t
	Connecting cable (replacement cable) Via the separate product structure: DKX002
	Further information on display and operating module DKX001 $\rightarrow$ $\  \  \  \  \  \  \  \  \  \  \  \  \ $
	Special Documentation SD01763D
External WLAN antenna	External WLAN antenna with 1.5 m (59.1 in) connecting cable and two angle brackets. Order code for "Accessory enclosed", option P8 "Wireless antenna wide area".
	• The external WLAN antenna is not suitable for use in hygienic applications.
	■ Further information on the WLAN interface → 🗎 99.
	Order number: 71351317
	Installation Instructions EA01238D
Protective cover	Is used to protect the measuring device from the effects of the weather: e.g. rainwater, excess heating from direct sunlight.
	• Order number: 71343505
	Installation Instructions EA01160D
Ground cable	Set, consisting of two ground cables for potential equalization.

# For the sensor

Accessories	Description
Ground disks	Are used to ground the medium in lined measuring tubes to ensure proper measurement.
	For details, see Installation Instructions EA00070D

# Communication-specific accessories

Accessories	Description
Commubox FXA195 HART	For intrinsically safe HART communication with FieldCare via the USB interface.  Technical Information TI00404F
HART Loop Converter HMX50	Is used to evaluate and convert dynamic HART process variables to analog current signals or limit values.  Technical Information TI00429F Operating Instructions BA00371F
Fieldgate FXA42	Is used to transmit the measured values of connected 4 to 20 mA analog measuring devices, as well as digital measuring devices
	<ul> <li>Technical Information TI01297S</li> <li>Operating Instructions BA01778S</li> <li>Product page: www.endress.com/fxa42</li> </ul>

Field Xpert SMT70	The Field Xpert SMT70 tablet PC for device configuration enables mobile plant asset management in hazardous and non-hazardous areas. It is suitable for commissioning and maintenance staff to manage field instruments with a digital communication interface and to record progress.  This tablet PC is designed as an all-in-one solution with a preinstalled driver library and is an easy-to-use, touch-sensitive tool which can be used to manage field instruments throughout their entire life cycle.
	<ul> <li>Technical Information TI01342S</li> <li>Operating Instructions BA01709S</li> <li>Product page: www.endress.com/smt70</li> </ul>
Field Xpert SMT77	The Field Xpert SMT77 tablet PC for device configuration enables mobile plant asset management in areas categorized as Ex Zone 1.
	<ul> <li>Technical Information TI01418S</li> <li>Operating Instructions BA01923S</li> <li>Product page: www.endress.com/smt77</li> </ul>

# Service-specific accessories

Accessories	Description
Applicator	Software for selecting and sizing Endress+Hauser measuring devices:  Choice of measuring devices for industrial requirements  Calculation of all the necessary data for identifying the optimum flowmeter: e.g. nominal diameter, pressure loss, flow velocity and accuracy.  Graphic illustration of the calculation results  Determination of the partial order code, administration, documentation and access to all project-related data and parameters over the entire life cycle of a project.
	Applicator is available:  Via the Internet: https://portal.endress.com/webapp/applicator As a downloadable DVD for local PC installation.
W@M	W@M Life Cycle Management Improved productivity with information at your fingertips. Data relevant to a plant and its components is generated from the first stages of planning and during the asset's complete life cycle.  W@M Life Cycle Management is an open and flexible information platform with online and on-site tools. Instant access for your staff to current, in-depth data shortens your plant's engineering time, speeds up procurement processes and increases plant uptime.  Combined with the right services, W@M Life Cycle Management boosts productivity in every phase. For more information, visit www.endress.com/lifecyclemanagement
FieldCare	FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.  Operating Instructions BA00027S and BA00059S
DeviceCare	Tool to connect and configure Endress+Hauser field devices.  Innovation brochure IN01047S

# System components

Accessories	Description
Memograph M graphic data manager	The Memograph M graphic data manager provides information on all the relevant measured variables. Measured values are recorded correctly, limit values are monitored and measuring points analyzed. The data are stored in the 256 MB internal memory and also on a SD card or USB stick.
	<ul> <li>Technical Information TI00133R</li> <li>Operating Instructions BA00247R</li> </ul>
iTEMP	The temperature transmitters can be used in all applications and are suitable for the measurement of gases, steam and liquids. They can be used to read in the medium temperature.
	"Fields of Activity" document FA00006T

# Supplementary documentation



For an overview of the scope of the associated Technical Documentation, refer to the following:

- W@M Device Viewer (www.endress.com/deviceviewer): Enter the serial number from nameplate
- Endress+Hauser Operations App: Enter the serial number from the nameplate or scan the 2D matrix code (QR code) on the nameplate

#### Standard documentation

# **Brief Operating Instructions**

*Brief Operating Instructions for the sensor* 

Measuring device	Documentation code
Proline Promag W	KA01266D

# *Brief Operating Instructions for transmitter*

	Documentation code						
Measuring device	HART	FOUNDATION Fieldbus	PROFIBUS PA	PROFIBUS DP	Modbus RS485	EtherNet/IP	PROFINET
Proline 300	KA01308D	KA01294D	KA01405D	KA01385D	KA01310D	KA01338D	KA01340D

# **Operating Instructions**

Measuring device	Documentation code						
	HART	FOUNDATION Fieldbus	PROFIBUS PA	PROFIBUS DP	Modbus RS485	EtherNet/IP	PROFINET
Promag W 300	BA01918D	BA01938D	BA01928D	BA01940D	BA01939D	BA01937D	BA01941D

#### **Description of Device Parameters**

Measuring device	Documentation code						
	HART	FOUNDATION Fieldbus	PROFIBUS PA	PROFIBUS DP	Modbus RS485	EtherNet/IP	PROFINET
Promag 300	GP01051D	GP01098D	GP01052D	GP01135D	GP01053D	GP01113D	GP01112D

# Device-dependent additional documentation

#### Safety instructions

Safety instructions for electrical equipment for hazardous areas.

Contents	Documentation code
ATEX/IECEx Ex d/Ex de	XA01414D
ATEX/IECEx Ex ec	XA01514D
cCSAus XP	XA01515D
cCSAus Ex d/ Ex de	XA01516D
cCSAus Ex nA	XA01517D
INMETRO Ex d/Ex de	XA01518D
INMETRO Ex ec	XA01519D
NEPSI Ex d/Ex de	XA01520D
NEPSI Ex nA	XA01521D
EAC Ex d/Ex de	XA01656D

Contents	Documentation code
EAC Ex nA	XA01657D
JPN Ex d	XA01775D

# Remote display and operating module DKX001

Contents	Documentation code
ATEX/IECEx Ex i	XA01494D
ATEX/IECEx Ex ec	XA01498D
cCSAus IS	XA01499D
cCSAus Ex nA	XA01513D
INMETRO Ex i	XA01500D
INMETRO Ex ec	XA01501D
NEPSI Ex i	XA01502D
NEPSI Ex nA	XA01503D

# **Special Documentation**

Contents	Documentation code
Information on the Pressure Equipment Directive	SD01614D
Radio approvals for WLAN interface for A309/A310 display module	SD01793D
Remote display and operating module DKX001	SD01763D
OPC-UA Server 1)	SD02043D

1) This Special Documentation is only available for device versions with a HART output.

Contents	Documentation code						
	HART	FOUNDATION Fieldbus	PROFIBUS PA	PROFIBUS DP	Modbus RS485	PROFINET	EtherNet/IP
Heartbeat Technology	SD01640D	SD01742D	SD01744D	SD02206D	SD01743D	SD01986D	SD01980D
Web server	SD01654D	SD01657D	SD01656D	SD02235D	SD01655D	SD01977D	SD01976D

# **Installation Instructions**

Content	Comment
Installation instructions for spare part sets and accessories	Documentation code: specified for each individual accessory $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $

# Registered trademarks

# **HART®**

Registered trademark of the FieldComm Group, Austin, Texas, USA

#### **PROFIBUS®**

Registered trademark of the PROFIBUS User Organization, Karlsruhe, Germany

# FOUNDATION™ Fieldbus

Registration-pending trademark of the FieldComm Group, Austin, Texas, USA

#### Modbus®

Registered trademark of SCHNEIDER AUTOMATION, INC.

	Trademark of ODVA, Inc.
	PROFINET®
	Registered trademark of the PROFIBUS User Organization, Karlsruhe, Germany
www.addresses.endr	ess.com

